

Smarthome Hackathon 11.12.2020

Prerequisites

If you are on **Windows** you can either install the package manager *Chocolatey* first, or install *NodeJS* and *Python3* by hand.

<https://chocolatey.org/docs/installation>

NodeJS

- Go to <https://nodejs.org/en/download>
- Select your OS version installer

Alternatively use package manager:

Ubuntu

- `sudo apt-get install nodejs`
- `sudo apt-get install npm`

MacOS X

- `brew install nodejs`

Windows

- `choco install nodejs`

Python 3

Any python3 version will work

- Visit the python3.9 download website at <https://www.python.org/downloads/release/python-390/>
- Scroll down and select your OS version installer
- Run installation and select `Add Python 3.9 to PATH`

Alternatively use package manager:

Ubuntu

- `sudo apt-get install python3.9`

MacOS X

- `brew install python`

Windows

- `choco install python3 --pre`

Mosquitto

- Visit the mosquitto download website at <https://mosquitto.org/download>
- Select your OS version installer
- Add mosquitto folder to environment path if necessary

Alternatively use package manager:

Ubuntu

- `sudo apt-get install mosquitto`
- `sudo apt-get install mosquitto-clients`

MacOS X

- `brew install mosquitto`

Version 2.X

```
listener 1883
allow_anonymous true
```

Disable auto start:

Ubuntu

- `sudo systemctl disable mosquitto.service`

Windows

- `net stop mosquitto`

MacOS X

- `launchctl disable mosquitto`

ESPHome

- Install using python package manager pip
- Open a terminal as administrator and enter
 - `# pip3 install esphome`

Node-Red

- Install using node package manager npm
- Open a terminal as administrator and enter
 - `# npm install -g node-red`

Windows Drivers

- Make sure you have the necessary usb driver installed and your computer can detect the nodeMCU board
- Install guide can be found here: <https://medium.com/@cilliemalan/installing-nodemcu-drivers-on-windows-d9bffd52>

Cable Switch

ESPHome setup

- Make sure you installed **ESPHome** successfully, for reference check the prerequisites section
- Create a new folder and open a terminal to start the ESPHome setup wizard
 - `$ esphome cable_switch.yaml wizard` – if you get an Errno -13 try to run esphome as admin
- Enter the following information, when prompted:
 - STEP 1 CORE:** cable_switch
 - STEP 2 ESP (platform):** ESP8266
 - STEP 2 ESP (board):** nodemcu2
 - STEP 3 WIFI (ssid):** YOUR_WIFI_SSID
 - STEP 3 WIFI (psk):** YOUR_WIFI_PASSWORD
 - STEP 4 OTA (password):** press enter (no password)
- Inspect the **cable_switch.yaml** file
- Use a micro usb cable to connect your NodeMCU to your computer
- Flash the above created firmware onto your NodeMCU with the following command
 - `$ esphome cable_switch.yaml run`
- After compilation enter `1` to select **USB Serial** to upload the firmware
- You should now see that your NodeMCU connects to your wifi

Output:

```
[12:12:44][C][wifi:303]:   SSID: 'WIFI_NAME'
[12:12:44][C][wifi:304]:   IP Address: IP_ADDRESS
```

Binary Sensor Component

- Open your **cable_switch.yaml** file and add following information

```
binary_sensor:
  - platform: gpio
    pin:
      number: D1
      mode: INPUT_PULLUP
      inverted: True
    name: "My first Binary Sensor"
```

- Flash the firmware onto your NodeMCU with the command
 - `$ esphome cable_switch.yaml run`
- Use a cable to connect the **D1** pin to a **G** pin on your NodeMCU
- You should see output similar to the following when connecting and disconnecting the two pins

Output:

```
[10:51:42][D][binary_sensor:036]: 'My first Binary Sensor': Sending state ON
[10:51:43][D][binary_sensor:036]: 'My first Binary Sensor': Sending state OFF
```

MQTT

- Open a new terminal and start the mqtt broker **mosquitto** with the command `$ mosquitto -v`

Output:

```
1603706412: mosquitto version 1.6.9 starting
1603706412: Using default config.
1603706412: Opening ipv4 listen socket on port 1883.
1603706412: Opening ipv6 listen socket on port 1883.
```

- Find out your computers local ip address and configure your mqtt broker in the **cable_switch.yaml** file

IP Address

```
ip add //Linux
ipconfig getifaddr en1 // MacOS X
ipconfig // Windows
```

Add following information to your **cable_switch.yaml** file

```
mqtt:
  broker: YOUR_LOCAL_IP_ADDRESS
```

- Flash the firmware onto your NodeMCU with the command
 - `$ esphome cable_switch.yaml run`

Output:

```
[09:08:38][C][mqtt.binary_sensor:018]: MQTT Binary Sensor 'My first Binary Sensor':
[09:08:38][C][mqtt.binary_sensor:019]:   State Topic: 'cable_switch/binary_sensor/my_first_binary_sensor/state'
```

- Make sure you installed **node-red** successfully, for reference check the prerequisites section
- Open a new terminal and start **node-red** with the command `$ node-red`

Output:

```
26 Oct 11:02:29 - [info] Server now running at http://127.0.0.1:1880/
26 Oct 11:02:29 - [info] Starting flows
26 Oct 11:02:29 - [info] Started flows
```

- Open a browser and go to `http://127.0.0.1:1880`
- Drag and drop a **mqtt in** node and a **debug** node onto the main frame
- Connect the two gray dots between the nodes
- Double click the **mqtt in** node and click the **pencil symbol**
- Enter a name like `mosquitto_local` for your local mqtt broker mosquitto, enter `localhost` in the server field and click **Add**

- Copy `cable_switch/binary_sensor/my_first_binary_sensor/state` into the topic field and click **Done**
- Click **Deploy** in the top right corner and click the **bug symbol** to see the debug output
- When connecting and disconnecting the **D1** and **G** pins on your NodeMCU you should see messages in the debug window

LED

ESPHome firmware

- Copy the information from your **binary_sensor.yaml** file to a new file named **led.yaml**
- Change the name specified in the yaml file to `esp_led`

```
esphome:
  name: binary_sensor //change to esp_led
  platform: ESP8266
  board: nodemcu2
```

TASK: LED1

- Go to <https://esphome.io/components/light/monochromatic.html>
- Add the a light and an output component to your yaml file
- Use jumper wires to connect the specified pin and a **3V** pin to your LED
- Flash the firmware onto your NodeMCU with
 - `$ esphome led.yaml run`

TASK: LED2

- Look for output starting with

```
[13:37:44][C][mqtt.light:054]: ...
```

- Find out which mqtt topic will turn the LED on and off

Configure node-red

- If not running anymore, start node-red and mosquitto again
- Go to <http://127.0.0.1:1880> in your browser
- Add a **mqtt in** node to find out what information will turn
- Add a **mqtt out** node and use `mosquitto_local` as mqtt broker
- Configure the topic you found in the terminal output above
- Add two **inject** nodes and send the json objects that will turn the LED on/off

TASK: LED3

- Find out what json objects to send to `esp_led/light/led_light/command`
- Hint: The LED sends state messages via MQTT

TASK: LED4

- Use your Cable Switch from the last step to turn your LED on and off

TASK: (optional) LED5

- Dim your LED with your smartphone
- See section **Additional** for smartphone app suggestions

Wireless Socket

Setup Transceiver

- Wire up the CC1101 antenna as shown in the picture `CC1101_wiring.png`
- Go to `<tnng-automation>/esp-smarthome/radio_transceiver.yaml` and change following information

```
wifi:
  ssid: "YOUR_WIFI_SSID"
  password: "YOUR_WIFI_PASSWORD"

mqtt:
  broker: YOUR_LOCAL_IP_ADDRESS
```

- Start mqtt broker mosquitto with `$ mosquitto`
- Flash the firmware onto your NodeMCU with
 - `$ esphome radio_transceiver.yaml run`
- Received RF timings are sent to the *radio_transceiver/radio/433toMQTT* topic
- MQTT messages with timings to *radio_transceiver/radio/MQTTto433* are sent via RF

Control wireless socket

- Go to `<tng-automation>/esp-smarthome` and inspect the *wireless_socket_on* and *wireless_socket_off* files
- Start node-red with `$ node-red` and open `http://127.0.0.1:1880` in your browser

TASK: SOCKET1 - Turn your wireless socket on/off by sending timings from the files *wireless_socket_on/off* via mqtt

De/Encode Signals

- Instead of sending the recorded timings from the *wireless_socket_on/off* files we try to decode the timings and send a binary code
- Open terminal in `<tng-automation>/node-red/on-off-keying` and run:
 - `$ npm install`
 - `$ npm run build`
- On startup, node-red should print out a line like `7 Nov 20:48:30 - [info] User directory : home/<user>/node-red`
- This is where node-red will keep user specific data like the flows you created, and where we can also install plugins
- Go to the node-red user directory and run
 - `$ npm install <tng-automation>/node-red/on-off-keying`
- Restart node-red and reload the node-red web interface
- There should now be four new nodes: *ook_decode*, *ook_encode*, *ook_split*, *ook_concat*
- Add a *ook_decode* node and double click it to see the configuration options

TASK: SOCKET2

- Inspect the `<tng-automation>/esp-smarthome/wireless_socket_on` file and find the correct patterns for zero, one, and start to configure the *ook_decode* node
- Use the *file in* node as input for the *ook_decode* node and a *debug* node as output
- When triggering the inject node you should see the 24 bit binary code necessary to turn on the wireless socket

END TASK

- Use a *inject* node to send the binary code as a string to an *ook_encode* node
- Configure the *ook_encode* node with the correct patterns for zero, one, and start
- Connect the output of the *ook_encode* with the *mqtt out* node
- Repeat this process with the *wireless_socket_off* file
- Now you should be able to turn your socket on and off using the correct binary code

TASK: SOCKET3 - Use your MQTT smartphone app to turn your socket on and off

TASK: (optional) SOCKET4 - Use your Cable Switch to send the 24 bit array to turn your socket on/off

TASK: (optional) SOCKET5 - Indicate the current status of your wireless socket with your LED

Weather Station

Decode Timings

- Output the timings sent to *radio_transceiver/radio/433toMQTT* in the node-red debug window
- Your NodeMCU should still be sending 433 MHz signals to the specified topic, otherwise flash the *radio_transceiver.yaml* file onto your device again
- Remove the backplate of your weather station and press the *TX* button to send 433 MHz signals

- You should see 433 MHz timings in the debug window

TASK: WEATHER1

- Try to find the correct patterns for zero, one, and start to configure a *ook_decode* node
- You should now see a binary array of length 40 in your debug window when pressing the *TX* button

Decode Binary

- Add a *function* node and use the 40 bit binary code as input

TASK: WEATHER2 - Look at the blog post <https://forum.pilight.org/showthread.php?tid=3080> - Find out how temperature and humidity are encoded in the 40 bit array

TASK: WEATHER3 - Extract temperature and humidity from the binary code as described here <https://forum.pilight.org/showthread.php?tid=3080> - You can use following function to calculate the decimal number from a binary array

```
function binaryToNumber(input) {
  return input.reduceRight(
    ((previousValue, currentValue, currentIndex, array) =>
      Math.pow(2, (array.length - currentIndex - 1)) * currentValue + previousValue), 0);
}
```

- Send temperature and humidity to your smartphone app

TASK: (optional) WEATHER4 - Turn on a fan (wireless socket) depending on room temperature

HomeAssistant (optional)

- Install HomeAssistant and run it in a virtual machine or on a raspberry pi
- Connect a smart home speaker (Amazon Alexa, Google Nest, ...) to your wireless socket and weather station

Issues

Deployment Node-Red

- On Windows it can happen that re-deployment in node-red does not update the specified mqtt topic
- Fix: Restart mosquitto broker

Firewall Settings for MQTT

- Make sure your firewall settings allow the mosquitto broker to send and receive mqtt messages
- Fix: Einstellungen -> *Firewall- & Netzwerkschutz* -> *Zugriff von App durch Firewall zulassen* -> Select Mqtt

Additional

MQTT on smartphone

- Download an MQTT App for your smartphone
 - [MQTT Dash\(IoT, Smart Home\)](#) (for Android)
 - [iHomeTouch](#) (for iOS)
- Control your wireless socket with your smartphone
- View temperature and humidity information on your smartphone