

See the given code at the top of

[https://georgeyork.github.io/ECE383\\_web/lecture/lecture18.html](https://georgeyork.github.io/ECE383_web/lecture/lecture18.html)

I'll refer to these as the "ninja" version.

## 0. Do Steps 1 to 11 of MicroBlaze\_Install\_Short\_Version

Or, just open your lecture\_17 vivado project and "Save As" an new project named Lecture\_18

### 1. Open your Lecture\_18 Vivado project

Go to **Tools** → **Create and package IP** → **next**

### 2. Create your custom IP project

2.1) Select **Create a new AXI4 peripheral** and click **Next**

2.2) Input "**My\_Counter\_IP**" in the name field and click **Next**

2.3) Change the number of Registers to **32** on the AXI interface and click **Next**

2.4) Select **Edit IP** and click **Finish**

### 3. Designing the IP core

3.1) A new instance of Vivado will open up for the new IP core. Expand the top level file **My\_Counter\_IP\_v1\_0**. Then double-click on **My\_Counter\_IP\_v1\_0\_S00\_AXI** to open it in the editor.

### 5. Modify **My\_Counter\_IP\_v1\_0\_S00\_AXI.vhd**

5.1) Add **Lines 20, 112-122, 671, 759-766** from the Ninja file to this Vivado file

5.2) Try to understand what these lines of code do by going through the powerpoint slides and handout for this lesson (like slides 14-31)

### 6. Modify **My\_Counter\_IP\_v1\_0.vhd**

5.1) Add **Lines 19, 59, 93** from the Ninja file to this Vivado file

5.2) Try to understand what these lines of code do by going through the powerpoint slides and handout for this lesson

### 4. Add the Lec 10 Counter to the My\_Counter\_IP\_v1\_0

4.1) "**Add Sources**" → **lec18.vhd** file

4.2) Try to understand what these lines of code do by going through the powerpoint slides and handout for this lesson

### 7. Packaging the IP core

7.0) Now click on **Package IP** in the Flow Navigator and you should see the Package IP tab.

7.1) Select **Compatibility** (under Packaging Steps) and make sure "Artix7" are present. If those are not there, you can add them by clicking the plus button. The Life Cycle does not matter at this point.

7.2) Select **Customization Parameters** and select the line for **Merge Changes from Customization Parameters Wizard**.

7.3) Select **Customization GUI**. This is where we get to change our graphical interface. No changes at this time.

- 7.3) Select **File Groups**, and select the line for **Merge Changes...**
- 7.4) select **Review and Package** and click the **Re-package IP** button.
- 7.5) A popup will ask if you want to close the project, Select **Yes**.

## 8. Add Custom IP to your design

- 8.1) In the project manager page of the original window, click **Open Block Design**.
- 8.2) Use the **Add IP (plus sign)** button to add your **my\_counter** IP you just created
- 8.3) Find your **my\_counter\_ip\_v1.0** block in the circuit diagram. Right click on output pin **LEDs** and select **Make External** and then run **Connection Automation**
- 8.5) Now you need to add a constraints file to add the LED net to the pins on the Artix 7 chip by adding the the constraints **Lec18.xdc** file. (Ensure the names of the output pins match the diagram... Mine were called **LED\_0**.)

**Add sources → add or create constraints → Lec18.xdc**

[Note: later when you do HW#10, you will need to modify this Custom IP counter... **insert step 24 at the end of this file here then...** you can skip this for now]

## 10. Verify Addressing Design

- 10.1) Click the **Address Editor** tab (next to **Diagram** tab)
- 10.2) Verify the addresses for the components match that of slide#47  
Uart is at 0x4060\_0000; my\_counter is at 0x44A0\_0000

## 11. Validate Design

- 11.1) Select **Validate Design** (check box symbol or F6).

## 12. Creating or Regenerate the HDL System Wrapper

- 12.1) right click on **design\_1** and select **Create HDL Wrapper**.  
Let Vivado manage the wrapper.

## 13. Generating Bit File

- 13.1) In the **Flow Navigator** panel on the left, under **Program and Debug** select the **Generate Bitstream** option.
- 13.3) After the bitstream has been generated, a message prompt will pop-up on the screen. You don't have to open the Implemented Design for this demo. Just click on **Cancel**.  
[Note: one MIG error [BD 41-1273] is okay]

## 14. Exporting Hardware Design to SDK

- 14.1) On the top left corner of the window, from the tool bar click on **File** and select **Export Hardware**. Make sure the generated **bitstream** is included by **checking the box**.

## 15. Launching SDK

- 15.1) Go to **File** and select **Launch SDK** and click **OK**.

## 17. Creating New Application Project in SDK

- 17.1) Go to **File** in the main tool bar and select **New → Application Project**.  
Project Name = **Lecture\_18\_counter**  
**Create New** under **Board Support Package**.  
Click **Next**.

## 18. Selecting Hello World Application from available templates

18.1) Select **Hello World** under *Available Templates* on the left panel and click **Finish**.

18.2) **Lecture\_18\_counter** is our main working source folder.

18.3) Replace with our C-code from lec18.c

- I just opened **hello\_world.c** and cut-n-pasted the code from **lec18.c** over the code in **hello\_world.c**

- Or you can follow the instructions in the powerpoint slides for a different method.

18.4) Try to understand what these lines of code do by going through the powerpoint slides and handout for this lesson (like slides 55-62)

## 19. Verify Linker Script File for Memory Region Mapping & Stack/Heap

19.0) **Double click** on the **lscript.ld** to open.

19.1) In the linker script, take a look at the **Section to Memory Region Mapping** box. If you did the *Make DDR3 External* step then the target memory region **must** read **mig\_7series\_0**. Scroll down to check if this applies to all rows. If for any region it does not say **mig\_7series\_0**, then click on the row under the **Memory Region** column and select **mig\_7series\_0**.

19.2) My stack size = **0x400** and Heap size = **0x800** [we made need to increase this when our C program gets larger]

19.3) microblaze...bram... size = **0x7FB0**

## 20. Programming FPGA with Bit File

20.1) Make sure that the Nexys Video board is turned on and connected to the host PC with the provided micro USB cable. Then click on the **Program FPGA** button to open the Program FPGA window. Make sure that the **Hardware Platform** is selected as **design\_1\_wrapper\_hw\_platform\_0**.

In the software configuration box, under *ELF File to Initialize in Block RAM ()* column, the row option must read **bootloop**. If not, click on the row and select **bootloop**.

Now click on **Program**.

## 21. Run Configuration Settings for STDIO Connection

21.1) From the *Project Explorer* panel, **right click** on the **lecture18\_counter** project folder. At the bottom of the drop down list, select **Run As** and then select **Run Configurations**.

The Run Configurations window is divided into two main sections. In the left panel, under Xilinx C/C++ application(GDB), select **display\_hello\_world.elf**. *Note: In case you see **display\_hello\_world Debug** instead of **display\_hello\_world.elf** in this step, you can still run it without any issues.*

On the right side of this window, you will see five main tabs. Select the **STDIO Connection** tab.

## 22. COM Port Selection for STDIO Connection

22.1) Port name should be the correct UART port. For me it showed up as COM4. Select Baud Rate as 9600. Have the **Connect STDIO to Console** box checked. (uncheck if you want to use another terminal emulator). Click **Apply** and **Run**.

23.1) **"Welcome to Lecture 18"** will be displayed on the Console tab

Type **"?"** to see list of commands to control the counter and LEDs

Now go and try to add the "roll" signal for HW#10. You'll need to modify your Counter Custom IP, adding these steps (insert after step 8 above)

## 24. Updating Custom IP

24.0) Go back to your project in Vivado, click **Open Block Design**

24.1) Right click on **My\_Counter\_IP\_1.0** block in the circuit diagram, and click **Edit in IP Packager** if you want to modify! (like adding "roll")

24.2) Make changes to appropriate files, such as **My\_Counter\_IP\_v1\_0\_S00\_AXI.vhd** and **lec18.vhd** [see hints below]

24.3) Now that you updated the core you need to re-select **Review and Package** and click the **Re-package**. [same as steps 7.0, 7.4, 7.5 above]

24.4) Now back in Vivado design\_1, a yellow bar on the top of the **Block Design – Design\_1** window should have a blue link titled **Show IP Status**. Click this link.

24.5) select your **my\_counter\_ip\_0** block in the circuit diagram, and then click **upgrade selected** (box at the bottom of the screen) → **ok** → **Generate**

24.6) resume with step 10.

[Note: For HW#10, you'll also need to make changes to the C code to interface with the "roll" signal]

### Hints on HW#10

First understand the Lecture 18 block diagram with the roll signal.

#### **lec18.vhd**

-- entity will need "roll" signal added

-- architecture will need to set "roll" to '1' when Q is the **maxCount**.

Since the counter size is Generic based on size N, to create **maxCount**, I added....

signal **maxCount**: unsigned (N-1 downto 0);

and CSA...

**maxCount** <= (others => '1');

#### **My\_Counter\_IP\_v1\_0\_S00\_AXI.vhd**

-- need to update counter's entity with new roll signal... (around line 116)

-- need an internal wire signal created to hook up to roll... I called this **roll\_sig** (around line 122)

-- your microblaze will be reading "roll", not writing to it. Your current design reads "Q" vector on **slv\_reg2**, so you need to modify this to read "roll" bit on **slv\_reg2**. So in the last line below, **slv\_reg2** will need to be replaced with a way to read **roll\_sig**.

(near lines 673-679)

case **loc\_addr** is

when b"00000" =>

reg\_data\_out <= X"000000" & std\_logic\_vector(Q);

when b"00001" =>

reg\_data\_out <= **slv\_reg1**;

when b"00010" =>

reg\_data\_out <= **slv\_reg2**; -- here is where we hook up **roll\_sig**

-- need to update counter's entity where it is instantiated, with new roll signal... (around line 767), and connect "roll" to **roll\_sig**

#### **HelloWorld.c or Lec18.c or main.c**

-- the register location for "roll" is defined for you

```
#define countRollReg          0x44a00008          // 1 LSBs of slv_reg2 for roll
```

-- need to add code to read the roll `countRollReg` register. Could add it as a printf under the "?" command similar to reading the Q count value:

```
printf("          count Q = %x\r\n",Xil_In16(countQReg));
```

See other hints in the HW#10 assignment