

## **Process Description:**

Noise estimation

## **Parameter Descriptions:**

### **Input Channels:**

This allows you to select which channels you want to perform noise estimation on. This should be applied to all channels that are going to be used for calculating the noise parameters. Select the channels by clicking on them in the "Available Input Channels" box and then clicking "Select>" to move them to the "Selected Channels" box. You can unselect a channel by clicking the "Delete" button

### **Frame selection:**

**Select region of interest for cropping:**