



Introduction

This document describes how to establish a setup to Test the Direct test mode between two Atmel® ATSAMB11 Xplained boards. A PC based tool will be used at both ends. The PC tool communicates to the ATSAMB11 using a serial bridge application.


Features

- DTM setup procedure
- Downloading DTM Firmware
- Running the setup

Table of Contents

Introduction	1
Features	1
Table of Contents	2
1 Demo Setup	3
2 Hardware Setup	3
3 Software Setup	4
3.1 Installation Steps	4
3.2 Build Procedure	4
4 DTM PC Tool	6
5 DTM Test Sequence	11
6 BluSDK SMART Software Architecture	12
7 ATMEL EVALUATION BOARD/KIT IMPORTANT NOTICE AND DISCLAIMER	13
8 Revision History	14


1 Demo Setup



2 Hardware Setup

Connect the ATSAMB11 board to the host PC using a Micro-USB cable.

Figure 2-1. EDBG USB Port



3 Software Setup

3.1 Installation Steps

1. Install the latest Atmel Studio [Atmel Studio 7.0 (build 629 or later) web installer (recommended)]

<http://www.atmel.com/tools/ATMELSTUDIO.aspx>

2. Install the latest Atmel Software Framework.

This package will install the following examples within the Atmel Studio environment:


- Direct Test Mode application for ATSAMB11

3.2 Build Procedure

The following procedure is explained for ATSAMB11 application example.


1. Select New Example Project.

Figure 3-1. Creating a New Example Project




2. Select "SAMB11" in device family, enter "DTM" in search window, and expand Atmel Corp Projects. The location and the name of the project can be selected in the respective fields. Click OK.

Figure 3-2. Selecting DTM Application from Example Projects




3. Accept the license Agreement. The Atmel studio will generate the Direct Test Mode Example project for ATSAMB11.
4. Build the solution.

Figure 3-3. Building the DTM Application




5. Download the application via the USB to the ATSAMB11 board by using the Device Programming option available in Tools as shown below.

Figure 3-4. Select Device Programming



6. Inside the device programming the user has to select the correct configuration for the device and finally program the device by using the program button.

Figure 3-5. Flashing Programming



7. Once the application is flashed, the Direct Test Mode application is ready for use.

4 DTM PC Tool

1. Start The DTM Tool by clicking “DTM-Tool.exe.”

Figure 4-1. Selecting the DTM PC Tool





Figure 4-2. DTM PC Tool Window



2. Next, initialize UART. Enter the COM port number and press “Init UART”. A successful initialization is indicated by receiving a chip response as shown below.

Figure 4-3. Init UART

The screenshot shows a software interface for initializing UART. It includes input fields for 'UART port' (set to 14) and 'Baud rate' (set to 115200), a checked 'FlowControl' checkbox, and an 'Init UART' button. Below these is a 'UART Log' section with a text area containing the hexadecimal string '04 0e 04 01 03 0c 00'. At the bottom is a 'Statistics' section with fields for 'Number of Tx Packets' (1500), 'Number of Rx Packets' (0), and 'PER' (0). Red annotations are present: a '1' points to the 'UART port' field, a '2' points to the 'Init UART' button, and a '3' points to the 'UART Log' text area.

3. Start the Direct Test Mode, configuring one board as TX and the other one as RX. Note that any side can be replaced by a standard compliant test equipment. Make sure to select the same RF Channel for both during the Test and to start the RX test before the TX Test in order not to miss any packets. You should see the chip response after each Start/Stop to make sure that the UART communication is still working fine.

Figure 4-4. TX Side Test Start






Figure 4-5. RX Side Test Start




4. On the RX board, press Stop RX Test button. The number of successful received packets is displayed after pressing “Stop Rx”.

Figure 4-6. RX Side Test Stop



- After pressing Stop RX Test button, the user can see the total number of received packets. The number of successful received packets is displayed after pressing “Stop Rx”.

Figure 4-7. Number of Packets Received




The PER is calculated assuming that the transmitter side sends 1500 packets for testing using R&S CBT equipment. For Peer testing, ignore the PER reading.

Some part of the UI buttons and options are left for later implementation. Using these options will lead to undetermined behavior of the DTM-Tool.

5 DTM Test Sequence

Figure 5-1 depicts the Direct Test Mode between the two ATSAMB11 devices. The DTM commands are initiated from DTM Tool. To create the below test setup, open the two instances of the DTM PC Tool. Enter the COM Port of each ATSAMB11 device and then the first command from the tool is UART Init, which will receive the response from the ATSAMB11.


Figure 5-1. DTM RX/TX Test Sequence



6 BluSDK SMART Software Architecture

Figure 6-1 illustrates the top level diagram for the ATSAMB11 configuration.

Figure 6-1. ATSAMB11 Software Architecture



7 **ATMEL EVALUATION BOARD/KIT IMPORTANT NOTICE AND DISCLAIMER**

This evaluation board/kit is intended for user's internal development and evaluation purposes only. It is not a finished product and may not comply with technical or legal requirements that are applicable to finished products, including, without limitation, directives or regulations relating to electromagnetic compatibility, recycling (WEEE), FCC, CE or UL. Atmel is providing this evaluation board/kit "AS IS" without any warranties or indemnities. The user assumes all responsibility and liability for handling and use of the evaluation board/kit including, without limitation, the responsibility to take any and all appropriate precautions with regard to electrostatic discharge and other technical issues. User indemnifies Atmel from any claim arising from user's handling or use of this evaluation board/kit. Except for the limited purpose of internal development and evaluation as specified above, no license, express or implied, by estoppel or otherwise, to any Atmel intellectual property right is granted hereunder. ATMEL SHALL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RELATING TO USE OF THIS EVALUATION BOARD/KIT.

ATMEL CORPORATION
1600 Technology Drive
San Jose, CA 95110
USA

8 Revision History

Doc Rev.	Date	Comments
42615A	03/2016	Initial document release.



Atmel Corporation 1600 Technology Drive, San Jose, CA 95110 USA T: (+1)(408) 441.0311 F: (+1)(408) 436.4200 | www.atmel.com

© 2016 Atmel Corporation. / Rev.: Atmel-42615A-ATSAMB11-BluSDK-SMART-Direct-Test-Mode-Getting-Started-Guide_UserGuide_032016.

Atmel®, Atmel logo and combinations thereof, Enabling Unlimited Possibilities®, and others are registered trademarks or trademarks of Atmel Corporation in U.S. and other countries. ARM®, ARM Connected® logo, and others are the registered trademarks or trademarks of ARM Ltd. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Atmel products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death ("Safety-Critical Applications") without an Atmel officer's specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Atmel products are not designed nor intended for use in military or aerospace applications or environments unless specifically designated by Atmel as military-grade. Atmel products are not designed nor intended for use in automotive applications unless specifically designated by Atmel as automotive-grade.