
ImpedanceFitter Documentation

Release 2.0.0

Julius Zimmermann, Leonard Thiele

May 05, 2020

CONTENTS:

1	Fitting	1
2	Statistical analysis	7
3	Utilitites	9
4	Circuit elements	11
5	Circuits	15
6	Post processing	19
7	Overview	21
8	Indices and tables	23
	Bibliography	25
	Python Module Index	27
	Index	29

FITTING

The script will cycle through all files in a selected directory (unless certain files are excluded or explicitly listed) and will store the experimental data. The experimental data can then be fitted to user-defined model.

1.1 Formulate the model

The ImpedanceFitter parser understands circuits that follow a simple pattern:

- Elements in series are connected by a +.
- Elements in parallel are connected by *parallel(A, B)*.

An example of a circuit could be:

```
parallel(R, C) + CPE
```

This stands for a resistor in parallel with a capacitor that are in series with a constant phase element (CPE).

Also nested parallels are possible:

```
parallel(parallel(L, C), R)
```

Find all available elements in Section *Circuit elements* and all available circuits in Section *Circuits*.

You can also use prefixes. This is needed if you want to combine multiple elements or circuits of the same type. Otherwise, the parameters cannot be distinguished by LMFIT.

For example:

```
parallel(R_f1, C_f1) + parallel(R_f2, C_f2)
```

1.2 Execute the fit

Using `impedancefitter.Fitter.run`, those files can be fitted to an equivalent circuit model. If there are two models involved that shall be fitted sequentially for each file, refer to `impedancefitter.Fitter.sequential_run()`. This method allows one to communicate inferred parameters to the second model. In³, an example of such a sequential procedure has been presented.

³ Sabuncu, A. C., Zhuang, J., Kolb, J. F., & Beskok, A. (2012). Microfluidic impedance spectroscopy as a tool for quantitative biology and biotechnology. *Biomicrofluidics*, 6(3). <https://doi.org/10.1063/1.4737121>

1.3 API Reference

class `impedancefitter.main.Fitter(inputformat, directory=None, **kwargs)`

The main fitting object class. All files in the data directory with matching file ending are imported to be fitted.

Parameters

- **inputformat** (*string*) – The inputformat of the data files. Must be one of the formats specified in `impedancefitter.utils.available_file_format()`.
- **directory** (*string, optional*) – Path to data directory. Provide the data directory if the data directory is not the current working directory.
- **LogLevel** (*{‘DEBUG’, ‘INFO’, ‘WARNING’}, optional*) – choose level for logger. Case DEBUG: the script will output plots after each fit, case INFO: the script will output results from each fit to the console.
- **excludeEnding** (*string, optional*) – For file ending that should be ignored (if there are files with the same ending as the chosen inputformat). Useful for instance, if there are files like `*_data.csv` and `*_result.csv` around and only the first should be fitted.
- **minimumFrequency** (*float, optional*) – If you want to use another frequency than the minimum frequency in the dataset.
- **maximumFrequency** (*float, optional*) – If you want to use another frequency than the maximum frequency in the dataset.
- **data_sets** (*int, optional*) – Use only a certain number of data sets instead of all in directory.
- **current_threshold** (*float, optional*) – Use only for data from E4980AL LCR meter to check current. If the current is not close to the threshold, the data point will be neglected.
- **write_output** (*bool, optional*) – Decide if you want to dump output to file. Default is False
- **fileList** (*list of strings, optional*) – provide a list of files that exclusively should be processed. No other files will be processed. This option is particularly good if you have a common fileending of your data (e.g., `.csv`)
- **savefig** (*bool, optional*) – Decide if you want to save the plots. Default is False.
- **trace_b** (*string, optional*) – For TXT files, which contain more than one trace. The data is only read in until `trace_b` is found. Default is `TRACE: B`.
- **skiprows_txt** (*int, optional*) – Number of header rows inside a TXT file. Default is 21.
- **skiprows_trace** (*int, optional*) – Lines between traces blocks in a TXT file. Default is 2.

Variables

- **omega_dict** (*dict*) – Contains frequency lists that were found in the individual files. The keys are the file names, the values the frequencies.
- **z_dict** (*dict*) – Contains corresponding impedances.
- **fit_data** (*dict*) – Contains the fitting results for each individual file. In case of a sequential run, the dictionary contains two sub-dictionaries with keys `model1` and `model2` and the results.
- **fittedValues** (`lmfit.model.ModelResult`) – The fitting result of the last data set that was fitted. Exists only when `run()` was called.
- **fittedValues1** (`lmfit.model.ModelResult`) – The fitting result of the last data set that was fitted. Exists only when `sequential_run()` was called and corresponds to the first model in this run.

- **fittedValues2** (`lmfit.model.ModelResult`) – The fitting result of the last data set that was fitted. Exists only when `sequential_run()` was called and corresponds to the second model in this run.

cluster_emcee_result (*constant=100.0*)

Apply clustering to eliminate low-probability samples.

Parameters **constant** (*float*) – The constant, which is used to define the threshold from which on walkers are eliminated.

Notes

The clustering approach described in⁴ is implemented in this function. The walkers are sorted by probability and subsequently the difference between adjacent walker probabilities Δ_j is evaluated. Then the average difference between the current and the first walker ($\bar{\Delta}_j$) is evaluated. Both differences are compared and a threshold is defined:

$$\Delta_j > \text{constant} \cdot \bar{\Delta}_j$$

When this inequality becomes true, all walkers with $k > j$ are thrown away.

References

emcee_conf_interval (*result*)

Compute emcee confidence intervals.

The 1σ to 3σ confidence intervals are computed for a fitting result generated by emcee since this case is not covered by the original LMFIT implementation.

Parameters **result** (`lmfit.model.ModelResult`) – Result from fit.

Returns

Dictionary containing limits of confidence intervals for all free parameters. The limits are structured in a list with 7 items, which are ordered as follows:

1. lower limit of 3σ confidence interval.
2. lower limit of 2σ confidence interval.
3. lower limit of 1σ confidence interval.
4. median.
5. upper limit of 1σ confidence interval.
6. upper limit of 2σ confidence interval.
7. upper limit of 3σ confidence interval.

Return type dict

emcee_report ()

Reports acceptance fraction and autocorrelation times.

initialize_model (*modelname*)

Interface to LMFIT model class.

The equivalent circuit (represented as a string) is parsed and a LMFIT Model is returned. This can be useful if one wants to compute the impedance values for a given model and use it in a different context.

⁴ Hou, F., Goodman, J., Hogg, D. W., Weare, J., & Schwab, C. (2012). An affine-invariant sampler for exoplanet fitting and discovery in radial velocity data. *Astrophysical Journal*, 745(2). <https://doi.org/10.1088/0004-637X/745/2/198>

Parameters `modelname` (*string*) – Provide equivalent circuit model to be parsed.

Returns `model` – The resulting LMFIT model.

Return type `lmfit.model.Model`

model_iterations (*modelclass*)

Information about number of iterations if there is an iterative scheme for a modelclass.

Parameters `modelclass` (*str*) – Name of the modelclass. This means that this model is represented in the equivalent circuit.

Returns Number of iteration steps.

Return type `int`

Notes

Double-Shell model

The following iterative procedure is applied:

1. 1st Fit: The data is fitted against a model comprising the double-shell model. Parameters to be determined in this fitting round: *kmed* and *emed*.
2. 2nd Fit: The parameters *kmed* and *emed* are fixed and the data is fitted again. To be determined in this fit: *km* and *em*.
3. 3rd Fit: In addition, the parameters *km* and *em* are fixed and the data is fitted again. To be determined in this fit: *kcp*.
4. last Fit: In addition, the parameter *kcp* is fixed. To be determined in this fit: all remaining parameters.

Single-Shell model

The following iterative procedure is applied:

1. 1st Fit: The data is fitted against a model comprising the single-shell model. Parameters to be determined in this fitting round: *kmed* and *emed*.
2. 2nd Fit: The parameters *kmed* and *emed* are fixed and the data is fitted again.

Cole-Cole model

1. 1st Fit: The data is fitted against a model comprising the Cole-Cole model. Parameters to be determined in this fitting round: *kdc* and *eh*.
2. 2nd Fit: The parameters *kdc* and *eh* are fixed and the data is fitted again.

See also:

```
impedancefitter.double_shell.double_shell_model(),      impedancefitter.
single_shell.single_shell_model(),                      impedancefitter.cole_cole.
cole_cole_model()
```

plot_initial_best_fit (*sequential=False*)

Plot initial and best fit together.

This method reveals how good the initial fit was.

Parameters `sequential` (*bool, optional*) – If a `sequential_run()` was performed, set this value to True.

plot_uncertainty_interval (*sigma=1, sequential=False*)

Plot uncertainty interval around best fit.

Parameters

- **sigma** (*{1, 2, 3}, optional*) – Choose sigma for confidence interval.
- **sequential** (*bool, optional*) – Set to True if you performed a sequential run before.

process_data_from_file (*filename, model, parameters, modelclass=None*)

Fit data from input file to model.

Wrapper for LMFIT fitting routine. If LogLevel is *DEBUG*, the fit result is visualised.

Parameters

- **filename** (*str*) – Filename, which is contained in the data dictionaries `omega_dict` and `z_dict`.
- **model** (`lmfit.model.Model` or `lmfit.model.CompositeModel`) – The model to fit to.
- **parameters** (`lmfit.parameter.Parameters`) – The model parameters to be used.
- **modelclass** (*str, optional*) – For an iterative scheme, the modelclass is passed to this function.

Returns Result of fit as `lmfit.model.ModelResult` object.

Return type `lmfit.model.ModelResult`

run (*modelname, solver=None, parameters=None, protocol=None, solver_kwargs={}, modelclass='none'*)

Main function that iterates through all data sets provided.

Parameters

- **modelname** (*string*) – Name of the model to be parsed. Must be built by those provided in `impedancefitter.utils.available_models()` and using `+` and `parallel(x, y)` as possible representations of series or parallel circuit.
- **solver** (*string, optional*) – Choose an optimizer. Must be available in LMFIT. Default is `least_squares`.
- **parameters** (*dict, optional*) – Provide parameters if you do not want to read them from a yaml file (for instance in parallel UQ runs).
- **protocol** (*string, optional*) – Choose ‘Iterative’ for repeated fits with changing parameter sets, customized approach. If not specified, there is always just one fit for each data set.
- **solver_kwargs** (*dict, optional*) – Customize the employed solver. Interface to the LMFIT routine.
- **modelclass** (*str, optional*) – Pass a modelclass for which the iterative scheme should be used. This is experimental support for iterative schemes, where parameters can be fixed during the fitting routine. In the future, a more intelligent approach could be found. See `impedancefitter.Fitter.model_iterations()`.

sequential_run (*model1, model2, communicate, solver=None, solver_kwargs={}, parameters1=None, parameters2=None, modelclass1=None, modelclass2=None, protocol=None*)

Main function that iterates through all data sets provided.

Here, two models are fitted sequentially and fitted parameters can be communicated from one model to the other.

Parameters

- **model1** (*string*) – Name of first model. Must be built by those provided in `impedancefitter.utils.available_models()` and using `+` and `parallel(x, y)` as possible representations of series or parallel circuit
- **model2** (*string*) – Name of second model. Must be built by those provided in `impedancefitter.utils.available_models()` and using `+` and `parallel(x, y)` as possible representations of series or parallel circuit
- **communicate** (*list of strings*) – Names of parameters that should be communicated from model1 to model2. Requires that model2 contains a parameter that is named appropriately.
- **solver** (*string, optional*) – choose an optimizer. Must be available in LMFIT. Default is `least_squares`
- **solver_kwargs** (*dict, optional*) – Customize the employed solver. Interface to the LMFIT routine.
- **parameters1** (*dict, optional*) – Parameters of model1. Provide parameters if you do not want to use a yaml file.
- **parameters2** (*dict, optional*) – Parameters of model2. Provide parameters if you do not want to use a yaml file.
- **modelclass1** (*str, optional*) – Pass a modelclass for which the iterative scheme should be used. This is experimental support for iterative schemes, where parameters can be fixed during the fitting routine. In the future, a more intelligent approach could be found.
- **modelclass2** (*str, optional*) – Pass a modelclass for which the iterative scheme should be used. This is experimental support for iterative schemes, where parameters can be fixed during the fitting routine. In the future, a more intelligent approach could be found.
- **protocol** (*string, optional*) – Choose ‘Iterative’ for repeated fits with changing parameter sets, customized approach. If not specified, there is always just one fit for each data set.

visualize_data (*savefig=False*)

Visualize impedance data.

Parameters **savefig** (*bool, optional*) – Decide if plots should be saved as pdf. Default is False.

STATISTICAL ANALYSIS

UTILITIES

`impedancefitter.utils.available_file_format()`

List available file formats.

Currently available:

XLSX and CSV:

The file is structured like: frequency, real part of impedance, imaginary part of impedance. There may be many different sets of impedance data, i.e. there may be more columns with the real and the imaginary part. Then, the frequencies column must not be repeated. In fact, the number of columns equals the number of impedance data sets plus one (for the frequency).

Todo: Clarify if header is needed.

CSV_E4980AL:

Read in data that is structured in 5 columns: frequency, real part, imaginary part of the impedance, voltage, current

Note: There is always only one data set in a file.

TXT:

These files contain frequency, real and imaginary part of the impedance (i.e., 3 columns). The TXT files may contain two traces; only one of them is read in.

`impedancefitter.utils.available_models()`

return list of available models

`impedancefitter.utils.check_parameters(bufdict)`

check parameters for physical correctness

Parameters `bufdict` (*dict*) – Contains all parameters and their values

Notes

Todo: this currently is not working with prefixes

`impedancefitter.utils.get_comp_model(modelname)`

Get LMFIT CompositeModel.

Parameters `modelname` (*str*) – String representation of the equivalent circuit.

Returns the final model of the entire circuit

Return type `lmfit.model.CompositeModel`

Notes

The parser is based on Pyparsing. It is sensitive towards extra (or) or +. Thus, keep the circuit simple.

`impedancefitter.utils.get_labels(params)`
 return the labels for every parameter in LaTeX code.

Parameters `params` (*list of string*) – list with parameters names (possible prefixes included)

Returns `labels` – dictionary with parameter names as keys and LaTeX code as values.

Return type dict

`impedancefitter.utils.return_diel_properties(omega, Z, c0)`
 return relative permittivity and conductivity from impedance spectrum Use that the impedance is

$$Z = (j\omega\varepsilon^*)^{-1},$$

where ε^* is the complex permittivity (see for instance¹ for further explanation).

The relative permittivity is the real part of ε^* divided by the vacuum permittivity and the conductivity is the imaginary part times the frequency.

Parameters

- **omega** (*double or ndarray of double*) – frequency array
- **Z** (*complex or array of complex*) – impedance array
- **c0** (*double*) – unit capacitance of device

Returns

- **eps_r** (*double*) – relative permittivity
- **conductivity** (*double*) – conductivity in S/m

References

`impedancefitter.utils.set_parameters(model, parameterdict=None, emcee=False)`

Parameters

- **model** (`lmfit.model.Model`) – The LMFIT model used for fitting.
- **parameterdict** (*dict, optional*) – A dictionary containing parameters for model with *min*, *max*, *vary* info for LMFIT. If it is None (default), the parameters are read in from a yaml-file.
- **emcee** (*bool, optional*) – if emcee is used, an additional `__Insigma` parameter will be set

Returns `params` – LMFIT Parameters object.

Return type `lmfit.parameter.Parameters`

¹ Grant, F. A. (1958). Use of complex conductivity in the representation of dielectric phenomena. Journal of Applied Physics, 29(1), 76–80. <https://doi.org/10.1063/1.1722949>

CIRCUIT ELEMENTS

The following elements are available. Since prefixes are possible, each element is referred to as by a special name. The elements' parameters are called as in the original function. This is the concept of LMFIT.

4.1 Names for building the model

Name	Corresponding function
R	<code>impedancefitter.elements.Z_R()</code>
C	<code>impedancefitter.elements.Z_C()</code>
L	<code>impedancefitter.elements.Z_L()</code>
W	<code>impedancefitter.elements.Z_W()</code>
Wo	<code>impedancefitter.elements.Z_Wo()</code>
Ws	<code>impedancefitter.elements.Z_Ws()</code>
Cstray	<code>impedancefitter.elements.Z_stray()</code>

4.2 API reference

`impedancefitter.elements.Z_C(omega, C)`
Capacitor impedance

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **C** (`double`) – capacitance of capacitor

Returns Impedance array

Return type `numpy.ndarray`, complex

`impedancefitter.elements.Z_CPE(omega, k, alpha)`
CPE impedance

$$Z_{\text{CPE}} = k^{-1}(j\omega)^{-\alpha}$$

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **k** (`double`) – CPE factor
- **alpha** (`double`) – CPE phase

Returns Impedance array

Return type `numpy.ndarray`, complex

`impedancefitter.elements.Z_L(omega, L)`

Impedance of an inductor.

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **L** (*double*) – inductance

Returns Impedance array

Return type `numpy.ndarray`, complex

`impedancefitter.elements.Z_R(omega, R)`

Create array for a resistor.

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **R** (*double*) – Resistance.

Returns Impedance array

Return type `numpy.ndarray`, complex

`impedancefitter.elements.Z_stray(omega, C_stray)`

Stray capacitance in pF

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **C_stray** (*double*) – Stray capacitance, for numerical reasons in pF.

Returns Impedance array

Return type `numpy.ndarray`, complex

`impedancefitter.elements.Z_w(omega, Aw)`

Warburg element

$$Z_W = A_W \frac{1-j}{\sqrt{\omega}}$$

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **A_w** (*double*) – Warburg coefficient

Returns Impedance array

Return type `numpy.ndarray`, complex

`impedancefitter.elements.Z_wo(omega, Aw, B)`

Warburg open element

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **A_w** (*double*) – Warburg coefficient
- **B** (*double*) – Second coefficient

Returns Impedance array

Return type `numpy.ndarray`, complex

Notes

Todo: Better documentation needed.

`impedancefitter.elements.Z_ws` (*omega*, *Aw*, *B*)

Warburg short element

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **A_w** (*double*) – Warburg coefficient
- **B** (*double*) – Second coefficient

Returns Impedance array

Return type `numpy.ndarray`, complex

Notes

Todo: Better documentation needed.

`impedancefitter.elements.parallel` (*Z1*, *Z2*)

Return values of parallel circuit.

Parameters

- **Z1** (`numpy.ndarray`, complex or real) – Impedance 1
- **Z2** (`numpy.ndarray`, complex or real) – Impedance 2

Returns Impedance array

Return type `numpy.ndarray`, complex

CIRCUITS

There exist a few predefined circuits that were implemented based on published papers. Usually, those circuits are rather complex and cannot be built by the existing elements or feature parameters in certain ranges or units that are not consistent with the generally chosen unit set.

5.1 Names for building the model

Name	Corresponding function
ColeCole	<code>impedancefitter.cole_cole.cole_cole_model()</code>
ColeColeR	<code>impedancefitter.cole_cole.cole_cole_R_model()</code>
Randles	<code>impedancefitter.randles.Z_randles()</code>
RandlesCPE	<code>impedancefitter.randles.Z_randles_CPE()</code>
DRC	<code>impedancefitter.RC.drc_model()</code>
RCfull	<code>impedancefitter.RC.RC_model()</code>
RC	<code>impedancefitter.RC.rc_model()</code>
SingleShell	<code>impedancefitter.single_shell.single_shell_model()</code>
DoubleShell	<code>impedancefitter.double_shell.double_shell_model()</code>
CPE	<code>impedancefitter.cpe.cpe_model()</code>
CPECT	<code>impedancefitter.cpe.cpe_ct_model()</code>
CPECTW	<code>impedancefitter.cpe.cpe_ct_w_model()</code>

5.2 Cole-Cole circuits

`impedancefitter.cole_cole.cole_cole_R_model(omega, Rinf, R0, tau, a)`

Standard Cole-Cole circuit for macroscopic quantities.

See for example² for more information.

Notes

Equation for calculations:

$$Z_{\text{Cole}} = R_{\infty} + \frac{R_0 - R_{\infty}}{1 + (j\omega\tau)^a}$$

² Schwan, H. P. (1957). Electrical properties of tissue and cell suspensions. Advances in biological and medical physics (Vol. 5). ACADEMIC PRESS INC. <https://doi.org/10.1016/b978-1-4832-3111-2.50008-0>

References

`impedancefitter.cole_cole.cole_cole_model` (*omega, c0, el, tau, a, kdc, eh*)

Cole-Cole model for dielectric properties.

The model was implemented as presented in¹. You need to provide the unit capacitance of your device to get the dielectric properties of the Cole-Cole model.

Notes

Warning: The unit capacitance is in pF! The time constant tau is in ns!

Equations for calculations:

$$\varepsilon_s = \varepsilon_h + \frac{\varepsilon_l - \varepsilon_h}{1 + (j\omega\tau)^a}$$

$$Z_s = \frac{1}{j\varepsilon_s\omega c_0 + \frac{\sigma_{dc}c_0}{\varepsilon_0}}$$

References

5.3 Single-Shell model

`impedancefitter.single_shell.single_shell_model` (*omega, em, km, kcp, ecp, kmed, emed, p, c0, dm, Rc*)

Equations for the single-shell-model(ν_1 is calculated like in the double-shell-model):

$$\varepsilon_{\text{cell}}^* = \varepsilon_m^* * \frac{(2 * (1 - \nu_1) + (1 + 2 * \nu_1) * E_1}{((2 + \nu_1) + (1 - \nu_1) * E_1}$$

$$E_1 = \frac{\varepsilon_{\text{cp}}^*}{\varepsilon_m^*}$$

$$\varepsilon_{\text{sus}}^* = \varepsilon_{\text{med}}^* * \frac{2 * (1 - p) + (1 + 2 * p) * E_0}{(2 + p) + (1 - p) * E_0}$$

$$E_0 = \frac{\varepsilon_{\text{cell}}^*}{\varepsilon_{\text{med}}^*}$$

Todo: needs to be checked

¹ Sabuncu, A. C., Zhuang, J., Kolb, J. F., & Beskok, A. (2012). Microfluidic impedance spectroscopy as a tool for quantitative biology and biotechnology. *Biomicrofluidics*, 6(3). <https://doi.org/10.1063/1.4737121>

5.4 Double-Shell model

`impedancefitter.double_shell.double_shell_model` (*omega, km, em, kcp, ecp, ene, kne, knp, enp, kmed, emed, p, c0, dm, Rc, dn, Rn*)

Equations for the double-shell-model:

$$\varepsilon_{\text{mix}}^* = \varepsilon_{\text{sup}}^* \frac{(2\varepsilon_{\text{sup}}^* + \varepsilon_c^*) - 2p(\varepsilon_{\text{sup}}^* - \varepsilon_c^*)}{(2\varepsilon_{\text{sup}}^* + \varepsilon_c^*) + p(\varepsilon_{\text{sup}}^* - \varepsilon_c^*)}$$

$$\varepsilon_c^* = \varepsilon_m^* \frac{2(1 - \nu_1) + (1 + 2\nu_1)E_1}{(2 + \nu_1) + (1 - \nu_1)E_1}$$

$$E_1 = \frac{\varepsilon_{\text{cp}}^*}{\varepsilon_m^*} \frac{2(1 - \nu_2) + (1 + 2\nu_2)E_2}{(2 + \nu_2) + (1 - \nu_2)E_2}$$

$$E_2 = \frac{\varepsilon_{\text{ne}}^*}{\varepsilon_{\text{cp}}^*} \frac{2(1 - \nu_3) + (1 + 2\nu_3)E_3}{(2 + \nu_3) + (1 - \nu_3)E_3}$$

$$E_3 = \frac{\varepsilon_{\text{np}}^*}{\varepsilon_{\text{ne}}^*}$$

with $R \hat{=}$ outer cell Radius; $R_n \hat{=}$ outer Radius of the nucleus; $d \hat{=}$ thickness of the membrane

$$\nu_1 = \left(1 - \frac{d}{R}\right)^3$$

$$\nu_2 = \left(\frac{R_n}{R - d}\right)^3$$

$$\nu_3 = \left(1 - \frac{d_n}{R_n}\right)^3$$

In [Erm2000] , there have been reported upper/lower limits for certain parameters. They could act as a first guess for the bounds of the optimization method.

Parameter	lower limit	upper limit
ε_m	1.4	16.8
σ_m	8e-8	5.6e-5
ε_{cp}	60	77
σ_{cp}	0.033	1.1
ε_{ne}	6.8	100
σ_{ne}	8.3e-5	7e-3
ε_{np}	32	300
σ_{np}	0.25	2.2
R	3.5e-6	10.5e-6
R_n	2.95e-6	8.85e-6
d	3.5e-9	10.5e-9
d_n	2e-8	6e-8

Todo: needs to be checked

5.5 Inductance circuits

`impedancefitter.loss.Z_in(omega, L, R)`

Lead inductance of wires connecting DUT.

Described for instance in⁶.

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **L** (*double*) – inductance
- **C** (*double*) – capacitance
- **R** (*double*) – resistance

Returns Impedance array

Return type `numpy.ndarray`, complex

References

`impedancefitter.loss.Z_loss(omega, L, C, R)`

Impedance for high loss materials, where LCR are in parallel.

Described for instance in⁵.

Parameters

- **omega** (`numpy.ndarray`) – List of frequencies.
- **L** (*double*) – inductance
- **C** (*double*) – capacitance
- **R** (*double*) – resistance

Returns Impedance array

Return type `numpy.ndarray`, complex

References

⁶ Kordzadeh, A., & De Zanche, N. (2016). Permittivity measurement of liquids, powders, and suspensions using a parallel-plate cell. Concepts in Magnetic Resonance Part B: Magnetic Resonance Engineering, 46(1), 19–24. <https://doi.org/10.1002/cmr.b.21318>

⁵ Kordzadeh, A., & De Zanche, N. (2016). Permittivity measurement of liquids, powders, and suspensions using a parallel-plate cell. Concepts in Magnetic Resonance Part B: Magnetic Resonance Engineering, 46(1), 19–24. <https://doi.org/10.1002/cmr.b.21318>

POST PROCESSING

```
class impedancefitter.postprocess.PostProcess (model, electrode_polarization=True,  
                                              yamlfile=None)
```

This class provides the possibility, to analyse the statistics of the fitted data. The fitting results are read in from the outfile.

Parameters

- **model** (*{string, DoubleShell OR SingleShell}*) – define, which model has been used
- **electrode_polarization** (*{bool, default True}*) – set to false if not used
- **yamlfile** (*{string, default None}*) – define path to yamlfile or use current working directory

```
best_model_bic (parameter, distributions)
```

Test, which distribution models your data best based on the Bayesian information criterion (see https://openturns.github.io/openturns/master/user_manual/_generated/openturns.FittingTest_BestModelBIC.html#openturns.FittingTest_BestModelBIC). suitable for small samples

Parameters distributions – list of strings like: ['Normal', 'Uniform']

```
best_model_chisquared (parameter, distributions)
```

Test, which distribution models your data best based on the chisquared test (see https://openturns.github.io/openturns/master/user_manual/_generated/openturns.FittingTest_BestModelChiSquared.html).

Parameters distributions – list of strings like: ['Normal', 'Uniform']

```
best_model_kolmogorov (parameter, distributions)
```

Test, which distribution models your data best based on the kolmogorov test (see https://openturns.github.io/openturns/master/user_manual/_generated/openturns.FittingTest_BestModelKolmogorov.html#openturns.FittingTest_BestModelKolmogorov). suitable for small samples

Parameters distributions – list of strings like: ['Normal', 'Uniform']

```
fit_to_histogram_distribution (parameter)
```

Generate histogram from results.

Parameters parameter – string, parameter that is to be fitted.

```
fit_to_normal_distribution (parameter)
```

Fit results for to normal distribution.

Parameters parameter – string, parameter that is to be fitted.

```
plot_histograms ()
```

Plot histograms for all determined parameters. fails if values are too close to each other

OVERVIEW

Impedance spectroscopy (IS) is a great tool to analyse the behaviour of an electrical circuit, characterise the response of a sample (e.g. biological tissue) or determine the dielectric properties of a sample¹.

Data analysis in IS relies often on non-linear least squares for parameter estimation of equivalent circuit models. ImpedanceFitter is a software that facilitates parameter estimation for various mechanistic models. The mechanistic model is based on an equivalent circuit that may comprise different standard elements or other models that have been formulated in the context of impedance spectroscopy. The unknown parameters are found by fitting to experimental impedance data. The underlying fitting software is LMFIT², which offers an interface to different optimization and curve-fitting methods. ImpedanceFitter allows one to build a custom equivalent circuit, fit an arbitrary amount of data sets and perform statistical analysis of the results.

¹ Barsoukov, E., & Macdonald, J. R. (Eds.). (2018). *Impedance Spectroscopy: Theory, Experiment, and Applications*. (3rd ed.). Hoboken, NJ: John Wiley & Sons, Inc. <https://doi.org/10.1002/9781119381860>

² Matt Newville, Renee Otten, Andrew Nelson, Antonino Ingargiola, Till Stensitzki, Dan Allan, Austin Fox, Faustin Carter, Michał, Dima Pustakhod, Yoav Ram, Glenn, Christoph Deil, Stuermer, Alexandre Beelen, Oliver Frost, Nicholas Zobrist, Gustavo Pasquevich, Allan L. R. Hansen, Tim Spillane, Shane Caldwell, Anthony Polloreno, andrewhannum, Julius Zimmermann, Jose Borreguero, Jonathan Fraine, deep-42-thought, Benjamin F. Maier, Ben Gamari, Anthony Almarza. (2019, December 20). *lmfit/lmfit-py 1.0.0 (Version 1.0.0)*. Zenodo. <http://doi.org/10.5281/zenodo.3588521>

INDICES AND TABLES

- `genindex`
- `modindex`
- `search`

BIBLIOGRAPHY

- [Erm2000] Ermolina, I., Polevaya, Y., & Feldman, Y. (2000). Analysis of dielectric spectra of eukaryotic cells by computer modeling. *European Biophysics Journal*, 29(2), 141–145. <https://doi.org/10.1007/s002490050259>

PYTHON MODULE INDEX

i

- `impedancefitter.cole cole`, [15](#)
- `impedancefitter.double_shell`, [17](#)
- `impedancefitter.elements`, [11](#)
- `impedancefitter.loss`, [18](#)
- `impedancefitter.postprocess`, [19](#)
- `impedancefitter.single_shell`, [16](#)
- `impedancefitter.utils`, [9](#)

A

`available_file_format()` (in module *impedancefitter.utils*), 9
`available_models()` (in module *impedancefitter.utils*), 9

B

`best_model_bic()` (*impedancefitter.postprocess.PostProcess* method), 19
`best_model_chisquared()` (*impedancefitter.postprocess.PostProcess* method), 19
`best_model_kolmogorov()` (*impedancefitter.postprocess.PostProcess* method), 19

C

`check_parameters()` (in module *impedancefitter.utils*), 9
`cluster_emcee_result()` (*impedancefitter.main.Fitter* method), 3
`cole_cole_model()` (in module *impedancefitter.cole_cole*), 16
`cole_cole_R_model()` (in module *impedancefitter.cole_cole*), 15

D

`double_shell_model()` (in module *impedancefitter.double_shell*), 17

E

`emcee_conf_interval()` (*impedancefitter.main.Fitter* method), 3
`emcee_report()` (*impedancefitter.main.Fitter* method), 3

F

`fit_to_histogram_distribution()` (*impedancefitter.postprocess.PostProcess* method), 19
`fit_to_normal_distribution()` (*impedancefitter.postprocess.PostProcess* method), 19
`Fitter` (class in *impedancefitter.main*), 2

G

`get_comp_model()` (in module *impedancefitter.utils*), 9
`get_labels()` (in module *impedancefitter.utils*), 10

I

impedancefitter.cole_cole (module), 15
impedancefitter.double_shell (module), 17
impedancefitter.elements (module), 11
impedancefitter.loss (module), 18
impedancefitter.postprocess (module), 19
impedancefitter.single_shell (module), 16
impedancefitter.utils (module), 9
`initialize_model()` (*impedancefitter.main.Fitter* method), 3

M

`model_iterations()` (*impedancefitter.main.Fitter* method), 4

P

`parallel()` (in module *impedancefitter.elements*), 13
`plot_histograms()` (*impedancefitter.postprocess.PostProcess* method), 19
`plot_initial_best_fit()` (*impedancefitter.main.Fitter* method), 4
`plot_uncertainty_interval()` (*impedancefitter.main.Fitter* method), 4
`PostProcess` (class in *impedancefitter.postprocess*), 19
`process_data_from_file()` (*impedancefitter.main.Fitter* method), 5

R

`return_diel_properties()` (in module *impedancefitter.utils*), 10
`run()` (*impedancefitter.main.Fitter* method), 5

S

`sequential_run()` (*impedancefitter.main.Fitter* method), 5

`set_parameters()` (in module *impedancefitter.utils*),
10
`single_shell_model()` (in module *impedancefitter.single_shell*), 16

V

`visualize_data()` (*impedancefitter.main.Fitter*
method), 6

Z

`Z_C()` (in module *impedancefitter.elements*), 11
`Z_CPE()` (in module *impedancefitter.elements*), 11
`Z_in()` (in module *impedancefitter.loss*), 18
`Z_L()` (in module *impedancefitter.elements*), 12
`Z_loss()` (in module *impedancefitter.loss*), 18
`Z_R()` (in module *impedancefitter.elements*), 12
`Z_stray()` (in module *impedancefitter.elements*), 12
`Z_w()` (in module *impedancefitter.elements*), 12
`Z_wo()` (in module *impedancefitter.elements*), 12
`Z_ws()` (in module *impedancefitter.elements*), 13