

Xilinx Zynq FPGA, TI DSP, MCU

프로그래밍 및 회로 설계 전문가 과정

김현, 최준호 PWM


문서화

목차

- PWM Custom IP 만들기
- 페타리눅스로 설계 내용을 이미지로 빌드
- 앱 테스트

LiDAR App

PWM Custom IP 만들기



Create and Package New IP

Create Peripheral, Package IP or Package a Block Design

Please select one of the following tasks.

Packaging Options

- ☐ Package your current project
Use the project as the source for creating a new IP Definition.
- ☐ Package a block design from the current project
Choose a block design as the source for creating a new IP Definition.
Select a block design:
- ☐ Package a specified directory
Choose a directory as the source for creating a new IP Definition.


Create AXI4 Peripheral

- ☒ Create a new AXI4 peripheral
Create an AXI4 IP, driver, software test application, IP Integrator AXI4 BFM simulation and debug demonstration design.

? < Back Next > Finish Cancel

Zynq에는 PWM IP가 따로 하드코어로 존재하지 않기 때문에 PL을 활용하여 새로 Custom IP를 만들어야 한다.

PWM Custom IP 만들기



```

19
20 set_property PACKAGE_PIN T20 [get_ports PWM0]
21 set_property IOSTANDARD LVCMOS33 [get_ports PWM0]
22 set_property PACKAGE_PIN U20 [get_ports PWM1]
23 set_property IOSTANDARD LVCMOS33 [get_ports PWM1]
24 set_property PACKAGE_PIN V20 [get_ports PWM2]
25 set_property IOSTANDARD LVCMOS33 [get_ports PWM2]
26 set_property PACKAGE_PIN W20 [get_ports PWM3]
27 set_property IOSTANDARD LVCMOS33 [get_ports PWM3]
    
```

생성한 Custom IP를 추가하고 .xdc에서 핀 제약을 설정한다.

PWM Custom IP 만들기

Peripheral Drivers

Drivers present in the Board Support Package.

Ship_PWM_Core_0	Ship_PWM_Core
ps7_afi_0	generic Documentation
ps7_afi_1	generic Documentation
ps7_afi_2	generic Documentation
ps7_afi_3	generic Documentation
ps7_can_0	canps Documentation Import Examples
ps7_coresight_comp_0	coresightps_dcc Documentation
ps7_ddr_0	ddrps Documentation
ps7_ddrc_0	generic Documentation
ps7_dev_cfg_0	devcfg Documentation Import Examples
ps7_dma_ns	dmaps Documentation Import Examples
ps7_dma_s	dmaps Documentation Import Examples
ps7_ethernet_0	emacps Documentation Import Examples
ps7_globaltimer_0	generic Documentation
ps7_gpio_0	gpiops Documentation Import Examples

ps7_can_0	0xe0008000	0xe0008fff		REGISTER
ps7_globaltimer_0	0xf8f00200	0xf8f002ff		REGISTER
ps7_dma_s	0xf8003000	0xf8003fff		REGISTER
ps7_iop_bus_config_0	0xe0200000	0xe0200fff		REGISTER
ps7_xadc_0	0xf8007100	0xf8007120		REGISTER
ps7_ddr_0	0x00100000	0x1fffffff		MEMORY
ps7_ddrc_0	0xf8006000	0xf8006fff		REGISTER
ps7_ocmc_0	0xf800c000	0xf800cfff		REGISTER
ps7_pl310_0	0xf8f02000	0xf8f02fff		REGISTER
ps7_uart_1	0xe0001000	0xe0001fff		REGISTER
ps7_coresight_comp_0	0xf8800000	0xf88fffff		REGISTER
ps7_i2c_0	0xe0004000	0xe0004fff		REGISTER
ps7_ttc_0	0xf8001000	0xf8001fff		REGISTER
ps7_i2c_1	0xe0005000	0xe0005fff		REGISTER
ps7_scugic_0	0xf8f00100	0xf8f001ff		REGISTER
ps7_ethernet_0	0xe000b000	0xe000bfff		REGISTER
Ship_PWM_Core_0	0x43c00000	0x43c0ffff	S00_AXI	REGISTER
ps7 dev cfa 0	0xf8007000	0xf80070ff		REGISTER

XSDK를 활용해 새로 추가한 PWM IP가 HDF 잘 기술 돼 있는지 확인한다.

페타리눅스로 설계 내용을 이미지로 빌드

```
pl.dtsi x pwm_test_f.c x test_i2c_app.c x pcw.dtsi x skeleton.dtsi x
1  /*
2  * CAUTION: This file is automatically generated by Xilinx.
3  * Version: HSI 2015.4
4  * Today is: Tue Jul  4 14:35:42 2017
5  */
6
7
8  / {
9      amba_pl: amba_pl {
10         #address-cells = <1>;
11         #size-cells = <1>;
12         compatible = "simple-bus";
13         ranges ;
14         Ship_PWM_Core_0: Ship_PWM_Core@43c00000 {
15             compatible = "xlnx,Ship-PWM-Core-1.0";
16             reg = <0x43c00000 0x10000>;
17             xlnx,s00-axi-addr-width = <0x4>;
18             xlnx,s00-axi-data-width = <0x20>;
19         };
20     };
21 };
22
```

페타리눅스에서 새로 생성된 IP의 정보를 잘 가져왔는지 확인하고 빌드한다.

앱 테스트

```
pl.dtsi x  pwm_test_f.c x  test_i2c_app.c x  pcw.dtsi x  skeleton.dtsi x
1  /*
2  * CAUTION: This file is automatically generated by Xilinx.
3  * Version: HSI 2015.4
4  * Today is: Tue Jul  4 14:35:42 2017
5  */
6
7
8  / {
9      amba_pl: amba_pl {
10         #address-cells = <1>;
11         #size-cells = <1>;
12         compatible = "simple-bus";
13         ranges ;
14         Ship_PWM_Core_0: Ship_PWM_Core@43c00000 {
15             compatible = "xlnx,Ship-PWM-Core-1.0";
16             reg = <0x43c00000 0x10000>;
17             xlnx,s00-axi-addr-width = <0x4>;
18             xlnx,s00-axi-data-width = <0x20>;
19         };
20     };
21 };
22
```

동영상 들어갈 부분

gpio-dev-mem 테스트 코드로 pwm이 잘 작동하는지 확인한다.
(with oscilloscope)