

IBM ASSIGNMENT - 4

TEAM ID : PNT2022TMID26590

NAME : NARESH BABU D

ROLL NO : 212919104031

1. Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cms send "Alert" to ibm cloud and display in device recent events.

Solution:

```
//Pins
const int TRIG_PIN = 7 ;
const int ECHO_PIN = 8;

//Anything over 400 cm (23200 us pulse) is "out of range"
const unsigned int MAX_DIST = 23200;

void setup() {

// The Trigger pin will tell the sensor to range find
  Pin Mode(TRIG_PIN, OUTPUT);
  digital Write(TRIG_PIN, LOW);

//Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
  pinMode(ECHO_PIN, INPUT ) ;

// We'll use the serial monitor to view the sensor output
```

```

Serial.begin(9600);
}

void loop() {
  unsigned long t1;
  unsigned long t2;
  unsigned long pulse_width;
  float cm;
  float inches;
  // Hold the trigger pin high for at least 10 us
  digitalWrite(TRIG_PIN, HIGH);
  delayMicroseconds(10);
  digitalWrite(TRIG_PIN, LOW);

  // Wait for pulse on echo pin
  while (digitalRead( ECHO_PIN )==0 );

  // Measure how long the echo pin was held high (pulse width)
  // Note: the micros() counter will overflow after-70 min
  t1= micros ();
  while (digitalRead(ECHO_PIN) == 1);
  t2= micros ();
  pulse_width = t2-t1;

  // Calculate distance in centimeters and inches. The constants
  //are found in the datasheet, and calculated from the assumed speed
  // of sound in air at sea level (- 340m/s)
  cm=pulse_Width / 58 ;
  inches = pulse_width/148.0;

```


```
// Print out results
if (pulse_width > MAX_DIST ){
  Serial.println("Out of range");
} else {
  Serial.println("*****");
  Serial.print("The Measured Distance in cm: ");
  Serial.println(cm);

  if( cm < 100 ){
    //while(true){
      Serial.println("Alert!!");
    //}
  }
  Serial.print("*****");
}

//wait at least 1000ms before next measurement
Delay(1000);
}
```

Output:

1.If the distance is less than 100 cms ,it alerts.



The screenshot shows the Wokwi simulation environment. On the left, the code for `hc-sr04.ino` is displayed. The code sets up an Arduino Uno with an HC-SR04 sensor. The `setup()` function configures the trigger pin (7) as an output and the echo pin (8) as an input. The `loop()` function measures the distance and prints it to the serial monitor. The right side of the image shows the simulation of the hardware. The sensor is connected to the Arduino. A pop-up window titled "Editing Ultrasonic Distance Sensor" shows the measured distance as 83cm. Below the simulation, the serial monitor output shows "The Measured Distance in cm : 84.14" and "Alert!!".

```
1 // Pins
2 const int TRIG_PIN = 7;
3 const int ECHO_PIN = 8;
4
5 // Anything over 400 cm (23200 us pulse) is "out of range"
6 const unsigned int MAX_DIST = 23200;
7
8 void setup() {
9
10  // The Trigger pin will tell the sensor to range find
11  pinMode(TRIG_PIN, OUTPUT);
12  digitalWrite(TRIG_PIN, LOW);
13
14  //Set Echo pin as input to measure the duration of
15  //pulses coming back from the distance sensor
16  pinMode(ECHO_PIN, INPUT);
17
18  // We'll use the serial monitor to view the sensor output
19  Serial.begin(9600);
20 }
21
22 void loop() {
23
24  unsigned long t1;
25  unsigned long t2;
26  unsigned long pulse_width;
27  float cm;
28  float inches;
29
30  // Hold the trigger pin high for at least 10 us
```


Simulation: 00:00.466 58%

Editing Ultrasonic Distance Sensor
Distance: 83cm

The Measured Distance in cm : 84.14
Alert!!

Activate Windows
Go to Settings to activate Windows.

2.If the distance is more than 100 cms,it won't alert



The screenshot shows the Wokwi simulation environment. On the left, the code for `hc-sr04.ino` is displayed. The code sets up an Arduino Uno with an HC-SR04 sensor. The `setup()` function configures the trigger pin (7) as an output and the echo pin (8) as an input. The `loop()` function measures the distance and prints it to the serial monitor. The right side of the image shows the simulation of the hardware. The sensor is connected to the Arduino. A pop-up window titled "Editing Ultrasonic Distance Sensor" shows the measured distance as 227.10cm. Below the simulation, the serial monitor output shows "The Measured Distance in cm : 227.10".

```
1 // Pins
2 const int TRIG_PIN = 7;
3 const int ECHO_PIN = 8;
4
5 // Anything over 400 cm (23200 us pulse) is "out of range"
6 const unsigned int MAX_DIST = 23200;
7
8 void setup() {
9
10  // The Trigger pin will tell the sensor to range find
11  pinMode(TRIG_PIN, OUTPUT);
12  digitalWrite(TRIG_PIN, LOW);
13
14  //Set Echo pin as input to measure the duration of
15  //pulses coming back from the distance sensor
16  pinMode(ECHO_PIN, INPUT);
17
18  // We'll use the serial monitor to view the sensor output
19  Serial.begin(9600);
20 }
21
22 void loop() {
23
24  unsigned long t1;
25  unsigned long t2;
26  unsigned long pulse_width;
27  float cm;
28  float inches;
29
30  // Hold the trigger pin high for at least 10 us
```

Simulation: 00:00.599 62%

Editing Ultrasonic Distance Sensor
Distance: 227.10cm

The Measured Distance in cm : 227.10

Activate Windows
Go to Settings to activate Windows.

3.Simulation and code execution

