

ICE Telescope

—

A ROS package

Biel Artigues Aguilo

December 22, 2015

Version 0.1.2

Abstract

ice_telescope is a ROS package to operate and remote control the telescope system at the ICE building in the UAB Campus. The full system is composed of a Meade LX200GPS telescope, an SBIG ST-7 CCD camera and a Baader Planetarium dome.

1 Synopsis

ROS

roscore

Server

roslaunch ice_telescope ice_telescope_node

Client

roslaunch ice_telescope ice_telescope_node action [params]

2 Description

ice_telescope is composed of several nodes –*ice_telescope_node*– that allow the control of the telescope system. In addition to the server to control all devices *ice_tel_server*, each of the system components (telescope, dome, ccd) has a pair of client–server nodes following the naming convention *brand_server* and *brand_client*:

Full-Server *ice_tel_server*.

Telescope *meade_server* and *meade_client*.

CCD *sbig_server* and *sbig_client*.

Dome *baader_server* and *baader_client*.

Note: The *brand_server* servers are there for your convenience but only the *ice_tel_server* is necessary to control them all.

The server node runs continuously waiting for petitions from the client node. When a client node's petition is received by the server node, the server processes the petition, sends a response back to the client and returns to the waiting mode. The client waits for the server response and finishes the execution.

Client node

The **action** parameter issues the desired order to the server.

[**params**] will depend on the system component and the selected **action**.

Note: *roscore* must be running at all times for node communication and interoperation.

3 Servers

The servers for all the system elements are executed without additional parameters and they must be running to listen to the clients commands.

Full-Server

```
roslaunch ice_telescope ice_tel_server
```

Telescope

```
roslaunch ice_telescope meade_server
```

CCD

```
roslaunch ice_telescope sbig_server
```

Dome

```
roslaunch ice_telescope baader_server
```

4 Telescope client

The telescope client issues the user's desired actions to perform with the Meade LX200GPS Telescope.

```
roslaunch ice_telescope meade_client action [params]  
roslaunch ice_telescope meade_client.py action [params]
```

Note: To run more than one *meade_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**_name:=DesiredName**]

4.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

goto Point the telescope to the specified coordinates.

```
roslaunch ice_telescope meade_client goto ra dec
```

- **ra** Right ascension as a double value.
- **dec** Declination as a double value.

messier Point the telescope to the selected catalog object.

star

```
roslaunch ice_telescope meade_client messier objectNum
```

deepsky

```
roslaunch ice_telescope meade_client star objectNum  
roslaunch ice_telescope meade_client deepsky objectNum
```

- **objectNum** The catalog number for the desired object.

gps Update the system's gps. **Note:** The dome must be open for the gps sync.

```
roslaunch ice_telescope meade_client gps
```

getobjradec Get the coordinates of the currently selected object.

```
roslaunch ice_telescope meade_client getobjradec
```

- gettelradec** Get the telescope's current pointing coordinates.
roslaunch ice_telescope meade_client gettelradec
- getdatetime** Get the telescope's current date and time.
roslaunch ice_telescope meade_client getdatetime
- setdatetime** Set the telescope's date and time to the current ones.
roslaunch ice_telescope meade_client setdatetime
- getlatlon** Get the telescope's latitude and longitude.
roslaunch ice_telescope meade_client getlatlon
- setlatlon** Set the telescope's latitude and longitude.
roslaunch ice_telescope meade_client setlatlon lat lon
- **lat** The current latitude as a double value.
 - **lon** The current longitude as a double value.
- focus** Move the telescope's focus (in/out). WORK IN PROGRESS.
- reconnect** Re-establish telescope connection.
roslaunch ice_telescope meade_client reconnect

5 CCD client

The CCD client issues the user's desired actions to perform with the SBIG ST-7 CCD.

```
roslaunch ice_telescope sbig_client action [params]
roslaunch ice_telescope sbig_client.py action [params]
```

Note: To run more than one *sbig_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**--name:=DesiredName**]

5.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

- capture** Start an exposure and save the result to file.
roslaunch ice_telescope sbig_client capture filePath fileType imgCount imgType expTime readoutMode top left width height fastReadout dualReadoutChannel
- **filePath:** The path for the saved image files.
 - **fileType:** FITS or SBIG file formats.
 - **imgCount:** Number of exposures to take.
 - **imgType:** LF (light frame) or DF (dark frame).
 - **expTime:** Number of seconds (or fraction of second) of exposure.
 - **readoutMode:** Binning. Options: 1x1, 2x2, 3x3.
 - **top:** Starting position in the 'Y' axis.
 - **left:** Starting position in the 'X' axis.
 - **width:** Image width in pixels.

- **height**: Image height in pixels.

Note: If all params (top, left, width and height) are zero, the full size of the CCD image is used.

- **fastReadout**: 1 for fast readout and 0 for normal readout.
- **dualReadoutChannel**: 1 for dual channel readout and 0 for single channel readout.

settemp Enable or disable the cooler to achieve the desired temperature for the CCD.

roslaunch ice_telescope sbig_client settemp enable temperature

- **enable**: 1 to enable and 0 to disable.
- **temperature**: double value with the desired temperature

gettemp Query the CCD temperature. The server returns the temperature, the power applied to the CCD as a percentage (0-1) and the cooler status (enabled/disabled).

roslaunch ice_telescope sbig_client gettemp

getcapstatus Query the CCD capture status. The server returns the exposure progress percentage or the IDLE status.

roslaunch ice_telescope sbig_client getcapstatus

reconnect Re-establish CCD connection.

roslaunch ice_telescope sbig_client reconnect

6 Dome client

The dome client issues the user's desired actions to perform with the Baader Planetarium Dome.

roslaunch ice_telescope baader_client action
roslaunch ice_telescope baader_client.py action

Note: To run more than one *baader_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**__name:=DesiredName**]

6.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

open Open the dome.

roslaunch ice_telescope baader_client open

close Close the dome.

roslaunch ice_telescope baader_client close

status Query the dome status. The possible states for the dome are: open, closed, moving and unknown.

roslaunch ice_telescope baader_client status

reconnect Re-establish dome connection.

roslaunch ice_telescope baader_client reconnect

7 Files

<code>ice_tel_server</code>	C++ implementation of the server to control all devices.
<code>meade_server</code>	C++ implementation of the telescope server.
<code>meade_client</code>	C++ implementation of the telescope client.
<code>meade_client.py</code>	Python implementation for the telescope client.
<code>sbig_server</code>	C++ implementation of the CCD server.
<code>sbig_client</code>	C++ implementation of the CCD client.
<code>sbig_client.py</code>	Python implementation for the CCD client.
<code>baader_server</code>	C++ implementation of the dome server.
<code>baader_client</code>	C++ implementation of the dome client.
<code>baader_client.py</code>	Python implementation for the dome client.

8 Example

```
$ roscore &

$ rosrun ice_telescope ice_tel_server &

$ rosrun ice_telescope baader_client open
$ rosrun ice_telescope sbig_client settemp 1 10.0
$ rosrun ice_telescope meade_client gps
$ rosrun ice_telescope meade_client setdatetime
$ rosrun ice_telescope meade_client messier 31
$ rosrun ice_telescope sbig_client capture /img/ FITS 10 LF 30.0 1x1 0
  0 0 0 1 1
$ rosrun ice_telescope baader_client close
```

9 See Also

ROS, *roscd*, *rosls*, *catkin_make*.

10 Requirements

ROS Environment *ice_telescope* requires ROS version $\geq 1.11.13$ (\geq Indigo distribution).

ROS Workspace If you want to compile or install the distributed system, you need a *catkin* workspace.

Libraries :

- **libusb-1.0.**
- **cfitsio.**
- **libsigudrv.** This library can be downloaded from <http://archive.sbig.com/sbwhtmls/devswframe.htm>.

11 Changes

Please check the file **CHANGELOG** for the list of changes and acknowledgment to people contributing bugfixes or enhancements.

12 Version

Version: 0.1.2 of December 22, 2015.

13 License and Copyright

Copyright © 2015, Biel Artigues Aguiló, ICE Building, Campus UAB, Bellaterra, Catalunya
artigues@ice.cat

The actual version of *ice-telescope* may be found on the following link
<https://baiels.redkaos.org/index.php/s/5uqq3uB47HYeQ0v>.

License This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

14 Author

Biel Artigues Aguiló
Email: artigues@ice.cat
Web: <http://www.ice.csic.es/>.