

ICE Telescope

—

A ROS package

Biel Artigues Aguilo

March 16, 2016

Version 0.1.3

Abstract

ice_telescope is a ROS package to operate and remote control the telescope system at the ICE building in the UAB Campus. The full system is composed of a Meade LX200GPS telescope, a SBIG ST-7 CCD camera, a Baader Planetarium dome, an APC Switched PDU and a Vaisala weather station..

1 Synopsis

ROS

roscore

Server

roslaunch ice_telescope ice_telescope_node

Client

roslaunch ice_telescope ice_telescope_node action [params]

2 Description

ice_telescope is composed of several nodes *ice_telescope_node* that allow the control of the telescope system. In addition to the server to control all devices *ice_tel_server*, each of the system components (telescope, dome, ccd, pdu, weather station) has a pair of client-server nodes following the naming convention *brand_server* and *brand_client*:

Full-Server *ice_tel_server*.

Telescope *meade_server* and *meade_client*.

CCD *sbig_server* and *sbig_client*.

Dome *baader_server* and *baader_client*.

PDU *apc_server* and *apc_client*.

WS *vaisala_server* and *vaisala_client*.

Note: The *brand_server* servers are there for your convenience but only the *ice_tel_server* is necessary to control them all.

The server node runs continuously waiting for petitions from the client nodes. When a client node's petition is received by the server node, the server processes the petition, sends a response back to the client and returns to the waiting mode. The client waits for the server response and

finishes the execution.

Client node

The **action** parameter issues the desired order to the server.

[**params**] will depend on the system component and the selected **action**.

Note: *roscore* must be running at all times for node communication and interoperation.

3 Servers

The server for all the system elements is executed without additional parameters and it must be running to listen to the clients commands.

Full-Server

```
roslaunch ice_telescope ice_tel_server
```

Telescope

```
roslaunch ice_telescope meade_server
```

CCD

```
roslaunch ice_telescope sbig_server
```

Dome

```
roslaunch ice_telescope baader_server
```

PDU

```
roslaunch ice_telescope apc_server
```

WS

```
roslaunch ice_telescope vaisala_server
```

4 Telescope client

The telescope client issues the user's desired actions to perform with the Meade LX200GPS Telescope.

```
roslaunch ice_telescope meade_client action [params]
```

Note: To run more than one *meade_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**__name:=DesiredName**]

4.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

<i>init</i>	Initialize the telescope for a remote session. <pre>roslaunch ice_telescope meade_client init</pre>
<i>goto</i>	Point the telescope to the specified coordinates. <pre>roslaunch ice_telescope meade_client goto ra dec</pre> <ul style="list-style-type: none">• ra Right ascension as a double value.• dec Declination as a double value.
<i>messier</i>	Point the telescope to the selected catalog object.
<i>star</i>	<pre>roslaunch ice_telescope meade_client messier objectNum</pre>

deepsky	<p><i>roslaunch ice_telescope meade_client star objectNum</i></p> <p><i>roslaunch ice_telescope meade_client deepsky objectNum</i></p> <ul style="list-style-type: none"> • objectNum The catalog number for the desired object.
move	<p>Move the telescope in a specific direction for a specific period of time.</p> <p><i>roslaunch ice_telescope meade_client move dir(north/south/east/west) milliseconds</i></p> <ul style="list-style-type: none"> • dir the desired movement direction. The possible directions are: north, south, east, west. • milliseconds the duration of the movement as a four-digit number (0-9999).
sync	<p>Synchronize the telescope coordinates with the current ones.</p> <p><i>roslaunch ice_telescope meade_client sync</i></p> <p><i>roslaunch ice_telescope meade_client sync ra dec</i></p> <ul style="list-style-type: none"> • ra Right ascension as a double value. • dec Declination as a double value.
park	<p>Slew the telescope to the parked position. Note: after parking, a power cycle is required.</p> <p><i>roslaunch ice_telescope meade_client park</i></p>
status	<p>Check if the telescope is moving or IDLE.</p> <p><i>roslaunch ice_telescope meade_client status</i></p>
gps	<p>Update the system's gps. Note: The dome must be open for the gps sync.</p> <p><i>roslaunch ice_telescope meade_client gps</i></p>
getobjradec	<p>Get the coordinates of the currently selected object.</p> <p><i>roslaunch ice_telescope meade_client getobjradec</i></p>
gettelradec	<p>Get the telescope's current pointing coordinates.</p> <p><i>roslaunch ice_telescope meade_client gettelradec</i></p>
getdatetime	<p>Get the telescope's current date and time.</p> <p><i>roslaunch ice_telescope meade_client getdatetime</i></p>
setdatetime	<p>Set the telescope's date and time to the current ones.</p> <p><i>roslaunch ice_telescope meade_client setdatetime</i></p>
getlatlon	<p>Get the telescope's latitude and longitude.</p> <p><i>roslaunch ice_telescope meade_client getlatlon</i></p>
setlatlon	<p>Set the telescope's latitude and longitude.</p> <p><i>roslaunch ice_telescope meade_client setlatlon lat lon</i></p> <ul style="list-style-type: none"> • lat The current latitude as a double value. • lon The current longitude as a double value.
focus	<p>Move the telescope's focus (in/out). WORK IN PROGRESS.</p>
reconnect	<p>Re-establish telescope connection.</p> <p><i>roslaunch ice_telescope meade_client reconnect</i></p>

5 CCD client

The CCD client issues the user's desired actions to perform with the SBIG ST-7 CCD.

```
roslaunch ice_telescope sbig_client action [params]
```

Note: To run more than one *sbig_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**__name:=DesiredName**]

5.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

capture Start an exposure and save the result to file.

```
roslaunch ice_telescope sbig_client capture filePath fileType imgCount imgType expTime readoutMode top left width height fastReadout dualReadoutChannel
```

- **filePath:** The path for the saved image files.
- **fileType:** FITS or SBIG file formats.
- **imgCount:** Number of exposures to take.
- **imgType:** LF (light frame) or DF (dark frame).
- **expTime:** Number of seconds (or fraction of second) of exposure.
- **readoutMode:** Binning. Options: 1x1, 2x2, 3x3.
- **top:** Starting position in the 'Y' axis.
- **left:** Starting position in the 'X' axis.
- **width:** Image width in pixels.
- **height:** Image height in pixels.

Note: If all params (top, left, width and height) are zero, the full size of the CCD image is used.

- **fastReadout:** 1 for fast readout and 0 for normal readout.
- **dualReadoutChannel:** 1 for dual channel readout and 0 for single channel readout.

settemp Enable or disable the cooler to achieve the desired temperature for the CCD.

```
roslaunch ice_telescope sbig_client settemp enable temperature
```

- **enable:** 1 to enable and 0 to disable.
- **temperature:** double value with the desired temperature

gettemp Query the CCD temperature. The server returns the temperature, the power applied to the CCD as a percentage (0-1) and the cooler status (enabled/disabled).

```
roslaunch ice_telescope sbig_client gettemp
```

getcapstatus Query the CCD capture status. The server returns the exposure progress percentage or the IDLE status.

```
roslaunch ice_telescope sbig_client getcapstatus
```

reconnect Re-establish CCD connection.

```
roslaunch ice_telescope sbig_client reconnect
```

6 Dome client

The dome client issues the user's desired actions to perform with the Baader Planetarium Dome.

```
roslaunch ice_telescope baader_client action
```

Note: To run more than one *baader_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**__name:=DesiredName**]

6.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

- | | |
|-------------------------|--|
| <i>open</i> | Open the dome. |
| | <pre>roslaunch ice_telescope baader_client open</pre> |
| <i>close</i> | Close the dome. |
| | <pre>roslaunch ice_telescope baader_client close</pre> |
| <i>status</i> | Query the dome status. The possible states for the dome are: open, closed, moving and unknown. |
| | <pre>roslaunch ice_telescope baader_client status</pre> |
| <i>reconnect</i> | Re-establish dome connection. |
| | <pre>roslaunch ice_telescope baader_client reconnect</pre> |

7 PDU client

The PDU client issues the user's desired actions to perform with the APC Switched PDU.

```
roslaunch ice_telescope apc_client action device
```

Note: To run more than one *apc_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**__name:=DesiredName**]

7.1 Options

The *action* parameter is the command to be sent to the server and the *device* parameter specifies on which system element the action has to be performed. The *device* parameter can be one of the following:

- | | |
|-------------------------|---|
| <i>telescope</i> | The specified <i>action</i> will be performed on the telescope. |
| | <pre>roslaunch ice_telescope apc_client action telescope</pre> |
| <i>ccd</i> | The specified <i>action</i> will be performed on the CCD. |
| | <pre>roslaunch ice_telescope apc_client action ccd</pre> |
| <i>vaisala</i> | The specified <i>action</i> will be performed on the weather station. |
| | <pre>roslaunch ice_telescope apc_client action vaisala</pre> |
| <i>light</i> | The specified <i>action</i> will be performed on the light inside the dome. |
| | <pre>roslaunch ice_telescope apc_client action light</pre> |

The *action* can be one of the following:

power_on Power on the specified device by switching on the corresponding outlet of the PDU.
`roslaunch ice_telescope apc_client power_on device`

power_off Power off the specified device by switching off the corresponding outlet of the PDU.
`roslaunch ice_telescope apc_client power_off device`

power_status Check the corresponding PDU's outlet status.
`roslaunch ice_telescope apc_client power_status device`

8 Weather Station client

The weather station client issues the user's desired actions to perform with the Vaisala weather station. The only action for the weather station is *getinfo*.

`roslaunch ice_telescope vaisala_client getinfo`

Note: To run more than one *vaisala_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**__name:=DesiredName**]

9 Example

```
$ roscore &

$ roslaunch ice_telescope ice_tel_server &

$ roslaunch ice_telescope baader_client open
$ roslaunch ice_telescope sbig_client settemp 1 10.0
$ roslaunch ice_telescope meade_client gps
$ roslaunch ice_telescope meade_client setdatetime
$ roslaunch ice_telescope meade_client messier 31
$ roslaunch ice_telescope sbig_client capture /img/ FITS 10 LF 30.0 1x1 0
    0 0 0 1 1
$ roslaunch ice_telescope baader_client close
```

10 See Also

ROS, *roslaunch*, *roscd*, *rosls*, *catkin_make*.

11 Requirements

ROS Environment *ice_telescope* requires ROS version $\geq 1.11.16$ (\geq Indigo distribution).

ROS Workspace If you want to compile or install the distributed system, you need a *catkin* workspace.

Libraries :

- **libusb-1.0.**
- **cfitsio.**
- **libsnmp-dev.**

- **libsbigudrv**. This library can be downloaded from <http://archive.sbig.com/sbwhtmls/devswframe.htm>.

12 Changes

Please check the file **CHANGELOG** for the list of changes and acknowledgment to people contributing bugfixes or enhancements.

13 Version

Version: 0.1.3 of March 16, 2016.

14 License and Copyright

Copyright © 2015, Biel Artigues Aguilo, ICE Building, Campus UAB, Bellaterra, Catalunya
artigues@ice.cat

License This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

15 Author

Biel Artigues Aguilo
Email: artigues@ice.cat
Web: <http://www.ice.csic.es/>.