

# ICE Telescope

—

## A ROS package

Biel Artigues Aguiló

February 18, 2016

Version 0.1.3

### Abstract

*ice\_telescope* is a ROS package to operate and remote control the telescope system at the ICE building in the UAB Campus. The full system is composed of a Meade LX200GPS telescope, a SBIG ST-7 CCD camera, a Baader Planetarium dome, an APC Switched PDU and a Vaisala weather station..

## 1 Synopsis

### ROS

*roscore*

### Server

*roslaunch ice\_telescope ice\_tel\_server*

### Client

*roslaunch ice\_telescope ice\_telescope\_node action [params]*

## 2 Description

*ice\_telescope* is composed of several nodes *ice\_telescope\_node* that allow the control of the telescope system. In addition to the server to control all devices *ice\_tel\_server*, each of the system components (telescope, dome, ccd, pdu, weather station) has a client node following the naming convention *brand\_client*:

**Full-Server** *ice\_tel\_server*.

**Telescope** *meade\_client*.

**CCD** *sbig\_client*.

**Dome** *baader\_client*.

**PDU** *apc\_client*.

**WS** *vaisala\_client*.

The server node runs continuously waiting for petitions from the client nodes. When a client node's petition is received by the server node, the server processes the petition, sends a response back to the client and returns to the waiting mode. The client waits for the server response and finishes the execution.

### Client node

The **action** parameter issues the desired order to the server.

[**params**] will depend on the system component and the selected **action**.

**Note:** *roscore* must be running at all times for node communication and interoperation.

### 3 Servers

The server for all the system elements is executed without additional parameters and it must be running to listen to the clients commands.

#### Full-Server

```
roslaunch ice_telescope ice_tel_server
```

### 4 Telescope client

The telescope client issues the user's desired actions to perform with the Meade LX200GPS Telescope.

```
roslaunch ice_telescope meade_client action [params]
```

**Note:** To run more than one *meade\_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**--name:=DesiredName**]

#### 4.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

- |                    |   |
|--------------------|---|
| <b>goto</b>        | Point the telescope to the specified coordinates.<br><pre>roslaunch ice_telescope meade_client goto ra dec</pre> <ul style="list-style-type: none"><li>• <b>ra</b> Right ascension as a double value.</li><li>• <b>dec</b> Declination as a double value.</li></ul> |
| <b>messier</b>     | Point the telescope to the selected catalog object.   |
| <b>star</b>        | <pre>roslaunch ice_telescope meade_client messier objectNum</pre>   |
| <b>deepsky</b>     | <pre>roslaunch ice_telescope meade_client star objectNum</pre> <pre>roslaunch ice_telescope meade_client deepsky objectNum</pre> <ul style="list-style-type: none"><li>• <b>objectNum</b> The catalog number for the desired object.</li></ul>                      |
| <b>gps</b>         | Update the system's gps. <b>Note:</b> The dome must be open for the gps sync.<br><pre>roslaunch ice_telescope meade_client gps</pre>  |
| <b>getobjradec</b> | Get the coordinates of the currently selected object.<br><pre>roslaunch ice_telescope meade_client getobjradec</pre>  |
| <b>gettelradec</b> | Get the telescope's current pointing coordinates.<br><pre>roslaunch ice_telescope meade_client gettelradec</pre>  |
| <b>getdatetime</b> | Get the telescope's current date and time.<br><pre>roslaunch ice_telescope meade_client getdatetime</pre>   |

**setdatetime** Set the telescope's date and time to the current ones.

*roslaunch ice\_telescope meade\_client setdatetime*

**getlatlon** Get the telescope's latitude and longitude.

*roslaunch ice\_telescope meade\_client getlatlon*

**setlatlon** Set the telescope's latitude and longitude.

*roslaunch ice\_telescope meade\_client setlatlon lat lon*

- **lat** The current latitude as a double value.
- **lon** The current longitude as a double value.

**focus** Move the telescope's focus (in/out). WORK IN PROGRESS.

**reconnect** Re-establish telescope connection.

*roslaunch ice\_telescope meade\_client reconnect*

## 5 CCD client

The CCD client issues the user's desired actions to perform with the SBIG ST-7 CCD.

*roslaunch ice\_telescope sbig\_client action [params]*

**Note:** To run more than one *sbig\_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**\_\_name:=DesiredName**]

### 5.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

**capture** Start an exposure and save the result to file.

*roslaunch ice\_telescope sbig\_client capture filePath fileType imgCount imgType expTime readoutMode top left width height fastReadout dualReadoutChannel*

- **filePath:** The path for the saved image files.
- **fileType:** FITS or SBIG file formats.
- **imgCount:** Number of exposures to take.
- **imgType:** LF (light frame) or DF (dark frame).
- **expTime:** Number of seconds (or fraction of second) of exposure.
- **readoutMode:** Binning. Options: 1x1, 2x2, 3x3.
- **top:** Starting position in the 'Y' axis.
- **left:** Starting position in the 'X' axis.
- **width:** Image width in pixels.
- **height:** Image height in pixels.

**Note:** If all params (top, left, width and height) are zero, the full size of the CCD image is used.

- **fastReadout:** 1 for fast readout and 0 for normal readout.

- **dualReadoutChannel:** 1 for dual channel readout an 0 for single channel readout.
- settemp** Enable or disable the cooler to achieve the desired temperature for the CCD.  
*roslaunch ice\_telescope sbig\_client settemp enable temperature*
- **enable:** 1 to enable and 0 to disable.
  - **temperature:** double value with the desired temperature
- gettemp** Query the CCD temperature. The server returns the temperature, the power applied to the CCD as a percentage (0-1) and the cooler status (enabled/disabled).  
*roslaunch ice\_telescope sbig\_client gettemp*
- getcapstatus** Query the CCD capture status. The server returns the exposure progress percentage or the IDLE status.  
*roslaunch ice\_telescope sbig\_client getcapstatus*
- reconnect** Re-establish CCD connection.  
*roslaunch ice\_telescope sbig\_client reconnect*

## 6 Dome client

The dome client issues the user's desired actions to perform with the Baader Planetarium Dome.

*roslaunch ice\_telescope baader\_client action*

**Note:** To run more than one *baader\_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**\_\_name:=DesiredName**]

### 6.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

- open** Open the dome.  
*roslaunch ice\_telescope baader\_client open*
- close** Close the dome.  
*roslaunch ice\_telescope baader\_client close*
- status** Query the dome status. The possible states for the dome are: open, closed, moving and unknown.  
*roslaunch ice\_telescope baader\_client status*
- reconnect** Re-establish dome connection.  
*roslaunch ice\_telescope baader\_client reconnect*

## 7 PDU client

The PDU client issues the user's desired actions to perform with the APC Switched PDU.

*roslaunch ice\_telescope apc\_client action device*

**Note:** To run more than one *apc\_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**\_\_name:=DesiredName**]

## 7.1 Options

The *action* parameter is the command to be sent to the server and the *device* parameter specifies on which system element the action has to be performed. The *device* parameter can be one of the following:

- telescope** The specified *action* will be performed on the telescope.  
*roslaunch ice\_telescope apc\_client action telescope*
- ccd** The specified *action* will be performed on the CCD.  
*roslaunch ice\_telescope apc\_client action ccd*
- weather\_station** The specified *action* will be performed on the weather station.  
*roslaunch ice\_telescope apc\_client action weather\_station*

The *action* can be one of the following:

- power\_on** Power on the specified device by switching on the corresponding outlet of the PDU.  
*roslaunch ice\_telescope apc\_client power\_on device*
- power\_off** Power off the specified device by switching off the corresponding outlet of the PDU.  
*roslaunch ice\_telescope apc\_client power\_off device*
- power\_status** Check the corresponding PDU's outlet status.  
*roslaunch ice\_telescope apc\_client power\_status device*

## 8 Weather Station client

The weather station client issues the user's desired actions to perform with the Vaisala weather station. The only action for the weather station is *getinfo*.

*roslaunch ice\_telescope vaisala\_client getinfo*

**Note:** To run more than one *vaisala\_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [**\_\_name:=DesiredName**]

## 9 Example

```
$ roscore &

$ roslaunch ice_telescope ice_tel_server &

$ roslaunch ice_telescope baader_client open
$ roslaunch ice_telescope sbig_client settemp 1 10.0
$ roslaunch ice_telescope meade_client gps
$ roslaunch ice_telescope meade_client setdatetime
$ roslaunch ice_telescope meade_client messier 31
$ roslaunch ice_telescope sbig_client capture /img/ FITS 10 LF 30.0 1x1 0
    0 0 0 1 1
$ roslaunch ice_telescope baader_client close
```

## 10 See Also

ROS, *roslaunch*, *roscd*, *rosls*, *catkin\_make*.

## 11 Requirements

**ROS Environment** *ice\_telescope* requires ROS version  $\geq 1.11.16$  ( $\geq$  Indigo distribution).

**ROS Workspace** If you want to compile or install the distributed system, you need a *catkin* workspace.

**Libraries :**

- **libusb-1.0.**
- **cfitsio.**
- **libsnmp-dev.**
- **libsbigudrv.** This library can be downloaded from <http://archive.sbig.com/sbwhtmls/devswframe.htm>.

## 12 Changes

Please check the file **CHANGELOG** for the list of changes and acknowledgment to people contributing bugfixes or enhancements.

## 13 Version

Version: 0.1.3 of February 18, 2016.

## 14 License and Copyright

**Copyright** © 2015, Biel Artigues Aguilo, ICE Building, Campus UAB, Bellaterra, Catalunya  
[artigues@ice.cat](mailto:artigues@ice.cat)

**License** This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

## 15 Author

Biel Artigues Aguilo  
Email: [artigues@ice.cat](mailto:artigues@ice.cat)  
Web: <http://www.ice.csic.es/>.