

Regulator Consumer Driver Interface

This text describes the regulator interface for consumer device drivers. Please see overview.txt for a description of the terms used in this text.

1. Consumer Regulator Access (static & dynamic drivers)

A consumer driver can get access to its supply regulator by calling

```
regulator = regulator_get(dev, "Vcc");
```

The consumer passes in its struct device pointer and power supply ID. The core then finds the correct regulator by consulting a machine specific lookup table. If the lookup is successful then this call will return a pointer to the struct regulator that supplies this consumer.

To release the regulator the consumer driver should call

```
regulator_put(regulator);
```

Consumers can be supplied by more than one regulator e.g. codec consumer with analog and digital supplies

```
digital = regulator_get(dev, "Vcc"); /* digital core */  
analog = regulator_get(dev, "Avdd"); /* analog */
```

The regulator access functions `regulator_get()` and `regulator_put()` will usually be called in your device drivers `probe()` and `remove()` respectively.

2. Regulator Output Enable & Disable (static & dynamic drivers)

A consumer can enable its power supply by calling:

```
int regulator_enable(regulator);
```

NOTE:

The supply may already be enabled before `regulator_enable()` is called. This may happen if the consumer shares the regulator or the regulator has been previously enabled by bootloader or kernel board initialization code.

A consumer can determine if a regulator is enabled by calling:

```
int regulator_is_enabled(regulator);
```

This will return > zero when the regulator is enabled.

A consumer can disable its supply when no longer needed by calling:

```
int regulator_disable(regulator);
```

NOTE:

This may not disable the supply if it's shared with other consumers. The regulator will only be disabled when the enabled reference count is zero.

Finally, a regulator can be forcefully disabled in the case of an emergency:

```
int regulator_force_disable(regulator);
```

NOTE:

this will immediately and forcefully shutdown the regulator output. All consumers will be powered off.

3. Regulator Voltage Control & Status (dynamic drivers)

Some consumer drivers need to be able to dynamically change their supply voltage to match system operating points. e.g. CPUfreq drivers can scale voltage along with frequency to save power, SD drivers may need to select the correct card voltage, etc.

Consumers can control their supply voltage by calling:

```
int regulator_set_voltage(regulator, min_uV, max_uV);
```

Where `min_uV` and `max_uV` are the minimum and maximum acceptable voltages in microvolts.

NOTE: this can be called when the regulator is enabled or disabled. If called when enabled, then the voltage changes instantly, otherwise the voltage configuration changes and the voltage is physically set when the regulator is next enabled.

The regulators configured voltage output can be found by calling:

```
int regulator_get_voltage(regulator);
```


Regulators use the kernel notifier framework to send event to their interested consumers.

7. Regulator Direct Register Access

Some kinds of power management hardware or firmware are designed such that they need to do low-level hardware access to regulators, with no involvement from the kernel. Examples of such devices are:

- clocksource with a voltage-controlled oscillator and control logic to change the supply voltage over I2C to achieve a desired output clock rate
- thermal management firmware that can issue an arbitrary I2C transaction to perform system poweroff during overtemperature conditions

To set up such a device/firmware, various parameters like I2C address of the regulator, addresses of various regulator registers etc. need to be configured to it. The regulator framework provides the following helpers for querying these details.

Bus-specific details, like I2C addresses or transfer rates are handled by the regmap framework. To get the regulator's regmap (if supported), use:

```
struct regmap *regulator_get_regmap(struct regulator *regulator);
```

To obtain the hardware register offset and bitmask for the regulator's voltage selector register, use:

```
int regulator_get_hardware_vsel_register(struct regulator *regulator,  
                                         unsigned *vsel_reg,  
                                         unsigned *vsel_mask);
```

To convert a regulator framework voltage selector code (used by `regulator_list_voltage`) to a hardware-specific voltage selector that can be directly written to the voltage selector register, use:

```
int regulator_list_hardware_vsel(struct regulator *regulator,  
                                 unsigned selector);
```