

# ioctl LIRC\_SET\_REC\_CARRIER

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\linux-master) (Documentation) (userspace-api) (media) (rc) lirc-set-rec-carrier.rst, line 2)

Unknown directive type "c.namespace".

```
.. c:namespace:: RC
```

## Name

LIRC\_SET\_REC\_CARRIER - Set carrier used to modulate IR receive.

## Synopsis

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\linux-master) (Documentation) (userspace-api) (media) (rc) lirc-set-rec-carrier.rst, line 18)

Unknown directive type "c.macro".

```
.. c:macro:: LIRC_SET_REC_CARRIER
```

```
int ioctl(int fd, LIRC_SET_REC_CARRIER, __u32 *frequency)
```

## Arguments

fd

File descriptor returned by open().

frequency

Frequency of the carrier that modulates PWM data, in Hz

## Description

Set receive carrier used to modulate IR PWM pulses and spaces.

### Note

If called together with [ref`LIRC\\_SET\\_REC\\_CARRIER\\_RANGE`](#), this ioctl sets the upper bound frequency that will be recognized by the device.

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\linux-master) (Documentation) (userspace-api) (media) (rc) lirc-set-rec-carrier.rst, line 38); [backlink](#)

Unknown interpreted text role "ref".

## Return Value

On success 0 is returned, on error -1 and the `errno` variable is set appropriately. The generic error codes are described at the [ref`Generic Error Codes <gen-errors>`](#) chapter.

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\linux-master) (Documentation) (userspace-api) (media) (rc) lirc-set-rec-carrier.rst, line 44); [backlink](#)

Unknown interpreted text role "ref".