

Audio Data Types

This section describes the structures, data types and defines used when talking to the audio device.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master) [drivers] [staging] [media] [av7110]audio_data_types.rst, line 12)
```

Unknown directive type "c.type".

```
.. c:type:: audio_stream_source
```

The audio stream source is set through the AUDIO_SELECT_SOURCE call and can take the following values, depending on whether we are replaying from an internal (demux) or external (user write) source.

```
typedef enum {
    AUDIO_SOURCE_DEMUX,
    AUDIO_SOURCE_MEMORY
} audio_stream_source_t;
```

AUDIO_SOURCE_DEMUX selects the demultiplexer (fed either by the frontend or the DVR device) as the source of the video stream. If AUDIO_SOURCE_MEMORY is selected the stream comes from the application through the `write()` system call.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master) [drivers] [staging] [media] [av7110]audio_data_types.rst, line 32)
```

Unknown directive type "c.type".

```
.. c:type:: audio_play_state
```

The following values can be returned by the AUDIO_GET_STATUS call representing the state of audio playback.

```
typedef enum {
    AUDIO_STOPPED,
    AUDIO_PLAYING,
    AUDIO_PAUSED
} audio_play_state_t;
```

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master) [drivers] [staging] [media] [av7110]audio_data_types.rst, line 47)
```

Unknown directive type "c.type".

```
.. c:type:: audio_channel_select
```

The audio channel selected via AUDIO_CHANNEL_SELECT is determined by the following values.

```
typedef enum {
    AUDIO_STEREO,
    AUDIO_MONO_LEFT,
    AUDIO_MONO_RIGHT,
    AUDIO_MONO,
    AUDIO_STEREO_SWAPPED
} audio_channel_select_t;
```

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master) [drivers] [staging] [media] [av7110]audio_data_types.rst, line 64)
```

Unknown directive type "c.type".

```
.. c:type:: audio_status
```

The AUDIO_GET_STATUS call returns the following structure informing about various states of the playback operation.

```
typedef struct audio_status {
    boolean AV_sync_state;
    boolean mute_state;
    audio_play_state_t play_state;
    audio_stream_source_t stream_source;
    audio_channel_select_t channel_select;
    boolean bypass_mode;
    audio_mixer_t mixer_state;
} audio_status_t;
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media][av7110]audio_data_types.rst, line 83)

Unknown directive type "c.type".

```
.. c:type:: audio_mixer
```

The following structure is used by the AUDIO_SET_MIXER call to set the audio volume.

```
typedef struct audio_mixer {
    unsigned int volume_left;
    unsigned int volume_right;
} audio_mixer_t;
```

audio encodings

A call to AUDIO_GET_CAPABILITIES returns an unsigned integer with the following bits set according to the hardware capabilities.

```
#define AUDIO_CAP_DTS      1
#define AUDIO_CAP_LPCM     2
#define AUDIO_CAP_MP1      4
#define AUDIO_CAP_MP2      8
#define AUDIO_CAP_MP3     16
#define AUDIO_CAP_AAC     32
#define AUDIO_CAP_OGG     64
#define AUDIO_CAP_SDDS    128
#define AUDIO_CAP_AC3     256
```