

Digital TV demux read()

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master\Documentation\userspace-api\media\dvb\dmx-fread.rst, line 2)

Unknown directive type "c:namespace".

```
.. c:namespace:: DTV.dmx
```

Name

Digital TV demux read()

Synopsis

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master\Documentation\userspace-api\media\dvb\dmx-fread.rst, line 18)

Unknown directive type "c:function".

```
.. c:function:: size_t read(int fd, void *buf, size_t count)
```

Arguments

fd

File descriptor returned by a previous call to `:c:func:'open()'`.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master\Documentation\userspace-api\media\dvb\dmx-fread.rst, line 24); [backlink](#)

Unknown interpreted text role "c:func".

buf

Buffer to be filled

count

Max number of bytes to read

Description

This system call returns filtered data, which might be section or Packetized Elementary Stream (PES) data. The filtered data is transferred from the driver's internal circular buffer to `buf`. The maximum amount of data to be transferred is implied by `count`.

Note

if a section filter created with `:c:type:'DMX_CHECK_CRC <dmx_sct_filter_params>'` flag set, data that fails on CRC check will be silently ignored.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master\Documentation\userspace-api\media\dvb\dmx-fread.rst, line 42); [backlink](#)

Unknown interpreted text role "c:type".

Return Value

On success 0 is returned.

On error -1 is returned, and the `errno` variable is set appropriately.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master [Documentation] [userspace-api] [media] [dvb]dmx-fread.rst, line 54)

Unknown directive type "tabularcolumns".

```
.. tabularcolumns:: |p{2.5cm}|p{15.0cm}|
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master [Documentation] [userspace-api] [media] [dvb]dmx-fread.rst, line 56)

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows: 0
   :stub-columns: 0
   :widths: 1 16

   - - ``EWOULDBLOCK``
     - No data to return and ``O_NONBLOCK`` was specified.

   - - ``EOVERFLOW``
     - The filtered data was not read from the buffer in due time,
       resulting in non-read data being lost. The buffer is flushed.

   - - ``ETIMEDOUT``
     - The section was not loaded within the stated timeout period.
       See ioctl :ref:`DMX_SET_FILTER` for how to set a timeout.

   - - ``EFAULT``
     - The driver failed to write to the callers buffer due to an
       invalid \*buf pointer.
```

The generic error codes are described at the [ref: Generic Error Codes <gen-errors>](#) chapter.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\linux-master [Documentation] [userspace-api] [media] [dvb]dmx-fread.rst, line 76); [backlink](#)

Unknown interpreted text role "ref".