




Congrats on getting your new X-Series Interbotix Turret on a Raspberry Pi!

## In Your Package...

- 1 x X-Series Interbotix Turret Kit (including onboard U2D2 and X-Series power hub)
- 1 x Raspberry Pi 4B (4GB RAM) Kit
- 1 x Original Sony PS4 Controller



There is not much required to get the Turret up and running as most of the setup is done for you. Just make sure to do the following steps:

- Remove the Turret from its packaging and place on a sturdy tabletop surface near an electrical outlet. To prevent the robot from potentially toppling during operation, secure it to a flat surface (via clamping or using the holes on the base's perimeter). At your own risk, you could instead place a small heavy bean-bag on top of the acrylic plate by the base of the robot. Finally, make sure that there are no obstacles within the turret's workspace.
- Plug the 12V Turret Power Supply cable into an outlet and insert the barrel plug into the barrel jack on the X-Series motor power hub (located under the see-through acrylic on the base of the robot). You should briefly see the LEDs on the motors flash red.
- Plug the microUSB cable into the U2D2 (also located under the see-through acrylic on the robot's base), and into a USB port on the RPi.

- If you purchased the Pi Kit with a turret, then there is no need to connect a keyboard, mouse, or monitor to the Pi as it should already be preconfigured to work with your turret and paired with the PS4 controller (unless you want to use the GUI). Just plug the 5V Raspberry Pi Power Supply cable into an outlet and insert the other side into the Type-C USB port. Then flick the switch on. Next, jump to the **Connecting to the Turret** section.
- If you purchased the Pi Kit without a turret, but would like to use it with a turret, make sure to connect a keyboard, mouse, and HDMI monitor to it. Then, plug the 5V Raspberry Pi Power Supply cable into an outlet and insert the other side into the Type-C USB port. Finally, flick the switch on the power cable and continue with the next section.

## PS4 Controller Setup

Getting a PS4 controller connected via Bluetooth to the Raspberry Pi is pretty straightforward. Once the Pi boots, click the *Bluetooth* icon on the top right of your Desktop, followed by *Setup New Device....* A window should pop up welcoming you to the 'Bluetooth device setup assistant.' Click the *Next* button. Then, press and hold the *Share* button on the PS4 controller. While holding the *Share* button, press and hold the *PS* button. After a few seconds, the triangular shaped LED located between the *L2* and *R2* buttons should start rapidly flashing white (about twice a second) at which point you can let go.

On the computer, click the 'magnifying glass' icon on the lower left of the 'Device' window. Wait until you see 'Wireless Controller' pop up, select it, and click *Next* on the bottom right of the window. A message should pop up asking if you would like to *Pair Device* or *Proceed Without Pairing*. Select *Pair Device* and click *Next* on the bottom right of the screen.

A new message should now display asking you to either connect to *Human Interface Device Service (HID)* or *Don't Connect*. Select the *Human Interface Device Service (HID)* option and click *Next*. In the following screen, you should see a message either saying that the *Device added successfully, but failed to connect* or that the *Device added and connected successfully*. This is typical and you should just click *Close* on the bottom right of the screen.

If the message said that the device connected successfully, you will need to disconnect and reconnect the controller for the next step. To do that, hold down the *PS* button for about 10 seconds until the blue LED at the front of the controller turns off. Then, tap the *PS* button on the controller (no need to hold it down), and after waiting a few seconds, you should see the LED at the front turn blue. At this point, you should see a small popup on the top right of the screen titled 'Bluetooth Authentication'. Make sure to click the *Always Accept* option. This means that the computer will always pair with your PS4 controller when you tap the *PS* button.

## Install Turret ROS Packages

To install the ROS packages, open a terminal (**Ctrl-Alt-T**), and type the following four commands in sequence (first make sure to connect to the Internet).

1. `sudo apt install curl`
2. `curl 'https://raw.githubusercontent.com/Interbotix/interbotix_ros_turrets/main/interbotix_ros_xsturrets/install/rpi4/xsturret_rpi4_install.sh' > xsturret_rpi4_install.sh`
3. `chmod +x xsturret_rpi4_install.sh`
4. `./xsturret_rpi4_install.sh`

After you run the last command, you will be prompted with a question asking about your robot model. Type the abbreviation on the right-hand-side of the table below for your arm type.

Robot Type	Abbreviation
PhantomX XL430 Robot Turret	pxxls
WidowX XM430 Robot Turret	wxxms
WidowX Dual XM430 Robot Turret	wxxmd
ViperX XM540 Robot Turret	vxxms
ViperX Dual XM540 Robot Turret	vxxmd
PhantomX Vision Tracking Kit	pxxls_cam

You will also be asked if you would like the 'Joystick ROS package to run at system boot'. In explanation, this 'program' is what allows you to control the turret with the PS4 controller. By typing 'y' or 'yes', the Pi will automatically start this program when turned on. By typing anything else, the Pi will not start the program. Instead, you will have to manually run the program yourself every time. As a recommendation, if you want a Plug N' Play solution, then say 'yes'. If you want to do your own development on the Pi, then type 'no'.

If you typed 'yes' and would like to disable that feature later on, open a terminal on the Pi and type `sudo systemctl disable xsturret_rpi4_boot.service`. However, if you just want to shut down the 'program' temporarily, but have it start again at the next boot, just type `pkill ros` in the terminal. Note that this will cause the motors in the turret to torque off. So make sure the turret is in a 'resting' position before typing this command.

Once the installation procedure completes, restart the Pi. At this point, you can disconnect the mouse, monitor, and keyboard, and continue with the next section.

## Connecting to the Turret

There are three ways to operate the Turret. They are:

- Using a PS4 controller only

- Interfacing with the Graphical User Interface tool directly on the Raspberry Pi
- Interfacing with the Graphical User Interface tool remotely on a Network

### *PS4 Control*

This is the simplest way of controlling the Turret. After turning on the Pi, wait until you see the red LEDs on the U2D2 flash white. At this point, tap the PS button on the controller. Then wait until the white LED on the front of the controller turns to a solid blue (a few seconds). This means that the controller has successfully connected to the Pi over Bluetooth. Now, go and have fun! Make sure to take a look at the *Turret Control Tutorial* guide to get familiar with the button mappings.

### *Directly Interfacing with the GUI*

In this mode, you must connect your own keyboard, mouse, and monitor to the Pi (which you should do before turning the Pi on). When the monitor turns on, you should see a graphical user interface that can be used to control the Turret. Please take a look at the *Turret Control Tutorial* guide to get familiar with it. If you would like to control the Turret with the PS4 controller in addition to the GUI, just follow the directions specified in the 'PS4 Control' section above. As an FYI, if you ever close the GUI, you can always reopen it by pressing the 'Interbotix Turret' shortcut on the Desktop.

### *Remotely Interfacing with the GUI*

In this mode, you will place the Raspberry Pi on your network and remote into it from whatever computer you want. The benefit of this approach is that you do not have to be physically near the Turret to control it. However, this will require some setup. Specifically, you will need to:

- Connect your Raspberry Pi to a network (via Wifi or Ethernet)
- Install software on your personal computer and on the Pi to allow remote control
- Remote into the Pi from your computer over the network

### **Step 1**

To get started, hook up a mouse, monitor, and keyboard to your Raspberry Pi, and turn it on. If you plan on using an Ethernet cable to connect the Pi to your network, plug it in now, and skip to **Step 2**. Otherwise, mouse over to the top-right of your screen and hit the 'Wifi' icon. Scroll down to where it says 'Disconnect' (should be under 'pibot') and press it. After a couple seconds, you should be able to see other available networks. Click your desired network and type in the password (assuming there is one).

Next, click the 'Wifi' icon again, and scroll down to where it says 'Edit Connections...'. Click it, then double click the 'pibot' name in the window that pops up. Navigate to the 'General' tab and uncheck 'Automatically connect to this network when it is available.' Then, click 'Save'. Now,

double click your network name and navigate to its 'General' tab. Make sure that the two checkboxes below are checked, then click 'Save'.

- Automatically connect to this network when it is available
- All users may connect to this network

## Step 2

In this step, you should install software on the Raspberry Pi and your own computer to allow remote control. While it is completely up to you what to install, we recommend installing TeamViewer. Look at the tutorial at <https://pimylifeup.com/raspberry-pi-teamviewer/> to learn how to install it on the Pi and your computer.

## Step 3

In this step, you should remote into the Raspberry Pi from your own computer. Regardless of which software you installed, make sure to write down any information you might need before removing your keyboard, mouse, and monitor from the Pi. For example, if using TeamViewer, you should write down the Pi's TeamViewer ID and Password somewhere safe. Now, when you remotely access the Pi, you should see the Turret Control GUI! Make sure to look at the *Turret Control Tutorial* guide to get familiar with it. If you would like to control the Turret with the PS4 controller in addition to the GUI, just follow the directions specified in the 'PS4 Control' section above. As an FYI, if you ever close the GUI, you can always reopen it by pressing the 'Interbotix Turret' shortcut on the Desktop.

## Troubleshooting

*If your PS4 controller isn't working...*

- Verify that the controller is paired with the Pi by confirming that the LED on the front of the controller is blue. If it's flashing white or not on, try repeating the **PS4 Controller Setup**. If the LED is a different color like red, green, or pink, that means your controller is paired with the Pi but connected to the wrong port. Most likely, this is because another controller is already paired with the Pi.
- Make sure that your controller is charged
- Make sure that the **External Joystick Checkbox** in the turret control GUI is checked

*If the turret control GUI is not responding or seems to be frozen...*

- Turn off the Pi, wait a few seconds, and turn it back on.

*If the turret control GUI doesn't pop up...*

- Make sure that you have entered the right robot abbreviation in the **Install Turret ROS Packages** section, then restart the Pi

*If the GUI is responding but the Turret is not moving...*

- This can happen if you unplugged a USB or power cable from the turret during operation. Just plug it back in and restart the Pi

*Your monitor is not displaying anything...*

- By default, if the Pi does not detect a monitor plugged in at boot, it will not display anything, even if the monitor is plugged in later. To use the monitor, make sure it's plugged in to the Pi before turning the Pi on.

## **Other Info**

If you purchased a Pi Kit from us and would like to work with it in a headless state, create a hotspot on your personal computer called 'master-hotspot' without requiring a password. The Pi is configured to automatically connect to this network when it's available.

To review the software and/or look at other questions customers have asked, please take a look at our GitHub page: [https://github.com/Interbotix/interbotix\\_ros\\_turrets](https://github.com/Interbotix/interbotix_ros_turrets). If you need assistance, feel free to contact us at [trsupport@trossenrobotics.com](mailto:trsupport@trossenrobotics.com). For other robotic kits, check out our website at <https://www.trossenrobotics.com>.

That's all! Have fun and good luck!

- From the InterbotiX Team