

# M88WI6800-K SDK

## User Manual


Reversion	Description	Status	Date
0.1	Initial version		20160321
0.2	Add firmware upgrade utility and SDK API		20160523
0.3	Update firmware utility and wireless API		20161212
0.4	Update timer and wireless API		20170926
<p><b><i>This document contains confidential and proprietary information that belongs to Montage. Using any of the information contained herein or imaging all or part of this document by any means is strictly forbidden without express written consent of Montage</i></b></p>			

# 1. M88WI6800 Introduction

The purpose of this document is to describe the usage of SDK and demonstrate how to build your code in M88WI6800 SDK.

## 1.1 Overview


M88WI6800 is a System-on-Chip with Wi-Fi micro processor with ADC/PWM/GPIOs/UART interfaces. The chip is designed to operate in 2.4 GHz frequency and full complies with IEEE 802.11b/g/n standard based on 1T1R technology. It integrates a 32-bits high performance 32 bits micro-processor with over 200 MIPS and 320KB embedded RAM on which all application programs executed. It also integrated with a 32 KHz low-speed clock and power manage unit to operate on low power state. It is an ideal solution for network enabled applications, such as internet of things. A block diagram illustrating the components of M88WI6800 is shown in Figure1.



## 1.2 Architecture

To simplify configuring connectivity of M88WI6800 chip, the SDK provides WLAN static library of station mode or access point mode. Real-time OS and TCPIP(LwIP) are also included in SDK library to easily achieve multi-tasking and networking application. To control the sensor or device M88WI6800 is incorporated into, PWM, GPIO, ADC

and UART APIs are provided to easily use. M88WI6800 SDK software architecture is shown as follows.



## 1.3 Memory Map

Memory teyp	End address	Start address	Size
ROM Library	0x0007_FFFF	0x0006_8000	96KB
Reserved	0x0006_7FFF	0x0006_0000	32KB
DMA SRAM	0x0005_FFFF	0x0005_0000	64KB
SRAM	0x0004_FFFF	0x0000_0000	320KB

- Program can not run directly from serial flash.
- All program runs from SRAM or ROM.
- DMA SRAM is reserved for Hardware.


## 1.4 Serial Flash Layout

Offset	Section	Size	Description
0x0	Bootloader	64 KBytes	Do RF calibration and load Primary firmware
0x10000	Config	64 KBytes	Store configuration
0x20000	User Firmware	320 KBytes	Primary firmware location
0x70000	OTA Firmware	320 KBytes	OTA firmware location
0xC0000	TBD	128 KBytes	User define
0xE0000	MP Firmware	128 KBytes	MP test firmware location

- Recommended size 1MB or more.
- Support maximum size to 16MB.


## 1.5 Firmware boot up sequence

M88WI6800 powers on and load bootloader image from serial flash to embedded RAM and execute. “bootloader” image checks integrity of user firmware on flash. If firmware is not exist or broken, it enters firmware upgrading state and wait for upgrade command from UART. Once firmware on flash passed verification of bootloader, bootloader loads firmware to embedded RAM and execute.



## 1.6 User Firmware flowchart

**app\_main()** is called once application start-up. Users can place structure or global parameter initialization here. It's recommended that users' software initialization is done before entering while loop in **user\_thread()**. **sys\_msleep()** is invoked to make user thread to sleep for some milliseconds. The all functions in while loop will be executed again once user thread is wake up. It is not recommend add any customized code into app\_main function. User\_thread is entry of the user task. We expect user code should be located on this function.



**Key features of M88WI6800 SDK:**

- BA22 Toolchain
- Static libraries for APIs
- Firmware upgrade tool
- Sample source codes
- Wi-Fi station or access point(AP) working mode
- Support open, share, WPA-PSK, WPA2-PSK, WAPI authentications
- Support WEP64/128, TKIP, CCMP, SMS4
- AP mode supports up to 8 stations
- Support concurrent station/AP mode on one device
- Support PS-nopoll, PS-Poll, and UAPSD power saving mechanisms
- Hidden SSID
- Embedded TCP/IP protocol stack supports IPv4, UDP, TCP, ICMP, ARP
- Support DHCP client and server
- Support DNS client
- Support HTTP server
- Access profile from flash
- Multiple task management
- Hardware PWM APIs
- GPIO APIs
- Software I2C master function
- Chip Power management
- Sample codes

## **2. Development Environment**

The section provides a guide to generate firmware image from SDK.

### **2.1 Preparing the build environment**

#### **2.1.1 Installing M88WI6800 SDK for Linux**

M88WI6800 SDK for Linux requires Ubuntu Linux. Any version can be used, however the 14.04 LTS 32-bit is recommended. If your Linux kernel is 64-bit, you need to install ia32-libs to support SDK toolchain.

```
“sudo apt-get install build-essential ia32-libs”
```

Step to install development environment:

1. Extract M88WI6800 SDK for Linux to your desired directory.  
“tar xzfv WI6800\_sdk.tgz”
2. Locate the tool chain file ba-elf\_4.7.3.tgz, and extract its content to SDK\_path/toolchain folder.  
“tar xzfv ba-elf\_4.7.3.tgz”

#### **2.1.2 Directory Structure**



```
├── doc
├── images
├── include
│   ├── arch
│   ├── freertos
│   └── mico
├── lib
│   ├── atcmd
│   ├── freertos
│   └── lwip
├── proj
│   └── iot_demo
├── toolchain
└── utility
```

- “doc” directory : the SDK related documents
- “images” directory : boot\_loader, firmware binaries
- “include” directory : SDK header files
- “lib” directory : the library files for SDK
- “proj” directory : the example codes. User can create new project name under this folder. “iot\_demo” is default example code of SDK.
- “toolchain” directory : BA2 tool chain should be extracted and placed at here.
- “utility” directory : checksum utility.

## 2.2 Building project

The default example is iot\_demo project which under “proj” folder. Enter the root directory of SDK.

“make clean-iot\_demo” → clean object code of proj/iot\_demo

“make iot\_demo” → build iot\_demo.img

After building, output files will be generated on images directory.

If you create new project folder under “proj”, for example, naming “user\_test”. Just type “make user\_test” to build “user\_test.img” firmware image.

## 2.3 Burning image into flash

### 2.3.1 Set up the environment in Windows

#### 1. Unzip package files


unzip firmware\_utility\_tan\_windows.zip ForWindows.zip

#### 2. Run the application


serial\_tan.exe

### 2.3.2 Operations

After generating the bootcode or firmware image, users can choose the images for burning them into the flash. Please follow the following steps.



1. Select the correct serial port.
2. Choose boot.img if need.
3. Choose Firmware iot\_demo.img
4. Press GO button
5. Flash download success will show as below



### 3. Programming Guide

#### 3.1 Firmware bootup sequence

The firmware of M88WI6800 should locate on serial flash. After chip power on, M88WI6800 will load bootloader and firmware from serial flash to execute. The detail sequence is shown in as follows:

1. M88WI6800 powers on and load bootloader image from serial flash to embedded RAM and execute.
2. “bootloader” image checks integrity of user firmware on flash. If firmware is not exist or broken, it enters firmware upgrading state and wait for upgrade command from UART.
3. Once firmware on flash passed verification of bootloader, bootloader loads firmware to embedded RAM and execute.
4. User firmware should execute first function, app\_main which located on app\_init.c file. The app\_main calls hw\_sys\_init function to initialize wlan hardware of M88WI6800 and spawns an user task finally. To make sure system bring up

smoothly, it is not recommend add any customized code into app\_main function.

5. User\_thread is entry of the user task. We expect user code should be located on this function.

## 3.2 Debug

M88WI6800 provides two hardware UARTs and system uses UART1 to output debug messages by default. User can utilize serial\_printf() to debug program. Default baudrate is 115200 bps.

## 3.3 Sample code

### User\_thread

void user\_thread(void \*arg) is the default method which provides users to add functions like network initialization, Wi-Fi parameters setting, and other initializations in the interface.

#### 3.3.1 Connecting M88WI6800 to a station

Example usage:

```
// Users can load, modify, and write back Wi-Fi configurations before invoking
// wlan_start() to start Wi-Fi. Users can invoke Wi-Fi related APIs to make
// Wi-Fi interfaces to receive and transmit data. Without user configurations,
// M88WI6800 uses default configurations if Wi-Fi is brought up.

// Setup STA configurations
memset(&wNetConfig, 0x0, sizeof(wNetConfig));
// Wlan ssid string
memcpy(wNetConfig.wifi_ssid, "Demo_AP", sizeof(wNetConfig.wifi_ssid));
// WEP key length:          ASCII=5(64 bits) or 13(128 bits)
//                          HEX=10(64 bits) or 26(128 bits)
// WPA/WPA2 key length:    ASCII=8-63, HEX=64

// Wlan key string or hex data
strcpy((char *)wNetConfig.wifi_key, "12345678");
// Station mode
wNetConfig.wifi_mode = STATION;
// Fetch Ip address from DHCP server
wNetConfig.dhcp_mode = DHCP_CLIENT;

strcpy((char *)wNetConfig.local_ip_addr, "192.168.0.105");
strcpy((char *)wNetConfig.net_mask, "255.255.255.0");
strcpy((char *)wNetConfig.gateway_ip_addr, "192.168.0.1");
strcpy((char *)wNetConfig.dnssvr_ip_addr, "8.8.8.8");
// Retry interval after a failure connection
wNetConfig.wifi_retry_interval = 100;
wlan_set_reconnect(1);
wlan_set_myaddr(STATION, my_bssid);
```

```
// Connect Now!
wlan_start(&wNetConfig);
```

### 3.3.2 Configuring M88WI6800 as an AP

Example usage:

```
// Users can load, modify, and write back Wi-Fi configurations before invoking
// wla_set_opmode() to start Wi-Fi. Users can invoke Wi-Fi related APIs to make
// Wi-Fi interfaces to receive and transmit data. Without user configurations,
// M88WI6800 uses default configurations if Wi-Fi is brought up.
```

```
#if 0
{
    // Setup channel number.
    wlan_set_channel(11);
    // Setup AP configurations
    memset(&wNetConfig, 0x0, sizeof(wNetConfig));
    // Wlan ssid string
    memcpy(wNetConfig.wifi_ssid, "Demo_AP1", sizeof(wNetConfig.wifi_ssid));
    // WEP key length:          ASCII=5(64 bits) or 13(128 bits)
    //                          HEX=10(64 bits) or 26(128 bits)
    // WPA/WPA2 key length:     ASCII=8-63, HEX=64

    // Wlan key string or hex data
    strcpy((char *)wNetConfig.wifi_key, "12345678");
    // AP mode
    wNetConfig.wifi_mode = SOFT_AP;
    // Start DHCP server
    wNetConfig.dhcp_mode = DHCP_SERVER;

    strcpy((char *)wNetConfig.local_ip_addr, "192.168.169.1");
    strcpy((char *)wNetConfig.net_mask, "255.255.255.0");
    strcpy((char *)wNetConfig.gateway_ip_addr, "192.168.169.1");
    strcpy((char *)wNetConfig.dnssvr_ip_addr, "8.8.8.8");
    // Retry interval after a failure connection
    wNetConfig.wifi_retry_interval = 100;
    wlan_set_myaddr(SOFT_AP, my_bssid);
    // Connect Now!
    wlan_start(&wNetConfig);
}
#endif
```

### 3.3.3 Create a new thread

```
// Create a new thread.
void demo_thread(void *param)
{
    :
}

void user_thread(void *arg)
{
    :
    // "demo"          ->name of thread.
    // demo_thread     ->Pointer to function to run.
    // NULL            ->Argument passed into function.
    // 2048            ->Required stack amount in bytes.
    // 5               ->Thread priority.
    sys_thread_new("demo", demo_thread, NULL, 2048, 5);
    :
}
```

## 4. SDK API

---

### Detailed Description

Timer API functions

**void\* add\_timeout (void\*)(void \*) *timer\_func*, void \* *func\_parm*, unsigned int *msec*)**

The function register a callback function on software timer list. Once the specific time is up, the callback function will be invoked.

#### Parameters:

<i>timer_func</i>	Pointer to callback function.
<i>func_parm</i>	Parameter of callback function.
<i>msec</i>	Milliseconds to count down.

#### Returns:

None.

**int arc4random (void )**

Random seed generator.

#### Parameters:

<i>None.</i>	
--------------	--

#### Returns:

A random seed.

**void del\_timeout (void\*)(void \*) *timer\_func*, void \* *func\_parm*)**

The function is used to delete a previously timer, registered on software timer. Note that the *timer\_func* and *func\_parm* must have same value with **add\_timeout()**.

#### Parameters:

<i>timer_func</i>	Pointer to callback function.
<i>func_parm</i>	Parameter of callback function.

#### Returns:

None.

**void get\_random\_bytes (void \* *buf*, unsigned int *len*)**

Generate random byte in specific array.

#### Parameters:

<i>buf</i>	Pointer to input array.
------------	-------------------------

<i>len</i>	Array size.
------------	-------------

**Returns:**

None.

**void hw\_timer\_start (unsigned int *us*, void(\*)*(void)* *func*, int *autoload*)**

Start hardware timer1 to countdown. When time is up, callback function is invoked and the timer is reloaded according autoload flag.

**Parameters:**

<i>us</i>	Microsecond to timeout.
<i>func</i>	Pointer to callback function.
<i>autoload</i>	Autoload flag.

**Returns:**

None.

**void hw\_timer\_stop (void )**

Stop hardware timer

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

None.

**int micros (void )**

Get system time in microsecond.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

Microsecond.

**int millis (void )**

Get system time in millisecond.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

Millisecond.

**void udelay (unsigned int *us*)**

Delay specific microseconds.

**Parameters:**

<i>us</i>	Microseconds to wait.
-----------	-----------------------

**Returns:**

None.

**void sys\_deep\_sleep (unsigned int *msec*)**

Deep sleep specific milliseconds.

**Parameters:**

<i>msec</i>	0: infinite time until GPIO 16/18 be triggered.(ROM v3 support only) others value: Millisecond to sleep. Trigger GPIO 16/18 can wake system up during sleep.
-------------	---

**Returns:**

None.

---

**Detailed Description**

Memory allocation API functions

**void free (void \* *mem*)**

The free function causes the space pointed to by *mem* to be deallocated, that is, made available for further allocation.

**Parameters:**

<i>mem</i>	Pointer to a previously allocated region of memory to be freed.
------------	---

**Returns:**

None.

**void\* malloc (size\_t *size*)**

The malloc function allocates space for an object whose size is specified by *size* and whose value is indeterminate.

**Parameters:**

<i>size</i>	Size, in bytes, of the region to allocate.
-------------	--

**Returns:**

NULL is returned if the space could not be allocated. Otherwise, a pointer to a region of the requested size is returned.



---

## Detailed Description

wireless API functions

### **int wlan\_add\_notification (notify\_types *type*, void \**functionAddress*)**

The function register notification and it's callback function.

#### **Parameters:**

<i>type</i>	system defined notifications.
<i>functionAddress</i>	callback function.

#### **Returns:**

NO\_ERR.

### **int wlan\_del\_notification (notify\_types *type*)**

The function unregister notification and it's callback function.

#### **Parameters:**

<i>type</i>	system defined notifications.
-------------	-------------------------------

#### **Returns:**

NO\_ERR.

### **int wlan\_del\_notification\_all (notify\_types *type*)**

The function unregister all notification and callback functions.

#### **Parameters:**

<i>type</i>	system defined notifications.
-------------	-------------------------------

#### **Returns:**

NO\_ERR.

### **int wlan\_disable\_powersave (void )**

Disable IEEE power save mode.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

NO\_ERR: succeed

WLAN\_ERR\_GENERAL: failed

### **void wlan\_drv\_init (void )**

The function initials Wi-Fi driver with LWIP.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

None.

### **int wlan\_enable\_powersave (void )**

Enable IEEE power save mode.

When this function is enabled, Wlan enter IEEE power save mode if Wlan is in station mode and has connected to an AP, and do not need any other control from application. To save more power, use mcu\_powersave\_config.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

NO\_ERR: succeed

WLAN\_ERR\_GENERAL: failed

### **int wlan\_get\_hidden\_ssid (void )**

Get Wi-Fi network hidden ssid status (ap mode only).

#### **Parameters:**

<i>type</i>	Specifies wlan interface.
-------------	---------------------------

#### **Returns:**

hidden ssid status.

### **int wlan\_get\_ht40 (void )**

The function gets HT 40MHz mode status.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

1: enabled

0: disabled

### **int wlan\_get\_ifs\_sm (wlan\_if\_types type)**

The function gets Wi-Fi connection status.

**Parameters:**

<i>type</i>	Specifies wlan interface.
-------------	---------------------------

**Returns:**

- 1: failed
- 1 0: STATE\_IDLE
- 2 1: STATE\_SCAN
- 3 2: STATE\_SCAN\_DONE
- 4 3: STATE\_LINK\_UP
- 5 4: STATE\_LINK\_DOWN

**int wlan\_get\_link\_sts (link\_sts \* sts, wlan\_if\_types type)**

Read current wireless link status.

**Parameters:**

<i>sts</i>	Point to the buffer to store the link status.
------------	---

**Returns:**

NO\_ERR.

**char\* wlan\_get\_myaddr (wlan\_if\_types type)**

Get Wi-Fi network MAC address.

**Parameters:**

<i>type</i>	Specifies wlan interface.
-------------	---------------------------

**Returns:**

Interface MAC address.

**int wlan\_get\_reconnect (void )**

The function gets reconnect policy in STA mode.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

- 1: enabled
- 0: disabled

**int wlan\_get\_resend\_params (resend\_cfg \* cfg)**

The function gets resend parameters.

**Parameters:**

<i>cfg</i>	Point to the buffer to store the resend cfg.
------------	--

**Returns:**

NO\_ERR: succeed

**int wlan\_get\_scan\_channel (void )**

The function gets scan channel.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

0-13

**int wlan\_get\_sta\_info (int(\*) (const char \*) *get\_mac\_callback*)**

The function gets Wi-Fi station information (ap mode only).

**Parameters:**

<i>get_mac_callback</i>	The callback function.
-------------------------	------------------------

**Returns:**

0: succeed

-1: failed

**int wlan\_get\_sta\_num (wlan\_if\_types *type*)**

The function gets Wi-Fi station number.

**Parameters:**

<i>type</i>	Specifies wlan interface.
-------------	---------------------------

**Returns:**

-1: failed

otherwise: station number

**void wlan\_init (void )**

The function initialize Wi-Fi basic settings.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

None.

**int wlan\_init\_notification (void )**

The function initializes notification center.

**Parameters:**

None.	
-------	--

**Returns:**

NO\_ERR.

**void wlan\_led\_install (void )**

The function starts to service Wi-Fi LED callback function.

**Parameters:**

None.	
-------	--

**Returns:**

None.

**void wlan\_led\_uninstall (void )**

The function stop to service Wi-Fi LED callback function.

**Parameters:**

None.	
-------	--

**Returns:**

None.

**int wlan\_monitor\_rx\_type (filter\_rx\_types type)**

Set which wifi packet will be captured. RX all wifi packet if didn't call this function. This function can be called more than once to set RX different type packet.

**Parameters:**

type	Capture packet type.
------	----------------------

**Returns:**

NO\_ERR.

**int wlan\_power\_off (void )**

Close the RF chip's power supply, all network connection is lost.

**Parameters:**

None.	
-------	--

**Returns:**

NO\_ERR: succeed

WLAN\_ERR\_GENERAL: failed

**int wlan\_power\_on (void )**

Open the RF's power supply and do some necessary initialization.

**Note:**

The default RF state is powered on after **wlan\_init**, so this function is not needed after wlan\_init.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

NO\_ERR: succeed

WLAN\_ERR\_GENERAL: failed

**void wlan\_register\_monitor\_cb (monitor\_cb\_t *fn*)**

Set the callback function to RX the captured wifi packet.

**Parameters:**

<i>fn</i>	Callback function.
-----------	--------------------

**Returns:**

None.

**void wlan\_scan\_result\_to\_buffer (void )**

The function dumps information of all APs into apps buffer without output to serial port.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

None.

**int wlan\_set\_ch\_bandwidth (int *channel*, int *ht40*)**

Set the monitor channel and bandwidth. Valid channel is 1~13. Set ht40 as 0 for 20M-Hz ,ht40 as 1 for 40M-Hz. In soft-AP + station mode, soft-AP will adjust its channel configuration to be as same as station and the API will return NO\_ERR.

**Parameters:**

<i>channel</i>	Monitor channel.
<i>ht40</i>	Bandwidth is 40M-Hz.

**Returns:**

NO\_ERR.

**int wlan\_set\_channel (int *channel*)**

Set the monitor channel. Valid channel is 1~13. In soft-AP + station mode, soft-AP will adjust its channel configuration to be as same as station and the API will return NO\_ERR.

**Parameters:**

<i>channel</i>	Monitor channel.
----------------	------------------

**Returns:**

NO\_ERR.

**void wlan\_set\_hidden\_ssid (int *en*)**

Set Wi-Fi network hidden ssid status (ap mode only).

**Parameters:**

<i>en</i>	Hidden ssid or not.
-----------	---------------------

**Returns:**

None.

**void wlan\_set\_ht40 (int *en*)**

The function sets HT 40MHz mode.

**Parameters:**

<i>en</i>	1: enable 0: disable
-----------	-------------------------

**Returns:**

None.

**void wlan\_set\_myaddr (wlan\_if\_types *type*, char \* *myaddr*)**

Set Wi-Fi network MAC address.

**Parameters:**

<i>type</i>	Specifies wlan interface.
<i>myaddr</i>	Interface MAC address.

**Returns:**

None.

**int wlan\_set\_phy (int *phy*)**

The function sets Wi-Fi physical mode. It checks range from 0 to 7 (bit[2:0]=ngb) and restarts Wi-Fi if it is running.

**Parameters:**

<i>phy</i>	The physical mode.
------------	--------------------

**Returns:**

0: succeed  
-1: failed  
-2: busy

**void wlan\_set\_reconnect (int *en*)**

The function sets reconnect policy in STA mode. If the policy is enabled, the STA will reconnect to AP once it's disconnected.

**Parameters:**

<i>en</i>	1: enable 0: disable
-----------	-------------------------

**Returns:**

None.

**void wlan\_set\_resend\_params (unsigned int *resend\_mode*,  
unsigned int *resend\_max\_cnt*, unsigned int *resend\_min\_rssi*)**

The function sets resend mode, maximum resend counter, and minimum resend RSSI.

**Parameters:**

<i>resend_mode</i>	0: disable 1: always 2:by RSSI
<i>resend_max_cnt</i>	0-15
<i>resend_min_rssi</i>	0-75

**Returns:**

None.

**int wlan\_set\_scan\_channel (int *channel*)**

The function sets scan channel, scan channel 1-13 if argument is zero.

**Parameters:**

<i>channel</i>	1-13: scan specific channel 0: scan channel 1-13
----------------	---



**Returns:**

NO\_ERR: succeed

WLAN\_ERR\_GENERAL: failed

**int wlan\_set\_txpwr (int *level*)**

The function sets TX power level. It checks range from 0 to 12 and restarts Wi-Fi if it is running.

**Parameters:**

<i>level</i>	The TX power level.
--------------	---------------------

**Returns:**

0: succeed

-1: failed

**int wlan\_start (network\_info \* *net*)**

Connect or establish a Wi-Fi network in normal mode (station or soft ap mode).

This function can establish a Wi-Fi connection as a station or create a soft AP that other stations can connect (4 stations Max). In station mode, Wlan first scan all of the supported Wi-Fi channels to find a wlan that matches the input SSID, and read the security mode. Then try to connect to the target wlan. If any error occurs in the connection procedure or disconnected after a successful connection, Wlan start the reconnection procedure in background after a time interval defined in inNetworkInitPara. Call this function twice when setup coexistence mode (station + soft ap). This function returns immediately in station mode, and the connection will be executed in background.

**Parameters:**

<i>net</i>	Specifies wlan parameters.
------------	----------------------------

**Returns:**

In station mode, always return WLAN\_NO\_ERR. In soft ap mode, return WLANXXXERR

**int wlan\_start\_adv (network\_info\_adv \* *net*)**

Connect to a Wi-Fi network with advantage settings (station mode only).

This function can connect to an access point with precise settings, that greatly speed up the connection if the input settings are correct and fixed. If this fast connection is failed for some reason, Wlan

change back to normal: scan + connect mode refer to **wlan\_start**. This function returns after the fast connection try.

**Note:**

This function cannot establish a soft ap, use **wlan\_start()** for this purpose. If input SSID length is 0, Wlan use BSSID to connect the target wlan. If both SSID and BSSID are all wrong, the connection will be failed.

**Parameters:**

<i>net</i>	Specifies the precise wlan parameters.
------------	--

**Returns:**

Always return WLAN\_NO\_ERR although error occurs in first fast try. Return WLAN\_ERR\_TIMEOUT if DHCP client timeout.

**int wlan\_start\_monitor (void )**

Start wifi monitor.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

NO\_ERR.

**void wlan\_start\_scan (void )**

Start a wlan scanning in 2.4GHz in background.

Once the scan is completed, Wlan sends a notify: NOTIFY\_WIFI\_SCAN\_COMPLETED, with callback function: void (\*function)(scan\_result \*pApList, Context\_t \* const inContext). Register callback function using add\_notification() before scan.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

None.

**int wlan\_stop\_monitor (void )**

Stop wifi monitor.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

NO\_ERR.

### **int wlan\_suspend (void )**

Close all the Wi-Fi connections, station mode and soft ap mode.

#### **Note:**

This function also stop the background retry mechanism started by **wlan\_start()** and **wlan\_start\_adv()**.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

NO\_ERR.

### **int wlan\_suspend\_station (void )**

Close the connection in station mode.

#### **Note:**

This function also stop the background retry mechanism started by **wlan\_start()** and **wlan\_start\_adv()**.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

NO\_ERR.

---

## **Detailed Description**

net API functions.

### **int net\_add\_notification (int *type*, void \* *functionAddress*)**

The function register notification and it's callback function.

#### **Parameters:**

<i>type</i>	system defined notifications.
<i>functionAddress</i>	callback function.

#### **Returns:**

NO\_ERR.

### **int net\_del\_notification (int *type*)**

The function unregister notification and it's callback function.

#### **Parameters:**

<i>type</i>	system defined notifications.
-------------	-------------------------------

#### **Returns:**

NO\_ERR.

### **int net\_del\_notification\_all (int *type*)**

The function unregister all notification and callback functions.

#### **Parameters:**

<i>type</i>	system defined notifications.
-------------	-------------------------------

#### **Returns:**

NO\_ERR.

### **void net\_drv\_init (void )**

The function initials LWIP device and all of netifs name.

#### **Parameters:**

<i>None.</i>	
--------------	--

#### **Returns:**

None.

### **int net\_get\_client\_info (const char \* *mac*)**

The function gets client information.

#### **Parameters:**

<i>mac</i>	The client's address.
------------	-----------------------

#### **Returns:**

err\_t error code

### **char\* net\_get\_dns (int *idx*, unsigned int \* *ipaddr*)**

The function gets DNS server's IP address.

#### **Parameters:**

<i>idx</i>	The DNS server index.
<i>ipaddr</i>	IP address.

#### **Returns:**

IP string of DNS server.

**int net\_get\_hostname (const char \* *name*, char \* *ipaddr*)**

The function queries host IP address by hostname. It also dumps host's IP address.

**Parameters:**

<i>name</i>	The hostname.
<i>ipaddr</i>	The host IP address.

**Returns:**

1: succeed  
0: failed

**char\* net\_get\_name (int *idx*)**

The function gets netif name.

**Parameters:**

<i>idx</i>	The netif index.
------------	------------------

**Returns:**

Name string of netif.

**void net\_if\_down (int *idx*)**

The function sets interface down.

**Parameters:**

<i>idx</i>	The netif index.
------------	------------------

**Returns:**

None.

**void net\_if\_ip\_sts (void \* *data*, int *type*)**

The function reads current IP status on a network interface.

**Parameters:**

<i>data</i>	Point to the buffer to store the IP address.
<i>type</i>	Specifies wlan interface.

**Returns:**

None.

**void net\_if\_up (int *idx*, unsigned char *dhcp*, char \* *mac*, unsigned char \* *\_ip*, unsigned char \* *\_mask*, unsigned char \* *\_gw*, unsigned char \* *\_dns*)**

The function sets interface up and network configurations.

**Parameters:**

<i>idx</i>	The netif index.
------------	------------------

<i>dhcp</i>	DHCP mode.
<i>mac</i>	MAC address.
<i>_ip</i>	IP address.
<i>_mask</i>	Net mask.
<i>_gw</i>	Gateway address.
<i>_dns</i>	DNS server address.

**Returns:**

None.

**int net\_init\_notification (void )**

The function initializes notification center.

**Parameters:**

<i>None.</i>	
--------------	--

**Returns:**

NO\_ERR.

**void net\_ping (unsigned int *dip*, unsigned int \* *size*, unsigned int \* *iter*, unsigned int \* *to*, unsigned int \* *interval*)**

The function ping destination address.

**Parameters:**

<i>dip</i>	Destination address.
<i>size</i>	Packet size.
<i>iter</i>	Iteration.
<i>to</i>	Timeout(seconds).
<i>interval</i>	Packet interval(milliseconds).

**Returns:**

None.

**void net\_set\_dns (int *idx*, unsigned int \* *ipaddr*)**

The function sets DNS server by server index.

**Parameters:**

<i>idx</i>	The DNS server index.
<i>ipaddr</i>	IP address.

**Returns:**

None.

---

## Detailed Description

GPIO API functions

### **void gpio\_enable (int *pin*, int *mode*)**

Enable GPIO function.

#### **Parameters:**

<i>pin</i>	GPIO number
<i>mode</i>	0: disable 1: enable

#### **Returns:**

None

### **void pin\_mode (int *pin*, int *mode*)**

Set GPIO pin mode, include gpio\_enable.

#### **Parameters:**

<i>pin</i>	GPIO number
<i>mode</i>	0: input 1: output

#### **Returns:**

None

### **int digital\_read (int *pin*)**

Read GPIO pin input data, call it after pin\_mode.

#### **Parameters:**

<i>pin</i>	GPIO number
------------	-------------

#### **Returns:**

0: low

1: high

### **void digital\_write (int *pin*, int *val*)**

Set GPIO pin output data, call it after pin\_mode.

#### **Parameters:**

<i>pin</i>	GPIO number
<i>val</i>	0: low

	1: high
--	---------

**Returns:**

None

**void digital\_write\_two (int *pin*, int *val*, int *pin2*, int *val2*)**

Set two GPIO pin output data at the same time, call it after pin\_mode.

**Parameters:**

<i>pin</i>	GPIO number
<i>val</i>	0: low 1: high
<i>pin2</i>	GPIO number
<i>val2</i>	0: low 1: high

**Returns:**

None

**void pin\_dis\_intr (int *pin*, int *mode*)**

Disable GPIO pin interrupt.

**Parameters:**

<i>pin</i>	GPIO number
<i>mode</i>	0: rising 1: falling 2: high level 3: low level

**Returns:**

None

**void pin\_en\_intr (int *pin*, int *mode*)**

Enable GPIO pin interrupt.

**Parameters:**

<i>pin</i>	GPIO number
<i>mode</i>	0: rising 1: falling 2: high level 3: low level

**Returns:**

None



---

## Detailed Description

I2C API functions. More details in appendix 5.4.

### **int i2c\_read\_byte (unsigned char *slave\_addr*)**

I2C master read data(1 byte).

#### **Parameters:**

<i>slave_addr</i>	I2C slave address
-------------------	-------------------

#### **Returns:**

data

### **void i2c\_read\_data (unsigned char *slave\_addr*, char \* *str*, int *len*)**

I2C master read data.

#### **Parameters:**

<i>slave_addr</i>	I2C slave address
<i>len</i>	data length, master must know the correct length of data

#### **Returns:**

None

### **int i2c\_send\_byte (unsigned char *slave\_addr*, unsigned char *byte*)**

I2C master send data(1 byte).

#### **Parameters:**

<i>slave_addr</i>	I2C slave address
<i>byte</i>	data

#### **Returns:**

0: ack

### **int i2c\_send\_data (unsigned char *slave\_addr*, char \* *data*, int *len*)**

I2C master send data.

#### **Parameters:**

<i>slave_addr</i>	I2C slave address
<i>*data</i>	data pointer
<i>len</i>	data length

#### **Returns:**

0: ack

**int i2c\_send\_str (unsigned char *slave\_addr*, char \* *str*)**

I2C master send string.

**Parameters:**

<i>slave_addr</i>	I2C slave address
<i>*str</i>	data pointer

**Returns:**

0: ack

---

## Detailed Description

MADC API functions

**int analog\_read (int *pin*)**

MADC read digital data.

**Parameters:**

<i>pin</i>	select made chan 0: CH I 1: CH Q
------------	--

**Returns:**

digital data(0 ~ 4095)

---

## Detailed Description

PWM API functions

**void pwm\_set\_enable (int *pwm\_ch*, int *value*)**

Set PWM enable

channel 1 use the same pin as PWM0,1 (GPIO6,7)

channel 2 use the same pin as PWM2,3 (GPIO8,9)

**Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
<i>value</i>	0: disable 1: enable

**Returns:**

None

### **void pwm\_set\_freq (int *pwm\_ch*, int *id*)**

Set PWM frequency

PWM0 and PWM1 share the same frequency setting. PWM1's frequency will be changed, if user changes PWM0's frequency. (PWM2 and PWM 3 as well). More details of PWM register setting in appendix 5.3.

id:

0: 0.3 Hz	1: 0.5	2: 10	3: 25	4: 45	5: 90
6: 160	7: 250.4	8: 500.8	9: 600.96	10: 849.18	11: 1k
12: 1.502k	13: 2.056k	14: 3k	15: 3.906k	16: 5k	17: 8k
18: 10k	19: 12.5k	20: 15k	21: 20.16k	22: 25k	23: 31.25k
24: 50k	25: 62.5k	26: 125k	27: 250k	28: 312.5k	29: 625k
30: 1250k					

#### **Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
<i>id</i>	0 ~ 30

#### **Returns:**

None

### **int pwm\_get\_freq (int *pwm\_ch*)**

Get PWM frequency

#### **Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
---------------	--------------------

#### **Returns:**

frequency id, -1: can't find correct id

### **void pwm\_set\_duty (int *pwm\_ch*, int *duty*)**

Set PWM duty

#### **Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
<i>duty</i>	0 ~ 31; 16 = 50%, 31 = 100%

#### **Returns:**

None

### **int pwm\_get\_duty (int *pwm\_ch*)**

Get PWM duty

#### **Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
---------------	--------------------

**Returns:**

duty 0 ~ 31

**void pwm\_set\_polarity (int *pwm\_ch*, int *value*)**

Set PWM polarity

**Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
<i>value</i>	0: active low 1: active high

**Returns:**

None

**int pwm\_get\_polarity (int *pwm\_ch*)**

Get PWM polarity

**Parameters:**

<i>pwm_ch</i>	0 ~ 3 (GPIO 6 ~ 9)
---------------	--------------------

**Returns:**

value

0: active low

1: active high

---

**Detailed Description**

Configuration API functions

**int config\_submit (void )**

Config data all burn into flash memory

**Returns:**

1: success

0: error

**int config\_get (sdk\_param \**param*)**

Config get data

**Parameters:**

<i>*param</i>	get data pointer
---------------	------------------

**Returns:**

1: success

0: error

### int config\_load (void )

Config load data to memory, initialize config read/write data process. Call config\_load before read/write config data.

#### Returns:

1: success

0: error

### int config\_set (sdk\_param \*param)

Config set data

#### Parameters:

<i>*param</i>	set data pointer
---------------	------------------

#### Returns:

1: success

0: error

---

## Detailed Description

Serial API functions

### void serial\_conf (int *br\_id*, int *parity*, int *stopbits*, int *chan*)

Uart configuration

#### Parameters:

<i>br_id</i>	baudrate table index 1 ~ 12 1: 2400      2: 4800      3: 9600 4: 19200     5: 38400     6: 57600 7: 115200    8: 230400    9: 460800 10: 500000   11: 576000   12: 921600 13: 1000000   14: 1152000   15: 1500000
<i>parity</i>	0: none 1: odd 2: even
<i>stopbits</i>	1, 2 bit
<i>chan</i>	uart chan 0 ~ 2

#### Returns:

None

### **int serial\_init (int *chan*)**

Serial initial

chan 0(UART1), chan 1-2(UART2), initial tx buffer for transparent mode.

#### **Parameters:**

<i>chan</i>	uart channel 0 ~ 2
-------------	--------------------

#### **Returns:**

1: success

0: error

### **int serial\_read\_byte (int *mode*, int *chan*, char \* *buf*, int *len*, char *end\_c*)**

Read serial data

#### **Parameters:**

<i>mode</i>	0: read one byte 1: read bytes 2: read bytes until terminator character
<i>chan</i>	uart channel 0 ~ 2
<i>*buf</i>	read buffer pointer
<i>len</i>	data length
<i>end_c</i>	terminator character

#### **Returns:**

mode 0: return the first byte of incoming serial data (-1 means no data available)

mode 1, 2 : return data length (0 means no valid data was found)

### **int serial\_write (int *chan*, char \* *pdata*, int *datalen*)**

Copy data to tx buffer and insert to fifo

Need to initial txbuf, call serial\_init(chan) first

#### **Parameters:**

<i>chan</i>	uart channel 0 ~ 2
<i>pdata</i>	rx buffer
<i>datalen</i>	data length

#### **Returns:**

stat

0: done

1: busy, tx buffer is full

-1: fail, tx buffer is null

**int uart\_no\_wait\_putc (int *chan*, int *c*)**

Uart tx put character no wait

**Parameters:**

<i>chan</i>	uart channel 0 ~ 2
<i>c</i>	character data

**Returns:**

0: tx fifo not full

-1: tx fifo full

**void uart\_set\_timeout (unsigned int *set\_timeout*)**

Set the maximum milliseconds to wait for serial data

**Parameters:**

<i>set_timeout</i>	time(ms)
--------------------	----------

**Returns:**

None

**int uart\_timeout\_getc (int *chan*)**

Uart get character, wait until time out

**Parameters:**

<i>chan</i>	uart channel 0 ~ 2
-------------	--------------------

**Returns:**

character, -1 means no data available

## 5. Appendix

### 5.1 PWM Frequency Formula

	Pre-scaler	$T_b$	$T_a$
--	------------	-------	-------

bit	29 - 22	19 - 17	16 - 14
0xc0010	PWM0 & PWM1	PWM1	PWM0
0xc0014	PWM2 & PWM3	PWM3	PWM2

$$\begin{aligned}
 Period_n(\text{ms}) &= \frac{1}{pwm\_clock} \times \frac{256}{1000} \times (Pre - scaler + 1) \times tick\_max \\
 &= \frac{1}{pwm\_clock} \times \frac{256}{1000} \times (Pre - scaler + 1) \times (T_n \times 1000 + 12000)
 \end{aligned}$$

$$\text{if } T_n = 0 \Rightarrow Period_n(\text{ms}) = \frac{1}{pwm\_clock} \times \frac{256}{1000} \times (Pre - scaler + 1)$$


$$\text{if } T_n = 7 \Rightarrow Period_n(\text{ms}) = \frac{1}{pwm\_clock} \times \frac{256}{1000} \times (Pre - scaler + 1) \times 32$$

$$n = a, b$$

### 5.3 I2C Master R/W Transfer Timing Diagram

Lynx I<sup>2</sup>C bus is emulated using two GPIO pins (GPIO 17 and GPIO 18). One pin is for clock signals (SCL), and one pin is for data signals (SDA).

#### a. Write Transfer Sequence



#### b. Read Transfer Sequence