

## MaxAir Technical – Zone Types


MaxAir supports nodes based on their type, these types define the basic capability of the zone:

- A node which is associated with both a temperature sensor and a system controller relay
- A node which is associated with only a temperature sensor
- A node which is associated with only a system controller relay
- A node which is not associated with either a temperature sensor or system controller relay

A number of Zone Types are pre-defined:

- Heating – has both a temperature sensor and a system controller relay
- Water – has both a temperature sensor and a system controller relay
- Immersion – has a temperature sensor
- Lamp – has system controller relay
- HVAC – has both a temperature sensor and a system controller relay

The currently defined Zone Types can be viewed from the 'Zone Type' menu option in the 'Settings/Node and Zone Configuration' menu.




The screenshot shows the MaxAir interface. The top navigation bar has a settings icon (gear) highlighted with a blue circle and labeled '1'. Below it, the 'Settings' menu is open, and the 'Zone Type' option is highlighted with a blue circle and labeled '2'. The 'Node and Zone Configuration' menu is also visible, with the 'Zone Type' option highlighted with a blue circle and labeled '3'.

Type	Category	
Heating	Sensor and System Control	
Water	Sensor and System Control	
Immersion	Sensor and NO System Control	
Lamp	NO Sensor and NO System Control	
HVAC	Sensor and System Control	

Close Add Type

Zone Types can be deleted by clicking on the 'trash' icon or addition ones added by clicking on the 'Add Type' button.



The 'Add Type' form is shown. It has a title 'Add Type' and a subtitle 'You can Add New Zone Types.' Below this, there is a text input field for 'Zone Type' with the placeholder text 'Zone type i.e. Heating, Hot Water or Electrical Immersion'. The input field contains the text 'Lamp'. Below the input field, there is a dropdown menu for 'Category' with the placeholder text 'Select Zone Type Category for Process Control'. The dropdown menu is open, showing the option 'NO Sensor and NO System Control' selected.

Close Save

Enter a name for the new Zone the and select the appropriate 'Category' from the dropdown list, finally click on the 'Save' button.