

```

%function [BER_1]=QPSKTXRXSim(EbNo)
clc
clear

load commqpsktxrx_sbits_100.mat; % length 174
% General simulation parameters
SimParams.M = 4; % M-PSK alphabet size
SimParams.Upsampling = 4; % Upsampling factor
SimParams.Downsampling = 2; % Downsampling factor
SimParams.Fs = 2e5; % Sample rate in Hertz
SimParams.Ts = 1/SimParams.Fs; % Sample time in sec
SimParams.FrameSize = 100; % Number of modulated
symbols per frame

% hAlamoutiEnc = comm.OSTBCEncoder;
% hAlamoutiDec = comm.OSTBCCCombiner;
Hray = zeros(100, 2, 2);
% Create the Rayleigh distributed channel response
matrix
%   for two transmit and two receive antennas
Hray(1:2:end, :, :) = (randn(50, 2, 2) + 1i*randn(50,
2, 2))/sqrt(2);
%   assume held constant for 2 symbol periods
Hray(2:2:end, :, :) = Hray(1:2:end, :, :);

SimParams.H21 = Hray(:, :, 1)/sqrt(2); %

% Tx parameters
SimParams.BarkerLength = 26; % Number of Barker code
symbols
SimParams.DataLength = (SimParams.FrameSize -
SimParams.BarkerLength)*2; % Number of data payload
bits per frame
SimParams.ScramblerBase = 2;
SimParams.ScramblerPolynomial = [1 1 1 0 1];
SimParams.ScramblerInitialConditions = [0 0 0 0];

SimParams.sBit = sBit; % Payload bits
SimParams.RxBufferedFrames = 10; % Received buffer
length (in frames)

SimParams.RaisedCosineFilterSpan = 10; % Filter span of
Raised Cosine Tx Rx filters (in symbols)
SimParams.MessageLength = 112;

```

```

SimParams.FrameCount = 100; % Number of frames
transmitted

% Channel parameters
SimParams.PhaseOffset = 0; % in degrees
SimParams.EbNo = 10; % in dB
SimParams.FrequencyOffset = 0; % Frequency offset
introduced by channel impairments in Hertz
SimParams.DelayType = 'Triangle'; % select the type of
delay for channel distortion

% Rx parameters
SimParams.CoarseCompFrequencyResolution = 25; %
Frequency resolution for coarse frequency compensation

% Look into model for details for details of PLL
parameter choice. Refer equation 7.30 of "Digital
Communications - A Discrete-Time Approach" by Michael
Rice.
K = 1;
A = 1/sqrt(2);
SimParams.PhaseRecoveryLoopBandwidth = 0.01; %
Normalized loop bandwidth for fine frequency
compensation
SimParams.PhaseRecoveryDampingFactor = 1; % Damping
Factor for fine frequency compensation
SimParams.TimingRecoveryLoopBandwidth = 0.01; %
Normalized loop bandwidth for timing recovery
SimParams.TimingRecoveryDampingFactor = 1; % Damping
Factor for timing recovery
SimParams.TimingErrorDetectorGain =
2.7*2*K*A^2+2.7*2*K*A^2; %  $K_p$  for Timing Recovery PLL,
determined by  $2KA^2 \cdot 2.7$  (for binary PAM), QPSK could be
treated as two individual binary PAM, 2.7 is for raised
cosine filter with roll-off factor 0.5

%QPSK modulated Barker code header
BarkerCode = [+1; +1; +1; +1; +1; -1; -1; +1; +1; -1;
+1; -1; +1; +1; +1; +1; +1; +1; -1; -1; +1; +1; -1; +1;
-1; +1]; % Bipolar Barker Code
SimParams.ModulatedHeader = sqrt(2)/2 * (-1-1i) *
BarkerCode;

% Generate square root raised cosine filter

```

```

coefficients (required only for MATLAB example)
SimParams.Rolloff = 0.5;

% Square root raised cosine transmit filter
SimParams.TransmitterFilterCoefficients = ...
    rcosdesign(SimParams.Rolloff,
SimParams.RaisedCosineFilterSpan, ...
    SimParams.Upsampling);

% Square root raised cosine receive filter
SimParams.ReceiverFilterCoefficients = ...
    rcosdesign(SimParams.Rolloff,
SimParams.RaisedCosineFilterSpan, ...
    SimParams.Upsampling);

%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%
%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%
prmQPSKTxRx = SimParams; % QPSK system parameters
printData = true; %true if the received data is to be
printed
useScopes = true; % true if scopes are to be used

%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%
%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%

% Initialize the components
% Create and configure the transmitter System object
hTx = QPSKTransmitterR(...
    'UpsamplingFactor', prmQPSKTxRx.Upsampling, ...
    'MessageLength', prmQPSKTxRx.MessageLength, ...

    'TransmitterFilterCoefficients',prmQPSKTxRx.Transmitter
FilterCoefficients, ...
    'DataLength', prmQPSKTxRx.DataLength, ...
    'ScramblerBase', prmQPSKTxRx.ScramblerBase, ...
    'ScramblerPolynomial',
prmQPSKTxRx.ScramblerPolynomial, ...
    'ScramblerInitialConditions',
prmQPSKTxRx.ScramblerInitialConditions,...
    'H21',prmQPSKTxRx.H21);

% Create and configure the AWGN channel System
object
hChan = QPSKChannelR('DelayType',

```

```

prmQPSKTxRx.DelayType, ...
    'RaisedCosineFilterSpan',
prmQPSKTxRx.RaisedCosineFilterSpan, ...
    'PhaseOffset', prmQPSKTxRx.PhaseOffset, ...
    'SignalPower', 1/prmQPSKTxRx.Upsampling, ...
    'FrameSize', prmQPSKTxRx.FrameSize, ...
    'UpsamplingFactor', prmQPSKTxRx.Upsampling, ...
    'EbNo', prmQPSKTxRx.EbNo, ...
    'BitsPerSymbol',
prmQPSKTxRx.Upsampling/prmQPSKTxRx.Downsampling, ...
    'FrequencyOffset',
prmQPSKTxRx.FrequencyOffset, ...
    'SampleRate', prmQPSKTxRx.Fs);

% Create and configure the receiver System object
hRx = QPSKReceiverR('DesiredAmplitude',
1/sqrt(prmQPSKTxRx.Upsampling), ...
    'ModulationOrder', prmQPSKTxRx.M, ...
    'DownsamplingFactor',
prmQPSKTxRx.Downsampling, ...
    'CoarseCompFrequencyResolution',
prmQPSKTxRx.CoarseCompFrequencyResolution, ...
    'PhaseRecoveryDampingFactor',
prmQPSKTxRx.PhaseRecoveryDampingFactor, ...
    'PhaseRecoveryLoopBandwidth',
prmQPSKTxRx.PhaseRecoveryLoopBandwidth, ...
    'TimingRecoveryDampingFactor',
prmQPSKTxRx.TimingRecoveryDampingFactor, ...
    'TimingRecoveryLoopBandwidth',
prmQPSKTxRx.TimingRecoveryLoopBandwidth, ...
    'TimingErrorDetectorGain',
prmQPSKTxRx.TimingErrorDetectorGain, ...
    'PostFilterOversampling',
prmQPSKTxRx.Upsampling/prmQPSKTxRx.Downsampling, ...
    'FrameSize', prmQPSKTxRx.FrameSize, ...
    'BarkerLength', prmQPSKTxRx.BarkerLength, ...
    'MessageLength', prmQPSKTxRx.MessageLength, ...
    'SampleRate', prmQPSKTxRx.Fs, ...
    'DataLength', prmQPSKTxRx.DataLength, ...
    'ReceiverFilterCoefficients',
prmQPSKTxRx.ReceiverFilterCoefficients, ...
    'DescramblerBase',
prmQPSKTxRx.ScramblerBase, ...
    'DescramblerPolynomial',

```

```

prmQPSKTxRx.ScramblerPolynomial, ...
    'DescramblerInitialConditions',
prmQPSKTxRx.ScramblerInitialConditions,...
    'PrintOption', printData,...
    'H21',prmQPSKTxRx.H21);

    if useScopes
        % Create the System object for plotting all the
scopes
        hScopes = QPSKScopes;
    end

hRx.PrintOption = printData;

for count = 1:prmQPSKTxRx.FrameCount
    [transmittedSignal] = step(hTx); % Transmitter
    corruptSignal = step(hChan, transmittedSignal, 0); %
AWGN Channel
    [RCRxSignal,coarseCompBuffer, timingRecBuffer,BER] =
step(hRx,corruptSignal); % Receiver
    % figure(1)
    % plot(real(transmittedSignal))
    % drawnow

    % figure(2)
    % plot(real(modulatedData))
    % drawnow
    %
    % figure(3)
    % plot(transmittedData)
    % drawnow
    %
    % pause(1)
    % if useScopes
    %
stepQPSKScopes(hScopes,RCRxSignal,coarseCompBuffer,
timingRecBuffer); % Plots all the scopes
    % end
end
% if isempty(coder.target)
%     release(hTx);
%     release(hChan);
%     release(hRx);
% end

```

```
% if useScopes
%     releaseQPSKScopes(hScopes);
% end
BER_1=BER(1);
fprintf('Error rate = %f.\n',BER(1));
fprintf('Number of detected errors = %d.\n',BER(2));
fprintf('Total number of compared samples
= %d.\n',BER(3));
```

```

classdef QPSKTransmitterR < matlab.System
    %#codegen
    % Generates the QPSK signal to be transmitted

    % Copyright 2012 The MathWorks, Inc.

    properties (Nontunable)
        UpsamplingFactor = 4;
        MessageLength = 105;
        DataLength = 174;
        TransmitterFilterCoefficients = 1;
        ScramblerBase = 2;
        ScramblerPolynomial = [1 1 1 0 1];
        ScramblerInitialConditions = [0 0 0 0];
        H21=zeros(100,2);
    end

    properties (Access=private)
        pBitGenerator
        pQPSKModulator
        pTransmitterFilter
    end

    methods
        function obj = QPSKTransmitterR(varargin)
            setProperties(obj,nargin,varargin{:});
        end
    end

    methods (Access=protected)
        function setupImpl(obj)
            obj.pBitGenerator = QPSKBitsGeneratorR(...
                'MessageLength', obj.MessageLength, ...
                'BernoulliLength', obj.DataLength-
obj.MessageLength, ...
                'ScramblerBase', obj.ScramblerBase, ...
                'ScramblerPolynomial',
obj.ScramblerPolynomial, ...
                'ScramblerInitialConditions',
obj.ScramblerInitialConditions);
            obj.pQPSKModulator =
comm.QPSKModulator('BitInput',true, ...
                'PhaseOffset', pi/4);
        end
    end
end

```

```

        obj.pTransmitterFilter =
dsp.FIRInterpolator(obj.UpsamplingFactor, ...
        obj.TransmitterFilterCoefficients);
    end

    function
[transmittedSignal,transmittedData,modulatedData]=
stepImpl(obj)
    % Generates the data to be transmitted
    [transmittedData, ~] =
step(obj.pBitGenerator);

    % Modulates the bits into QPSK symbols
    modulatedData = step(obj.pQPSKModulator,
transmittedData);

    hAlamoutiEnc = comm.OSTBCEncoder;

    % Alamouti Space-Time Block Encoder
    encData = step(hAlamoutiEnc, modulatedData);

    chanOut21 = sum(obj.H21.* encData, 2);

    transmittedSignal=chanOut21;
    % Square root Raised Cosine Transmit Filter
    %transmittedSignal =
step(obj.pTransmitterFilter, chanOut21);
end

function resetImpl(obj)
    reset(obj.pBitGenerator);
    reset(obj.pQPSKModulator );
    reset(obj.pTransmitterFilter);
end

function releaseImpl(obj)
    release(obj.pBitGenerator);
    release(obj.pQPSKModulator );
    release(obj.pTransmitterFilter);
end

function N = getNumInputsImpl(~)
    N = 0;

```



```
        end
    end
end
```

```

classdef QPSKReceiverR < matlab.System

% Copyright 2012-2015 The MathWorks, Inc.

    properties (Nontunable)
        DesiredAmplitude = 1/sqrt(2);
        ModulationOrder = 4;
        DownsamplingFactor = 2;
        CoarseCompFrequencyResolution = 50;
        PhaseRecoveryLoopBandwidth = 0.01;
        PhaseRecoveryDampingFactor = 1;
        TimingRecoveryDampingFactor = 1;
        TimingRecoveryLoopBandwidth = 0.01;
        TimingErrorDetectorGain = 5.4;
        PostFilterOversampling = 2;
        FrameSize = 100;
        BarkerLength = 26;
        MessageLength = 105;
        SampleRate = 200000;
        DataLength = 148;
        ReceiverFilterCoefficients = 1;
        DescramblerBase = 2;
        DescramblerPolynomial = [1 1 1 0 1];
        DescramblerInitialConditions = [0 0 0 0];
        PrintOption = false;
        H21=zeros(100,2);
    end

    properties (Access = private)
        pAGC
        pRxFilter
        pCoarseFreqEstimator
        pCoarseFreqCompensator
        pFineFreqCompensator
        pTimingRec
        pFrameSync
        pDataDecod
        pBER
    end

    properties (Access = private, Constant)
        pUpdatePeriod = 4 % Defines the size of vector
that will be processed in AGC system object
        pBarkerCode = [+1; +1; +1; +1; +1; -1; -1; +1;

```

```

+1; -1; +1; -1; +1 ; +1; +1; +1; +1; +1; -1; -1; +1;
+1; -1; +1; -1; +1]; % Bipolar Barker Code
    pModulatedHeader = sqrt(2)/2 * (-1-1i) *
QPSKReceiverR.pBarkerCode;
end

methods
    function obj = QPSKReceiverR(varargin)
        setProperties(obj,nargin,varargin{:});
    end
end

methods (Access = protected)
    function setupImpl(obj, ~)
        obj.pAGC = comm.AGC;

        obj.pRxFilter = dsp.FIRDecimator( ...
            'Numerator',
obj.ReceiverFilterCoefficients, ...
            'DecimationFactor',
obj.DownsamplingFactor);

        obj.pCoarseFreqEstimator =
comm.PSKCoarseFrequencyEstimator( ...
            'ModulationOrder',
obj.ModulationOrder, ...
            'Algorithm',            'FFT-based', ...
            'FrequencyResolution',
obj.CoarseCompFrequencyResolution, ...
            'SampleRate',            obj.SampleRate);

        obj.pCoarseFreqCompensator =
comm.PhaseFrequencyOffset( ...
            'PhaseOffset',            0, ...
            'FrequencyOffsetSource', 'Input port', ...
            'SampleRate',            obj.SampleRate);

        obj.pFineFreqCompensator =
comm.CarrierSynchronizer( ...
            'Modulation',            'QPSK', ...
            'ModulationPhaseOffset', 'Auto', ...
            'SamplesPerSymbol',
obj.PostFilterOversampling, ...
            'DampingFactor',

```

```

obj.PhaseRecoveryDampingFactor, ...
    'NormalizedLoopBandwidth',
obj.PhaseRecoveryLoopBandwidth);

    obj.pTimingRec = comm.SymbolSynchronizer( ...
        'TimingErrorDetector', 'Zero-Crossing
(decision-directed)', ...
        'SamplesPerSymbol',
obj.PostFilterOversampling, ...
    'DampingFactor',
obj.TimingRecoveryDampingFactor, ...
    'NormalizedLoopBandwidth',
obj.TimingRecoveryLoopBandwidth, ...
    'DetectorGain',
obj.TimingErrorDetectorGain);

    obj.pFrameSync = FrameFormation( ...
        'OutputFrameLength',
obj.FrameSize, ...
    'PerformSynchronization', true, ...
    'FrameHeader',
obj.pModulatedHeader);

    obj.pDataDecod =
QPSKDataDecoderR('FrameSize', obj.FrameSize, ...
    'BarkerLength', obj.BarkerLength, ...
    'ModulationOrder',
obj.ModulationOrder, ...
    'DataLength', obj.DataLength, ...
    'MessageLength', obj.MessageLength, ...
    'DescramblerBase',
obj.DescramblerBase, ...
    'DescramblerPolynomial',
obj.DescramblerPolynomial, ...
    'DescramblerInitialConditions',
obj.DescramblerInitialConditions, ...
    'PrintOption', obj.PrintOption,...
    'H21',obj.H21);
end

function [RCRxSignal, fineCompSignal,
timingRecBuffer,BER] = stepImpl(obj, bufferSignal)
    % AGC control
    RCRxSignal=0;

```

```

        fineCompSignal=0;
        timingRecBuffer=0;
    %
        AGCSignal =
obj.DesiredAmplitude*step(obj.pAGC, bufferSignal);
    %
    %
        % Pass the signal through Square-Root
Raised Cosine Received Filter
    %
        RCRxSignal = step(obj.pRxFilter,
AGCSignal);
    %
    %
        % Coarse frequency offset estimation
        freqOffsetEst =
step(obj.pCoarseFreqEstimator, RCRxSignal);
    %
    %
        % Coarse frequency compensation
        coarseCompSignal =
step(obj.pCoarseFreqCompensator, RCRxSignal, -
freqOffsetEst);
    %
    %
        % Fine frequency compensation
        fineCompSignal =
step(obj.pFineFreqCompensator, coarseCompSignal);
    %
    %
        % Symbol timing recovery
        [timingRecSignal, timingRecBuffer] =
step(obj.pTimingRec, fineCompSignal);

    %
        % Frame synchronization
        [symFrame, isFrameValid] =
step(obj.pFrameSync, timingRecSignal);
        isFrameValid=1;
        symFrame=bufferSignal;
        if isFrameValid % Decode frame of symbols
            obj.pBER = step(obj.pDataDecod, symFrame);
        end

    BER = obj.pBER;
end

function resetImpl(obj)
    obj.pBER = zeros(3, 1);
    reset(obj.pAGC);
    reset(obj.pRxFilter);
    reset(obj.pCoarseFreqEstimator);

```

```

        reset(obj.pCoarseFreqCompensator);
        reset(obj.pFineFreqCompensator);
        reset(obj.pTimingRec);
        reset(obj.pFrameSync);
        reset(obj.pDataDecod);
    end

    function releaseImpl(obj)
        release(obj.pAGC);
        release(obj.pRxFilter);
        release(obj.pCoarseFreqEstimator);
        release(obj.pCoarseFreqCompensator);
        release(obj.pFineFreqCompensator);
        release(obj.pTimingRec);
        release(obj.pFrameSync);
        release(obj.pDataDecod);
    end

    function N = getNumOutputsImpl(~)
        N = 4;
    end
end
end
end

```

```

classdef QPSKDataDecoderR < matlab.System

% Copyright 2012-2014 The MathWorks, Inc.

    properties (Nontunable)
        FrameSize = 100;
        BarkerLength = 13;
        ModulationOrder = 4;
        DataLength = 174;
        MessageLength = 105;
        DescramblerBase = 2;
        DescramblerPolynomial = [1 1 1 0 1];
        DescramblerInitialConditions = [0 0 0 0];
        PrintOption = false;
        H21=zeros(100,2);
    end

    properties (Access = private)
        pCorrelator
        pQPSKDemodulator
        pDescrambler
        pBitGenerator
        pErrorRateCalc
    end

    properties (Constant, Access = private)
        pBarkerCode = [+1; +1; +1; +1; +1; -1; -1; +1;
+1; -1; +1; -1; +1; +1; +1; +1; +1; +1; +1; -1; -1; +1; +1;
-1; +1; -1; +1]; % Bipolar Barker Code
        pModulatedHeader = sqrt(2)/2 * (-1-1i) *
QPSKDataDecoderR.pBarkerCode;
    end

    methods
        function obj = QPSKDataDecoderR(varargin)
            setProperties(obj,nargin,varargin{:});
        end
    end

    methods (Access = protected)
        function setupImpl(obj, ~)
            obj.pCorrelator = dsp.Crosscorrelator;

```

```

        obj.pQPSKDemodulator =
comm.QPSKDemodulator('PhaseOffset',pi/4, ...
        'BitOutput', true);

        obj.pDescrambler =
comm.Descrambler(obj.DescramblerBase, ...
        obj.DescramblerPolynomial,
obj.DescramblerInitialConditions);

        obj.pBitGenerator =
QPSKBitsGeneratorR('MessageLength',
obj.MessageLength, ...
        'BernoulliLength', obj.DataLength-
obj.MessageLength, ...
        'ScramblerBase', obj.DescramblerBase, ...
        'ScramblerPolynomial',
obj.DescramblerPolynomial, ...
        'ScramblerInitialConditions',
obj.DescramblerInitialConditions);

        obj.pErrorRateCalc = comm.ErrorRate;
end

function BER = stepImpl(obj, data)
    % Phase offset estimation
    %phaseEst =
round(angle(mean(conj(obj.pModulatedHeader) .*
data(1:obj.BarkerLength)))*2/pi)/2*pi;

    % Compensating for the phase offset
    %phShiftedData = data .* exp(-1i*phaseEst);

    hAlamoutiDec = comm.OSTBCCCombiner;

    % Alamouti Space-Time Block Combiner
    decData = step(hAlamoutiDec, data, obj.H21);

    % Demodulating the phase recovered data
    demodOut = step(obj.pQPSKDemodulator,
decData);

    % Performs descrambling
    deScrData = step(obj.pDescrambler, ...
        demodOut( ...

```



```

obj.BarkerLength*log2(obj.ModulationOrder)+1 : ...
    obj.FrameSize*log2(obj.ModulationOrder)));

    % Recovering the message from the data
    Received = deScrData(1:obj.MessageLength);
    bits2ASCII(obj, Received);

    [~, transmittedMessage] =
step(obj.pBitGenerator);

    BER = step(obj.pErrorRateCalc,
transmittedMessage, Received);
end

function resetImpl(obj)
    reset(obj.pCorrelator);
    reset(obj.pQPSKDemodulator);
    reset(obj.pDescrambler);
    reset(obj.pBitGenerator);
    reset(obj.pErrorRateCalc);
end

function releaseImpl(obj)
    release(obj.pCorrelator);
    release(obj.pQPSKDemodulator);
    release(obj.pDescrambler);
    release(obj.pBitGenerator);
    release(obj.pErrorRateCalc);
end
end

methods (Access=private)
    function bits2ASCII(obj,u)
        coder.extrinsic('disp')

        % Convert binary-valued column vector to 7-
bit decimal values.
        w = [64 32 16 8 4 2 1]; % binary digit
weighting
        Nbits = numel(u);
        Ny = Nbits/7;
        y = zeros(1,Ny);
        for i = 0:Ny-1

```

```
        y(i+1) = w*u(7*i+(1:7));
    end

    % Display ASCII message to command window
    if(obj.PrintOption)
        disp(char(y));
    end
end
end
end
```

```

classdef QPSKChannelR < matlab.System
    %#codegen

    % Copyright 2012-2013 The MathWorks, Inc.

    properties (Nontunable)
        DelayType = 'Triangle';
        RaisedCosineFilterSpan = 10;
        PhaseOffset = 47;
        SignalPower = 0.25;
        FrameSize = 100;
        UpsamplingFactor = 4;
        EbNo = 7;
        BitsPerSymbol = 2;
        FrequencyOffset = 5000;
        SampleRate = 200000;
    end

    properties (Access=private)
        pPhaseFreqOffset
        pVariableTimeDelay
        pAWGNChannel
    end

    properties (Constant, Access=private)
        pDelayStepSize = 0.05;
        pDelayMaximum = 8;
        pDelayMinimum = 0.1;
    end

    methods
        function obj = QPSKChannelR(varargin)
            setProperties(obj,nargin,varargin{:});
        end
    end

    methods (Access=protected)
        function setupImpl(obj, ~, ~)
            obj.pPhaseFreqOffset =
comm.PhaseFrequencyOffset(...
                'PhaseOffset', obj.PhaseOffset, ...
                'FrequencyOffset',
obj.FrequencyOffset, ...

```

```

        'SampleRate',obj.SampleRate);
    obj.pVariableTimeDelay =
dsp.VariableFractionalDelay(...
        'MaximumDelay',
obj.FrameSize*obj.UpsamplingFactor);
    obj.pAWGNChannel = comm.AWGNChannel('EbNo',
obj.EbNo, ...
        'BitsPerSymbol', obj.BitsPerSymbol, ...
        'SignalPower', obj.SignalPower, ...
        'SamplesPerSymbol', obj.UpsamplingFactor);
end

```

```

function corruptSignal = stepImpl(obj, TxSignal,
count)

```

```

    % Calculates the delay
    if strcmp(obj.DelayType,'Ramp')
        delay = ...
            min(((count - 1) * obj.pDelayStepSize
+ obj.pDelayMinimum), ...
                (obj.FrameSize-
obj.RaisedCosineFilterSpan) ...
                *obj.UpsamplingFactor); % Variable
delay taking the form of a ramp
    else

```

```

        % Variable delay taking the shape of a
triangle
        index = mod(count-
1,2*obj.pDelayMaximum/obj.pDelayStepSize);
        if index <=
obj.pDelayMaximum/obj.pDelayStepSize
            delay = index * obj.pDelayStepSize;
        else
            delay = 2*obj.pDelayMaximum - index *
obj.pDelayStepSize;
        end
    end
end

```

```

    % Signal undergoes phase/frequency offset
    rotatedSignal =
step(obj.pPhaseFreqOffset,TxSignal);

```

```

    % Delayed signal

```

```

        delayedSignal = step(obj.pVariableTimeDelay,
rotatedSignal, 0);

        % Signal passing through AWGN channel
        corruptSignal = step(obj.pAWGNChannel,
delayedSignal);

    end

    function resetImpl(obj)
        reset(obj.pPhaseFreqOffset);
        reset(obj.pVariableTimeDelay);
        reset(obj.pAWGNChannel);
    end

    function releaseImpl(obj)
        release(obj.pPhaseFreqOffset);
        release(obj.pVariableTimeDelay);
        release(obj.pAWGNChannel);
    end

    function N = getNumInputsImpl(~)
        N = 2;
    end
end
end
end

```

```

classdef QPSKBitsGeneratorR < matlab.System
    %#codegen
    % Generates the bits for each frame

    % Copyright 2012 The MathWorks, Inc.

    properties (Nontunable)
        MessageLength = 105;
        BernoulliLength = 69;
        ScramblerBase = 2;
        ScramblerPolynomial = [1 1 1 0 1];
        ScramblerInitialConditions = [0 0 0 0];
    end

    properties (Access=private)
        pHeader
        pScrambler
        pMsgStrSet
        pCount
    end

    methods
        function obj = QPSKBitsGeneratorR(varargin)
            setProperties(obj,nargin,varargin{:});
        end
    end

    methods (Access=protected)
        function setupImpl(obj, ~)
            bbc = [+1 +1 +1 +1 +1 -1 -1 +1 +1 -1 +1 -1 +1
+1 +1 +1 +1 +1 -1 -1 +1 +1 -1 +1 -1 +1]; % Bipolar
Barker Code
            ubc = ((bbc + 1) / 2)'; % Unipolar Barker
Code
            temp = (repmat(ubc,1,2))';
            obj.pHeader = temp(:);
            obj.pCount = 0;
            obj.pScrambler =
comm.Scrambler(obj.ScramblerBase, ...
                obj.ScramblerPolynomial,
obj.ScramblerInitialConditions);
            obj.pMsgStrSet = ['Hello world 1000';...
                'Hello world 1001';...
                'Hello world 1002';...

```

'Hello world 1003';...
'Hello world 1004';...
'Hello world 1005';...
'Hello world 1006';...
'Hello world 1007';...
'Hello world 1008';...
'Hello world 1009';...
'Hello world 1010';...
'Hello world 1011';...
'Hello world 1012';...
'Hello world 1013';...
'Hello world 1014';...
'Hello world 1015';...
'Hello world 1016';...
'Hello world 1017';...
'Hello world 1018';...
'Hello world 1019';...
'Hello world 1020';...
'Hello world 1021';...
'Hello world 1022';...
'Hello world 1023';...
'Hello world 1024';...
'Hello world 1025';...
'Hello world 1026';...
'Hello world 1027';...
'Hello world 1028';...
'Hello world 1029';...
'Hello world 1030';...
'Hello world 1031';...
'Hello world 1032';...
'Hello world 1033';...
'Hello world 1034';...
'Hello world 1035';...
'Hello world 1036';...
'Hello world 1037';...
'Hello world 1038';...
'Hello world 1039';...
'Hello world 1040';...
'Hello world 1041';...
'Hello world 1042';...
'Hello world 1043';...
'Hello world 1044';...
'Hello world 1045';...
'Hello world 1046';...

'Hello world 1047';...
'Hello world 1048';...
'Hello world 1049';...
'Hello world 1050';...
'Hello world 1051';...
'Hello world 1052';...
'Hello world 1053';...
'Hello world 1054';...
'Hello world 1055';...
'Hello world 1056';...
'Hello world 1057';...
'Hello world 1058';...
'Hello world 1059';...
'Hello world 1060';...
'Hello world 1061';...
'Hello world 1062';...
'Hello world 1063';...
'Hello world 1064';...
'Hello world 1065';...
'Hello world 1066';...
'Hello world 1067';...
'Hello world 1068';...
'Hello world 1069';...
'Hello world 1070';...
'Hello world 1071';...
'Hello world 1072';...
'Hello world 1073';...
'Hello world 1074';...
'Hello world 1075';...
'Hello world 1076';...
'Hello world 1077';...
'Hello world 1078';...
'Hello world 1079';...
'Hello world 1080';...
'Hello world 1081';...
'Hello world 1082';...
'Hello world 1083';...
'Hello world 1084';...
'Hello world 1085';...
'Hello world 1086';...
'Hello world 1087';...
'Hello world 1088';...
'Hello world 1089';...
'Hello world 1090';...


```

        'Hello world 1091';...
        'Hello world 1092';...
        'Hello world 1093';...
        'Hello world 1094';...
        'Hello world 1095';...
        'Hello world 1096';...
        'Hello world 1097';...
        'Hello world 1098';...
        'Hello world 1099'];
end

function [y,msg] = stepImpl(obj)

    % Converts the message string to bit format
    cycle = mod(obj.pCount,100);
    msgStr = obj.pMsgStrSet(cycle+1,:);
    msgBin = de2bi(int8(msgStr),7,'left-msb');
    msg =
reshape(double(msgBin).',obj.MessageLength,1);
    data = [msg ; randi([0 1],
obj.BernoulliLength, 1)];

    % Scramble the data
    scrambledData = step(obj.pScrambler, data);

    % Append the scrambled bit sequence to the
header
    y = [obj.pHeader ; scrambledData];

    obj.pCount = obj.pCount+1;
end

function resetImpl(obj)
    obj.pCount = 0;
    reset(obj.pScrambler);
end

function releaseImpl(obj)
    release(obj.pScrambler);
end

function N = getNumInputsImpl(~)
    N = 0;
end

```

```
function N = getNumOutputsImpl(~)
    N = 2;
end
end
end
```

```

% Copyright 2012 The MathWorks, Inc.

classdef QPSKScopes < matlab.System

    properties (Access=private)
        pRxScope % Spectrum analyzer System object to
plot received signal after filtering
        pRxConstellation % Constellation scope System
object to plot received signal after filtering
        pFreqRecConstellation % Constellation scope
System object to plot received signal after filtering
        pTimingError % Time scope System object to plot
normalized timing error
    end

    methods
        function obj = QPSKScopes(varargin)
            setProperties(obj,nargin,varargin{:});
        end
    end

    methods (Access=protected)
        function setupImpl(obj, ~, ~, ~)
            obj.pRxScope =
dsp.SpectrumAnalyzer('SpectralAverages', 2, ...
                    'PowerUnits', 'dBW', 'YLimits', [-130
-15], ...
                    'Title', 'After Raised Cosine Rx
Filter', ...
                    'SpectralAverages', 1, ...
                    'YLabel', 'PSD', ...
                    'SpectrumType', 'Power density', ...
                    'Position', figposition([1.5 37.2 24
26]));
            obj.pRxConstellation =
comm.ConstellationDiagram( ...
                    'ShowGrid', true, ...
                    'Position', figposition([1.5 72 17
20]), ...
                    'SamplesPerSymbol', 2, ...
                    'YLimits', [-1 1], ...
                    'XLimits', [-1 1], ...
                    'Title', 'After Raised Cosine Rx
Filter');

```

```

        obj.pFreqRecConstellation =
comm.ConstellationDiagram( ...
    'ShowGrid', true, ...
    'Position', figposition([19 72 17
20]), ...
    'YLimits', [-1 1], ...
    'XLimits', [-1 1], ...
    'SamplesPerSymbol', 2, ...
    'Title', 'After Fine Frequency
Compensation');
    obj.pTimingError = dsp.TimeScope( ...
    'Title', 'Normalized Timing
Error', ...
    'YLabel', 'mu (half symbols)',
    'TimeSpan', 1000, ...
    'YLimits', [-0.1 1.1], 'ShowGrid',
true, ...
    'Position', figposition([26 45 11.8
17.8]));
    end

    function stepImpl(obj, RCRxSignal,
coarseCompBuffer, timingRecBuffer)

        % Plots the constellation of the filtered
signal
        step(obj.pRxConstellation,RCRxSignal);

        % Plots the spectrum scope of the filtered
signal
        step(obj.pRxScope,RCRxSignal);

        % Plots the constellation of the phase
recovered signal
        step(obj.pFreqRecConstellation,coarseCompBuffer);

        % Plots the time scope of normalized
timing error
        step(obj.pTimingError,
timingRecBuffer(1:10:end));
    end

```

```

function resetImpl(obj)
    reset(obj.pRxConstellation);
    reset(obj.pFreqRecConstellation);
    reset(obj.pRxScope);
    reset(obj.pTimingError);
end

function releaseImpl(obj)
    release(obj.pRxConstellation);
    release(obj.pFreqRecConstellation);
    release(obj.pRxScope);
    release(obj.pTimingError);
end

function N = getNumInputsImpl(~)
    N = 3;
end

function N = getNumOutputsImpl(~)
    N = 0;
end
end
end
end

```