

# momcozy



EN FR DE IT ES

## BABY CARRIER INSTRUCTIONS

# CATALOG

EN	-----	01
FR	-----	10
DE	-----	19
IT	-----	28
ES	-----	37

**IMPORTANT! READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE CARRIER. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.**



## WARNING

### FALL AND SUFFOCATION HAZARD

**FALL HAZARD – INFANTS CAN FALL THROUGH A WIDE LEG OPENING OR OUT OF CARRIER.**

- Adjust leg openings to fit baby's legs snugly.
- Before each use, make sure all fasteners are secure.
- Take special care when leaning or walking.
- Never bend at waist; bend at knees.
- Only use this carrier for children between 7lb and 44 lb (3.2 kg – 20 kg).

**SUFFOCATION HAZARD** – Infants under 4 months can suffocate in this product if face is pressed tight against your body.

- Do not strap infant too tight against your body.
- Allow room for head movement.
- Keep infant's face free from obstructions at all times.

**WARNING:**

- Read all instructions before assembling and using the soft carrier.
- Keep instructions for future use.
- Check to assure all buckles, snaps, straps, and adjustments are secure before each use.
- Check for ripped seams, torn straps or fabric and damaged fasteners before each use.
- Ensure proper placement of child in product including leg placement.
- Premature infants, infants with respiratory problems, and infants under 4 months are at greatest risk of suffocation.
- Never use a soft carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Never use a soft carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.
- Never wear a soft carrier while driving or being a passenger in a motor vehicle.
- Your balance may be adversely affected by your movement and that of your child.
- Take care when bending or leaning forward or sideways.
- This carrier is not suitable for use during sporting activities.
- For low birth weight babies and children with medical conditions, seek advice from a health professional before using the product.
- An awareness of hazards in the domestic environment e.g. heat sources, spilling of hot drinks.
- Stop using the carrier if parts are missing or damaged.
- Constantly monitor your child and ensure their mouth and nose are unobstructed.
- For pre-term, low birth-weight babies and children with medical conditions, seek advice from a health professional before using this product.
- Ensure your child's chin is not resting on its chest, as its breathing may be obstructed, which could lead to suffocation.
- To prevent hazards from falling, ensure that your child is securely positioned in the carrier.
- Great care should be taken near hot objects or when drinking hot liquids (where there exists a danger of spilling).
- Never leave a child unattended in or with the carrier.

## **FURTHER PRECAUTIONS**

- The maximum weight allowed for the carrier is 20 kg.
- The carrier should be kept out of the reach of children.
- The carrier should be checked regularly for possible signs of damage to the carrier.
- The carrier is suitable for only one child at a time.
- Your movement and the child's movement may affect your balance.
- The carrier is not suitable for use during sporting activities, e.g. running, cycling, swimming, and skiing.
- Be aware of the increased risk of the child falling out of the carrier as it becomes more active.
- Ensure proper placement of the child in the product, including leg placement.
- Premature infants, infants with respiratory problems, and infants under 4 months are at greatest risk of suffocation.
- Never use the carrier when your balance or mobility is impaired due to exercise, drowsiness, or medical conditions.
- Never use the carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.
- Never wear the carrier while driving or when riding as a passenger in a motor vehicle.
- We recommend that you first use the carrier at home, with a second person on hand to offer assistance.
- Keep the carrier away from children when it is not in use.

# HOW TO ADJUST YOUR MOMCOZY BABY CARRIER BEFORE USE

## ADJUSTING THE BODY PANEL TO THREE DIFFERENT SIZING POSITIONS

Your MOMCOZY Baby Carrier's body panel features three different sizing positions that can be adjusted depending on the length and weight of your baby. Different sizes can be created by adjusting the snaps that are hidden inside the waist belt as shown below.



The snaps, hidden inside the waist belt, can be adjusted depending on the length and weight of your child.

### SUITABLE FROM 2 MONTHS\*

Until a maximum weight of 9 kg / 20 lb.



Slide the body panel inwards to the smallest size and attach the one innermost snap accordingly on each side. Leave the other snaps unused.

### SUITABLE FROM 6 MONTHS\*

Until a maximum weight of 14 kg / 31 lb.



Slide the body panel inwards and attach the middle and innermost snaps accordingly on each side. Leave the other snap unused.

### SUITABLE FROM 8 MONTHS\*

Until a maximum weight of 20 kg / 44 lb.






As shown in the picture, attach all snaps accordingly on each side.


## Step-by-Step Instructions

For use for babies 3.2 kg / 7 lb to 20 kg / 44 lb.

### Finding the Correct Position for Your Baby

When adjusting the body panel's sizing, always check to see if your baby's knees are higher than his/her thighs, making an 'm'shape as shown below.





Position the waist belt with the warning label so that they face inwards and the carrier's body panel is centered on your body.



Feed the male-end of the buckle (including any extra strap length) through the elastic safety loop.



Secure the waist belt by fastening the buckle until it clicks.



Tighten the waist belt by pulling on the adjustable black strap until it sits tightly above the hips. Tuck the excess length of the black strap into the storage loop.



Ensure that, prior to beginning use, the shoulder straps are adjusted to be as long as possible and the buckles are unfastened. Lift the body panel up by placing the left shoulder strap on your left shoulder.






Pull the left shoulder strap across your back.



Fasten the male-end of the buckle of the left shoulder strap into the female-end of the buckle on the right side of the body panel until it clicks.



Pick up your child and position the child on your right side.




Use your right hand to support your child facing towards you, while using the other hand to slip the child's right leg between the panel and your body.



Use your left hand to support your child, while using the other hand to slip the child's left leg underneath the strap already buckled to the side of the body panel.




Pull the right shoulder strap, lifting the body panel up behind your child's back.



While still holding the child with your left hand, pull the right shoulder strap over your right shoulder.



Pull the right shoulder strap across your back.



Feed the entire male-end of the buckle (including extra strap length) through the elastic safety loop. Fasten the male-end of the buckle of the right shoulder strap into the female-end of the buckle on the left side of the body panel until it clicks.



Pull the body panel up from its upper edge to make sure there are no folds on it.



Tighten both side straps simultaneously. Make sure your child is comfortable and not too tightly pressed up against your body. Allow room for the child's head movement.



Ensure the child's back is slightly arched while sitting in the carrier. Make sure your child's bottom is seated deep in the carrier's body panel just above the waist belt. You and your child are ready to go.



You can reduce excess strap length by rolling up the strap and securing it with the elastic storage loop attached to the end of the strap.

