

---

# **BIBO 3D PRINTER LASER ENGRAVING**

## **---Operation Manual**



**SHAOXING BIBO AUTOMATIC EQUIPMENT CO., LTD.**

V1.2J

**Please operate the machine strictly according to this operation manual !**

**REVISION RIGHTS RESERVED**

## 1. Precautions

[★★★ Make sure you read and understand the steps detailed in this guide]

The Bibo 3D printer is very sensitive to static electricity, so make sure you contact a grounded object before operating the machine.





Before repairing or making any alterations to the Bibo 3D printer it is essential that the machine is turned off and the power cord is unplugged.

Laser are dangerous and can hurt or make you blind. Please wear the goggles to protect your eyes.


Do not leave the machine unattended when in operation.

## 2. Initial Hardware Installation

The first step is to unlock the cooling fan connector to extruders, then take the extruders off the X-carriage to the back of the printer as the photo below:




The second step is to connect cooling fan wire to laser engraving module:




The fourth step is to fix the laser on the X-carriage:

Fix the laser with two bolts in 16mm length and nuts




### 3. Laser focus

The Laser we sent has already been focused.



Please put a **thin yellow paper** which we sent to you on the **glass build plate center**. Then use repetier-host or screen on machine to let coordinate in **Z axis be 40 mm** (that means build plate moves down 40mm after home z axis) and **turn on the fan**(Laser is connected with cooling fan's wire. **For touch screen, fan menu is under settings menu**). You will see there is a small blue point on the paper and smoke too. Now the laser is focused.

If not, **please turn off the fan (Laser) first**, then you can rotate the end of laser in one direction about 180 degree, Then turn on the fan (laser), see the laser blue point is bigger or smaller. Now Turn off the fan (laser) again, if the blue point is bigger, you should rotate the end of laser in opposite direction. If smaller, that means the direction you rotated just now is right. If you rotate the end of laser again, the blue point can't be smaller and already have the smoke on yellow paper, that means you focus it already, and this is also the aim we want. Remember, when rotate the laser end, please turn off the fan (laser) first.



After finding the focus, you can laser engrave yellow paper at Z40 coordinate. If the object you want to engrave is 10mm in thickness, then you can engrave it at Z50 coordinate. So please add the object thickness to Z axis coordinate when you want to engrave it.

#### 4. Generate g-code for laser

1. Download Inkscape from <https://inkscape.org/en/download/>  
Or copy the inkscape install document from SD card we sent to you. Then install it on your computer.
2. Open the Plug-in file named "BIBO 3D printer Laser Tool" in SD card.  
This plug-in will convert a path object in inkscape into a G Code file for use in the printer. Put the contents of this folder into the "inkscape\share\extensions" folder where you installed the inkscape. Once it is there and you restart inkscape ,it will show up under the "extensions" tab in inkscape.

#### Drawing Text

Engraving text into materials is a very common need for the laser upgrade. **Our printer engrave area is 214\*186 mm, the same as printing area. The origin of coordinates (0,0) is in the bed center. For four corner of glass build plate coordinate is below(if facing the printer):**

**Left front (-107,93)   Left back (-107,-93)   Right front (107,93)   Right back (107,-93)**


**So when drawing or place some photoes in inkscape, please let them be in the center (bottom left corner in inkscape) , not bigger than coordinate**




mentioned above.

Here is how to accomplish this.


**Step 1:** Use the TEXT tool in inkscape to draw your text. The bottom left corner is you 0,0 location of you machine.




**Step 2:** You need to convert the object into a path. All items drawn in inkscape are a vector object. You can convert them into a “path” that will actually “draw” the object. The laser then takes this path to generate the G Code.



**Step 3:** Under “Extensions” click on “Generate G Code” and “BIBO 3D printer Laser Tool.



**Step 4:** Fill out the Laser Tool Dialog.




Please fill out the directory you want to store the gcode file on your printer. For example, D:\home

The parameter of Laser speed and Laser power is very important. If laser engrave is not strong enough, you can slow down the laser speed or increase Laser power.


With 500mw Laser in full power, engraving on colored paper, the laser speed can be 500mm/min to 600mm/min. If on density wood board, the laser speed also can be 500mm/min. You can try to laser a small laser engraving test on the material you want to engrave to see the performance, then adjust the parameter for better performance. Usually, BIBO 3D printer's laser can do engraving on paper(colored paper is better), wood, leather, acrylics, and many other materials, but can't engrave on metal and glass.

**Step 5:** When finished filling out the form, click APPLY to start.






**Step 6:** The laser path will be outlined and the code will be generated in the location provided in the tool.



Here is an example of the G Code file produced.



```
output_0009.gcode - 记事本
文件(F) 编辑(E) 格式(O) 查看(V) 帮助(H)

M107 S0


G90
G21
G1 F3000
G1 X168.309 Y32.1107
G4 P0
M106 S255
G4 P0
G1 F300.000000
G2 X165.9667 Y21.0442 I-27.3127 J-0.
G2 X159.1672 Y11.4831 I-26.8624 J11.905
G2 X149.1378 Y5.1882 I-21.2814 J22.7698
G2 X137.0969 Y2.9388 I-12.041 J31.1026
G2 X125.0559 Y5.1882 I-0. J33.3521
G2 X115.0265 Y11.4831 I11.252 J29.0646
G2 X108.2271 Y21.0442 I20.0629 J21.4661
G2 X105.8847 Y32.1107 I24.9703 J11.0664
G2 X108.2271 Y43.1772 I27.3127 J0.
G2 X115.0265 Y52.7383 I26.8624 J-11.905
G2 X125.0559 Y59.0331 I21.2814 J-22.7698
G2 X137.0969 Y61.2826 I12.041 J-31.1027
G2 X149.1378 Y59.0331 I0. J-33.3521
G2 X159.1672 Y52.7383 I-11.252 J-29.0646
G2 X165.9667 Y43.1772 I-20.0629 J-21.4661
G2 X168.309 Y32.1107 I-24.9703 J-11.0665

第 4 行, 第 4 列
```

Now add

**G28 X0 Y0**

Before the first line M107 S0 as the photo below:



```
output_0009.gcode - 记事本
文件(F) 编辑(E) 格式(O) 查看(V) 帮助(H)


G28 X0 Y0
M107 S0

G90
G21
G1 F3000
G1 X168.309 Y32.1107
G4 P0
M106 S255
G4 P0

第 4 行, 第 4 列
```

To use Laser engraving, this step to add one command(Home x and y axis) is necessary for BIBO 3D printer. The origin of coordinates is in the center of the build plate.

You can also load the gcode to repetier host for some big are engravings. Then check the engraving area whether over the bed size (It is dangerous to engrave or print over the bed area):




Everything is now finished, just copy this gcode to a SD card, then use BIBO 3D printer to print from SD card for laser engraving. PS. use repetier-host or screen on printer to let coordinate in Z axis be 40 mm first, that means build plate moves down 40mm after home z axis. If the object you want to engrave is 10mm in thickness, then you can engrave it at Z axis be 50mm coordinate. So please add the object thickness to Z axis coordinate when you want to engrave it.

During laser engraving, when you pause or stop the engraving, please turn off the fan (laser) to protect the laser for a long life. Usually, please don't let the laser run continuously more than one hour.

## Drawing Other Objects


Similar to the text, you can draw anything you want with the other tools. Just do the same as the first part Laser Text's steps to convert it to G Code for the laser. Here is an example of a swirl:




## Drawing Multiple Objects


In order to draw multiple objects in the same toolpath, you must first group all of the objects and convert to path before generating. Here is an example:

**Step 1:** Draw your separate objects.



**Step 2: Group your objects.****Step 3: Turn them all into a path.**






**Step 4:** Start the Laser Tool converter and do all the same as the first part Laser Text's steps.


### Importing Black and White Pictures

A cool thing to engrave are black and white "high contrast" images that only have two colors. Here are the steps to engrave them.


**Step 1:** Import your image on "file -> Import". Note it is two colors.




**Step 2:** Trace the outline of the image to get the path for the laser.




**Step 3:** Using edge detection, update the image and press “OK” to apply the changes.



**Step 4:** Delete the original layer underneath the new edge detected layer.



**Step 5:** Select “object to path” to create laser path.



**Step 6:** Generate your laser G Code file by entering your parameters and pressing "Apply". The laser path will be outlined. And add one line commands in the gcode generated as the first part laser text's steps.