

## QUICK START GUIDE FOR ARRAY PERFORMANCE INFORMATION

### TABLE OF CONTENTS

Quick Start Guide for ARRAY PERFORMANCE information .....	1
Introduction .....	1
WHAT IS A QUICK START GUIDE .....	1
TOOL USED FOR THE QUICK START GUIDE ILLUSTRATION .....	2
THE MOCK IMPLEMENTATIONS .....	2
HOW A GUIDE WORKS .....	2
THE QUICK START GUIDE FOR ARRAY PERFORMANCE .....	2
PERFORMANCE CAPABILITIES .....	3
BLOCK STATISTICS SERVICE .....	4
STATISTICS COLLECTION .....	5
BLOCK STATISTICAL DATA .....	6
BLOCK STATISTICS MANIFESTS AND COLLECTION .....	11

### Introduction

#### WHAT IS A QUICK START GUIDE

SMI-S is 2516 pages of reading spread across 8 books, plus it references another 14 or so DMTF profiles which amount to another 660 pages of reading. So, the question is where do you start? We have come up with a series of Quick Start Guides that are designed to help you get started by illustrating how to find useful SMI-S information in mock servers (mock ups of SMI-S server implementations). The Quick Start Guides don't illustrate EVERYTHING in the 3176 pages, but they give you a head start at finding some important items in SMI-S.

We currently have quick start guides for:

1. The Interop Namespace - What is it and what does it tell us?
2. Performance Information - Where do I find performance information in an SMI-S Server?
3. Capacity Information - Where do I find storage capacity information in an SMI-S Server?
4. Hardware Information - Where do I find hardware information in an SMI-S Server?
5. Product Information - Where do I find product information in an SMI-S Server?
6. Software Information - Where do I find software information in an SMI-S Server?

## TOOL USED FOR THE QUICK START GUIDE ILLUSTRATION

The tool used for illustrating how to find information in SMI-S is the pywbemcli. It is a command line interface for accessing any CIM Server. It uses pywbem, an interface for python program access to any CIM Server. The pywbemcli and pywbem are python programs that use a set of python packages. Pywbem and the pywbemcli are actively being maintained and are available on Github.

We will be using the latest version of the pywbemcli in these guides. You can find documentation on the pywbemcli at the following website:

We will be using the latest version of the pywbemcli in these guides. You can find documentation on the pywbemcli at the following website:

<https://pywbemtools.readthedocs.io/en/latest/>

## THE MOCK IMPLEMENTATIONS

The mock implementations mock selected autonomous profiles and some of their component profiles in SMI-S 1.8.0.

We currently have mock ups for the following autonomous profiles:

1. The SNIA Server Profile
2. The DMTF WBEM Server Profile
3. The Array Profile
4. The NAS Head Profile

And we plan on doing a Fabric (and Switch) mock up.

We chose to do mock ups of the SMI-S 1.8.0 versions of these profiles to illustrate differences between 1.8.0 and 1.6.1. We don't mock everything that is new in 1.8.0, but we do highlight some key changes ... like the DMTF WBEM Server profile, new indications and Advance Metrics (performance) for Arrays.

## HOW A GUIDE WORKS

The guide is a sequence of text explaining what we are looking for, followed by the command to obtain the information, followed by command output and then text that explains the output.

## THE QUICK START GUIDE FOR ARRAY PERFORMANCE

In this guide we will be exploring performance information provided by an SMI-S Server for an Array. The mock for the Array supports SMI-S 1.8.0 and we will identify the differences between 1.6.1 and 1.8.0.

This 13 page document highlights information that can be found in about 70 pages of SMI-S, the block server performance profile in the block book of SMI-S.

In this script we will be working with beta3 of pywbem 1.0.0 and version 0.7.1 of pywbemtools (pywbemcli).

So, let's begin. First, we go to our virtual environment for beta3:

```
C:\Users\FarmerMike>workon beta3
(beta3) c:\Users\FarmerMike\devenv>
```

We are now in our virtual environment for beta3.

We will be working with a mock server that supports an SMI-S 1.8.0 Array. We will point out items that were introduced after 1.6.1. So, we need to establish a connection to the Array mock up:

```
(beta3) c:\Users\FarmerMike\devenv>pywbemcli -o table --name ArrayMock
Enter 'help' for help, <CTRL-D> or ':q' to exit pywbemcli or <CTRL-r> to search history,
pywbemcli>
```

In our command, I requested the default format of output to be in “table” format (-o table) and name the mock that I want (--name ArrayMock). The command worked and we get a pywbemcli prompt to start entering commands on the ArrayMock.

#### PERFORMANCE CAPABILITIES

In SMI-S 1.8.0 Advanced Metrics was defined for storage Arrays. We can determine if our Mock Array supports this by inspecting the CIM\_BlockStatisticsCapabilities. Specifically, the SupportedFeatures property will include the value "6".

So, let's get the performance capabilities. We will do this with two requests for readability.

```
pywbemcli> instance enumerate CIM_BlockStatisticsCapabilities --pl InstanceID,SupportedFeatures
/Loading classes into the Mock Repository
\Loading instances into the Mock Repository
-DONE Loading instances into the Mock Repository
Instances: CIM_BlockStatisticsCapabilities
+-----+-----+
| InstanceID          | SupportedFeatures          |
+-----+-----+
| "ACME+CF2A5091300089" | 3 (Client Defined Sequence), 6 (Advanced Metrics) |
+-----+-----+
pywbemcli>
pywbemcli> instance enumerate CIM_BlockStatisticsCapabilities --pl
InstanceID,ElementTypesSupported
Instances: CIM_BlockStatisticsCapabilities
+-----+-----+
| InstanceID          | ElementTypesSupported      |
+-----+-----+
| "ACME+CF2A5091300089" | 2 (Computer System), 6 (Front-end Port), 8 (Volume), 10 (Disk Drive) |
+-----+-----+
pywbemcli>
```

In the first request we see SupportedFeatures does, indeed, contain the value "6" (as well as the value "3"). In the second request we also see that statistics are being kept for the Array itself, the front end port, storage volume and disk drive elements.

Next we will see what other capabilities are supported by running the following commands:

```
pywbemcli> instance enumerate CIM_BlockStatisticsCapabilities --pl
InstanceID,SynchronousMethodsSupported
Instances: CIM_BlockStatisticsCapabilities
```

```

+-----+-----+
| InstanceID          | SynchronousMethodsSupported |
+-----+-----+
| "ACME+CF2A5091300089" | 4 (GetStatisticsCollection), 5 (Manifest Creation), 6 (Manifest Modification), 7 (Manifest Removal) |
+-----+-----+
pywbemcli>
pywbemcli> instance enumerate CIM_BlockStatisticsCapabilities --pl InstanceID,ClockTickInterval
Instances: CIM_BlockStatisticsCapabilities
+-----+-----+
| InstanceID          | ClockTickInterval |
+-----+-----+
| "ACME+CF2A5091300089" | 100000 |
+-----+-----+
pywbemcli>

```

In the first request we see that the methods supported are GetStatisticsCollection, Manifest Creation, Manifest Modification and Manifest Removal. And in the second request we see that the implementation has a clock tick interval of 100000 microseconds.

Next we will look for what the BlockStatisticsCapabilities are related to with the following command:

```

pywbemcli> -o mof instance shrub CIM_BlockStatisticsCapabilities.?
CIM_BlockStatisticsCapabilities.InstanceID="ACME+CF2A5091300089"
+-- Capabilities(Role)
  +-- CIM_ElementCapabilities(AssocClass)
    +-- ManagedElement(ResultRole)
      +-- CIM_BlockStatisticsService(ResultClass)(1 insts)
        +-- /:CIM_BlockStatisticsService.~,Name="BlockStatisticsService",~,~
pywbemcli>

```

This command is a shrub command. It is looking for everything that is directly related to CIM\_BlockStatisticsCapabilities. The -o mof option says we want to switch to the mof format for the output for this command.

And we see the capabilities are related to an instance of CIM\_BlockStatisticsService (via the CIM\_ElementCapabilities association).

#### BLOCK STATISTICS SERVICE

So, let's get the related service.

```

pywbemcli> instance enumerate CIM_BlockStatisticsService --pl
Name,EnabledDefault,EnabledState,RequestedState,Started
Instances: CIM_BlockStatisticsService
+-----+-----+-----+-----+-----+
| Name          | EnabledDefault | EnabledState | RequestedState | Started |
+-----+-----+-----+-----+-----+

```

-----+-----+-----+-----+-----
"BlockStatisticsService"   2 (Enabled)   2 (Enabled)   12 (Not Applicable)   true
+-----+-----+-----+-----+-----+
pywbemcli>

We see that both the EnabledState and the EnabledDefault is Enabled and RequestedState is not applicable.

## STATISTICS COLLECTION

In terms of finding the statistics there are a couple of approaches to take. You could start with an element for which statistics are kept. But a more straightforward approach is to find the Statistics Collection. This collection collects all the statistics for all the element types.

So, lets find the statistics collection with the following command:

```
pywbemcli> -o mof instance enumerate CIM_StatisticsCollection
instance of CIM_StatisticsCollection {
    SampleInterval = "00000000001500.000000:000";
    TimeLastSampled = "20131029094525.737000-240";
    InstanceID = "ACME+CF2A5091300089";
    ElementName = "Statistics Collection";
};
pywbemcli>
```

The statistics collection identifies the sample interval (15 minutes) and the last time they statistics were collected.

Next, we need to inspect the shrub for the Statistics Collection.

```
pywbemcli> -o mof instance shrub CIM_StatisticsCollection.?
CIM_StatisticsCollection.InstanceID="ACME+CF2A5091300089"
+-- Statistics(Role)
| +-- CIM_AssociatedBlockStatisticsManifestCollection(AssocClass)
|   +-- ManifestCollection(ResultRole)
|       +-- CIM_BlockStatisticsManifestCollection(ResultClass)(1 insts)
|           +-- /:CIM_BlockStatisticsManifestCollection.InstanceID="ACME+CF2A5091300089+MANIFEST_DEFAULT"
+-- Dependent(Role)
| +-- CIM_HostedCollection(AssocClass)
|   +-- Antecedent(ResultRole)
|       +-- CIM_ComputerSystem(ResultClass)(1 insts)
|           +-- /:CIM_ComputerSystem.~,Name="ACME+CF2A5091300089"
+-- Collection(Role)
    +-- CIM_MemberOfCollection(AssocClass)
        +-- Member(ResultRole)
            +-- CIM_BlockStorageStatisticalData(ResultClass)(12 insts)
                +-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
                +-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
```

```

+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
+-- /:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
pywbemcli>

```

We see that there are three associations to other elements. There is a CIM\_AssociatedBlockStatisticsManifestCollection to a CIM\_BlockStatisticsManifestCollection. There is a CIM\_HostedCollection to a CIM\_ComputerSystem. And there is a CIM\_MemberOfCollection to a bunch of instances of CIM\_BlockStorageStatisticalData. These instances contain the statistic data for the element types identified in the CIM\_BlockStatisticsCapabilities.

We will start by looking at the instances of CIM\_BlockStorageStatisticalData.

#### BLOCK STATISTICAL DATA

We will look at one instance of each element type, starting with the Array. To illustrate what the Advanced Metrics offers, I will run two requests for each element type. The first command will retrieve the basic statistics and the second will retrieve the advanced statistics.

For the Array (type 2) the command to retrieve the basic statistics is:

```

pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl
InstanceID,ElementType,TotalIIOs,KBytesTransferred

```

Pick Instance name to process

```

0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"

```

Input integer between 0 and 11 or Ctrl-C to exit selection:

Input integer between 0 and 11 or Ctrl-C to exit selection: 0

Instances: CIM\_BlockStorageStatisticalData

```

+-----+-----+-----+-----+

```

InstanceID	ElementType	KBytesTransferred	TotalIOs
"ACME+CF2A5091300089+Array"	2 (Computer System)	66	132

pywbemcli>

The command to get the advanced statistics or the Array is:

```
pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl
InstanceID,ReadIOs,ReadHitIOs,KBytesRead,WriteIOs,WriteHitIOs,KBytesWritten

Pick Instance name to process
0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
Input integer between 0 and 11 or Ctrl-C to exit selection:
Input integer between 0 and 11 or Ctrl-C to exit selection: 0
Instances: CIM_BlockStorageStatisticalData
+-----+-----+-----+-----+-----+-----+
| InstanceID | KBytesRead | KBytesWritten | ReadHitIOs | ReadIOs | WriteHitIOs | WriteIOs |
+-----+-----+-----+-----+-----+-----+
| "ACME+CF2A5091300" | 66 | 0 | 1844272 | 132 | 1845899 | 0 |
| "089+Array" | | | | | | |
+-----+-----+-----+-----+-----+-----+
```

pywbemcli>

I repeated InstanceID to verify the two queries are on the same element. We see the Advanced Metrics adds quite a few property values over the basic support.

For the Front End Ports (type 6) the command to retrieve the basic statistics is:

```
pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl
InstanceID,ElementType,TotalIOs,KBytesTransferred

Pick Instance name to process
0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
```



```

6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
Input integer between 0 and 11 or Ctrl-C to exit selection:
Input integer between 0 and 11 or Ctrl-C to exit selection: 1
Instances: CIM_BlockStorageStatisticalData
+-----+-----+-----+-----+
| InstanceID          | ElementType      | KBytesTransferred | TotalIOs |
+-----+-----+-----+-----+
| "ACME+CF2A5091300089+FEPort+SP_A:" | 6 (Front-end Port) | 33 | 66 |
| "0"                  |                  |    |    |
+-----+-----+-----+-----+
pywbemcli>

```

This shows the basic metrics. Now we retrieve the advanced metrics:

```

pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl InstanceID,ElementType,IOTimeCounter
Pick Instance name to process
0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
Input integer between 0 and 11 or Ctrl-C to exit selection:
Input integer between 0 and 11 or Ctrl-C to exit selection: 1
Instances: CIM_BlockStorageStatisticalData
+-----+-----+-----+
| InstanceID          | ElementType      | IOTimeCounter |
+-----+-----+-----+
| "ACME+CF2A5091300089+FEPort+SP_A:0" | 6 (Front-end Port) | 935579 |
+-----+-----+-----+
pywbemcli>

```

We see the Advanced Metrics adds the IOTimeCounter statistic.

For the Storage Volumes (type 8) the command to retrieve the basic statistics is:



```
pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl
InstanceID,ElementType,TotalIOs,KBytesTransferred,ReadIOs,WriteIOs

Pick Instance name to process
0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
Input integer between 0 and 11 or Ctrl-C to exit selection:
Input integer between 0 and 11 or Ctrl-C to exit selection: 3

Instances: CIM_BlockStorageStatisticalData
+-----+-----+-----+-----+-----+-----+
| InstanceID | ElementType | KBytesTransferred | ReadIOs | TotalIOs | WriteIOs |
+-----+-----+-----+-----+-----+-----+
| "ACME+CF2A5091300089+" | 8 (Volume) | 66 | 132 | 132 | 0 |
| "Volume+00005" | | | | | |
+-----+-----+-----+-----+-----+-----+
```

This shows the basic metrics. Now we retrieve the advanced metrics:

```
pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl
InstanceID,ElementType,IOTimeCounter,KBytesRead,KBytesWritten

Pick Instance name to process
0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array"
1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0"
2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1"
3:
root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"
4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
Input integer between 0 and 11 or Ctrl-C to exit selection:
Input integer between 0 and 11 or Ctrl-C to exit selection: 3

Instances: CIM_BlockStorageStatisticalData
```

InstanceID	ElementType	IOTimeCounter	KBytesRead	KBytesWritten
"ACME+CF2A5091300089+Volume+0"	8 (Volume)	152996	66	0
"0005"				

pywbemcli>

We see the Advanced Metrics adds the IOTimeCounter, KBytesRead and KBytesWritten statistics.

For the Disk Drives (type 10) the command to retrieve the basic statistics is:

pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl InstanceID,ElementType,TotalIOs,KBytesTransferred,ReadIOs																					
Pick Instance name to process 0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array" 1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0" 2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1" 3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005" 4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0" 5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1" 6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2" 7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3" 8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4" 9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5" 10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6" 11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7" Input integer between 0 and 11 or Ctrl-C to exit selection:																					
Input integer between 0 and 11 or Ctrl-C to exit selection: 4																					
Instances: CIM_BlockStorageStatisticalData <table><tr><td>+-----+-----+-----+-----+-----+</td></tr><tr><td>  InstanceID</td><td>  ElementType</td><td>  KBytesTransferred</td><td>  ReadIOs</td><td>  TotalIOs</td><td> </td></tr><tr><td> -----+-----+-----+-----+----- </td></tr><tr><td>  "ACME+CF2A5091300089+Disk"</td><td>  10 (Disk Drive)</td><td>  453576349</td><td>  38658792</td><td>  39726146</td><td> </td></tr><tr><td>  "+0_0_0"</td><td> </td><td> </td><td> </td><td> </td><td> </td></tr><tr><td>+-----+-----+-----+-----+-----+</td></tr></table>	+-----+-----+-----+-----+-----+	InstanceID	ElementType	KBytesTransferred	ReadIOs	TotalIOs		-----+-----+-----+-----+-----	"ACME+CF2A5091300089+Disk"	10 (Disk Drive)	453576349	38658792	39726146		"+0_0_0"						+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+																					
InstanceID	ElementType	KBytesTransferred	ReadIOs	TotalIOs																	
-----+-----+-----+-----+-----																					
"ACME+CF2A5091300089+Disk"	10 (Disk Drive)	453576349	38658792	39726146																	
"+0_0_0"																					
+-----+-----+-----+-----+-----+																					
pywbemcli>																					

This shows the basic metrics. Now we retrieve the advanced metrics

pywbemcli> instance get CIM_BlockStorageStatisticalData.? --pl InstanceID,IOTimeCounter,KBytesRead,WritelOs,KBytesWritten,IdleTimeCounter
Pick Instance name to process 0: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Array" 1: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:0" 2: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+FEPort+SP_A:1" 3: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Volume+00005"

```

4: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_0"
5: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_1"
6: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_2"
7: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_3"
8: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_4"
9: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_5"
10: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_6"
11: root/cimv2:CIM_BlockStorageStatisticalData.InstanceID="ACME+CF2A5091300089+Disk+0_0_7"
Input integer between 0 and 11 or Ctrl-C to exit selection:
Input integer between 0 and 11 or Ctrl-C to exit selection: 4
Instances: CIM_BlockStorageStatisticalData
+-----+-----+-----+-----+-----+
| InstanceID          | IdleTimeCounter | IOTimeCounter | KBytesRead | KBytesWritten | WriteIOs |
+-----+-----+-----+-----+-----+
| "ACME+CF2A5091300089+" | 460929424 | 1941691 | 428873067 | 24703282 | 1067354 |
| "Disk+0_0_0"          |              |              |              |              |              |
+-----+-----+-----+-----+-----+
pywbemcli>

```

The advance metrics add quite a few statistics. Actually, Advanced Metrics calls for EITHER the IOTimeCounter OR the IdleTimeCounter.

#### BLOCK STATISTICS MANIFESTS AND COLLECTION

One last thing to point out on the block server performance profile. The CIM\_BlockStatisticsManifestCollection associated with the Statistics Collection (see the shrub for the CIM\_StatisticsCollection) contains manifests for each of the element types. There is some important information in these manifests. So, let's look at those manifests:

```

pywbemcli> -o mof instance shrub CIM_BlockStatisticsManifestCollection.? --ac CIM_MemberOfCollection
CIM_BlockStatisticsManifestCollection.InstanceID="ACME+CF2A5091300089+MANIFEST_DEFAULT"
+-- Collection(Role)
+-- CIM_MemberOfCollection(AssocClass)
+-- Member(ResultRole)
+-- CIM_BlockStatisticsManifest(ResultClass)(4 insts)
+-- /:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+Array"
+-- /:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+Disk"
+-- /:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+FEPort"
+-- /:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+Volume"
pywbemcli>

```

Here we see there are default manifests for each element type. So, let's look at one to illustrate what the manifest tells us.

```

pywbemcli> -o mof instance get CIM_BlockStatisticsManifest.?
Pick Instance name to process
0: root/cimv2:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+Array"
1: root/cimv2:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+Disk"
2: root/cimv2:CIM_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+FEPort"

```

3: root/cimv2:CIM\_BlockStatisticsManifest.InstanceID="ACME+CF2A5091300089+ACMEMANIFEST\_DEFAULT+Volume"  
 Input integer between 0 and 3 or Ctrl-C to exit selection:

We will look at the manifest for the Array (selection 0).

Input integer between 0 and 3 or Ctrl-C to exit selection: 0

```
instance of CIM_BlockStatisticsManifest {
  InstanceID = "ACME+CF2A5091300089+ACMEMANIFEST_DEFAULT+Array";
  ElementType = 2;
  RateElementType = 0;
  IncludeStartStatisticTime = false;
  IncludeStatisticTime = true;
  IncludeTotalIOs = true;
  IncludeKBytesTransferred = true;
  IncludeIOTimeCounter = true;
  IncludeReadIOs = true;
  IncludeReadHitIOs = true;
  IncludeReadIOTimeCounter = false;
  IncludeReadHitIOTimeCounter = false;
  IncludeKBytesRead = true;
  IncludeWriteIOs = true;
  IncludeWriteHitIOs = true;
  IncludeWriteIOTimeCounter = false;
  IncludeWriteHitIOTimeCounter = false;
  IncludeKBytesWritten = true;
  IncludeIdleTimeCounter = false;
  IncludeMaintOp = false;
  IncludeMaintTimeCounter = false;
  CSVSequence = { "InstanceID", "ElementType", "StatisticTime", "TotalIOs",
    "KBytesTransferred", "IOTimeCounter", "ReadIOs", "ReadHitIOs",
    "KBytesRead", "WriteIOs", "WriteHitIOs", "KBytesWritten" };
  CSVRateSequence = { };
  IncludeRateIntervalStartTime = false;
  IncludeRateIntervalEndTime = false;
  IncludeTotalIOsRate = false;
  IncludeKBytesTransferredRate = false;
  IncludeReadIOsRate = false;
  IncludeReadHitIOsRate = false;
  IncludeKBytesReadRate = false;
  IncludeWriteIOsRate = false;
  IncludeWriteHitIOsRate = false;
  IncludeKBytesWrittenRate = false;
  IncludeMaintOpRate = false;
  ElementName = "ACME+CF2A5091300089:DEFAULT";
};

pywbemcli>
```

The first thing we see is that the manifest contains a lot of "Include ..." properties. This tells us what statistics are kept for the element type. These are booleans. A value of true means the statistic is kept.

Next there is the CSVSequence property. It tells what sequence the data should be ordered in a data record (this is unrelated to the sequence provided by CIM or pywbem or the pywbemcli). When the data is retrieved and written to a file, the CSVSequence identifies the desired order of headers and values.