

AIM-Edge ncox/ncon  
Jetpack 6.1 Developer Image Refresh

User Manual

28 November 2024  
Version 2.1

## Content

1.	Introduction .....	1
2.	Board Overview .....	1
3.	Getting Started.....	2
3.1.	Hardware Requirement .....	2
3.2.	Download Image & Root FileSystem Backup Package.....	2
3.3.	Image Refresh Procedures.....	4
3.4.	Enter Force USB Recovery Mode .....	4
3.5.	AlMobile Container Usage.....	5
3.6.	Image Backup/Restore .....	5
3.7.	Root FileSystem Package in Parts.....	6
4.	Known Issue .....	7

CONFIDENTIAL


## Revision History

Date	Version	Modification
2023/7/7	1.0	Creation
2023/10/2	1.1	1. Modified for Jetpack 5.1.2 2. Add a known issue for boot logo disappear
2023/10/3	1.2	Add image backup/restore command
2023/10/4	1.3	Wording modification
2023/10/18	1.4	Add warning message to restore image to the same type SoM only
2023/10/24	1.5	The image refresh package is split to image file and root filesystem package.
2023/11/13	1.6	Rename the pre-installed docker image to AIMobile docker
2024/09/05	2.0	Upgrade to Jetpack 6.0
2024/11/26	2.1	Upgrade to Jetpack 6.1

## 1. Introduction

This document is to describe how to download Jetpack 6.1 system image to AIM-Edge ncox/ncon device, including hardware requirement, download environment & image preparation and download procedures.

## 2. Board Overview



## 3. Getting Started

### 3.1. Hardware Requirement

1. Linux Host PC/Notebook with Ubuntu Linux X64 20.04 or 18.04
2. USB Type-A to Micro USB cable (to connect Host PC/NB to AIM-Edge ncox/ncon)

### 3.2. Download Image & Root FileSystem Backup Package

1. Check the OneDrive URL provided by AIMobile for image refresh package ([O1\\_dev\\_6.1\\_V01](#) in the example below), two files will be there, they are the image file ([O1\\_dev\\_6.1\\_V01.tar.bz2](#)) and the root filesystem backup package ([nvme0n1p1.tar.zst](#)).

Lin.StevenYY 林彥宇 AIM > O1\_dev\_6.1 > O1\_dev\_6.1\_V01

名稱	修改...	修改者	檔案大小
O1_dev_6.1_V01_OTA	33 分鐘前	Lin.StevenYY 林彥宇	4 個項目
MD5	33 分鐘前	Lin.StevenYY 林彥宇	398 個位元組
nvme0n1p1.tar.zst	33 分鐘前	Lin.StevenYY 林彥宇	12.3 GB
O1_dev_6.1_V01.tar.bz2	33 分鐘前	Lin.StevenYY 林彥宇	826 MB

2. Download all files to Linux Host PC/NB, and extract the image file ([O1\\_dev\\_6.1\\_V01.tar.bz2](#)) with the command “`tar -jxvf O1_dev_6.1_V01.tar.bz2`”. The image burning script [O1\\_flash.sh](#) and the prerequisites script [l4t\\_flash\\_prerequisites.sh](#) is in the extracted file folder ([O1\\_dev\\_6.1\\_V01/](#)).

名稱	大小
bootloader	869 862 917
kernel	44 312 816
rootfs	104 730 304
tools	445 817 936
nv_tegra	1 706
p3768-0000-p3767-0000-a0.conf	4 652
flash.sh	152 568
jetson-orin-nano-devkit.conf	1 902
p3767.conf.common	8 276
l4t_flash_prerequisites.sh	2 529
O1_flash.sh	89

3. Move the root filesystem backup package ([nvme0n1p1.tar.zst](#)) to the sub folder “[./tools/backup\\_restore/images/](#)” of the image package extracted folder ([O1\\_dev\\_6.1\\_V01/](#)). The root filesystem backup package will be used as a base of the image refresh process.

CONFIDENTIAL

### 3.3. Image Refresh Procedures

1. Run prerequisites script([l4t\\_flash\\_prerequisites.sh](#)) on Linux Host PC to prepare download environment, it only needs to do once on the Linux Host PC/NB.
2. Connect Linux Host PC/NB to AIM-Edge ncox/ncon device with USB Type-A to Micro USB cable
3. Put ncox/ncon to force USB recovery mode. (check Section 3.4 below)
4. Enter the extracted image refresh package folder on Linux Host PC/NB and execute [O1\\_flash.sh](#) to download image to ncox/ncon, it takes around 15 minutes.
5. After image is refreshed, ncox/ncon will reboot automatically.

### 3.4. Enter Force USB Recovery Mode

To update your device, you must be in Force USB Recovery Mode so that you can transfer system image to the Jetson device. To place device in Force USB Recovery Mode,

1. Power down the device. If connected, remove the DC power from the device. The device must be powered OFF, and not in a suspend or sleep state.
2. Connect the Micro-B plug on the USB cable to the Recovery (USB Micro-B) Port on the device and the other end to an available USB port on the host PC.
3. Connect the power adapter to the device.
4. With the system powered on:
  - Press and hold the RECOVERY button with paperclip.
  - While pressing the RECOVERY button, press and release the RESET button with paperclip.
  - Wait 2 seconds and release the RECOVERY button.
5. After ncox/ncon enter Force USB Recovery Mode, if it connected to Linux Host PC/NB already, execute “lsusb” command on Host PC/NB, a “0955:7323 NVidia Corp.” device will appear. If not, perform Step 4 above again.

```
Bus 002 Device 001: ID 1d6b:0003 Linux Foundation 3.0 root hub
Bus 001 Device 074: ID 0955:7323 NVidia Corp.
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
```

Jetson SoM	USB ID
Orin NX 16GB	0955:7323
Orin NX 8GB	0955:7423
Orin Nano 8GB	0955:7523
Orin Nano 4GB	0955:7623

### 3.5. AIMobile Container Usage

Please check [readme.txt](#) on Ubuntu desktop about pre-installed AIMobile container usage including how to relocate the container image.

The AIMobile container image is pre-installed to root file system, it takes around 13GB, and it can be removed with “[docker system prune -af](#)” command.

```
aim@AIM-dev-4737:~$ docker images
REPOSITORY          TAG          IMAGE ID      CREATED      SIZE
aimobile/l4t-jetpack r35.4.1     353b9824dd21 2 weeks ago  12.9GB
```

### 3.6. Image Backup/Restore

To backup/restore the device image to host machine, you can use the tool script in the image refresh package. The command is as below, and the image backup folder is at “[./tools/backup\\_restore/images](#)” under the image refresh package extracted folder. Besides, it needs to put ncox/ncon to force USB recovery mode (refer to section 3.4) before restore image.

Backup Image:

```
sudo ./tools/backup_restore/l4t_backup_restore.sh -b jetson-orin-nano-devkit
```

Restore Image:

```
sudo ./tools/backup_restore/l4t_backup_restore.sh -r jetson-orin-nano-devkit
```

**Warning:** The backup image should be restored to the same type of SoM only (e.g., Orin NX 16G to Orin NX 16G is OK, not Orin NX 8G or Orin Nano).










### 3.7. Root Filesystem Package in Parts

If user meets problem on downloading OTA image file because of slow internet speed, we split the nvme0n1p1.tar.zst file to 2GB files to ease the downloading process. After all split files are downloaded, they can be combined with the command below.

```
cat nvme0n1p1.tar.zst-part* > nvme0n1p1.tar.zst
```

Lin.StevenYY 林彥宇 AIM > O1\_dev\_6.1 > O1\_dev\_6.1\_V01

名稱 ↑	修改時間	修改者	檔案大小
 nvme0n1p1.tar.zst-part00	昨天 11:36 PM	Lin.StevenYY 林彥宇	2 GB
 nvme0n1p1.tar.zst-part01	昨天 11:36 PM	Lin.StevenYY 林彥宇	2 GB
 nvme0n1p1.tar.zst-part02	昨天 11:37 PM	Lin.StevenYY 林彥宇	2 GB
 nvme0n1p1.tar.zst-part03	15 小時前	Lin.StevenYY 林彥宇	2 GB
 nvme0n1p1.tar.zst-part04	14 小時前	Lin.StevenYY 林彥宇	2 GB
 nvme0n1p1.tar.zst-part05	14 小時前	Lin.StevenYY 林彥宇	2 GB
 nvme0n1p1.tar.zst-part06	14 小時前	Lin.StevenYY 林彥宇	344 MB

#### 4. Known Issue

N/A

CONFIDENTIAL