

# **WCDMA UGxx MMS**

# **AT Commands Manual**

**UMTS/HSPA Module Series**

Rev. WCDMA\_UGxx\_MMS\_AT\_Commands\_Manual\_V1.2

Date: 2015-04-01



**Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:**

**Quectel Wireless Solutions Co., Ltd.**

Office 501, Building 13, No.99, Tianzhou Road, Shanghai, China, 200233

Tel: +86 21 5108 6236

Mail: [info@quectel.com](mailto:info@quectel.com)

**Or our local office, for more information, please visit:**

<http://www.quectel.com/support/salesupport.aspx>

**For technical support, to report documentation errors, please visit:**

<http://www.quectel.com/support/techsupport.aspx>

Or Email: [Support@quectel.com](mailto:Support@quectel.com)

**GENERAL NOTES**

QUECTEL OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

**COPYRIGHT**

THIS INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTABLE, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THIS CONTENTS ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

**Copyright © Quectel Wireless Solutions Co., Ltd. 2015. All rights reserved.**

# About the Document

## History

Revision	Date	Author	Description
1.0	2014-12-13	Jonathan WEN	Initial
1.1	2015-03-03	Yolanda YAO	1. Changed the document name from "UG95" to "UGxx". 2. Modified the maximum length of the attachment file name to 80 bytes. 3. Modified the range of <contextID> to 1-20.
1.2	2015-04-01	Yolanda YAO	Updated applicable modules.

## Contents

About the Document.....	2
Contents .....	3
Table Index.....	4
<b>1 Introduction .....</b>	<b>5</b>
1.1. General Process of Sending MMS Message.....	5
1.2. Error Handling .....	6
1.2.1. Executing MMS AT Command Fails .....	6
1.2.2. PDP Activation Fails .....	6
1.2.3. Error Response of AT+QMMSSEND .....	6
<b>2 Description of AT Command .....</b>	<b>7</b>
2.1. AT+QMMSCFG Configure the Parameters of MMS .....	7
2.2. AT+QMMSEDIT Edit MMS Message .....	9
2.2.1. Add the Recipient Address.....	11
2.2.2. Add CC Recipient or BCC Recipient .....	11
2.2.3. Edit the Title of MMS Message .....	12
2.2.4. Add Attachment.....	12
2.2.5. Clear all the Content of MMS Message.....	14
2.3. AT+QMMSSEND Send MMS Message .....	14
<b>3 Example .....</b>	<b>16</b>
3.1. Send MMS Message.....	16
<b>4 Summary of Error Codes .....</b>	<b>20</b>
<b>5 Description of HTTP Response Codes.....</b>	<b>22</b>
<b>6 Appendix A Reference.....</b>	<b>23</b>

## Table Index

TABLE 1: SUMMARY OF ERROR CODES .....	20
TABLE 2: DESCRIPTION OF HTTP RESPONSE CODE .....	22
TABLE 3: RELATED DOCUMENTS .....	23
TABLE 4: TERMS AND ABBREVIATIONS .....	23

Quectel  
Confidential

# 1 Introduction

UGxx provides MMS application interface for sending messages including multimedia objects (image, audio, rich text, etc.). This document is a reference guide to all the AT commands defined for MMS.

This document is applicable to UGxx modules.

## 1.1. General Process of Sending MMS Message

**Step 1:** Configure and activate the PDP context.

- 1) Configure the PDP context parameters of <apn>, <username>, <password> and other parameters by AT+QICSGP (For more details, please refer to *Quectel\_WCDMA\_UGxx\_TCPIP\_AT\_Commands\_Manual*). If QoS settings need to be updated, configure them by commands AT+CGQMIN, AT+CGEQMIN, AT+CGQREQ and AT+CGEQREQ (Please refer to *Quectel\_WCDMA\_UGxx\_AT\_Commands\_Manual*).
- 2) Activate the PDP context by AT+QIACT.
- 3) Configure the PDP context ID for MMS by AT+QMMSCFG="contextid",<contextID>.

**Step 2:** Configure the URL and proxy of MMSC.

- 1) Configure the URL of MMSC by AT+QMMSCFG="mmsc",<URL>.
- 2) Configure the proxy of MMSC by AT+QMMSCFG="proxy",<gateway>,<port>.

**Step 3:** Configure the sending parameters.

Configure the sending parameters by AT+QMMSCFG="sendparam",<valid>,<pri>,<sendrep>,<visible>,<class>.

**Step 4:** Edit the MMS message.

- 1) Add recipient address by AT+QMMSEDT=1,1,<optstring>.
- 2) Add CC recipient address by AT+QMMSEDT=2,1,<optstring>.
- 3) Add BCC recipient address by AT+QMMSEDT=3,1,<optstring>.
- 4) Edit the title by AT+QMMSEDT=4,1,<optstring>. You should specify the character set as title by AT+QMMSCFG="character",<charset> first.
- 5) Add attachments by AT+QMMSEDT=5,1,<optstring>. The attachments can be RAM files. And you can upload a file to RAM by AT+QFUP command (Please refer to *Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_Manual*). After sending MMS message successfully, you should delete the file by AT+QFDEL command (Please refer to *Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_Manual*). If the attachment is a text file, you should specify the character

set by AT+QMMSCFG="character",<charset> first.

**Step 5:** Send MMS message by AT+QMMSEND=<timeout>. It may take some time to send MMS message successfully. You should not send MMS message again before "+QMMSEND:<err>,<httprsp>[,<mmsrsp>]" which indicates the ending of MMS message sending.

**Step 6:** Clear the content of MMS message by AT+QMMSEDT=0 and delete the files as attachments by AT+QFDEL (Please refer to *Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_Manual*).

Step 4 to step 6 can be repeated. And step 2 to step 6 can be repeated too.

## 1.2. Error Handling

### 1.2.1. Executing MMS AT Command Fails

If you execute MMS AT command and receive response "ERROR" from UGxx module, please check if the SIM card is inserted and CPIN is in "+CPIN: READY" status by executing command "AT+CPIN?".

### 1.2.2. PDP Activation Fails

If you failed to activate PDP context by AT+QIACT command, please check the following aspects:

1. Query whether the PS domain is attached by AT+CGATT? command or not. If not, please execute AT+CGATT=1 command to attach PS domain.
2. Query the PS domain status by AT+CGREG? and make sure the PS domain is registered.
3. Query the PDP context parameters by AT+QICSGP command and make sure the APN of specified PDP context is set.
4. Make sure the specified PDP context ID is neither used by PPP nor activated by AT+CGACT.
5. According to 3GPP specification, it only supports three PDP contexts activated simultaneously, so you must make sure the number of activated PDP contexts is less than 3.

If the result of checking is OK, but you still fail to activate PDP context by executing AT+QIACT command, please reboot the module to resolve this issue. After booting the module, please check the terms mentioned above at least three times and each time at an interval of 10 minutes to avoid frequently rebooting the module.

### 1.2.3. Error Response of AT+QMMSEND

+QMMSEND: <err>,<httprsp>[,<mmsrsp>] will be returned after operating AT+QMMSEND. If <err> is not 0, it indicates the sending is failed, please resend it. If resending is not successfully, you should deactivate the PDP context by AT+QIDEACT command, and try again. (Please refer to Chapter 1.2.2).

## 2 Description of AT Command

### 2.1. AT+QMMSCFG Configure the Parameters of MMS

You can configure the PDP context ID, MMSC, proxy, character type and sending parameter of MMS by AT+QMMSCFG.

AT+QMMSCFG Configure the Parameters of MMS	
Test Command <b>AT+QMMSCFG=?</b>	Response <b>+QMMSCFG: "contextid",(1-20)</b> <b>+QMMSCFG: "mmsc",&lt;url&gt;</b> <b>+QMMSCFG: "proxy",&lt;gateway&gt;,(1-65535)</b> <b>+QMMSCFG:</b> <b>"character",("ASCII","UTF8","UCS2","GBK")</b> <b>+QMMSCFG:</b> <b>"sendparam"[,(0-6),(0-3),(0,1),(0,1),(0-2),(0-4)]</b>  <b>OK</b>
Write Command <b>AT+QMMSCFG="contextid",&lt;contextid&gt;]</b>	Response If <contextid> is not omitted, <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>  Else, query the current settings, <b>+QMMSCFG: "contextid",&lt;contextID&gt;</b>  <b>OK</b>
Write Command <b>AT+QMMSCFG="mmsc",&lt;url&gt;]</b>	Response If <URL> is not omitted, <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>  Else, query the current settings, <b>+QMMSCFG: "mmsc",&lt;URL&gt;</b>



	OK
Write Command <b>AT+QMMSCFG="proxy",&lt;gateway&gt;,&lt;port&gt;]</b>	Response If <gateway> and <port> are not omitted, <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>  Else, query the current settings, <b>+QMMSCFG: "proxy",&lt;gateway&gt;,&lt;port&gt;</b>  <b>OK</b>
Write Command <b>AT+QMMSCFG="character",&lt;charset&gt;]</b>	Response If <charset> is not omitted, <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>  Else, query the current settings, <b>+QMMSCFG: "character",&lt;charset&gt;</b>  <b>OK</b>
Write Command <b>AT+QMMSCFG="sendparam",&lt;valid&gt;,&lt;pri&gt;,&lt;sendrep&gt;,&lt;readrep&gt;,&lt;visible&gt;,&lt;class&gt;]</b>	Response If <valid>,<pri>,<sendrep>,<readrep>,<visible>,<class> are not omitted, <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>  Else, query the current settings, <b>+QMMSCFG: "sendparam",&lt;valid&gt;,&lt;pri&gt;,&lt;sendrep&gt;,&lt;readrep&gt;,&lt;visible&gt;,&lt;class&gt;</b>  <b>OK</b>

## Parameter

<b>&lt;contextID&gt;</b>	Integer type, PDP context ID, the range is 1-20, default value is 1
<b>&lt;url&gt;</b>	String type, the address of MMSC, the maximum length of URL is 100 bytes
<b>&lt;gateway&gt;</b>	String type, the IP address of MMS proxy, the maximum length of gateway is 50 bytes
<b>&lt;port&gt;</b>	Integer type, the port of MMS proxy. The range is 1-65535
<b>&lt;charset&gt;</b>	String type, indicates the type of character
	"ASCII" US-ASCII character set
	"UTF8" UTF8 character set

	"UCS2"	ISO-10646-UCS-2 character set, this needs to specify Big Endian order
	"GBK"	GBK character set
<valid>	Integer type, the validity period of MMS message	
	0	1 hour
	1	12 hours
	2	24 hours
	3	2 days
	4	1 week
	5	Maximum
	6	Use the network configuration
<pri>	Integer type, priority	
	0	Low
	1	Normal
	2	High
	3	Use the network configuration
<sendrep>	Integer type, whether need to delivery report	
	0	No
	1	Yes
<readrep>	Integer type, whether need to read report	
	0	No
	1	Yes
<visible>	Integer type, whether to hide address	
	0	Hide any address
	1	Show even BCC address
	2	Use the network configuration
<class>	Integer type, the class of the MMS message	
	0	Personal
	1	Advertisement
	2	Informational
	3	Auto
	4	Use the network configuration
<err>	Integer type, indicates the type of error, please refer to Chapter 4	

## 2.2. AT+QMMSEDT Edit MMS Message

You can add recipient address, edit title and add attachments for MMS message by AT+QMMSEDT. The character set of title or a text file is specified by AT+QMMSCFG="character",<charset>. For example, if the content of a text file uses UTF8 character set, AT+QMMSCFG="character", "UTF8" must be executed first.

## AT+QMMSEdit Edit MMS Message

Test Command <b>AT+QMMSEdit=?</b>	Response <b>+QMMSEdit: (0-5),(0,1),&lt;optstring&gt;</b>  <b>OK</b>
Write Command <b>AT+QMMSEdit=0</b>	Delete all content about MMS message, response: <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>
Write Command <b>AT+QMMSEdit=&lt;function&gt;</b> <function> is not 0	Query the specified settings of <function>, response: <b>List of [+QMMSEdit: &lt;function&gt;,&lt;optstring&gt;]</b> <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>
Write Command <b>AT+QMMSEdit=&lt;function&gt;,0</b>	Delete the specified settings of <function>, response: <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>
Write Command <b>AT+QMMSEdit=&lt;function&gt;,1,&lt;optstring&gt;</b>	Configure the specified settings of <function>, response: <b>OK</b> or <b>+CME ERROR: &lt;err&gt;</b>

### Parameter

<b>&lt;function&gt;</b>	Integer type, operated function 0 Delete all 1 Operate "TO address" 2 Operate "CC address" 3 Operate "BCC address" 4 Operate title 5 Operate file as attachment
<b>&lt;optstring&gt;</b>	String type If <function>=1, 2, 3, it is recipient address. The maximum number of "TO address", "CC address" and "BCC address" is 6 respectively. The maximum length of address is 50 bytes If <function>=4, it is the title. The maximum length of title is 200 bytes If <function>=5, it is the file name of attachments. If the file name is started with "RAM:", the file is from "RAM". It is strongly recommended to use RAM file to upload the attachments. The max length of file name is 80 bytes, the maximum number of

attachments is 12, and the maximum size of total attachments is restricted by the operator

**<err>** Integer type, indicates the type of error, please refer to Chapter 4

The following examples show how to edit a MMS message.

### 2.2.1. Add the Recipient Address

//You can add phone number or email address as recipients. The maximum number of recipients address is 6.

**AT+QMMSEdit=1,1,"13856122546"** //Add a phone number as recipient.

OK

**AT+QMMSEdit=1,1,"recipient.test@quectel.com"** //Add an email address as recipient.

OK

**AT+QMMSEdit=1** //Query recipient address.

+QMMSEdit: 1,"13856122546"

+QMMSEdit: 1,"recipient.test@quectel.com"

OK

//Of course, if you want to delete the recipient address, you can run AT+QMMSEdit=1,0 as follows:

**AT+QMMSEdit=1,0** //Delete recipient.

OK

**AT+QMMSEdit=1** //Query recipient address.

OK

### 2.2.2. Add CC Recipient or BCC Recipient

//Add CC recipient or BCC recipient. The operation is the same as adding recipient address, the difference is <function> value. For CC recipient, the <function> value is 2, for BCC recipient, it is 3.

**AT+QMMSEdit=2,1,"13856122546"** //Add a phone number as CC recipient.

OK

**AT+QMMSEdit=2** //Query CC recipient address.

+QMMSEdit: 2,"13856122546"

OK

//Of course, if you want to delete the CC recipient address, you can run AT+QMMSEdit=2,0 as follows:

**AT+QMMSEdit=2,0** //Delete CC recipient.

OK

**AT+QMMSEdit=2** //Query CC recipient address.

OK

### 2.2.3. Edit the Title of MMS Message

//The character set of title is set by AT+QMMSCFG="character",<charset>. If the <charset> is "ASCII", add title as follows:

```
AT+QMMSCFG="character","ASCII"           //Set the charset as "ASCII".
OK
AT+QMMSEDT=4,1,"test UGxx mms"           //Edit the title of MMS message.
OK
AT+QMMSEDT=4                               //Query the title of MMS message.
+QMMSEDT: 4,"ASCII","test UGxx mms"
OK
```

//If the <charset> is not ASCII, the <optstring> should be the hex string of the inputted data.

```
AT+QMMSCFG="character","UTF8"           //Set the charset as "UTF8".
OK
AT+QMMSEDT=4,1,"746573742075633230206D6D73" //Edit the title of MMS message,
                                              "746573742075633230206D6D73" is the
                                              hex string of "test UGxx mms" in UTF8.
OK
AT+QMMSEDT=4                               //Query the title of MMS message.
+QMMSEDT: 4,"UTF8","746573742075633230206D6D73"
```

OK

//Of course, if you want to delete the title, you can run AT+QMMSEDT=4,0.

```
AT+QMMSEDT=4,0                           //Delete the title of MMS message.
OK
AT+QMMSEDT=4                               //Query the title of MMS message.
+QMMSEDT: 4,"UTF8",""
```

OK

### 2.2.4. Add Attachment

//You can add attachments for MMS message. The attachments can be RAM files. It is strongly recommended to use RAM file to upload the attachments. The maximum number of attachments is 12, and the maximum length of file name is 80 bytes. The total size of attachments may be restricted by the Operator. In the following example, the attachment is a RAM text file:

```
AT+QFUP="RAM:test_mms.txt",100,200,1 //Upload a file to RAM, the file will be saved as
                                         "test_mms.txt" and the maximum size of file is 100
                                         bytes. 200 indicates timeout, 1 indicates ACK mode.
```

(Please refer to *Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_Manual*).

CONNECT

<Input 100 bytes data>

+QFUPL: 100,0

OK

AT+QFLST="RAM:\*

//Query the file list of RAM.

+QFLST: "RAM:test\_mms.txt",100

OK

AT+QMMSCFG="character","ASCII"

//Set the charset as "ASCII" for "RAM:test\_mms.txt".

OK

AT+QMMSEdit=5,1,"RAM:test\_mms.txt"

//Add attachment for MMS message.

OK

AT+QMMSEdit=5

//Query the attachments.

+QMMSEdit: 5,"RAM:test\_mms.txt"

OK

//In the following example, the attachment is a RAM JPG file:

AT+QFUPL="RAM:test\_pic.jpg",200,300,1

//Upload a file to RAM, the file will be saved as "test\_pic.jpg" and the maximum size of file is 200 bytes. 300 indicates timeout, 1 indicates ACK mode. (Please refer to *Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_Manual*).

CONNECT

<Input 200 bytes data>

+QFUPL: 200,0

OK

AT+QFLST="RAM:\*

//Query the file list of RAM.

+QFLST: "RAM:test\_mms.txt",100

+QFLST: "RAM:test\_pic.jpg",200

OK

AT+QMMSEdit=5,1,"RAM:test\_pic.jpg"

//"RAM:test\_pic.jpg" is not text file, you need not specify the character set.

OK

AT+QMMSEdit=5

//Query the attachments.

+QMMSEdit: 5,"RAM:test\_mms.txt"

+QMMSEdit: 5,"RAM:test\_pic.jpg"

OK

//If you want to delete the attachments, do as follows:

```
AT+QMMSEdit=5,0           //Delete attachments for MMS message, all attachments
                             will be deleted.

OK
AT+QMMSEdit=5               //Query the attachments.
OK

//After sending MMS message successfully, you should delete the files by AT+QFDEL.

AT+QFDEL="RAM:test_mms.txt" //Delete the RAM file.
OK
AT+QFDEL="RAM:test_pic.jpg" //Delete the RAM file.
OK
AT+QFLST="RAM:*"            //Query the file list of RAM.
OK
```

### 2.2.5. Clear all the Content of MMS Message

//AT+QMMSEdit=0 will delete the recipient, CC recipients, BCC recipients, title and attachments of MMS message.

```
AT+QMMSEdit=0               //Clear all the content of MMS message.
OK
AT+QMMSEdit=1               //Query the recipients.
OK
AT+QMMSEdit=2               //Query the CC recipients.
OK
AT+QMMSEdit=3               //Query the BCC recipients.
OK
AT+QMMSEdit=4               //Query the title of MMS message.
+QMMSEdit: 4,"ASCII",""
OK
AT+QMMSEdit=5               //Query the attachments.
OK
```

## 2.3. AT+QMMSEND Send MMS Message

AT+QMMSEND is used to send MMS message. You should not re-execute AT+QMMSEND until "+QMMSEND: <err>,<httprsp>,<mmsrsp>" is returned. When the <timeout> is reached, but the process of sending MMS message has not finished yet, MMS sending will be interrupted.

## AT+QMMSEND Send MMS Message

Test Command  
**AT+QMMSEND=?**

Response  
**+QMMSEND: (1-65535)**

**OK**

Write Command  
**AT+QMMSEND=<timeout>**

Response  
**OK**

**+QMMSEND: <err>,<httprsp>[,<mmsrsp>]**

or

**+CME ERROR: <err>**

### Parameter

<b>&lt;timeout&gt;</b>	Integer type, the maximum time to send MMS. The unit is second. The range is 1-65535.
<b>&lt;err&gt;</b>	If you send MMS successfully, <err> is 0, else <err> indicates the type of error, please refer to Chapter 4
<b>&lt;httprsp&gt;</b>	Integer type, the reply code of HTTP, for reference only. For example, 200 indicates HTTP posts data successfully, please refer to Chapter 5
<b>&lt;mmsrsp&gt;</b>	String type, the reply string from MMSC when sending MMS message failed, for reference only

### Example

**AT+QMMSEND=100**

//Send MMS message.

**OK**

**+QMMSEND: 0,200**

//Indicate the result of sending MMS message.



## 3 Example

### 3.1. Send MMS Message

//Step 1: Configure and activate the PDP context.

**AT+QICSGP=1,1,"UNIWAP","", "",1**

//Configure PDP context 1, APN is "UNIWAP" for China Unicom.

OK

**AT+QIACT=1**

//Activate PDP context 1.

OK

//Activate successfully.

**AT+QIACT?**

//Query the state of PDP context.

**+QIACT: 1,1,1,"10.7.157.1"**

OK

**AT+QMMSCFG="contextid",1**

//Set the PDP context ID as 1. The PDP context ID must be activated first.

OK

**AT+QMMSCFG="contextid"**

//Query the PDP context ID.

**+QMMSCFG: "contextid",1**

OK

//Step 2: Configure the URL and proxy of MMSC.

**AT+QMMSCFG="mmsc","mmsc.myuni.com"**

//Configure the URL of MMSC, "mmsc.myuni.com" is for China Unicom.

OK

**AT+QMMSCFG="mmsc"**

//Query the URL of MMSC.

**+QMMSCFG: "mmsc","mmsc.myuni.com"**

OK

**AT+QMMSCFG="proxy","10.0.0.172",80**

//Configure the proxy address and port of MMSC "10.0.0.172:80" is for China Unicom.

OK

**AT+QMMSCFG="proxy"**

//Query the proxy address and port of MMSC.

**+QMMSCFG: "proxy","10.0.0.172",80**

OK

//Step 3: Configure sending parameter.

**AT+QMMSCFG="sendparam",6,2,0,0,2,4**

**OK**

**AT+QMMSCFG="sendparam"**

**+QMMSCFG: "sendparam",6,2,0,0,2,4**

**OK**

//Step 4: Edit the MMS message.

**AT+QMMSEdit=1,1,"13856122546"**

**OK**

**AT+QMMSEdit=2,1,"copy.test@quectel.com"**

**OK**

**AT+QMMSEdit=3,1,"secret.test@quectel.com"**

**OK**

**AT+QMMSEdit=1**

**+QMMSEdit: 1,"13856122546"**

**OK**

**AT+QMMSEdit=2**

**+QMMSEdit: 2,"copy.test@quectel.com"**

**OK**

**AT+QMMSEdit=3**

**+QMMSEdit: 3,"secret.test@quectel.com"**

**OK**

**AT+QMMSCFG="character","ASCII"**

**OK**

**AT+QMMSEdit=4,1,"test UGxx mms"**

**OK**

**AT+QMMSEdit=4**

**+QMMSEdit: 4,"ASCII","test UGxx mms"**

**OK**

//Add attachments.

**AT+QFupl="RAM:test\_ram.txt",100,300,1**

**CONNECT**

//Configure the sending parameters.

//Query the sending parameters.

//Add a phone number as recipient.

//Add an email address as CC recipient.

//Add an email address as BCC recipient.

//Query recipient address.

//Query CC recipient address.

//Query BCC recipient address.

//Configure the character type as ASCII for title.

//Edit the title of MMS message.

//Query the title of MMS message.

//Upload a file to RAM, the file will be saved as "test\_ram.txt" and the maximum size of file is 100. 300 indicates timeout, 1 indicates ACK mode. (For more details, please refer to *Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_Manual*).

<Input 100 bytes data>

+QFUPL: 100,0

OK

AT+QFLST="RAM:?"

//Query the file list of RAM.

+QFLST: "RAM:test\_ram.txt",100

OK

AT+QMMSCFG="character","ASCII"

//Configure the character type as ASCII for  
"RAM:test\_ram.txt".

OK

AT+QMMSEdit=5,1,"RAM:test\_ram.txt"

//Add attachment for MMS message, "test\_ram.txt"  
is RAM file.

OK

AT+QMMSEdit=5

//Query the attachments.

+QMMSEdit: 5,"RAM:test\_ram.txt"

OK

AT+QFUPL="RAM:test\_pic.jpg",200,300,1

//Upload a file to RAM, the file will be saved as  
"test\_pic.jpg" and the maximum size of file is 200  
bytes. 300 indicates timeout, 1 indicates ACK  
mode. (For more details, please refer to  
*Quectel\_WCDMA\_UGxx\_FILE\_AT\_Commands\_*  
*Manual*).

CONNECT

<Input 200 bytes data>

+QFUPL: 200,0

OK

AT+QFLST="RAM:?"

//Query the file list of RAM.

+QFLST: "RAM:test\_mms.txt",100

+QFLST: "RAM:test\_pic.jpg",200

OK

AT+QMMSEdit=5,1,"RAM:test\_pic.jpg"

//"RAM:test\_pic.jpg" is not text file, you do not need  
to specify the character set.

OK

AT+QMMSEdit=5

//Query the attachments.

+QMMSEdit: 5,"RAM:test\_mms.txt"

+QMMSEdit: 5,"RAM:test\_pic.jpg"

OK

//Step 5: Send MMS message.

<b>AT+QMMSEND=100</b>	//Send MMS message.
OK	
<b>+QMMSEND: 0,200</b>	//Indicate the result of sending MMS message.
//Step 6: Clear the content of MMS message.	
<b>AT+QMMSEDT=0</b>	//Clear the contents of MMS message.
OK	
<b>AT+QFDEL="RAM:test_ram.txt"</b>	//Delete the RAM file.
OK	
<b>AT+QFDEL="RAM:test_pic.jpg"</b>	//Delete the RAM file.
OK	

Quectel  
Confidential

## 4 Summary of Error Codes

<err> indicates an error related to mobile equipment or network. The details about <err> are described in the following table.

**Table 1: Summary of Error Codes**

<err>	Meaning
751	Unknown error
752	URL length error
753	URL error
754	Proxy type invalid
755	Proxy address error
756	Invalid parameter
757	Recipient address full
758	CC recipient address full
759	BCC recipient address full
760	Attachments full
761	File error
762	No recipient
763	File not found
764	MMS busy
765	Server response failed
766	Error response of HTTP post
767	Invalid report of HTTP post
768	Activate PDP fail

---

769	PDP deactivated
770	Socket create fail
771	Socket connect fail
772	Socket read fail
773	Socket write fail
774	Socket closed
775	Timeout
776	Encode data error
777	HTTP decode data error

---

## 5 Description of HTTP Response Codes

The HTTP response error code <httprsp> indicates an error replied from MMSC. Please refer to RFC2616 (Hypertext Transfer Protocol--HTTP/1.1). The details about <httprsp> are described in the following table.

Table 2: Description of HTTP Response Code

<httprsp>	Meaning
200	OK
400	Bad request
403	Forbidden
404	Not found
409	Conflict
411	Length required
500	Internal server error
502	Bad gate way

# 6 Appendix A Reference

**Table 3: Related Documents**

SN	Document Name	Remark
[1]	Wap-209-mmsencapsulation-20020105-a	Wap MMS protocol standard package of documents
[2]	RFC2616	Hypertext Transfer Protocol--HTTP/1.1
[3]	Quectel_WCDMA_UGxx_FILE_AT_Commands_Manual	Introduction about UGxx FILE AT commands
[4]	Quectel_WCDMA_UGxx_TCPIP_AT_Commands_Manual	Introduction about UGxx TCPIP AT commands
[5]	Quectel_WCDMA_UGxx_AT_Commands_Manual	UGxx AT commands manual

**Table 4: Terms and Abbreviations**

Abbreviation	Description
MMS	Multimedia Messaging Service
MMSC	Multimedia Messaging Service Center
HTTP	Hypertext Transfer Protocol
CC	Carbon Copy
BCC	Blind Carbon Copy
PDP	Packet Data Protocol
URL	Uniform Resource Locator