



Computer Organization

Lab1 Introduction

2021 Spring term

wangw6@sustech.edu.cn

contact

- Sakai site:
 - CS202- spring2021
- QQ group:
 - 389296479




Assignments Submission Rules

- ▶ All assignments must **be submitted to Sakai** site, any other forms of submission are not accepted.
- ▶ If the submission is **delayed for one day, 20% discount** on the total score. If it is **delayed for more than a week**, any submission is **NOT ACCEPTABLE! This assignment is 0 point**.
- ▶ In the case of plagiarism:
at the 1st time, the assignment was 0 for all concerned students and at the 2nd time, the grade of the experimental course is 0 for all concerned students.
- ▶ Reminder:
 - ▶ Assignment scoring and the score publication would be completed within two weeks after the publication of assignment. **If you have any question about the score, please email the relevant reviewer in one week after the score publication.**


Experimental Suite

QtSpim /Mars, vivado & minisys board

- ▶ Learn and practice **MIPS** (QtSpim / Mars)



- ▶ Design and implement an **CPU**



QtSpim (1)

▶ QtSpim

<http://spimsimulator.sourceforge.net/>

- ▶ **QtSpim** is the newest version of *Spim* that currently being actively maintained, runs on **Microsoft Windows, Mac OS X, and Linux**.
 - ▶ *Spim* , A self-contained simulator that runs MIPS32 program developed by Prof. James Larus from University of Wisconsin-Madison
- ▶ *QtSpim* reads and executes programs written in **assembly language** for a **MIPS** computer. *QtSpim* **does not execute binary (compiled) programs**. To simplify programming, *QtSpim* provides a simple **debugger** and small set of **operating system services**
- ▶ *QtSpim* implements **most of the MIPS32** assembler-extended instruction set. (It omits the floating point comparisons and rounding modes and the memory system page tables.) which means that *QtSpim* will not run programs for all MIPS processors.

Name ↕	Modified ↕	Size ↕
qtspim_9.1.20_linux64.deb	2017-08-29	19.8 MB
QtSpim_9.1.20_mac.mpkg.zip	2017-08-29	12.4 MB
QtSpim_9.1.20_Windows.msi	2017-08-29	13.8 MB

QtSpim (2)

QtSpim load file clear register run the simulation in different ways

File Simulator Registers Text Segment Data Segment Window Help

FP Regs Int Regs [16] Data Text

Int Regs [16]

PC = 0
EPC = 0
Cause = 0
BadVAddr = 0
Status = 3000fff10
HI = 0
LO = 0
R0 [r0] = 0
R1 [at] = 0
R2 [v0] = 0
R3 [v1] = 0
R4 [a0] = 1
R5 [a1] = 7ffff53c
R6 [a2] = 7ffff544
R7 [a3] = 0
R8 [t0] = 0
R9 [t1] = 0
R10 [t2] = 0
R11 [t3] = 0
R12 [t4] = 0
R13 [t5] = 0
R14 [t6] = 0
R15 [t7] = 0
R16 [s0] = 0
R17 [s1] = 0
R18 [s2] = 0
R19 [s3] = 0
R20 [s4] = 0
R21 [s5] = 0

display integer/floating-point register

Text

User Text Segment [00400000]..[00440000]

[00400000] lw \$4, 0(\$29)
[00400004] addiu \$5, \$29, 4
[00400008] addiu \$6, \$5, 4
[0040000c] sll \$2, \$4, 2
[00400010] addu \$6, \$6, \$2
[00400014] jal 0x00000000 [main]
[00400018] nop
[0040001c] ori \$2, \$0, 10
[00400020] syscall

Kernel Text Segment [80000000]..[80010000]


[80000180] addu \$27, \$0, \$1
[80000184] lui \$1, -28672
[80000188] sw \$2, 512(\$1)
[8000018c] lui \$1, -28672
[80000190] sw \$4, 516(\$1)
[80000194] mfc0 \$26, \$13
[80000198] srl \$4, \$26, 2
[8000019c] andi \$4, \$4, 31
[800001a0] ori \$2, \$0, 4
[800001a4] lui \$4, -28672 [__m1_]
[800001a8] syscall
[800001ac] ori \$2, \$0, 1
[800001b0] srl \$4, \$26, 2
[800001b4] andi \$4, \$4, 31
[800001b8] syscall
[800001bc] ori \$2, \$0, 4
[800001c0] andi \$4, \$26, 60
[800001c4] lui \$1, -28672
[800001c8] addu \$1, \$1, \$4

display instruction / data segment

Memory and registers cleared

SPIM Version 9.1.20 of August 29, 2017
Copyright 1990-2017 by James Larus.
All Rights Reserved.
SPIM is distributed under a BSD license.
See the file README for a full copyright notice.
QtSPIM is linked to the Qt library, which is distributed under the GNU Lesser General Public License version 3 and version 2.1.

display status of Qtspim




QtSpim (3)

Load file and Do the simulation

- ▶ Step1: loading a file (assembly code file usually have the extension “.s”)
 - ▶ Open file : **File->Load File** or **File ->Reinitialize and Load File**
 - ▶ Tips:
 - ▶ Reinitialize and Load File : Clears all the changes made by a program, deleting all of its instructions, then reload the last file
 - ▶ Before doing the simulation, make sure clear registers ,you can do it by : Simulator->Clear Registers or tools
- ▶ Step2:
 - ▶ Run file : **Simulator->Run / Continue**
 - ▶ The value of register in left window will be refreshed, the program's output will appear in the Console window.

Mars(1)

<http://courses.missouristate.edu/kenvollmar/mars/download.htm>



MARS is a **lightweight** interactive development environment (**IDE**) for programming in **MIPS** assembly language, intended for educational-level use with Patterson and Hennessy's Computer Organization and Design.

MARS requires Java J2SE 1.5 (or later) SDK installed on your computer.

Mars(2)

run one step at a time
run the program
clear memory and registers

Text Segment

Bkpt	Address	Code	Basic	Source
	0x00400000	0x24020004	addiu \$2, \$0, 0x0...	6: li \$v0, 4
	0x00400004	0x3c011001	lui \$1, 0x00001001	7: la \$a0, str
	0x00400008	0x34240000	ori \$4, \$1, 0x000...	
	0x0040000c	0x0000000c	syscall	8: syscall
	0x00400010	0x2402000a	addiu \$2, \$0, 0x0...	10: li \$v0, 10
	0x00400014	0x0000000c	syscall	11: syscall

Data Segment

Address	Value (+...	Value (+...	Value (+...	Value (+...	Value (+...	Value (+...	Value (+...	Value (+...
0x100...	0x6e6...	0x6f7...	0x006...	0x000...	0x000...	0x000...	0x000...	0x000...
0x100...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...
0x100...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...
0x100...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...
0x100...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...
0x100...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...
0x100...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...	0x000...

Registers

Name	Number	Value
\$zero	0	0x00000000
\$at	1	0x00000000
\$v0	2	0x00000000
\$v1	3	0x00000000
\$a0	4	0x00000000
\$a1	5	0x00000000
\$a2	6	0x00000000
\$a3	7	0x00000000
\$t0	8	0x00000000
\$t1	9	0x00000000
\$t2	10	0x00000000
\$t3	11	0x00000000
\$t4	12	0x00000000
\$t5	13	0x00000000
\$t6	14	0x00000000
\$t7	15	0x00000000
\$s0	16	0x00000000
\$s1	17	0x00000000
\$s2	18	0x00000000
\$s3	19	0x00000000
\$s4	20	0x00000000
\$s5	21	0x00000000
\$s6	22	0x00000000
\$s7	23	0x00000000
\$t8	24	0x00000000
\$t9	25	0x00000000
\$k0	26	0x00000000
\$k1	27	0x00000000
\$gp	28	0x10008000
\$sp	29	0x7fffffc
\$fp	30	0x00000000
\$ra	31	0x00000000
pc		0x00400000
hi		0x00000000
lo		0x00000000

Mars Messages

Assemble: assembling D:\计算机组成原理\2020s\LAB\lab1\mips1.asm

Assemble: operation completed successfully.

Go: running mips1.asm

Go: execution completed successfully.

Run Settings Tools Help

Assemble F3

Go F5

Mars Messages Run I/O

Assemble: assembling D:\计算机组成原理\2020s\LAB\lab1\mips1.asm

Assemble: operation completed successfully.

Go: running mips1.asm

Go: execution completed successfully.

Mars Messages Run I/O

Hello, world

— program is finished running —

Assembly Language Overview

- ▶ Assembly language

- ▶ The main body of assembly language is assembly instruction. Assembly instructions and machine instructions differ in instruction expression. Assembly instruction is a human-friendly writing format of machine instruction. Assembly language is the mnemonic of machine language.

- ▶ For example


machine instruction "1000100111011000" means that send the contents of register BX to AX.

The assembly instructions are written as "mov ax, bx".

Such writing is similar to human language and easy to read and remember.

- ▶ Feature : programs written in assembly language are inherently machine-specific and must be totally rewritten to run on another computer architecture

- ▶ CISC (intel x86) vs RISC (ARM , MIPS)



Assembly Program Structure

Program Structure

- data declarations, program code
- data declaration section followed by program code section

Data Declarations

- placed in section of program identified with assembler directive `.data`
- declare variable names used in program; storage allocated in main memory (RAM)

Code

- placed in section of text identified with assembler directive `.text`
- contains program code (instructions)
- starting point for code e.g. execution given label `main:`
- ending point of main code should use exit system call (see below in "System Calls" part)

Comments

- anything following `#` on a line
This stuff would be considered as comment

```
# Comment giving name of program and description of function
# Template.s
# Bare-bones outline of MIPS assembly language program

.data      # variable declarations follow this line
           # ...

.text      # instructions follow this line

main:      # indicates start of code (first instruction to execute)
           # ...

# End of program, leave a blank line afterwards to make SPIM happy
```

System Calls

- **System Calls**

- SPIM provides a small set of operating-system-like services through the system call (syscall) instruction.
- To request a service, a program loads the system call code into register \$v0 and arguments into registers \$a0-\$a3 (or \$f12 for floating-point values).
- System calls that return values put their results in register \$v0 (or \$f0 for floating-point results).

Service	System call code	Arguments	Result
print_int	1	\$a0 = integer	
print_float	2	\$f12 = float	
print_double	3	\$f12 = double	
print_string	4	\$a0 = string	
read_int	5		integer (in \$v0)
read_float	6		float (in \$f0)
read_double	7		double (in \$f0)
read_string	8	\$a0 = buffer, \$a1 = length	
sbrk	9	\$a0 = amount	address (in \$v0)
exit	10		
print_char	11	\$a0 = char	
read_char	12		char (in \$v0)
open	13	\$a0 = filename (string), \$a1 = flags, \$a2 = mode	file descriptor (in \$v0)
read	14	\$a0 = file descriptor, \$a1 = buffer, \$a2 = length	num chars read (in \$v0)
write	15	\$a0 = file descriptor, \$a1 = buffer, \$a2 = length	num chars written (in \$v0)
close	16	\$a0 = file descriptor	
exit2	17	\$a0 = result	

Practice & think

- 1. **Install QtSpim/Mars on your PC and refer to the help page to find:**
 - Which version of MIPS does the simulator support?
 - Is the function of 'syscall' in Qtspim the same with Mars?
 - What's the name and ID of the registers used while invoke the "print string" syscall?
- 2. **Make an assembly file, load and run it by QtSpim/Mars:**
 - The assembly code should get your ID and name, and print them out
 - Is there any object file or executable file generated while doing the simulation?
 - (Optional) What's the Machine code of the MIPS instruction "li \$v0,4"
- 3. (Optional) **Find an assembler for MIPS from the Internet**, use it to assemble the code of question 2 to generate an executable file, Can the executable file run on your computer and why?

A demo

```
# text segment
.text
.globl main
main:
    la $a0, str      # execution starts here
    li $v0, 4         # put string address into a0
    syscall           # system call to print
    li $v0, 10
    syscall           # system call to exit
#data segment
.data
str: .asciiz "hello Internet\n"
```

The screenshot displays the QtSpim MIPS simulator interface. The main window is divided into several panes:

- Registers:** A table showing the state of MIPS registers. The PC (Program Counter) is highlighted in red and contains the value 400038. Other registers like R0-R31 are shown with their current values.
- Text Segment:** A pane showing the assembly code being executed. The code is organized into segments: User Text Segment (starting at 00400000) and Kernel Text Segment (starting at 80000000). The instruction at address 00400038, `syscall`, is highlighted in blue.
- Console:** A small window titled "Console" showing the output of the program: "hello Internet".

At the bottom of the simulator window, there is a status bar with the following text:

All Rights Reserved.
SPIM is distributed under a BSD license.
See the file README for a full copyright notice.
QtSPIM is linked to the Qt library, which is distributed under the GNU Lesser General Public License version 3 and version 2.1.
Instruction references undefined symbol at 0x00400014
[0x00400014] 0x0c000000 jal 0x00000000 [main] ; 188: jal main

Memory and registers cleared