

**When all the legs don't touch the ground on a chaise lounge:**

- If the corner legs on end of the seat or back legs don't touch the ground, place wood block under middle legs and push down on each end to make all the legs touch the ground (see below).
- If middle legs don't touch, place wood block under the corner legs on seat or the back and push down on the center of the seat to make all the legs touch the ground.



**Below are some pictures showing how to straighten frames when chairs seem to have uneven legs:**

1. Stand in front of chair and rock chair back and forth to determine which **back leg doesn't come off the ground**.
2. Then pick chair up and strike same leg down onto wood block.
3. Repeat as needed.

