

Morfeas WEB User Guide Configuration

1 License

Copyright (C) 12022 Sam Harry Tzavaras.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".

2 Change History

Jan 20,12022 : Sam Harry Tzavaras – Initial Work.

Contents

1	License	2
2	Change History	2
3	Introduction	4
4	Morfeas System Loggers	4
5	Morfeas ISO Channel Linker	5
6	Morfeas System configuration	5
7	Network configuration	5

List of Figures


1	Morfeas System Loggers	4
2	Morfeas ISO Channel Linker Utility	5
3	Morfeas WEB Utility for Network Configuration	6

3 Introduction

This reference guide will introduce the utilities that are related to configuration of the Morfeas system and network.

The “Morfeas WEB” is published under the AGPLv3 or later.

4 Morfeas System Loggers

The Morfeas System Loggers utility is made to show information related to the Morfeas System’s components. It’s can be accessed for the Morfeas WEB front page by the button with this  symbol.




Figure 1: Morfeas System Loggers

At table 1 present the functionality of the utility’s tabs.

Tab Name	Purpose
Errors	Table with Sensors that reporting error.
Sensors	Table with all the available sensor.
Details	Table with report of component’s status.
System Logs	Loggers from Morfeas’ system components (Default).

Table 1: Morfeas System Loggers values

The “System logs” is the tab that shown by default at the opening of the utility. For the drop-down list at the bottom right it’s can be selected the logger of the component on interest. Each “Morfeas Component loggers”, is a human readable output (ASCII text) of the component. The “Reload Logger names” button refresh the list of components, by request from the device server. The Components of the “Morfeas system” configured from the “Morfeas System configuration” utility (section 6).

The “Details” tab shows all the status reports from the components. The “Sensors” tab present a list of the active sensors from all components. And the “Error” all the sensors that reporting error at status.

5 Morfeas ISO Channel Linker

The “Morfeas ISO Channel Linker” is an utility made to create ISO channels and link them with sensors. It’s can be accessed by the Morfeas WEB front page from the button with the anchor (🔗) symbol. At figure 2 shown an example of the “Morfeas ISO Channel Linker” utility.




Figure 2: Morfeas ISO Channel Linker Utility

The utility window split in three sections: the status bar, the filters section, and the ISO Channels table.

The status bar show the last update date if at least one channel exist, or a message that informing the user to add channel(s).

The filter section, is filtering the ISO channels table, accordingly to the command from the user. The filtering command is specified from the two drop-down lists and the text input field. The first drop-down is selecting the column that the filtering will applied. The second drop-down select the filter type; for most of the columns (except “Min” and “Max”) is “like” and “regex”. The “Like” filter type is filter and show all the elements in the specified column, that contains the word in the search field, and similarly the “regex” the fields that agree with the regular expression phrase. For columns “Min” and “Max” the filter type become numerical compare. The button with the broom is cleaning the filter.

b

6 Morfeas System configuration

7 Network configuration

The network configuration utility is accessed by the front page of the Morfeas WEB from the button with this ↔ symbol. At figure 3 shown an example of the network configuration utility.

Value	Purpose
Hostname	Name for discovery services (avahi, samba, etc)
MAC Address	Identifier of the Ethernet interface
Mode	Internet address configuration mode (Static, DHCP)
Network IP	IP address and subnet range bits (In static mode only)
Gateway	Gateway’s IP address (In static mode only)
NTP IP	IP address of the local network time protocol server
SDAQNet(CAN-ifs)	Configuration of the bitrate for each available can-if

Table 2: Network configuration values

The screenshot displays a web-based configuration utility for a network device. It is organized into several sections:
1. **Machine Identifier**: Contains a text field for 'Hostname' with the value 'Morfeas-test'.
2. **Ethernet Identifier**: Displays the 'MAC Address' as '00:13:95:0B:72:03'.
3. **Internet Configuration**: Includes a 'Mode' dropdown menu set to 'Static'. Below it are input fields for 'Network IP' (10.0.0.230/24) and 'Gateway' (10.0.0.3).
4. **NTP Configuration**: Features an 'NTP IP' field with the value 192.168.0.201 and a 'Stats' button.
At the bottom of the interface, there are two buttons: 'Load Last' on the left and 'Set' on the right.

Figure 3: Morfeas WEB Utility for Network Configuration

At table 2 present the values and purpose of the configuration fields of the utility. The two buttons at the bottom of the utility window(Load last, Set), have purpose to send the current configuration to the device (Set), and reload the last configuration from the device (Load Last).