



Morfeas WEB User Guide  
IOBOX-if/Portal

## 1 License

Copyright (C) 12022 Sam Harry Tzavaras.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included at the LICENSE file.

## 2 Change History

Feb 16,12022 : Sam Harry Tzavaras – Initial Work.

## Contents

<b>1</b>	<b>License</b>	<b>2</b>
<b>2</b>	<b>Change History</b>	<b>2</b>
<b>3</b>	<b>Introduction</b>	<b>4</b>
<b>4</b>	<b>Installation</b>	<b>4</b>
<b>5</b>	<b>Morfeas WEB IOBOX-if/Portal UI</b>	<b>4</b>

## List of Figures

1	Example of Morfeas WEB IOBOX-if UI . . . . .	4
---	--	---

### 3 Introduction

The "Morfeas WEB IOBOX if/Portal" is the web user interface of the Morfeas WEB for IOBOX devices. IOBOXs are RF devices with four individual transceivers that supports a variate of telemetry devices, and use MODBus-TCP as output communication protocol. The "Morfeas WEB IOBOX if/Portal" works in conjunction with the "Morfeas IOBOX if" component which is part of the "Morfeas core".

The "Morfeas WEB IOBOX if/Portal" is published under the AGPLv3 or later.

### 4 Installation

The installation of the IOBOX start by configuring the Morfeas System, by adding a Morfeas\_MDAQ\_if component to the IPv4 address of the IOBOX, together with an identification name for the component. This done from the Morfeas "System Configuration" WEB utility.

### 5 Morfeas WEB IOBOX-if/Portal UI

The "Morfeas WEB IOBOX-if/Portal" can be accessed from the Morfeas WEB front page by the button with the identical label. An example of the "Morfeas WEB IOBOX-if/Portal UI" derived at figure 1. At the top left corner are a drop down menu that can select the IOBOX component under interest, by it's defined name.

The "Morfeas WEB IOBOX-if/Portal UI" split in three sections. The to drop down menu that explained above, the status box, and the measurement table. The status text box show the last update (fetch) date, or the last error that happens. The measurement table on the upper side show the configuration of the component together with the connection status. The lower part contains that measurements that comes from the IOBOX.

The next section of the measurement table is the "Wireless Inductive Power Supply" section. This section provide the voltage and current measurements from the IOBOX's inductive power supply. This Power supply have 4 outputs that controlled by some buttons on the IOBOX's front panel.

The followed four section provide the measurement of the telemetries. The upper row of each telemetry measurements section, show the order name and the state of the receiver followed from the reception success rate indicator (RSSID). The next lines have the measurements of each acquisition channel of the telemetry. In case that the telemetry is out of power/range or the RF Channels is not configured the section filled with the word: **Disconnected**.

The RF channels can be configured only (unfortunately) by a proprietary software that given by the manufacture.




Figure 1: Example of Morfeas WEB IOBOX-if UI