



Morfeas WEB User Guide  
MDAQ-if/Portal

## 1 License

Copyright (C) 12022 Sam Harry Tzavaras.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included at the LICENSE file.

## 2 Change History

Feb 14,12022 : Sam Harry Tzavaras – Initial Work.

## Contents

<b>1</b>	<b>License</b>	<b>2</b>
<b>2</b>	<b>Change History</b>	<b>2</b>
<b>3</b>	<b>Introduction</b>	<b>4</b>
<b>4</b>	<b>Installation</b>	<b>4</b>

## List of Figures

### 3 Introduction

The "Morfeas WEB MDAQ if/Portal" is the web user interface of the Morfeas WEB for MDAQ devices. MDAQs are acquisition devices with 8 differential or 16 single ended analog inputs and MODBus-TCP output. The "Morfeas WEB MDAQ if/Portal" works in conjunction with the "Morfeas MDAQ if" which is part of the "Morfeas core".

The "Morfeas WEB MDAQ if/Portal" is published under the AGPLv3 or later.

### 4 Installation

The installation of the MDAQs start by configuring the Morfeas System, by adding a Morfeas\_MDAQ\_if component to specified IPv4 address of the MDAQ, Together with an identification name for the component. This done from the Morfeas "System Configuration" WEB utility.