

INSTRUCTION MANUAL FOR CHEATS 'N CODES FOR USE WITH THE PLAYSTATION GAME CONSOLE

Instructions

Congratulations! You have purchased the ultimate game enhancer for the 9000 Series or higher Sony PlayStation gameconsole that will take your gaming to new levels of fun and excitement. The Cheats 'N Codes disc allows you to use the pre-loaded codes, programmer's cheats and game saves to make enhancements to your PlayStation games that you once thought were impossible. Find new levels in your favorite games, gain infinite lives and modify the game to your specifications.

Start-Up Instructions

1. Turn off your PlayStation. Now place the Cheats N' Codes CD-ROM in your PlayStation and close the lid.
2. Insert a game controller into Controller Port #1.
3. Turn your PlayStation ON.

Main Menu

The Main Menu is composed of 4 items:

1. Start GameShark
2. Go Big
3. Programmer's Cheats and Game Saves
4. What is GameShark

Press up and down on the directional pad (D-Pad) to highlight one of these items, and press the X button to select it.

Start GameShark

Selecting this option will start the GameShark cheat engine. The first menu will give you two options: Start Game and Select Cheat Codes.

Start Game - This selection takes you to the Start Game Options menu. You will then be presented with three options. Press up or down on the D-Pad to highlight an option and press the X button to select it.

Option 1: Start Game With Selected Codes

This option starts the game using the enhancement codes chosen from the Select Cheat Codes menu. You will be prompted to remove your Cheats 'N Codes CD-ROM, and then insert the game CD.

Option 2: Start Game Without Codes

This option starts the game without any enhancement codes. The game will play as normal.

Option 3: Cancel - This option takes you back to the Main Menu.

Select Cheat Codes - This option takes you to the built-in list of PlayStation titles currently supported by the Cheats 'N Codes disc. All titles are listed alphabetically. Press up or down on the directional pad to highlight the desired game and press the X button to select. The O button will return you to the previous menu. L1 will scroll the list up and R1 will scroll the list down.

The bottom of the Select Cheat Codes screen will display the highlighted game, the number of enhancements codes that are currently active for that specific game, and the percentage of storage space available within the Cheats 'N Codes disc memory for codes.

Once you've selected a game, a full list of enhancement codes will appear on the screen for that game. These descriptions represent a code. Press up or down on the direction pad to highlight an individual code. The X button will toggle the codes on and off. You can activate almost any combination of enhancements. Active codes will be highlighted in yellow.

To delete a code, press the Triangle button. When you are finished selecting the desired cheats, press the O button to return to the previous menu, or the Start button to go to the Start Game menu.

NOTE: Some games require an access code labeled as (M), which means that this code "ALWAYS MUST BE ON." This code will be highlighted in green at all times or the Cheats 'N Codes disc will not be able to load the game properly.

Go Big

Selecting this option will give you details on InterAct Accessories, Inc. Go Big Win Big promotion.

Programmer's Cheats and Game Saves

Selecting this option will take you to the menu that will allow you to transfer the included game saves onto your memory card. Each game included on this disc will have either programmer's cheats listed and/or selected game saves.

What is GameShark

Selecting this option will provide a brief tutorial on what GameShark is and how it and GameShark.com combine to provide the best possible gaming experience for all of your games.

Trouble Shooting

If you are having problems with codes, make sure you have entered the code or codes properly. Some games require an access code labeled as "ALWAYS MUST BE ON." This code should be highlighted in green at all times or the Cheats and Codes disc will

not be able to load the game properly. If you are still having problems, you can call our Technical Support department at (410) 785-4064. Please DO NOT call this number for codes, as they are not available through Tech Support.

WARRANTY INFORMATION

InterAct Accessories, Inc. warrants to the original purchaser of this product that it will be free from defects in materials and/or workmanship for a period of ninety (90) days from the date of purchase. If a defect covered by this warranty is discovered within the 90-day warranty period, InterAct Accessories, Inc. will repair or replace, at its option, free of charge, any part that InterAct Accessories, Inc. determines to be defective, provided that a copy of the original sales receipt is included with the product return.

This warranty is limited to the internal works of this product and the external housing. It will not apply if your InterAct product has been damaged by abuse, misuse, negligence, accident, modification, tampering, or by any other causes unrelated to defective materials and/or workmanship. Compensation or restoration of data loss and software are not covered. InterAct is not liable for loss of revenue or loss of use of equipment.

Repair or replacement as provided under this warranty is InterAct Accessories, Inc.'s exclusive prerogative. Any applicable implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited to 90 days from the date of purchase and are subject to the conditions set forth in this limited warranty. In no event shall InterAct Accessories, Inc. or its affiliates be liable for consequential or incidental damages resulting from the breach of any express or implied warranties.

Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental/consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights which vary from state to state.

To obtain warranty service within the warranty period:

IN THE USA: Return product to the place of purchase or send the defective item postage prepaid with a copy of the sales receipt, return address and a brief description of the problems you are experiencing to:

**InterAct Accessories, Inc.
335 Clubhouse Lane
Hunt Valley, MD 21031
ATTN: Consumer Service
Video Game Products**

IN CANADA: Return product to the place of purchase, or contact InterAct Canada's consumer service support at canadiansupport@gameshark.com or TEL: 905-831-7177 x. 607 for instructions.

For trouble-shooting, assistance in any other region, or to obtain service after the warranty period has expired, contact InterAct's Consumer Service department by any of the following means:

PHONE: 410-785-4064, Mon – Fri, 9:00 am – 8:00 pm EST

FAX: 410-785-5725

Email: support@gameshark.com

©2000 InterAct Accessories, Inc. A RECOTON® COMPANY. InterAct is a registered trademark of STD Manufacturing, Ltd. Printed in England.