

Preparing Ubuntu 22.04 OS for KRIA KV260 board

Download the Ubuntu 22.04 image from the [download link](#)

Ubuntu Desktop 22.04 LTS

The version of Ubuntu with up to 10 years of long term support, until April 2032.

Works on:

- ✓ KR260 Robotics Starter Kit
- ✓ KV260 Vision AI Starter Kit

① Please check the [AMD Kria™ Wiki](#) for the platform's latest boot firmware, technical documentation, and the [Ubuntu for AMD-Xilinx Devices Wiki](#) for known issues and limitations.

[Download 22.04 LTS](#)

[Kria™ KR260 Getting Started Guide for Ubuntu 22.04](#)

[Kria™ KV260 Getting Started Guide for Ubuntu 22.04](#)

Next, prepare the SD card with the above downloaded Ubuntu image using burning tools like Balena Etcher.

Now boot the KV260 with the SD card with Ethernet and USB to Serial cable connected to board. We will be using Serial console for initial access and debugging and Ethernet network for accessing through SSH and KV260 connected to the internet.

For initial login here are the Login Details:

Username : ubuntu


Password: ubuntu

This will ask to change the password. So update the password and login the system.

After successful login, one can access the KV260 device console.

Create IoT Hub in Azure Portal:

- Go to Azure portal " <https://portal.azure.com> ".
- Create a resource >> IoT Hub.



Microsoft Azure

Home >

Create a resource

Get Started

Recently created

Categories

- AI + Machine Learning
- Analytics
- Blockchain
- Compute
- Containers
- Databases
- Developer Tools
- DevOps
- Identity
- Integration
- Internet of Things**
- IT & Management Tools
- Media
- Migration
- Mixed Reality
- Monitoring & Diagnostics
- Networking
- Security
- Storage
- Web

Search services and marketplace

Getting Started? Try our Quickstart center

Popular Azure services

See more in All services

- IoT Hub**
Create | Docs | MS Learn
- IoT Central application
Create | Docs | MS Learn
- IoT Hub Device Provisioning Service
Create | Docs | MS Learn
- Azure Digital Twins
Create | Docs | MS Learn
- Time Series Insights
Create | Docs | MS Learn
- Azure Stack Edge
Create | Docs | MS Learn
- Event Grid Topic
Create | Docs
- Function App
Create | Docs
- Getting Started with GPUs
Create | Learn more
- Vision Get Started Module
Create | Docs

Popular Marketplace products

See more in Marketplace

- Azure Blob Storage on IoT Edge
Create | Learn more
- Simulated Temperature Sensor
Create | Learn more
- Azure SQL Edge Developer
Create | Learn more
- Usage-based plan
Set up + subscribe | Learn more
- OPC Publisher
Create | Learn more
- IoT Edge Metrics Collector
Create | Learn more
- YOLOv3 gRPC-CPU Extension
Create | Learn more
- Free
Create | Learn more
- Small EJBICA SaaS Deployment with Azure KeyVault backed keys in a US region
Set up + subscribe | Learn more
- Node-RED
Create | Learn more

Next, create one IoT Hub Service and fill in the necessary details

Next, create one IoT Hub Service and fill in the necessary details

Project details

Choose the subscription you'll use to manage deployments and costs. Use resource groups like folders to help you organize and manage resources.

Subscription * ⓘ

Resource group * ⓘ

[Create new](#)

Instance details

IoT hub name * ⓘ

Region * ⓘ

Tier *

i Free trial explores the app with live data. Trials cannot scale or be upgraded later.

[Compare tiers](#)


Daily message limit * ⓘ


x Free IoT hubs are limited to one per subscription


- Click on Review+ Create button to create the Azure IoT Hub.
- Next, create a device where you can actually receive some data from the hardware.

Create an IoT Device


Go to the IoT Device and click on new, and give the device ID





 Find Certified for Azure IoT devices in the Device Catalog


Device ID * 


☒ IoT Edge Device

Authentication type 
Symmetric key X.509 Self-Signed

Auto-generate keys 
☒

Connect this device to an IoT hub 
Enable Disable

Parent device 
No parent device
[Set a parent device](#)

Child devices 
0
Choose child devices

rix

After this device will be available in the IoT hub Device list.

View, create, delete, and update devices in your IoT Hub. [Learn more](#)

[+](#) Add Device [≡](#) Edit columns [↻](#) Refresh [🏷️](#) Assign tags [🗑️](#) Delete

<input type="text" value="enter device ID"/>	Types: All	+ Add filter				
Device ID	Type	Status	Last status update	Authentication type	C2D messages queued	Tags
KR260-dev10	IoT Edge Device	Enabled	--	Shared Access Signature	0	
KD240-dev01	IoT Edge Device	Enabled	--	Shared Access Signature	0	
kv260-dev01	IoT Edge Device	Enabled	--	Shared Access Signature	0	

Next, look into device information for getting the keys and connection string.

kv260-dev01

KR260-IOT-HUB

[Save](#)
[⚙️ Set modules](#)
[👤 Manage child devices](#)
[🛠 Troubleshoot](#)
[👤 Device twin](#)
[↻ Refresh](#)

Device ID

kv260-dev01

Primary key

.....

Secondary key

.....

Primary connection string

.....

Secondary connection string

.....

IoT Edge runtime response

NA

Tags

No tags

Enable connection to IoT Hub

☒ Enable
 ☐ Disable

Parent device

No parent device

Modules

IoT Edge hub connections

Deployments and Configurations

Name	Type	Specified in Deployment	Reported by Device	Runtime Status	Exit Code
\$edgeAgent	Module Identity	NA	NA	NA	NA
\$edgeHub	Module Identity	NA	NA	NA	NA

Copy the “Primary Connection String” which will be used in the python application for sending the sensor data to IoT hub.

Adding python application in KRIA

Copy the simulated_sensor.py example code in KV260 board.

Next update the "CONNECTION STRING" with the above Primary Connection string.

```
1 import random
2 import time
3
4 from azure.iot.device import IoTHubDeviceClient, Message
5
6 CONNECTION_STRING = "<Connection String>"
7
8 TEMPERATURE = 20.0
9 HUMIDITY = 60
10 MSG_TXT = '{"temperature": {temperature},"humidity": {humidity}}'
11
12 def iot_hub_client_init():
13     client = IoTHubDeviceClient.create_from_connection_string(CONNECTION_STRING)
14     return client
15
16 def iot_hub_client_telemetry_sample_run():
17
18     try:
19         client = iot_hub_client_init()
```

Then run the simulated application in console:

```
python3 simulated_sensor.py
```

Here is the console log after successful message send to Azure IoT hub.


```
IoT Hub Quickstart #1 - Simulated device
Press Ctrl-C to exit
IoT Hub device sending periodic messages, press Ctrl-C to exit
Sending message: {"temperature": 21.869834376404423,"humidity": 74.29759396046798}
Message successfully sent
Sending message: {"temperature": 32.86165169899766,"humidity": 76.24063097582776}
Message successfully sent
Sending message: {"temperature": 26.783131268254383,"humidity": 64.12216333418469}
Message successfully sent
█
```

Viewing message in Host Machine

For viewing the message published by Azure IoT Device in KV260, one can use Azure IoT explorer available in following link:


<https://github.com/Azure/azure-iot-explorer/releases>

In IoT Hubs page of the application, in +Add connection copy the connection string for the IoT hub and save the configs:



One can find the corresponding device list in the IoT HuB page of Azure IoT explorer application.

[Home](#) > [KR260-IoT-HUB](#) > [Devices](#)



Just click onto the device to view the device information and also the message send by python application running in the KV260 board.

For viewing the message send to device, go to Telemetry and click the >Start button. After this one can view the message send to the device.

Device identity

Device twin

Telemetry

Direct method

Cloud-to-device message

Module identities

Stop

Clear events

Simulate a device

Customize Content Type

Telemetry

You can monitor telemetry that the device sends to the IoT hub

Consumer group

\$Default

Specify enqueue time

No

Use built-in event hub

Yes

Show system properties

Receiving events...

Fri Dec 15 2023 17:06:03 GMT+0545 (Nepal Time):

```
{
  "body": {
    "temperature": 25.25847962061951,
    "humidity": 62.77776214518302
  },
  "enqueuedTime": "Fri Dec 15 2023 17:06:03 GMT+0545 (Nepal Time)",
  "properties": {
    "temperatureAlert": "false"
  }
}
```

Fri Dec 15 2023 17:05:59 GMT+0545 (Nepal Time):

```
{
  "body": {
    "temperature": 20.3589672917612,
    "humidity": 73.20813395493155
  },
  "enqueuedTime": "Fri Dec 15 2023 17:05:59 GMT+0545 (Nepal Time)",
  "properties": {
    "temperatureAlert": "false"
  }
}
```