



Perfect Wireless Experience  
完美无线体验

---

# FIBOCOM L610 AT Commands\_HTTP

Version: V1.0.0

Date: 2019-11-29



## Applicability Type

No.	Type	Note
1	L610	NA

Draft



## Copyright

Copyright ©2019 Fibocom Wireless Inc. All rights reserved.

Without the prior written permission of the copyright holder, any company or individual is prohibited to excerpt, copy any part of or the entire document, or transmit the document in any form.

## Attention

The document is subject to update from time to time owing to the product version upgrade or other reasons. Unless otherwise specified, the document only serves as the user guide. All the statements, information and suggestions contained in the document do not constitute any explicit or implicit guarantee.

## Trademark



The trademark is registered and owned by Fibocom Wireless Inc.

## Versions

Version	Author	Assessor	Approver	Update Date	Description
V1.0.0	Robin	Long Zhongyou	Long Zhongyou	2019-11-29	Initial version

# Contents

<b>1</b>	<b>HTTP Commands</b>	<b>5</b>
1.1	+HTTPSET, Set HTTP or HTTPS parameters	5
1.2	+HTTPDATA, send POST data to modem	7
1.3	+HTTPACT, start HTTP or HTTPS service	8
1.4	+HTTPREAD, Read data	9
1.5	+HTTPHEAD, Set HTTP or HTTPS header parameters	10

Draft

# 1 HTTP Commands

## 1.1 +HTTPSET, Set HTTP or HTTPS parameters

### 1.1.1 Description

This command is used to set service type of HTTP or HTTPS.

### 1.1.2 Syntax

Command	Response
+HTTPSET=<"httpParam">,<"httpParamValue">	OK or ERROR
+HTTPSET?	+HTTPSET: "httpParam","httpParamValue" +HTTPSET: "httpParam","httpParamValue" ... OK
+HTTPSET=?	+HTTPSET: (<"httpParam">),( <"httpParamValue">)  OK

### 1.1.3 Attributes

Pin Restricted	Persistent	Sync Mode	Effect Immediately	Time of duration
Yes	No	Yes	Yes	< 1s

### 1.1.4 Defined Values

httpParam	httpParamValue
URL	<p>http server address, character string type, string length is 0-255, the string format must be any kind of the following:</p> <p>For HTTP</p> <p><a href="http://host/path:port">http://host/path:port</a> e.g. <a href="http://news.sohu.com/20131010/n387881216.shtml">http://news.sohu.com/20131010/n387881216.shtml</a>:80</p> <p><a href="http://host/path">host/path:port</a> e.g. news.sohu.com/20131010/n387881216.shtml:80</p> <p><a href="http://host/path">http://host/path</a> e.g. <a href="http://news.sohu.com/20131010/n387881216.shtml">http://news.sohu.com/20131010/n387881216.shtml</a></p>

httpParam	httpParamValue
	<p>For HTTPS</p> <p><a href="https://host:port">https://host:port</a>e.g. <a href="https://www.googleapis.com:443">https:// www.googleapis.com:443</a></p> <p><a href="https://host">https://host</a>e.g. <a href="https://www.googleapis.com">https:// www.googleapis.com</a></p> <p>Notes:</p> <p>Host --- http or https host name or host IP address</p> <p>Path --- the file path requested by http or https</p> <p>Port --- http or https port , optional setting. The default number for http is 80, and 443 for https.</p> <p>Note:</p> <p>No matter http or https, it requires the port in the end of URL string.</p>
UAGENT	User-Agent Value, character string type, optional settings.
CTYPE	Content-Type Value, character string type, optional settings.
ACCEPT	Accept Value, character string type, optional settings.
RESPONSEHEAD ER	Response Header Value, character string type, optional settings, the default value is "0", it means HTTP head information is showed in AT+HTTPREAD output.
MODE	<p>Read mode Value, character string type, optional settings, the default value is "0".</p> <p>When the value is "1", the received data will be sent to UART since connection built up. AT+HTTPREAD execution can read continuous data until the end of receiving.</p>
REDIR	<p>Redirect Value, character string type, option settings, the default value is "0".</p> <p>When the value is "1", and the module receives 3XX or 500 and other return codes from server, it will redirect to the new URL automatically.</p>
RANGE	Content-Range value, character string type, optional settings, the default value is NULL. Enter each time you use it in accordance with the protocol standard format, such as "bytes=0-12". Receives 206 for success. Overwrite the last record each time it is used. If you don't want to use RANGE, you can assign it to NULL. Post does not apply.
IPV6	Connection type value, character string type, option settings, the default value is "0". When the value is "0", it means connecting to an IPV4 address. When the value

httpParam	httpParamValue
	is "1", it means connecting to an IPV6 address.


**Note:**

The value of <httpParam> is only support capital letter.

## 1.2 +HTTPDATA, send POST data to modem

### 1.2.1 Description

This command is used to send data to the module via UART for HTTPPOST procedure.

### 1.2.2 Syntax

Command	Response
+HTTPDATA=<length>	>  .....  OK or ERROR
+HTTPDATA?	OK
+HTTPDATA=?	+HTTPDATA: (list of supported <length>s)  OK

### 1.2.3 Attributes

Pin Restricted	Persistent	Sync Mode	Effect Immediately	Time of duration
Yes	No	YES	Yes	< 1s

### 1.2.4 Defined Values

<length>: integer type; length of the data will be input. Range 1-64000 byte.


**Note:**

When the received data length reaches to the given size, the module exits from data mode and responses OK.

The time out of data input is 30 seconds, then the module exits from data mode and response ERROR

## 1.3 +HTTTPACT, start HTTP or HTTPS service

### 1.3.1 Description

This command used to start HTTP or HTTPS connect (GET or POST)

### 1.3.2 Syntax

Command	Response
+HTTTPACT=<mode>[,<timernum>]	OK or ERROR:
+HTTTPACT?	OK
+HTTTPACT=?	+HTTTPACT: (list of supported <mode>s) [,list of supported <timernum>s]  OK
URC	+HTTP: <status> +HTTPS: <status>
URC	+HTTTPRES: <mode>,<reply>,<length>

### 1.3.3 Attributes

Pin Restricted	Persistent	Sync Mode	Effect Immediately	Time of duration	
Yes	No	No	Yes	< 1s	

### 1.3.4 Defined Values

<mode>: integer type and range 0-1

- 0 GET
- 1 POST.

<timernum>: integer type; timeout value, default value is 15s, range 10-60s.

<reply>: HTTP result code

- 200 OK
- 404 Not Found
- More in RFC2616

<length>: integer type; the length of data receive form server, max support 360000 byte.



<status>: integer type

- 0 connection failed
- 1 connection success

## 1.4 +HTTPREAD, Read data

### 1.4.1 Description

This command used to read data from module which are received from HTTP or HTTPS server.

### 1.4.2 Syntax

Command	Response
Read all received data: AT+HTTPREAD	OK +HTTPREAD: <reslength> Data or ERROR
Read part of received data: AT+HTTPREAD=<offset>,<length>	+HTTPREAD: <reslength> Data  OK or ERROR
AT+HTTPREAD?	OK
AT+HTTPREAD=?	+HTTPREAD: [<offset>,<length>]  OK

### 1.4.3 Attributes

Pin Restricted	Persistent	Sync Mode	Effect Immediately	Time of duration
Yes	No	No	Yes	< 1s

## 1.4.4 Defined Values

<offset>: integer type; offset from the head of received data. 0-360000

<length>: integer type; length to read. 1-360000

<reslength>: integer type; read data length actually. 1-360000



### Note:

HTTPREAD does not take parameters. After reading all the data, it clears the receiving buffer of HTTP or HTTPS.

## 1.5 +HTTPHEAD, Set HTTP or HTTPS header parameters

### 1.5.1 Description

The purpose of this command is that it will require HTTP header data to import modules through the serial port. Use in HTTP GET and POST requests.

### 1.5.2 Syntax

Command	Response
+HTTPHEAD=<length>	> ..... OK or ERROR
+HTTPHEAD?	OK
+HTTPHEAD=?	+HTTPHEAD: (1-5120)  OK

### 1.5.3 Attributes

Pin Restricted	Persistent	Sync Mode	Effect Immediately	Time of duration
Yes	No	YES	Yes	< 1s

### 1.5.4 Defined Values

<length>: integer type; length of the data will be input. Range 1-5120 byte.

**Note:**

1. When using HTTPHEAD, except URL, the other head parameters set by HTTPSET are invalid.
2. When the received data length reaches to the given size, the module exits from data mode and responses OK.
3. The time out of data input is 30 seconds, then the module exits from data mode and response ERROR.

Draft