

**NAME**

**mbgrd2obj** – GMT plug-in module to convert grid to OBJ format 3D model file.

**VERSION**

Version 5.0

**SYNOPSIS**

**mbgrd2obj** <gridfile> **-G**<objfile> [**-R**<west>/<east>/<south>/<north>[+r]] [**-V**[<level>]]

**DESCRIPTION**

**mbgrd2obj** is a plug-in module to generate a Geographically located GeoTiff image from a **GMT** grid file using **GMT** (Generic Mapping Tools). Like **mbgrdtiff**, **mbcontour**, and **mbswath**, **mbgrd2obj** is fully compatible with the **GMT** package version 6.

The OBJ format is used for 3D model files that can be imported into visualization software or used by 3D printers. This open format was developed by Wavefront Technologies for its visualization animation software, and has since been widely adopted in the 3D graphics and printing industries. This is a text based format that defines the geometry of objects and surfaces, and can also define color and texture. The OBJ files generated by **mbgrd2obj** represent the topographic surface derived from the input grid file as a set of triangles without color or texture information (though those capabilities may be added later). The **-R** option can be used to specify the bounds of the OBJ output; these bounds must be a subset of the area covered by the input grid. Areas of the grid represented as having no data are not included in the OBJ output. By default, the output OBJ file is named by replacing the ".grd" suffix of the input grid file with ".obj", or adding the ".obj" suffix to the input filename if the input does not have a ".grd" suffix. The **-G** option can be used to specify a different output OBJ file name.

In order for **GMT** to successfully execute **mbgrd2obj**, the location of the shared library *libmbgmt* containing this module must be known to **GMT**. This can be accomplished by either setting the GMT\_CUSTOM\_LIBS parameter in the file gmt.conf that is part of the GMT installation, by setting this parameter in the file gmt.conf in the user's home directory, or by using the GMT module **gmtset** to modify this parameter in the current working directory. If, for instance, the *libmbgmt* shared library has been installed in the file /usr/lib/libmbgmt.dylib, then the GMT\_CUSTOM\_LIBS parameter in a gmt.conf file can be set to:

```
GMT_CUSTOM_LIBS = /usr/lib/libmbgmt.dylib
```

On a linux system use the mbsystem shared library, e.g.:

```
GMT_CUSTOM_LIBS = /usr/local/lib/mbsystem.so
```

**MB-SYSTEM AUTHORSHIP**

David W. Caress

Monterey Bay Aquarium Research Institute

Dale N. Chayes

Center for Coastal and Ocean Mapping

University of New Hampshire

Christian do Santos Ferreira

MARUM - Center for Marine Environmental Sciences

University of Bremen

**OPTIONS**

**-G** <objfile>

Output topography OBJ format file. Default is to add ".obj" suffix to the input grid file name (replacing ".grd" suffix if possible). **-R** Specify the min/max coordinates of your data region in user units.

Use dd:mm[:ss] for regions given in arc degrees, minutes [and seconds].

Use **-R**<*xmin/xmax/ymin/ymax*>+<*unit*> for regions given in projected coordinates. with <*unit*> selected from e|f|k|M|n|u.

Use [*yyy[-mm[-dd]]T[hh[:mm[:ss[.xxx]]]]*] format for time axes. Append +r if **-R** specifies the coordinates of the lower left and upper right corners of a rectangular area.

Use **-R**<*gridfile*> to use its limits (and increments if applicable).

Use **-Rg** and **-Rd** as shorthands for **-R0/360/-90/90** and **-R-180/180/-90/90**. Derive region from closed polygons from the Digital Chart of the World (DCW): Append a comma-separated list of ISO 3166 codes for countries to set region, i.e., <*code1*>,<*code2*>,... etc., using the 2-character ISO country codes (see `pscoast -E+l` for list). To select a state of a country (if available), append .state, e.g. US.TX for Texas. To select a whole continent, give =AF|AN|AS|EU|OC|NA|SA as <*code*>.

Use +r to modify the region from polygon(s): Append <*inc*>, <*xinc*>/<*yinc*>, or <*winc*>/<*einc*>/<*sinc*>/<*ninc*> to round region to these multiples; use +R to extend region by those increments instead [0].

Or use **-R**<*code*><*x0*>/<*y0*>/<*n\_columns*>/<*n\_rows*> for origin and grid dimensions, where <*code*> is a 2-char combo from [T|M|B][L|C|R] (top/middle/bottom/left/center/right) and grid spacing must be specified via -I<*dx*>[/<*dy*>] (also see -r). **-V** Change the v erbosity level (currently v). Choose among 6 levels; each level adds more messages:

- q - Quiet, not even fatal error messages.
- n - Normal verbosity: only error messages.
- c - Also produce compatibility warnings [Default when no -V is used].
- v - Verbose progress messages [Default when -V is used].
- l - Long verbose progress messages.
- d - Debugging messages.

## EXAMPLES

Suppose we have obtained a GRD file called ZTopo.grd that contains seafloor topography. In order to obtain an OBJ file named ZTopo.obj, we use:

```
gmt mbgrd2obj ZTopo.grd -Vl
```

The output to the shell is:

```
mbgrd2obj [INFORMATION]: Processing input grid
mbgrd2obj [INFORMATION]: Reading grid from file ZTopo.grd
mbgrd2obj [INFORMATION]: Set boundary condition for all edges: natural
mbgrd2obj [INFORMATION]: Set boundary condition for left edge: natural
mbgrd2obj [INFORMATION]: Set boundary condition for right edge: natural
mbgrd2obj [INFORMATION]: Set boundary condition for bottom edge: natural
mbgrd2obj [INFORMATION]: Set boundary condition for top edge: natural
mbgrd2obj [INFORMATION]: 285087 vertices output
mbgrd2obj [INFORMATION]: 562024 triangles output
```

## SEE ALSO

**mbsystem(1)**, **mbgrid(1)**, **mbm\_grdtiff(1)**, **gmt(1)**

## BUGS

Let us know.