


AHB Master Project Documentation

Table of Contents

1. [About the protocol](#)
 2. [Supported and Unsupported Features](#)
 3. [Hardware Architecture and FSMs State Diagram](#)
 4. [HDL Coding](#)
 5. [Testing \(Test Cases and Testbenches\)](#)
 6. [Signal Descriptions](#)
 7. [Downloading & Runing the Simulation](#)
-

About the protocol

- AMBA AHB-Lite addresses the requirements of high-performance synthesizable designs.
- It is a bus interface that supports a single bus master and provides high-bandwidth operation.



Supported and Unsupported Features

Supported Features:

- Implements AHB-Lite Master functionality, capable of generating both read and write transactions.
- Supports burst modes of operation:
 - INCR: Incremental bursts where addresses increase sequentially.
 - SINGLE: Single data transfer.
- Data widths of 32 bits supported.
- State transitions for different types of transactions (IDLE, NONSEQ, SEQ, and BUSY) are implemented.

Unsupported Features:

- Advanced burst types such as WRAP are not supported in this module.
- No support for split, retry, or error handling mechanisms.
- Only HSIZE values supporting 4-byte transfers (word size) are implemented.

- Does not support multi-layer AHB implementations.

Hardware Architecture and FSMs State Diagram

Hardware Architecture:

The AHB Master consists of:

- **Control Unit:** FSM responsible for controlling the transaction phases.
- **Data Path:** Handles the transfer of data between the master and the slave.
- **Burst Controller:** Manages bursts, ensuring correct sequence of address increments for burst transfers.
- **CPU Interface:** Connects the master with an external CPU, providing instruction and control information.

FSM State Diagram:

1. IDLE State (HTRANS = 2'b00):

- Default state where no transfers are taking place. The master waits for work from the CPU interface.

2. NONSEQ State (HTRANS = 2'b10):

- Non-sequential address phase, indicating a new transfer request has started.


3. SEQ State (HTRANS = 2'b11):

- Sequential state, where burst transfers take place in sequence without gaps in the address space.

4. BUSY State (HTRANS = 2'b01):

- When the master cannot continue transferring but needs to keep the bus occupied.

The FSM transitions based on the availability of work, HREADY signal, and burst conditions.



HDL Coding

The module is written in Verilog HDL, implementing AHB Master logic as per the AHB-Lite protocol.

Key RTL Components:

- **HTRANS Generation:** The FSM drives the HTRANS signal based on transaction phases.
- **Data Path:** Handles input/output data from the CPU and writes/reads to/from the AHB slave.

Code Snippet:

```

always @(posedge HCLK or negedge HRESETn) begin
    if (!HRESETn)
        begin
            HTRANS <= IDLE;
        end
    else
        begin
            case (HTRANS)
                IDLE:begin
                    if (HREADY && work) begin
                        HTRANS <= NONSEQ;
                        burst_counter <= 0;
                    end
                end
                BUSY:begin
                    if (HREADY && work) begin
                        HTRANS <= SEQ;
                    end
                end
                NONSEQ:begin
                    if (HREADY) begin
                        if (!work)
                            HTRANS <= BUSY;
                        else if (HBURST) begin
                            // slave will increment the adress " HADDR <= HADDR + (4
<< HSIZE); "
                            burst_counter <= burst_counter + 1;
                            HTRANS <= SEQ;
                        end else begin
                            HTRANS <= IDLE;
                        end
                    end
                end
                SEQ:begin
                    if (HREADY) begin
                        // slave will increment the adress " HADDR <= HADDR + (4
<< HSIZE); "
                        burst_counter <= burst_counter + 1;
                        if (!work)
                            HTRANS <= BUSY;
                        else if (burst_counter < HBURST)
                            HTRANS <= SEQ;

                        else begin
                            HTRANS <= IDLE;
                        end
                    end
                end
                default:HTRANS <= IDLE;
            endcase
        end
    end
end

```

```
        endcase
    end
end
```

Testing (Test Cases and Testbenches)

The `AHB_Master_tb` testbench is designed to verify the functionality of the `AHB_Master` module by simulating various AHB-Lite transactions. This includes both read and write operations, handling of burst transfers, and appropriate state transitions within the finite state machine (FSM).

Testbench Description

The testbench instantiates the `AHB_Master` module and drives its inputs to simulate different operational scenarios. It checks the outputs and internal state transitions to ensure that the `AHB_Master` behaves as expected under various conditions.

Procedure:

- Apply a reset (`HRESETn = 0`) and then release it (`HRESETn = 1`).
- Check the initial state of `HTRANS` and other control signals.

Expected Result:

- `HTRANS` should be set to IDLE (`2'b00`).

2. Write Transaction (Incrementing Burst)

Objective:

Test the write operation in an incrementing burst mode.

Procedure:

- Set `cpu_inst` to initiate a write to address `0xAAAAAAAA` with data `0x00000000`.
- Configure `cpu_cont` for a 4-byte incrementing burst (`HBURST = INCR`), size 4-byte (`HSIZE = 3'b010`), and set `HWRITE` high.
- Assert `HREADY` and observe state transitions.

Expected Results:

- `HTRANS` should transition from IDLE to NONSEQ (`2'b10`), and then to SEQ (`2'b11`) for the burst continuation.
- The address should increment correctly for each beat of the burst.

3. Handling Slave Busy Signal

Objective:

Verify that the FSM correctly handles a busy slave by waiting on `HREADY`.

Procedure:

- During a burst write, set **HREADY** = 0 to simulate a busy slave.
- Observe the behavior of **HTRANS** and ensure it waits properly.

Expected Results:

- **HTRANS** should not advance to the next state while **HREADY** = 0.
- Once **HREADY** returns to 1, the FSM should continue to SEQ state as expected.

4. Read Transaction (Single Transfer)

Objective:

Verify a read operation with a single transfer type.

Procedure:

- Set **cpu_inst** to address 0xBFFFFFFF with no data (read operation).
- Configure **cpu_cont** for a single read transfer (**HBURST** = **SINGLE**) and set **HWRITE** low.
- Simulate valid read data from the slave on **HRDATA**.


Expected Results:

- **HTRANS** should transition to NONSEQ (2'b10) for the read operation.
- The correct data should be captured when **HREADY** = 1.

All cases were successful

```
VSIM 21> run
# NONSEQ transaction started at time 30
# SEQ transaction continued at time 70
# NONSEQ Read transaction started at time 90
# Transaction ended successfully at time 110
# Break in Module AHB_Master_tb at C:/Users/most'fa/Desktop/ADI/ASS/AMBA 3 AHB-Lite/AHB_Master_tb.v line 98
```

Wave Form




Signal Descriptions

Signal Name	Width	Direction	Description
HCLK	1	Input	Clock signal for the module.
HRESETn	1	Input	Active-low reset signal to initialize the module.
HADDR	32	Output	Address of the transaction being initiated by the master.
HBURST	3	Output	Burst type of the transaction (SINGLE, INCR, WRAP).

Signal Name	Width	Direction	Description
HSIZE	3	Output	Indicates the size of the data being transferred.
HTRANS	2	Output	Indicates the type of transfer (IDLE, BUSY, NONSEQ, SEQ).
HWDATA	32	Output	Data to be written to the slave during a write transaction.
HWRITE	1	Output	Indicates whether the current transfer is a write (1) or read (0).
HRDATA	32	Input	Data read from the slave during a read transaction.
HREADY	1	Input	Indicates whether the slave is ready to proceed with the transaction.
HRESP	1	Input	Indicates an error (1) or OK (0) response from the slave.
cpu_inst	64	Input	Contains the instruction from the CPU (address and data).
cpu_cont	8	Input	Control signals from the CPU (size, burst, work).

Detailed Descriptions:

- **HCLK**: The main clock signal that drives the timing of the AHB Master module.
- **HRESETn**: An active-low reset signal that initializes or resets the state of the AHB Master module.
- **HADDR**: Carries the memory address for read/write transactions initiated by the master.
- **HBURST**: Specifies the type of burst transaction, such as single, incremental (INCR), or wrapped (WRAP).
- **HSIZE**: Indicates the size of the data for the current transaction (e.g., 4 bytes for 32-bit data).
- **HTRANS**: Defines the type of transfer, including IDLE, BUSY, NON-SEQ (non-sequential), and SEQ (sequential).
- **HWDATA**: The data to be written to the slave during write transactions.
- **HWRITE**: Signals whether the current operation is a write (1) or a read (0).
- **HRDATA**: The data read from the slave during read transactions.
- **HREADY**: Indicates if the slave is ready to accept the next transaction or is still processing the current one.
- **HRESP**: Provides feedback from the slave, where 1 indicates an error and 0 indicates success.
- **cpu_inst**: Contains both the address (upper 32 bits) and data (lower 32 bits) from the CPU for the current operation.
- **cpu_cont**: Control signals from the CPU that include burst size, data size, and the direction of the transfer (read or write).



Downloading & Running the Simulation

Downloading the Repository

To download the testbench and associated files, follow these steps:

1. Clone the repository from GitHub:

```
git clone https://github.com/mgma10/ahb_master_project.git
```

2. Navigate to the project directory:

```
cd ahb_master_project
```

Running the Simulation

The simulation can be run using the run.do script provided in the repository. This script automates the compilation and simulation process.

1. Open your simulation tool (e.g., ModelSim).
2. Load the run.do script:

bash

```
do run.do
```

3. The script will compile the testbench and run the simulation. You can view the results in the waveform window.