

Operators AFFE_CHAR_CINE and AFFE_CHAR_CINE_F

1 Drank

Définir a loading of the type "imposed degrees of freedom".

This command can be used with a mechanical, thermal or acoustic model. The processing of these "kinematical" conditions will be done without dualisation and thus without addition of degrees of freedom of Lagrange.

- 1) For AFFE_CHAR_CINE (except for case EVOL_IMPO) , the affected values do not depend on any parameter and are defined by actual values (mechanics or thermal) or complex values (acoustics). These values can be null (blocking).
- 2) For AFFE_CHAR_CINE_F, the values affected are functions of one (or several) parameters to be chosen as a whole (INST, X, Y, Z) .

Product a data structure of the char_cine_* type .

2 Syntax Générale

```
CH [char_cine_*] = AFFE_CHAR_CINE

( ♦MODELE      = Mo ,                                [model]

  ♦ /  MECA_IMPO =                                (see key word MECA_IMPO),
    /THER_IMPO  =                                (see key word THER_IMPO),
    /ACOU_IMPO  =                                (see key word ACOU_IMPO),
    /EVOL_IMPO  = evoimp / [evol_ther]
                                / [evol_elas]
                                / [evol_noli]

                                ♦NOM_CMP      = lcmp                                [l_TXM]

)

siMECA_IMPOalors                                [*]                                meca
siTHER_IMPOther
siACOU_IMPOacou
siEVOL_IMPOalors                                [*]                                meca or ther
(according to evoimp)
```

```
CH [char_cine_*] = AFFE_CHAR_CINE_F

( ♦MODELE      = Mo ,                                [model]

  ♦ /  MECA_IMPO =                                (see key word MECA_IMPO),
    /THER_IMPO  =                                (see key word THER_IMPO),

)

siMECA_IMPOalors                                [*]                                meca
siTHER_IMPOther
```

3 Généralités

Ces two commands creates concepts of the type `char_cine_*` (`_meca/_ther`).

Command `AFFE_CHAR_CINE` can also create concepts of the `char_cine_acou` type .

These types are different from the type `loads` created by commands `AFFE_CHAR_MECA` [U4.44.01], `AFFE_CHAR_THER` [U4.44.02] or `AFFE_CHAR_ACOU` [U4.44.04]).

The objects created are thus not interchangeable.

The advantage of the “kinematical” loads is that they do not increase the number of unknown factors of the systems to be solved, contrary to the method of dualisation by LAGRANGE multipliers, used in the commands producing a concept of the type `charges` .

On the other hand, the use of these loads comprises the following limitations:

- one can use them only in the case of relation of the type “d. o. f. imposed” (and not for linear relations),
- these loads are not yet allowed in all the total commands. Today the possible commands are:
 - `STATIC MECA_`, `STAT_NON_LINE`, `DYNA_NON_LINE`
 - `THER_LINEAIRE`
- for a computation not using the total commands: assembly of a matrix, then resolution, the sequence of commands to be used is more intricate than with “ordinary” loads as one can see it in example 2 [§ 5.2].

4 Généralités

4.1 operands on the operands

Les operands under the key words factors MECA_IMPO , THER_IMPO and ACOU_IMPO are of two forms:

- operands specifying the geometrical entities on which the loadings are affected (key words GROUP_MA , GROUP_NO , NODE ...). The arguments of these operands are identical for the two operators.
- operands specifying the affected values (DX , DY , DZ , etc...). The meaning of these operands is the same one for the two operators. The arguments of these operands are all of the real type for operator AFFE_CHAR_CINE and of the standard function (or formulates) for operator AFFE_CHAR_CINE_F .

This is true near with an exception: the key word factor ACOU_IMPO (which does not exist in command AFFE_CHAR_CINE_F) is always of complex type.

We will thus not distinguish in this document, except mention express of the opposite, two operators AFFE_CHAR_CINE and AFFE_CHAR_CINE_F .

In a general way, the entities on which values must be affected are defined by nodes:

- 1) either by the operand TOUT = "OUI" which makes it possible to indicate all the nodes of the mesh,
- 2) or by operand GROUP_NO allowing to indicate a list of nodes groups,
- 3) or by the operand NODE allowing to indicate a list of nodes.
- 4) maybe by the operands GROUP_MA and MESH allowing to indicate all the nodes carried by the meshes indicated by the lists of MESH and GROUP_MA .

4.2 Behavior in the event of overload:

4.2.1 Overload within one only command AFFE_CHAR_CINE

Lorsqu' one uses within the same command, several occurrences of MECA_IMPO (or THER_IMPO ,...) and that certain nodes are affected several times, it is the last occurrence which precedes. For example:

```
chcine= AFFE_CHAR_CINE (MECA_IMPO= (
    _F (TOUT='OUI',    DX= 1. ,...)
    _F (NOEUD='N3',    DX= 3. ,...)
```

In this case, displacement imposed DX for the N3 node is worth: 3.

4.2.2 Overload between several commands AFFE_CHAR_CINE

If several different commands are used, the behavior is different. For example:

```
chcin1= AFFE_CHAR_CINE (MECA_IMPO= _F (TOUT='OUI',    DX= 1. ,...)
chcin2= AFFE_CHAR_CINE (MECA_IMPO= _F (NOEUD='N3',    DX= 3. ,...)
```

In this case, displacement imposed DX for the N3 node is worth: 4 (because 1+3)

4.2.3 Surcharge between AFFE_CHAR_CINE and AFFE_CHAR_MECA

If one "mixes" commands AFFE_CHAR_MECA and AFFE_CHAR_CINE , the code will stop in fatal error (FACTOR_41) by explaining why there is a superabundant relation of blocking (N3 NODE / DX).

4.3 Operand MODELE

◆MODELE = Mo

Product concept by operator AFFE_MODELE [U4.41.01] where the types of finite elements affected on the mesh are defined.

4.4 Key word MECA_IMPO

4.4.1 Drank

Key word factor usable to impose, with nodes or nodes groups, a value of displacement, definite component by component in the total reference.

These boundary conditions will be treated, thereafter, by the method known as of elimination of the imposed degrees of freedom (i.e. without dualisation, contrary to the processing of the same type of limiting condition by the use of operators AFFE_CHAR_MECA or AFFE_CHAR_MECA_F [U4.44.01]).

4.4.2 Syntax

AFFE_CHAR_CINE

```

    /MECA_IMPO      =  ( _F      (  ◆  /  TOUT =      'OUI'  ,
                                /  |  NODE =lno                ,
[l_noeud]
                                |  GROUP_NO =lgno      ,      [l_gr_noeud]
                                |  NET =lma            ,      [l_maille]
                                |  GROUP_MA =lgma      ,
[l_gr_maille]
                                ◆  |  DX =UX            ,      [R]
                                |  DY =UY            ,      [R]
                                |  ... (see the complete listing below)
                                ), ),
    ), ),

```

AFFE_CHAR_CINE_F

```

    /MECA_IMPO      =  ( _F      (  ◆  /  TOUT =      'OUI'  ,
                                /  |  NODE =lno                ,
[l_noeud]
                                |  GROUP_NO =lgno      ,      [l_gr_noeud]
                                |  NET =lma            ,      [l_maille]
                                |  GROUP_MA =lgma      ,
[l_gr_maille]
                                ◆  |  DX =u              xf      ,      [function (
* ) ]
                                |  DY =u              yf      ,      [function (
* ) ]
                                |  ... (see the complete listing below)
                                ), ),
    ), ),

```

function (*): function or Liste

formula of the key words available under MECA_IMPO in AFFE_CHAR_CINE :

"DRX"	"DRY"	"DRZ"	"DX"	"DY"	"DZ"
"E1X"	"E1Y"	"E1Z"	"E2X"	"E2Y"	"E2Z"
"E3X"	"E3Y"	"E3Z"	"E4X"	"E4Y"	"E4Z"
"GONF"	"GRX"	"H1X"	"H1Y"	"H1Z"	"PHI"
"PRE1"	"PRE2"	"PRES"	"PRES11"	"PRES12"	"PRES13"
"PRES21"	"PRES22"	"PRES23"	"PRES31"	"PRES32"	"PRES33"
"TEMP"	"UI2"	"UI3"	"UI4"	"UI5"	"UI6"
"UO2"	"UO3"	"UO4"	"UO5"	"UO6"	"V11"
"V12"	"V13"	"V21"	"V22"	"V23"	"V31"
"V32"	"V33"	"VI2"	"VI3"	"VI4"	"VI5"
"VI6"	"VO2"	"VO3"	"VO4"	"VO5"	"VO6"
"WI1"	"WI2"	"WI3"	"WI4"	"WI5"	"WI6"
"WO"	"WO1"	"WO2"	"WO3"	"WO4"	"WO5"
"WO6"	"LH1"				

List key words available under MECA_IMPO in AFFE_CHAR_CINE_F :

"DRX"	"DRY"	"DRZ"	"DX"	"DY"	"DZ"
"GRX"	"PRE1"	"PRE2"	"PRES"	"TEMP"	"PHI"

They are the names of the degrees of freedom carried by the finite elements of the model. The meaning of these names is to be sought in the documentation of the finite elements.

4.4.3 Operands

/MECA_IMPO

DX = ux or ux f	Valeur of the component of displacement
DY = uy or uy f	in translation imposed
DZ = uz or uz f	on the specified nodes

Uniquement for the nodes of a comprising model 3D of the beam elements, plates, shell, discrete:

DRX = drx or drx f	Valeur of the component of displacement
DRY = dry or dry f	in rotation imposed
DRZ = drz or drz f	on the specified nodes

Pour "exotic" degrees of freedom more: GRX , TEMP , PRES and PHI , one will refer to the documentation of command AFFE_CHAR_MECA [U4.44.01 §3.9].

Caution:

It is checked that the specified degree of freedom exists in this node for at least one of the elements of the model (key word `MODELE`) which lean on this node.

Moreover, the rule of overload is observed when the same degree of freedom of the same node is imposed several times: only the last value is retained.

4.5 Key word THER_IMPO

4.5.1 Drank

Key word factor usable to impose, with nodes or nodes groups, a value of nodal temperature.

These boundary conditions will be treated, thereafter, by the method known as of elimination of the imposed degrees of freedom (i.e.: without dualisation contrary to the processing of the same type of limiting condition by the use of operators AFFE_CHAR_THER or AFFE_CHAR_THER_F [U4.44.02])

4.5.2 Syntaxe

for AFFE_CHAR_CINE

```
/THER_IMPO = (_F ( ♦ /TOUT = 'OUI" ,
                  / | NODE =lno , [l_noeud]
                  | GROUP_NO =lgno , [l_gr_noeud]
                  | NET =lma , [l_maille]
                  | GROUP_MA =lgma , [l_gr_maille]
                  ♦ | TEMP =T , [R]
                  | TEMP_SUP =TSUP , [R]
                  | TEMP_INF =tinf , [R]
                  ), ),
```

for AFFE_CHAR_CINE_F

```
/THER_IMPO = (_F ( ♦ / TOUT = 'OUI' ,
                  / | NODE =lno , [l_noeud]
                  | GROUP_NO =lgno , [l_gr_noeud]
                  | NET =lma , [l_maille]
                  | GROUP_MA =lgma , [l_gr_maille]
                  ♦ | TEMP =ft , [function ( *
                  | TEMP_SUP =ftsup , [function ( *
                  | TEMP_INF =ftinf , [function ( *
                  ), ),
```

function (*): function or Opérandes

4.5.3 formula

- | TEMP
Temperature imposed on the nodes (or on the average layer for the thermal shells)
- | TEMP_INF
Temperature imposed on the lower face for the thermal shell elements.
- | TEMP_SUP
Temperature imposed on the higher face for the thermal shell elements.

For the shells, the sides lower and higher are defined, mesh by mesh, the direction of the external norm deducted of the numbers of the nodes: see FACE_IMPO of AFFE_CHAR_MECA [U4.44.01].

4.6 Key word ACOU_IMPO

4.6.1 Drank

Key word factor usable to impose, with nodes or nodes groups, a value of acoustic pressure.

These boundary conditions will be treated, thereafter, by the method known as of elimination of the imposed degrees of freedom (i.e.: without dualisation contrary to the processing of the same type of limiting condition by the use of operator AFFE_CHAR_ACOU [U4.44.04]).

4.6.2 Syntax

For AFFE_CHAR_CINE

```
/ACOU_IMPO = ( _F ( ♦ /TOUT = 'OUI' ,  
/ | NODE =lno ,  
[l_noeud]  
| GROUP_NO =lgno , [l_gr_noeud]  
| NET =lma , [l_maille]  
| GROUP_MA =lgma ,  
[l_gr_maille]  
♦PRES =p , [C]  
) , ) ,
```

Pour AFFE_CHAR_CINE_F :

No key word ACOU_IMPO because it does not have yet a complex function there.

4.6.3 Operands

PRES

Valeur of the complex acoustic pressure imposed on (S) the node (S) specified (S).

4.7 Key word EVOL_IMPO = evoimp NOM_CMP = ("DX", "DY")

This key word allows the "structural zoom" (see for example the test zzzz230a).

The effect of this key word is to impose **all** the ddls of the evolution **evoimp** as if they were functions of time. This possibility is offered for the data structures **evol_elas**, **evol_noli** and **evol_ther**.

To make a "structural zoom", it should not be forced the ddls that on the nodes of edge of model "the zoom". That wants to say that it is in general necessary to project "coarse" computation on the meshes of edge of model "the zoom".

If, moreover, one does not want to impose all the components, it is necessary to use key word **NOM_CMP** to choose the components to be imposed (by defect: all).

Note:

- *Attention not to use several **EVOL_IMPO** on areas common (if not there will be office plurality of the specified values)*
- *Attention to the use of **FONC_MULT** with **EVOL_IMPO** : the result will not be can be not until one waits!*
- *The **EVOL_IMPO** will be used for any value of time understood enters **tmin** and **tmax** (extreme values of times of transient **EVOL_IMPO**). Apart from this interval, one emits a fatal error (prohibited extrapolation).*

- If `EVOL_IMPO` has only one time, one allows the "constant" prolongation and one emits an alarm.

5 Degrees of freedom

5.1 examples imposed in mechanics

```
chcine =AFFE_CHAR_CINE      (MODELE = Mo,  
                             MECA_IMPO= (  
                               _F (TOUT = "OUI" , DRZ = 0.),  
                               _F (GROUP_NO = "bord1", DX =0 ., DY =0 ., DZ =0 .,  
                                   DRX =0 ., DRY =0 .,))
```

For this problem of plate in the plane XY , one locks all the degrees of freedom of rotation around Z and one embeds the plate on his edge *bord1* .

5.2 Compared use of the kinematical loads and “ordinary”

5.2.1 Total commands

```
ch1=AFFE_CHAR_THER      (...)
ch2=AFFE_CHAR_CINE_F    (TEMP_IMPO =_F  (...))
evoth=THER_LINEAIRE     ( ...
EXCIT = ( _F (LOAD = ch1),
          _F (LOAD = ch2),
          ...)
```

There is no difference.

5.2.2 Computation “step by step”

ordinary Loads

```
ch1=AFFE_CHAR_MECA      (...)
mel=CALC_MATR_ELEM      (... OPTION = "RIGI_MECA" , = ch1 CHARGES)
matas=ASSE_MATRICE      ( MATR_ELEM = mel...)
matas=FACTORISER        ( reuse = subdued, MATR_ASSE = subdued)
U=RESOUDRE              ( MATR = subdued, CHAM_NO = F)
```

Kinematical loads

```
ch1=AFFE_CHAR_CINE      (...)
mel=CALC_MATR_ELEM      (... OPTION = "RIGI_MECA")
matas=ASSE_MATRICE      ( MATR_ELEM = mel,..., CHAR_CINE = ch1)
matas=FACTORISER        ( reuse = subdued, MATR_ASSE = subdued,)
vcine=CALC_CHAR_CINE    (... , CHAR_CINE = ch2,)
U=RESOUDRE              ( MATR = subdued, CHAM_NO = F,
                        CHAM_CINE = vcine)
```

Les terms induced by the kinematical loads are deferred to the second member what requires the computation of an additional field to the nodes *vcine* by command `CALC_CHAR_CINE` [U4.61.03].