

3mflmporter

[Desktop Automation]

This class is used to import 3MF files in a custom way.

- [Properties](#)
- [Methods](#)

Properties

Property	Read/write	Type	Description
meshcount	Read	Number	Number of meshes inside the 3MF (1 if <code>SplitMeshes</code> was set to FALSE when the object was created.
splitmeshes	Read	Boolean	The value of the "SplitMeshes" parameter passed on creation

[Back to top](#)

Methods

Name	Syntax	Description
getmesh	Mesh = importer.getmesh(Index: Number);	Returns the mesh at the given index. Returns <code>nil</code> if the index is out of bounds.
getpartnumber	PartNumber = importer.getpartnumber(Index: Number);	Get the part number of a mesh. Returns an empty string if index is out of bounds.

[Back to top](#)

Parent page: System (?guid=NETF-LUA-SYSTEMOBJ)