

microcontroller - Pin references and cpu functionality

The `microcontroller` module defines the pins from the perspective of the microcontroller. See `board` for board-specific pin mappings.

`microcontroller.cpu` :*Processor*

CPU information and control, such as `cpu.temperature` and `cpu.frequency` (clock frequency). This object is the sole instance of `microcontroller.Processor`.

`microcontroller.delay_us(delay: int) → None`

Dedicated delay method used for very short delays. **Do not** do long delays because this stops all other functions from completing. Think of this as an empty `while` loop that runs for the specified (`delay`) time. If you have other code or peripherals (e.g audio recording) that require specific timing or processing while you are waiting, explore a different avenue such as using `time.sleep()`.

`microcontroller.disable_interrupts() → None`

Disable all interrupts. Be very careful, this can stall everything.

`microcontroller.enable_interrupts() → None`

Enable the interrupts that were enabled at the last disable.

`microcontroller.on_next_reset(run_mode: microcontroller.RunMode) → None`

Configure the run mode used the next time the microcontroller is reset but not powered down.

Parameters: `run_mode` (*RunMode*) – The next run mode

`microcontroller.reset() → None`

Reset the microcontroller. After reset, the microcontroller will enter the run mode last set by `on_next_reset`.

Warning: This may result in file system corruption when connected to a host computer. Be very careful when calling this! Make sure the device “Safely removed” on Windows or “ejected” on Mac OSX and Linux.

`microcontroller.nvm` :*Optional[ByteArray]*

Available non-volatile memory. This object is the sole instance of `nvm.ByteArray` when available or `None` otherwise.

Type: `nvm.ByteArray` or `None`

`microcontroller.watchdog` :*Optional[WatchDogTimer]*

Available watchdog timer. This object is the sole instance of `watchdog.WatchDogTimer` when available or `None` otherwise.

`class microcontroller.Pin`

Identifies an IO pin on the microcontroller.

Identifies an IO pin on the microcontroller. They are fixed by the hardware so they cannot be constructed on demand. Instead, use `board` or `microcontroller.pin` to reference the desired pin.

class `microcontroller.Processor`

Microcontroller CPU information and control

Usage:

```
import microcontroller
print(microcontroller.cpu.frequency)
print(microcontroller.cpu.temperature)
```

You cannot create an instance of `microcontroller.Processor`. Use `microcontroller.cpu` to access the sole instance available.

frequency :*int*

The CPU operating frequency in Hertz. (read-only)

temperature :*Optional[float]*

The on-chip temperature, in Celsius, as a float. (read-only)

Is `None` if the temperature is not available.

uid :*bytearray*

The unique id (aka serial number) of the chip as a `bytearray`. (read-only)

voltage :*Optional[float]*

The input voltage to the microcontroller, as a float. (read-only)

Is `None` if the voltage is not available.

class `microcontroller.RunMode`

run state of the microcontroller

Enum-like class to define the run mode of the microcontroller and CircuitPython.

NORMAL :*RunMode*

Run CircuitPython as normal.

SAFE_MODE :*RunMode*

Run CircuitPython in safe mode. User code will not be run and the file system will be writeable over USB.

BOOTLOADER :*RunMode*

Run the bootloader.