

# quick Mesh project (qMp.cat) workshop

guifi.net community

December 23, 2014

## Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
<b>2</b>	<b>Installer basics: Items</b>	<b>2</b>
<b>3</b>	<b>Installer basics: 5GHz devices</b>	<b>3</b>
<b>4</b>	<b>Flash qMp node</b>	<b>4</b>
<b>5</b>	<b>qMp basics: Testing operations</b>	<b>9</b>
<b>6</b>	<b>qMp basics: Basic install and maintaining</b>	<b>14</b>
<b>7</b>	<b>qMp basics: Navigating inside the network</b>	<b>17</b>
<b>8</b>	<b>Proposed qMp cloud node designs: WAN node design</b>	<b>17</b>
<b>9</b>	<b>Proposed qMp cloud node designs: General node design</b>	<b>19</b>
<b>10</b>	<b>Making a panorama with Hugin</b>	<b>20</b>
<b>11</b>	<b>About monitoring</b>	<b>22</b>
11.1	From the guifi web . . . . .	22
11.2	munin: . . . . .	24
11.3	qmpsu: . . . . .	25

## 1 Introduction

The basic material to deploy qMp cloud networks.

The radios used have Power over Ethernet (PoE) of 24V, it means that the electrical power and data of the radio goes through an ethernet cable. The blue cable in figure 1 is what is deployed into an outdoor place (typically rooftop or a balcony) where the qMp devices will be installed and takes the POE interface in PoE injector. The other interface in the PoE injector is LAN <sup>1</sup> and can be placed to a PC or a switch/router if it is wanted to connect more PC's. Finally, the PoE injector requires standard electrical power. **Warning:** a PoE connection to a device that is not prepared to work with PoE 24V, for example an ethernet interface of a computer, can produce malfunction of its ethernet interface.




Figure 1: PoE network diagram

## 2 Installer basics: Items

- Outdoor cable and rj45 connectors (sold separately)  
The cable should be for outdoor to resist the weather.
- UTP cable: cable without protection. But sometimes it is enough.

---

<sup>1</sup>LAN cable can make a length up to 100m if only is carrying data

- FTP cable (recommended): cable with basic protection. ESD prevention <sup>2</sup>. The difference is that the cable has ground.
- Crimp tool: to join rj45 connector to cable.
- Cable tester (recommended): a unexpensive one can help to work quickly and reliably in the installation of cable.
- Cable cutter: To take a segment of cable for a installation. Note: UTP cable is easier to cut than FTP.
- Cable tie: To lock the cable & radio to a mast and other cables.
- Shopping cart or traveling bag with wheels (recommended): carry all the items needed.
- Measure meter: measure accurately the length of cable needed (optional).

### 3 Installer basics: 5GHz devices

The devices selected are working in the 5 GHz band because 2.4GHz is widely used in cities and have more interferences. They are from Ubiquiti manufacturer and compatible with qMp firmware.

**Unexpensive** less than 100 euro.

**NanoStation Loco M5 (NSLM5)** Short distances (less than 1km). The connection with the other candidate node has an acceptable connection and there is no need to increase the power signal of wifi. It uses the same firmware as NanostationM5.

**Nanostation M5 (NSM5)** <sup>3</sup> If is needed a better connection to specific node.

**NanoBeam M5 different models** <sup>4</sup> When there is a long distance connection (more than 1km). Use the same firmware as NanostationM5. Is the evolution of NanoBridge M5 that is now deprecated.

**Expensive** more than 100 euro.

---

<sup>2</sup>[http://en.wikipedia.org/wiki/Electrostatic\\_discharge](http://en.wikipedia.org/wiki/Electrostatic_discharge)

<sup>3</sup>[http://dl.ubnt.com/datasheets/nanostationnm/nsm\\_ds\\_web.pdf](http://dl.ubnt.com/datasheets/nanostationnm/nsm_ds_web.pdf)

<sup>4</sup>[http://ubnt.com/downloads/datasheets/nanobeam/NanoBeamM\\_DS.pdf](http://ubnt.com/downloads/datasheets/nanobeam/NanoBeamM_DS.pdf)

**Rocket M5** <sup>5</sup> Base station to put different kind of antennas.

**Rocket M5 + Sector Antenna (S) 90 or 120 deg** <sup>6</sup> when the need is to cover a sector region with constant coverage of 90 or 120 deg. There are High Gain (HG) and Mid Gain (MG) versions.

**Rocket M5 + Dish (D)** <sup>7</sup> Longest distances (50km link <sup>8</sup>).

Summary of some relevant information at Table 1:

Devices	Table 1: Devices specifications				
	Gain (dBi)	Beamwidth (deg) Hpol/Vpol/Elevation	Proc.	RAM (MB)	Flash (MB)
NSLM5	13	45/45/45	24KC	32 S	8
NSM5	16	43/41/15	24KC	32 S	8
NBM5	16, 19, 22, 25	see on datasheet	74KC	64 D	8
RM5 S90 MG, HG	17, 20	see on datasheet	24KC	64 S	8
RM5 S120 MG, HG	16, 19	see on datasheet	24KC	64 S	8
RM5 D	30, 34	see on datasheet	24KC	64 S	8

**Proc** Processor Specs.

**24KC** Atheros MIPS 24KC, 400MHz

**74KC** Atheros MIPS 74KC, 560MHz

**RAM** Type of RAM:

**S** SDRAM

**D** DDR2

## 4 Flash qMp node

Steps to flash a device with qMp firmware. It is assumed a GNU/Linux Ubuntu/Debian computer:

---

<sup>5</sup>[http://ubnt.com/downloads/rocketM5\\_DS.pdf](http://ubnt.com/downloads/rocketM5_DS.pdf)

<sup>6</sup><http://dl.ubnt.com/AirMax5GSectors.pdf>

<sup>7</sup>[http://ubnt.com/downloads/datasheets/rocketdish/rd\\_ds\\_web.pdf](http://ubnt.com/downloads/datasheets/rocketdish/rd_ds_web.pdf)

<sup>8</sup><http://blog.altermundi.net/article/completamos-el-enlace-de-50km/>

1. Download the **Factory image** <sup>9</sup> for a supported device that has the factory operating system <sup>10</sup>. **Sysupgrade image** is for OpenWRT or qMp nodes that want to upgrade. **Guifi image** has better integration with guifi.net web.
2. Rename the downloaded file to `qmp.bin`.
3. Download the tftp packets with the system's repository. In terminal:  
`$ sudo apt-get install tftp-hpa.`
4. Disconnect the internet connection.
5. Open a terminal and put:

```
$ ping 192.168.1.20
```

It will help to know when the antenna is in the reset mode.

6. Connect the equipments as shown in Figure 2.
7. Configure the network following one of these options:
  - (a) **GUI option:** configure in the preferred network manager a ethernet network with static IP in the computer to connect to the device:  
IP: 192.168.1.10  
Subnet: 192.168.1.100  
Gateway: 192.168.1.1
  - (b) **Terminal option:**  
`$ sudo ip a a 192.168.1.25/24 dev eth0`
8. Reset the device following one of these options:
  - (a) **Reset in the antenna option:** Disconnect the interface of the antenna. Remove the antenna's lid. With one hand take an object with round toe, press and hold reset button (Figure 3) while with the other hand insert the ethernet cable to the interface in antenna.

---

<sup>9</sup><http://fw.qmp.cat/>

<sup>10</sup>[http://qmp.cat/Supported\\_devices](http://qmp.cat/Supported_devices)




Figure 2: Network Diagram to Flash Antenna

- (b) **Reset in the PoE injector option:** Check if the device has PoE (Figure 4). Disconnect the POE interface in PoE injector. With one hand take an object with round toe, press and hold reset button while with the other hand insert the ethernet cable to the POE interface in PoE injector.

9. Observe if the antenna start the reset mode needed for continue:

- **Antenna led option:** Wait until the led 1 and 3 change to 2 and 4 cyclically. With this video resource it will give an idea of time and led colors involved in the process <sup>11</sup>.
- **PC screen option:** the ping starts responding. The output of

<sup>11</sup>[https://www.youtube.com/watch?v=xIf1E\\_-V-B4#t=50s](https://www.youtube.com/watch?v=xIf1E_-V-B4#t=50s)



Figure 3: Reset antenna

the ping 192.168.1.20 should be something like:

64 bytes from X: icmp\_req=X ttl=X time=X ms

10. If is in reset mode stop pressing the reset button and put the device in a stable place.
11. In a new terminal window, go where is the downloaded firmware qmp.bin:

```
cd /path/to/the/qmpbin_folder
```

And there, execute:

```
$ tftp 192.168.1.20
$ mode octet
$ trace
$ put qmp.bin
```

```
[ Transmission process ]
```

```
$ quit
```



Figure 4: Reset power injector

12. After about 5 minutes, the 4th led of the ramp (the most right led, Figure 5) is on, and not blinking. This is the moment to go the next step.
13. Reconfigure the network to do a DHCP client in ethernet port (Automatic IP) and try to connect again the PC with the device.
14. Check that the device responds to ping:

```
$ ping 172.30.22.1
```

This is the fixed IP address in roaming mode.

More general approach is to get the gateway address:

```
$ ip r | grep default | cut -f3 -d' '
```

Open a web browser and check if this web can be accessed (**Warning** admin.qmp it will only work if the PC is connected to the device via DHCP):

```
http://admin.qmp
```

alternatives:

```
http://172.30.22.1
```

```
http://<gateway_ip>
```






Figure 5: Led system in the antenna

15. Login access is user: root  
password: 13f

Other references <sup>12</sup> , <sup>13</sup> , <sup>14</sup>

## 5 qMp basics: Testing operations

Figure 6 shows the first screen obtained when there is a log in a qMp node. To come back to this screen, go to the menu clicking at:

qMp/Mesh / Status

alternatively:

`http://admin.qmp/cgi-bin/luci/qmp/status`

When there is a scroll down action, appears Associated Stations. Figure 7 has the wifi links with other qMp nodes and what signal associated (dBm). The guifi.net good practices says that the backbone should be better than -75dBm <sup>15</sup>. In that figure there are different kind of links with different qualities. Good quality means high parameters of: dBm, RX Rate, TX Rate [bandwidth (Mbps)] and MCS codification (the number).

These qualities refer to connection to different nodes, only is shown the MAC address. But the MAC is enough to identify a node, because the last

<sup>12</sup>[http://wiki.ubnt.com/Firmware\\_Recovery](http://wiki.ubnt.com/Firmware_Recovery)

<sup>13</sup><http://www.qmp.cat/#Use-the-firmware>

<sup>14</sup>ftp info: <http://wiki.openwrt.org/doc/howto/generic.flashing.tftp>

<sup>15</sup>Catalan: <http://guifi.net/ca/BonesPractiquesUER>




Figure 6: First screen

four characters are appended in every hostname of the network. Later, it will be known how to navigate to different nodes in the network.

Another measure of quality is shown on Figure 8. This is the quality in terms of the protocol bmx6. A 0-100 rating in terms of reception and transmission (rx/tx).

To arrive there, go to the menu clicking at:

qMp/Mesh / Mesh / Links

alternatively:

`http://admin.qmp/cgi-bin/luci/qmp/mesh/links`

Also, can be made a bandwidth test between nodes. Figure 9 perform a TCP connection benchmark and give the Mbps between the node and other possible destinations. Wait until a single test ends to know all the bandwidth in the link or route.

To arrive there, go to the menu clicking at:

qMp/Mesh / Tools

alternatively:

`http://admin.qmp/cgi-bin/luci/qmp/tools`

Figure 10. After the general scan, when there is a node candidate to do a durable connection, there is the need to analyse the quality of this link in real-time. This helps to select an optimised place to lock the antenna in the installation.

Active Connections

49 / 16384 (0%)

DHCP Leases

Hostname	IPv4-Address	MAC-Address	Leasetime remaining
There are no active leases.			

DHCPv6 Leases

Hostname	IPv6-Address	DUID	Leasetime remaining
There are no active leases.			

Wireless

Generic 802.11an Wireless Controller (radio0)

71%

SSID: [BCNPonsiGallarza24-](#)

Mode: Ad-Hoc

Channel: 132 (5.660 GHz)

Bitrate: 131.6 Mbit/s

BSSID: 02:CA:FF:EE:BA:BE

Encryption: -

Associated Stations

MAC-Address	Network	Signal	Noise	RX Rate	TX Rate
DC:9F:D8:04:85:23	<a href="#">Ad-Hoc "BCNPonsiGallarza24-"</a>	-77 dBm	-95 dBm	6.0 Mbit/s, MCS 0, 20MHz	60.0 Mbit/s, MCS 9, 40MHz
24:A4:3C:E8:5F:BC	<a href="#">Ad-Hoc "BCNPonsiGallarza24-"</a>	-85 dBm	-95 dBm	6.0 Mbit/s, MCS 0, 20MHz	6.5 Mbit/s, MCS 0, 20MHz
24:A4:3C:00:0F:28	<a href="#">Ad-Hoc "BCNPonsiGallarza24-"</a>	-40 dBm	-95 dBm	6.0 Mbit/s, MCS 0, 20MHz	270.0 Mbit/s, MCS 15, 40MHz

Mesh nodes

Hostname	Primary IP	Via Device	Metric	Last Desc	Last Ref	Blocked
BCNLafabraRd2-8523	f666:66:66:29:de9f:dbff:fe05:8523	wlan0.12	52472K	23153	0	0
BCNLenguadoc17p0-d94d	f666:66:66:7:c24a:ff:fe93:d94d	wlan0.12	37808K	5767	1	0
BCNLenguadoc17p3-dad3	f666:66:66:7:c24a:ff:fe93:dad3	wlan0.12	37808K	6577	1	0
BCNLenguadoc17rouffp-3958	f666:66:66:79:de9f:dbff:fe44:3958	wlan0.12	37808K	23932	1	0
BCNPonsiGallarza10-0f28	f666:66:66:9:26a4:3cff:fe01:f28	wlan0.12	56000K	18614	0	0
BCNPonsiGallarza24-0e1d	f666:66:66:6b:de9f:dbff:fe9a:e1d	---	128G	18532	0	0
BCNlaronabath57fd1-0b2f	f666:66:66:9:26a4:3cff:fe05:b2f	wlan0.12	39487K	26922	0	0
BCNVirgil2-5fbc	f666:66:66:4b:26a4:3cff:fe08:5fbc	wlan0.12	50072K	16542	0	0

Figure 7: Associated stations

Status	Mesh	Node configuration	Tools	About	qMp/Mesh	OpenWRT
<div> <div>Links</div> <div> <div> <div> <div>BCNLafabraRd2-8523</div> <ul style="list-style-type: none"> <li>Local IP: <a href="#">f666:66:66:29:de9f:dbff:fe05:8523</a></li> <li>Device: wlan0.12</li> <li>Rate (r/tb): 100/98</li> <li>Routes: 19</li> </ul> </div> </div> <div> <div> <div>BCNLenguadoc17p0-d94d</div> <ul style="list-style-type: none"> <li>Local IP: <a href="#">f666:66:66:7:c24a:ff:fe93:d94d</a></li> <li>Device: br-lan.12</li> <li>Rate (r/tb): 100/100</li> <li>Routes: 1</li> </ul> </div> </div> </div> </div>						

Figure 8: Links of the node

To arrive there, go to the menu clicking at:

OpenWRT / Status / Realtime Graphs / Wireless

alternatively:

<http://admin.qmp/cgi-bin/luci/admin/status/realtime/wireless>

The situation could be that cannot be a connection to the node to the network. Perhaps it is in another channel. Figure 11 shows a wifi scan. qMp always use BSSID: 02:CA:FF:EE:BA:BE, in Mode Ad-Hoc. These are two solid references to find other qMp networks. In the figure there are two qMp networks in channels: 140 and 132.

To arrive there, go to the menu clicking at:

OpenWRT / Network / Wifi / "Scan"




Figure 9: Bandwidth Test




Figure 10: Strength of the best wifi signal in real-time

alternatively:

<http://admin.qmp/cgi-bin/luci/admin/network/wireless> and click Scan.

If there is a design of a new qMp network it is important to select a channel that is not used. Figure 12 shows how another AP is also using channel 140.

Figure **wifi-channel-power** shows where to change wifi parameters as wifi channel and power signal to the qMp network. By default, qMp uses 17, but it can be increased to 22 (max value).

Use the transmission power of wifi signal with care, in the interested network is a communication signal, but for the other networks it is another noise in the environment that make its communications more difficult.

To arrive there, go to the menu clicking at:

OpenWRT / Node configuration / Wireless Settings

alternatively:

<http://admin.qmp/cgi-bin/luci/qmp/configuration/wifi/>




Figure 11: Wifi scan: find qMp network



Figure 12: Wifi scan interference

Figure 14 (marked as red) shows that there is a WAN Node, the node makes announcement of this network as **Internet**. If can be arrived there, it means there is an internet connection, try it with a browser. Also could be interesting to perform additional bandwidth tests <sup>16</sup> , <sup>17</sup> , <sup>18</sup> , <sup>19</sup> .

But perhaps the WAN node cannot be accessed, or there is not a WAN node in the network. Can be checked if there is a tunnel to Internet.

In the same view, can be browsed for a Border Node. Figure 14 shows it (marked as blue), the node makes announcement of the network 10.0.0.0/8, it means, access to the rest of guifi.net

To arrive there, go to the menu clicking at:

qMp/Mesh / Mesh / Tunnels

<sup>16</sup><http://www.catnix.net/en/speedtest>

<sup>17</sup><http://speedtest.net>

<sup>18</sup><http://testdevelocidad.es>

<sup>19</sup><http://testvelocidad.eu/>




Figure 13: Wifi: Channel & Power

alternatively:  
`http://admin.qmp/cgi-bin/luci/qmp/Mesh/Tunnels`

Gateways tunnel announcements

Tunnel	Node	Network	Bandwidth	SearchNet	Path Metric	Tun metric	Rating	Src	Search id
community6	---	---	---	11/0	---	---	100	---	.
inet6	---	---	---	11/0	---	---	100	---	.
cloud	BCNLafabrad5-359e	10.1.56.0/27	128G	10.0.0.0/8	52428K	61656K	100	0.0.0.0/0	.
cloud	BCNLafabrad2-8523	10.1.56.0/27	128G	10.0.0.0/8	52428K	51380K	100	0.0.0.0/0	.
cloud	BCNPensGallera24-0d1d	10.1.56.0/27	128G	10.0.0.0/8	36700K	42781K	100	0.0.0.0/0	.
cloud	BCNLenguadoc17roftop-3958	10.1.56.94/27	128G	10.0.0.0/8	999M	1187M	100	0.0.0.0/0	.
cloud	BCNPamentBalle57Rd1-0b2f	10.1.56.160/27	128G	10.0.0.0/8	36700K	44040K	100	0.0.0.0/0	.
cloud	BCNLenguadoc17p0-d94d	10.1.56.192/27	128G	10.0.0.0/8	999M	1187M	100	0.0.0.0/0	.
cloud	BCNPensGallera10-0f28	10.1.56.224/27	128G	10.0.0.0/8	30932K	37119K	100	0.0.0.0/0	.
cloud	BCNVirgil2-5fbc	10.1.57.0/27	128G	10.0.0.0/8	53477K	62914K	100	0.0.0.0/0	.
community	BCNLafabrad2-8523	10.0.0.0/8	98304	10.0.0.0/8	52428K	61656K	100	0.0.0.0/0	.
cloud6	BCNPamentBalle57Rd1-0b2f	2012:0:0:32f::/64	128G	11/0	36700K	44040K	100	11/0	.
cloud6	BCNPensGallera24-0d1d	2012:0:0:41d::/64	128G	11/0	36700K	42781K	100	11/0	.
cloud6	BCNPensGallera10-0f28	2012:0:0:518::/64	128G	11/0	30932K	37119K	100	11/0	.
cloud6	BCNLafabrad5-359e	2012:0:0:359e::/64	128G	11/0	52428K	61656K	100	11/0	.
cloud6	BCNLenguadoc17roftop-3958	2012:0:0:3958::/64	128G	11/0	999M	1187M	100	11/0	.
cloud6	BCNVirgil2-5fbc	2012:0:0:5fbc::/64	128G	11/0	53477K	62914K	100	11/0	.
cloud6	BCNLafabrad2-8523	2012:0:0:8523::/64	128G	11/0	52428K	61656K	100	11/0	.
cloud6	BCNLenguadoc17p0-d94d	2012:0:0:d94d::/64	128G	11/0	999M	1187M	100	11/0	.
---	BCNLenguadoc17p0-d94d	Internet	98304	---	999M	---	0	0.0.0.0/0	---

Figure 14: Tunnels

## 6 qMp basics: Basic install and maintaining

Figure 15, this is the final setup when the node is prepared to be in testing phase.

In guifi.net web page, after adding the device, it is received a unique ip address, and is needed a 255.255.255.244 netmask. Use the same name as in the web or the network organization page.  
To arrive there, go to the menu clicking at:

qMp/Mesh / Node configuration / qMp easy setup

alternatively:

[http://admin.qmp/cgi-bin/luci/qmp/configuration/easy\\_setup/](http://admin.qmp/cgi-bin/luci/qmp/configuration/easy_setup/)

community

**Node name**  
Choose a name for this node. It will be used to identify the device in the network. Use only alphanumeric characters, spaces are not allowed.

BICNLIengquadoc17rooftop

**IP address and network mask**  
Specify the IP address and the network mask for this node, according to the planification of your community or your network deployment. End-user devices will get an IP address within the valid range determined by these two values.

10.1.56.97  
Main IPv4 address for this node.

255.255.255.224  
Network mask to be used with the IPv4 address above.

**Interface modes**  
Select the working mode of the network interfaces:

- LAN mode is used to provide connectivity to end-users (a DHCP server will be enabled to assign IP addresses to the devices connecting)
- WAN mode is used on interfaces connected to an Internet up-link or any other gateway connection
- Mesh mode is used on wireless interfaces to join the qMp mesh and, on wired interfaces, to link with other qMp nodes
- AP mode is used on wireless interfaces to act as an access point and provide connectivity to end-users

Interface	Mode
Wired interface eth0	Lan
Wired interface eth1	Lan
Wireless interface wlan0	Mesh

Use mesh in all devices ☒ If this option is enabled, all the node's network devices will be used for meshing (recommended)

Figure 15: Quick setup

Figure 16: When the node is working fine is important to make a backup of the configuration. It is not recommended to upgrade the node using this menu for the qMp firmware.  
To arrive there, go to the menu clicking at:

OpenWRT / System / "Backup/Flash Firmware"

alternatively:

<http://admin.qmp/cgi-bin/luci/admin/system/flashops>

For upgrade the node at the moment it is only possible via terminal. Do a login with ssh session:

```
ssh root@admin.qmp
```

password: 13f

From this point, there are three methods:

1. Automatic upgrade (with internet connection in the node).




Figure 16: Backup

```
qmpcontrol upgrade
```

2. Upgrade with a link (with internet connection in the node).

```
qmpcontrol upgrade "http://...qmp.bin"
```

It means the URL where is located the qMp firmware, remember that can be found all the firmwares supported here: <http://fw.qmp.cat>

3. Upgrade with a local file (without internet connection in the node).

- (a) Put the file inside qMp node, open a new terminal and put

```
scp qmp.bin root@admin.qmp:/tmp
```

It will ask for the password

- (b) With the existing ssh session opened before, or a new one, login with ssh and:

```
qmpcontrol upgrade "/tmp/qmp.bin"
```

Confirm to continue with the upgrade process and wait until it is finished.

Note: qMp only save common settings after the upgrade, concretely:

```
# cat /etc/config/qmp | grep preserve
```

For other file changes, perform a backup before the upgrade.



## 7 qMp basics: Navigating inside the network


Figure 17 shows a screen that presents all the qMp nodes conforming the cloud. By clicking the blue spherical icon to the left of each node it is possible to obtain additional information about them. In particular, the network address announced by one node can be found under the **Gateways announced** label, and the IP of the node in the first address of that network. In the example shown in the figure, the network address is 10.1.56.96 and the IP of the qMp node is 10.1.56.97.

To arrive there, go to the menu clicking at:

qMp/Mesh / Mesh / Nodes

alternatively:

<http://admin.qmp/cgi-bin/luci/qmp/mesh/nodes>



The screenshot shows the qMp Quick Mesh Project web interface. The top navigation bar includes 'Status', 'Mesh', 'Node configuration', 'Tools', 'About', 'qMp/Mesh', and 'OpenWRT'. The main content area is titled 'Node originators' and displays information for a specific node: BCNLengquadoc17p3-dad3. It shows 'Available IPs' (f66:66:66:80:de9f:dbff:fe45:3958, f66:66:66:80:de9f:dbff:fe44:3958, f66:66:66:80:de9f:dbff:fe43:3958), 'Gateways announced' (10.1.56.96/27 | 128G), and 'Networks announced'. Below this, the 'Mesh nodes' section contains a table with columns: Hostname, Primary IP, Via Device, Metric, Last Desc, Last Ref, and Blocked.

Hostname	Primary IP	Via Device	Metric	Last Desc	Last Ref	Blocked
BCNLafabrafz2-8523	f66:66:66:29:de9f:dbff:fe05:8523	eth0.12	41943K	30479	3	0
BCNLengquadoc17p0-d94d	f66:66:66:7:c24a:ff:fe93:d94e	eth0.12	999M	24548	0	0
BCNLengquadoc17p3-dad3	f66:66:66:7:c24a:ff:fe93:da64	---	128G	22977	0	0
BCNLengquadoc17p0top-3958	f66:66:66:80:de9f:dbff:fe45:3958	eth0.12	999M	26939	0	0
BCNPmsGallarza10-0f28	f66:66:66:9:26a4:3dff:fe21:f28	eth0.12	28311K	5329	4	0
BCNPmsGallarza24-0e1d	f66:66:66:b:de9f:dbff:fe5a:e1d	eth0.12	31981K	3594	3	0

Figure 17: IP address of nodes

Figure 18 is the graph that shows the nodes, the edges with the bmx6's quality rate show how each are connected.

To arrive there, go to the menu clicking at:

qMp/Mesh / Mesh / Graph

alternatively:

<http://admin.qmp/cgi-bin/luci/qmp/mesh/graph>

## 8 Proposed qMp cloud node designs: WAN node design

To build a WAN node, figure 19 shows how the qMp node should be connected to the *mesh* network (through wifi via bmx6 routing) and Internet (through ethernet to ISP <sup>20</sup> router via DHCP client).

<sup>20</sup>Internet Service Provider




Figure 18: Graph of the network

It is recommended to use the device Nanostation M5 because it has two ethernet interfaces (eth0, eth1). With one can be made a DHCP server to connect to the qMp node with a laptop. And for the other ethernet, a DHCP client to the ISP router.

In the case that there is a Nanostation Loco M5, it only has one ethernet (eth0<sup>21</sup>). It will be for the DHCP client to the ISP router and it means that there is no DHCP server to directly connect to the qMp node. An easy solution is that the connection to the qMp node could be possible with another qMp node in the network (it is being used the wifi interface).

To set the ethernet that will do the DHCP client to the ISP router there are 2 options.

Option 1: in the quick setup, last part says what to do with interfaces (figure 20). The interfaces have 3 selections: **Mesh**, **Lan** (DHCP server) and **WAN** (DHCP client).

Option 2: Figure 21 shows the screen that set the DHCP client interface, and there is no need to do a quick setup with the node.

To arrive there, go to the menu clicking at:

## OpenWRT / Node configuration / Network Settings

alternatively:

<http://admin.qmp/cgi-bin/luci/qmp/configuration/network/>

To test that is working the DHCP client to the ISP router, check the IPv4 WAN Status, section Network. Figure 22 shows a successful WAN

---

<sup>21</sup>eth1 is ignored




Figure 19: Network diagram generic WAN node

Wired interface <b>eth0</b>	Wan
Wired interface <b>eth1</b>	Lan
Wireless interface <b>wlan0</b>	AP

Figure 20: Option 1: Set DHCP client to interface with quick setup

connection. Figure 23 shows a unsuccessful WAN connection: there is no DHCP client or is not correctly connected.

To arrive there, go to the menu clicking at:

qMp/Mesh / Mesh / Status

alternatively:

<http://admin.qmp/cgi-bin/luci/qmp/status>

## 9 Proposed qMp cloud node designs: General node design

Figure 24 shows the elements of a simple node installation: A qMp node connected to its network and a 2.4 GHz wifi router as an Access Point that it is necessary to give wifi coverage inside the place.




Figure 21: Option 2: Set DHCP client to interface with network settings



Figure 22: WAN status online

## 10 Making a panorama with Hugin

With Hugin it is very easy to do panorama photos, and is free open source software <sup>22</sup>.

1. How to do the photos? Take the same physical point and start doing photos with 20% of overlap between them.
2. Follow the steps in Hugin's program (Figure: 25)

<sup>22</sup><http://hugin.sourceforge.net/>




Figure 23: WAN status offline




Figure 24: Network diagram generic node

- (a) 1.**Load images**, select all images in the folder it is wanted to do a panorama.
  - (b) 2.**Align**.
    - this takes a process to search for control points for give sensation of continuity in the photo.
    - if there is not enough control points, search control points manually or do the photos again.
  - (c) 3.**Create panorama**: save a .pto and .tiff files in the folder with all images.
3. Conversion of .tiff to .jpeg  
If it is wanted to share the panorama.

```

sudo apt-get install imagemagick
convert pan.tiff pan.jpeg

```

An example is showed in figure 26




Figure 25: Hugin



Figure 26: Example of panorama using hugin

## 11 About monitoring

Perform a monitoring of the network is important as a measure of quality assurance. Are presented 3 alternatives.

### 11.1 From the guifi web

can be obtained the graphs. It helps to know if the device is up, its ping and the network traffic. Figure 27 shows how it looks like.

It is required a qMp version with guifi package: **qMp-Guifi** should appear in the bin package name.

The server part uses a package developed by guifi.net community called **snpservices**. For install it can be followed this guide <sup>23</sup>, basically, a Debian

<sup>23</sup>There is no English translation: http://ca.wiki.guifi.net/wiki/Servidor\_de\_gr%




Figure 27: Graph server in guifi.net

repository is obtained, it is installed the package and is set the id of the graph server (other parameters remain default). To obtain the id of the graph server create a service of type graph server in the guifi.net web. For example, the id of the graph server of Barcelona can be obtained from the URL: <http://guifi.net/en/node/55045>, and it is 55045.

qMp uses the package `mini_snmpd`<sup>24</sup> configured to the guifi.net website. After creating the node and the device in the web, it generates the `unsolclic` file. Figure 28 shows how simple is: put there the URL of the device and apply.



Figure 28: guifi.net menu in qMp firmware

<sup>24</sup><http://wiki.openwrt.org/doc/howto/snmp.server>

## 11.2 munin:

For a GNU/Linux Debian 7 Wheezy server (apache 2.2)

```
sudo apt-get install munin
```

by default it does monitoring of the server itself (localhost).

For make the graphs available for every user <sup>25</sup> in order to follow the Community Network model of open all network data change the following lines in `/etc/munin/apache.conf`:

```
Order allow,deny
Allow from localhost 127.0.0.0/8 ::1
Options None
```

like so:

```
Order allow,deny
Allow from all
Options FollowSymLinks SymLinksIfOwnerMatch
```

Apply the changes in the HTTP server:

```
# service apache2 restart
```

Add qMp nodes for monitor them editing the file `/etc/munin/munin.conf`:

```
[qMp-node1]
    address 10.x.x.x
    use_node_name yes
[qMp-node2]
    address 10.x.x.x
    use_node_name yes
```

Apply the changes in the monitor (it will start appearing after few minutes):

```
# service munin-node restart
```

The graphics are very similar to those of guifi, but provide more information. Except that there is an error with network traffic monitoring and is not provided.

---

<sup>25</sup>Solution for apache 2.2 and 2.4: <http://stackoverflow.com/questions/9127802>



### 11.3 qmpsu:

At the moment, there is not a generic package of qmpsu for qMp networks, only for Sants Poblenou. More information see [Situation of mesh networks in Barcelona](#). Figure 29 shows how it looks like.




Figure 29: qmpsu view