



QUICK SET UP GUIDE (5 min. or less)

NOTE: These instructions are generalized and may apply to all ULTRA BOXX Media Streaming Systems
Certain options and or features may differ according to your exact model, for complete instructions specific to your device go to www.TVPLUSMEDIA.com



(A) QUICK CONNECTIONS SETUP: (1 min. or less)

- 1- Connect the HDMI cable to your TV or Monitor (i.e. HDMI 2 or INPUT 2)
Now make sure to change the **Source** or **Input** on your TV or Monitor to where you just connected your ULTRA BOXX, (i.e. HDMI 2 or INPUT 2)
- 2- Connect only the INCLUDED AC Power Supply to the wall outlet & then to the device. **CAUTION:** Use only the included AC Power Supply, failure to do so may cause permanent damage to your device due to improper voltage and is **NOT COVERED UNDER WARRANTY. BE ADVISED:** Damage is immediate, permanent and over voltage will be detected as the cause!
- 3- Locate & Press the power button and wait for the system to Power Up to the Device HomePage (Android OS)(4).
- 4- This is your ULTRA-BOXX Device Home Page (4)



(B) INTERNET CONNECTION SETUP: (2 min. or less)

- 5- Click the **Menu Button** on your remote (3 little lines/bars, see Remote General Functions below) or Select and click the logo in the top left of the HomePage(5)
- 6- Select & Click OK on Network
- 7- Click Wi-Fi to scan for all available Wi-Fi networks within range
- 8- Highlight or Choose your access point (choose your Home Wi-Fi-Network)
- 9- Click OK and use the virtual keyboard to Input your Password
- 10-Click OK/Connect (you must enter exactly your password “case sensitive”)
- 11-For a Wired or Ethernet Connection simply plug in your Ethernet cable
Whenever possible, Ethernet is the preferred connection and is far more reliable than Wi-Fi. Note: Ethernet needs no special set up and becomes active the moment you plug a cable (Ethernet overrides any Wi-Fi connection)

(C) DISPLAY SIZE & POSITION (1 min. or less)

Should you need to adjust the display size to fit your TV or Monitor, go back into the same menu as above (step B) click on MORE..., next click on DISPLAY, then SCREEN POSITION. Use Zoom In or Zoom Out as required.

(D) BASIC REMOTE FUNCTIONS:

Your basic remote keys for every day use will be the (8) **DIRECTION KEYS / ARROWS**, the (9) **OK / SELECT** and the (7) **BACK / EXIT KEY**. Focus on learning these keys to navigate your system. **TIP:** For every screen you click OK to enter, use the Back/Return key to Cancel or Navigate backwards.
***IMPORTANT:** You may activate a mouse pointer (arrow head) on your screen to access more advanced features on your system. When Active, use the mouse pointer to CLICK menus & items *(on some models HOLD and SWIPE with mouse)
NOTE: You may need to use a mouse pointer to access certain features, optional remotes & keyboards are available at www.TVPLUSMEDIA.com
- *On select models, on the HomePage PRESS & HOLD the microphone button to use voice command. Search internet pages or ask google a question.

(E) ULTRA BOXX SMART TV

Your ULTRA BOXX HomePage (4) is just like an ANDROID Tablet on your BIG SCREEN. Use it like you would any tablet for Internet, Google Searches, Facebook, Skype or millions of other Apps available on the Google Play Store

(F) *TV PLUS MEDIA CENTER* (Adult section password 277)

- 12- CLICK on the **TVPMC** icon to enter TV PLUS Media Center
- 13- Click on TV PLUS in the main menu bar
- 14- Click on TV PLUS (Start Here) or WICKED XXX to confirm your choice
- 15- Inside TV PLUS, choose an Add-on, make your selections and follow the prompts. If your selection fails on the first host or server, simply choose another & try again. Please visit our support pages for more information.



(G) TIPS & TRICKS (DO's & DONT's)

- 16- Always **QUIT** TV PLUS Media Center to save your session & files (failing to QUIT may damage your software and is NOT covered under any warranty.
- 17- If your device seems to be misbehaving, QUIT TV PLUS & Reboot your System for a Fresh Start. You may also Power off & Power back on
NOTE: For more information on how to reboot please refer to the device manufactureres instructions. It is never recomended to unplug the device prior to closing your apps, saving your files and a proper shutdown procedure.
- 18- If you are having trouble connecting on multiple or different streams, check your Wi-Fi signal or internet connection! 99% of support issues are Internet rel;ayed. Please contact your internet provider regarding any streaming, buffering or interenet connectivity issues.
- 19- **DO NOT** unplug your device prior to doing a proper shutdown.

WARRANTY & SUPPORT

- TV PLUS MEDIA ULTRA BOXX Manufacturers Device
Hardware Warranty is TWO (2) YEARS

- TV PLUS NICE Optional Accessories
Manufacturers Warranty is THIRTY (30) days

- **IMPORTANT** - We do NOT warranty any
3rd party Software, ADD-ONs or PLUG-INS

For support Visit
www.TVPLUSMEDIA.com

GENERAL FUNCTIONS

- 1 Power button
- 2 Microphone on while pressed / Turn off Mouse
- 3 Menu / options
- 4 Customizable key / screenshot
- 5 Home
- 6 Turn on Mouse
- 7 Back / Exit
- 8 Directional keys
- 9 OK / Select
- 10 Volume + / -

Please refer to your specific device for remote functions & availability

ADULT SECTION PASSWORD

Enter the number **277**
or easy to remember = **ASS**

Please keep these password away from any minor children



