


QUICK SET UP GUIDE (5 min. or less)


NOTE: These instructions are generalized and may apply to multiple devices and systems

Certain options and or features may differ according to your model, for complete instructions use the device manufacturers instructions specific to your model



(A) QUICK CONNECTIONS SETUP: (1 min. or less)

- 1- Connect the HDMI cable to your TV or Monitor (i.e. HDMI 2 or INPUT 2)
Now make sure to change the **Source** or **Input** on your TV or Monitor to where you just connected your ULTRA BOXX, (i.e. HDMI 2 or INPUT 2)
- 2- Connect only the INCLUDED AC Power Supply to the wall outlet & then to the device. **CAUTION:** Use only the included AC Power Supply, failure to do so may cause permanent damage to your device due to improper voltage and is **NOT COVERED UNDER WARRANTY. BE ADVISED:** Damage is immediate, permanent and over voltage will be detected as the cause!
- 3- Locate & Press the power button and wait for the system to Power Up to the Device HomePage (Android OS)(4).
- 4- Once your device has started from the Device HomePage (4)



(B) INTERNET CONNECTION SETUP: (2 min. or less)

- 5- Click the **Menu Button** on your remote (3 little lines/bars) or Select and click the logo (if applicable) in the top left corner of the HomePage (5)
- 6- Select & Click OK on Network
- 7- Click Wi-Fi to scan for all available Wi-Fi networks within range
- 8- Highlight or Choose your access point (choose your Home Wi-Fi-Network)
- 9- Click OK and use the virtual keyboard to Input your Password. You must enter exactly your password as it is "case sensitive"
- 10-Click OK/Connect, if you cannot connect, contact your internet provider.
- 11-For a Wired or Ethernet Connection simply plug in your Ethernet cable
Whenever possible, Ethernet is the preferred connection and is far more reliable than Wi-Fi. Note: Ethernet needs no special set up and becomes active the moment you plug a cable (Ethernet overrides any Wi-Fi connection)

(C) DISPLAY SIZE & POSITION (1 min. or less)

Should you need to adjust the display size to fit your TV or Monitor, **go back** into the same menu as above (step B) click on MORE..., then click on DISPLAY, then SCREEN POSITION. Use Zoom In or Zoom Out as required.

(D) BASIC REMOTE FUNCTIONS:

Your basic remote keys for every day use will be the 4 **DIRECTION KEYS / ARROWS**, the **OK / SELECT** button in the middle and the **BACK / EXIT KEY** that looks like a return arrow. Focus on learning these keys to navigate your system. **TIP:** For every screen you click OK to enter, use the Back/Return key to Cancel or Navigate backwards.

***IMPORTANT:** You may activate a mouse pointer (arrow head button) on your screen to access more advanced features on your system. When Active, use the mouse pointer to CLICK menus & items *(on some models HOLD & SWIPE with mouse) **Make sure to deactivate the mouse for regular controls**

NOTE: You may need to use a mouse pointer to access certain features, optional remotes & keyboards are available at www.TVPLUSMEDIA.com

Always refer to the device manufacturers instructions for your specific remote controls function list and specific options

(E) TV PLUS MEDIA CENTER (Adult section password 277)

- 12- On the devices homepage (the first screen when the device starts up) CLICK on the **TVPMC** icon to launch TV PLUS Media Center
- 13- Click on the TV PLUS center icon in the main menu bar
- 14- Click on TV PLUS (Start Here) or WICKED XXX to confirm your choice
- 15- Inside TV PLUS, choose an Add-On, make your selections and follow the prompts. If your selection fails from the first host or provider, simply choose another & try again. Be Patient...Practice, Trial & Error are the best teachers and within a few days you will learn how to navigate and use your systems various features.



(F) TIPS & TRICKS (DO's & DONT's)

- 16- Always **QUIT** TV PLUS Media Center - TVPMC to save your session & files (failing to **QUIT** may damage your software and is NOT covered under any warranty).
- 17- If your device seems to be misbehaving, **QUIT** TVPMC & Reboot your System for a Fresh Start. You may also Power off & Power back on
NOTE: For more information on how to reboot please refer to the device manufacturers instructions. It is never recommended to unplug the device prior to closing all your apps, saving your files and a proper shutdown procedure.
- 18- If you are having trouble connecting on multiple or different streams, check your Wi-Fi signal or internet connection! 99% of support issues are Internet related. TIP: Always use a wired ETHERNET Connection when possible. If connecting on Wi-Fi we suggest locking on and using the wireless routers channel #2 for best performance. We suggest checking with your internet provider to assist you with these settings if required.

BE ADVISED: We do not provide any support for internet of Wi-Fi related issues. Please contact your internet provider directly regarding any streaming, buffering or internet connectivity issues.

Buffering or cache full messages are either an issue with your internet / Wi-fi or with the Host or provider of your stream, it does not mean you device is

ADULT SECTION PASSWORD

Enter the number **277**

or easy to remember = **ASS**

**Please keep this password away from any minor children*



WARRANTY & SUPPORT

**FOR ANY ISSUES DIRECTLY RELATING TO GET-WICKED OR TVPMC
EMAIL US AT SUPPORT@TVPLUSMEDIA.COM**

IMPORTANT - WE DO NOT WARRANTY OR SUPPORT ANY THIRD PARTY SOFTWARE, PLUG-INS OR ADD-ONS

BE ADVISED: - WE DO NOT HAVE ANY AFFILIATION WITH ANY KIND OF MEDIA SUCH AS MUSIC, TV, MOVIE, SPORTS ETC... WE DO NOT PROVIDE ANY INFORMATION ON ANY MEDIA OF ANY KIND.

FIND HELP at www.TVPLUSMEDIA.com