




LC3 Codec **Programmer's Guide**

For HiFi DSPs and Fusion F1 DSP



Cadence Design Systems, Inc.
2655 Seely Ave.
San Jose, CA 95134
www.cadence.com

© 2022 Cadence Design Systems, Inc. All rights reserved.
Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. (Cadence) contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 1-800-862-4522.

All other trademarks are the property of their respective holders.

Patents: Licensed under U.S. Patent Nos. 7,526,739; 8,032,857; 8,209,649; 8,266,560; 8,650,516

Restricted Print Permission: This publication is protected by copyright and any unauthorized use of this publication may violate copyright, trademark, and other laws. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. This statement grants you permission to print one (1) hard copy of this publication subject to the following conditions:

- The publication may be used solely for personal, informational, and noncommercial purposes;
- The publication may not be modified in any way;
- Any copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement;
- The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration; and
- Cadence reserves the right to revoke this authorization at any time, and any such use shall be discontinued immediately upon written notice from Cadence.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. The information contained herein is the proprietary and confidential information of Cadence or its licensors, and is supplied subject to, and may be used only by Cadence's customer in accordance with, a written agreement between Cadence and its customer. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

For further assistance, contact Cadence Online Support at <https://support.cadence.com/>.
Copyright © 2022, Cadence Design Systems, Inc. All rights reserved.

Version: 1.6
Last Updated: May 2022

Cadence Design Systems, Inc.
2655 Seely Ave.
San Jose, CA 95134
www.cadence.com

Contents

1.	Introduction to HiFi LC3 Codec	1
1.1	LC3 Description	1
1.2	Document Overview	1
1.3	HiFi LC3 Codec Specifications	1
1.4	HiFi LC3 Performance	2
1.4.1	Memory	3
1.4.2	Timings	3
2.	Generic HiFi Speech Codec API	5
2.1	Memory Management	5
2.1.1	API Handle / Persistent Memory	5
2.1.2	Scratch Memory	6
2.1.3	Input Buffer	6
2.1.4	Output Buffer	6
2.2	C Language API	6
2.3	Generic API Errors	7
2.4	Common API Errors	8
2.5	Files Describing the API	8
3.	HiFi DSP LC3 Codec API	9
3.1	Files Specific to the LC3 Codec	9
3.2	I/O Formats	9
3.3	Control Structure for LC3 Codec	9
3.4	API Functions	10
3.4.1	Startup Stage	10
3.4.2	Memory Allocation Stage	11
3.4.3	Initialization Stage	12
3.4.4	Execution Stage	14
4.	Introduction to the Example Test Bench	23
4.1	Making the Executable	23
4.2	Usage	24
5.	Reference	27

Figures

Figure 1 HiFi Speech Codec Interfaces	5
Figure 2 Speech Codec Flow Overview.....	7

Tables

Table 1-1 Relation between Sampling Frequency and Supported Bitrate.....	2
Table 3-1 Encoder Control Structure xa_lc3_enc_init_cfg_t Parameters.....	9
Table 3-2 Decoder Control Structure xa_lc3_dec_init_cfg_t Parameters	10
Table 3-3 Library Identification Functions.....	10
Table 3-4 Memory Management Functions	11
Table 3-5 LC3 Encoder Initialization Function	12
Table 3-6 LC3 Decoder Initialization Function	13
Table 3-7 Macros used to calculate I/O buffer size	14
Table 3-8 LC3 Encoder Execution Function	15
Table 3-9 LC3 Decoder Execution Function.....	16
Table 3-10 LC3 Encoder Set Parameter Function.....	18
Table 3-11 LC3 Encoder Set Parameter Commands	19
Table 3-12 LC3 Encoder Get Parameter Function	19
Table 3-13 Encoder Get Parameter Commands	20
Table 3-14 LC3 Decoder Get Parameter Function	20
Table 3-15 LC3 Decoder Get Parameter Commands	21
Table 3-16 LC3 Decoder Set Parameter Function	21
Table 3-17 LC3 Decoder Set Parameter Commands.....	22

Document Change History

Version	Changes
1.0	Initial customer release.
1.1	Added performance numbers for HiFi 3/3z/4/5 and Fusion F1.
1.2	Support added for LC3 specification version 0.9 which enables use of 7.5 ms frame size.
1.3	Now supports three separate packages: lc3_codec, lc3_dec, and lc3_enc.
1.4	Codebase upgraded to support LC3 specification version 1.0.
1.5	Codebase updated with HiFi 1 specific optimizations.
1.6	Updated performance data for all HiFi cores.

1. Introduction to HiFi LC3 Codec

The HiFi LC3 codec is a library supplied by Cadence that provides the implementation of the Low Complexity Communication Codec (LC3) specifications version 1.0 on HiFi processors.

For this document, HiFi DSPs include Fusion F1 DSP.

1.1 LC3 Description

LC3 Low Complexity Communication Codec is the standard for all-band audio communication. LC3 codec obtains very high audio quality at medium bitrates utilizing a low computational complexity. LC3 incorporates flexible coding modes and includes audio bandwidth from narrow-band (NB) to full-band (FB) at bitrates from 16 kbps to 426.667 kbps. The codec operates with associated channel coding in a rate-adaptive scheme, which improves quality and resilience for degraded channels.

1.2 Document Overview

This guide covers all the information required to integrate the HiFi LC3 into an application. The HiFi codec libraries implement a simple API to encapsulate the complexities of the coding operations and simplify the application and system integration.

Parts of the API are common to all the HiFi codecs; these are described after the introduction in Section 2. Section 3 covers all the features and information particular to the HiFi LC3. Finally, an example test bench is described in Section 4. Section 5 lists the reference materials.

1.3 HiFi LC3 Codec Specifications

The HiFi DSP LC3 codec from Cadence implements the following features:

- Cadence Speech Codec API is used.
- LC3 Codec specification 1.0 based encoder and decoder.
- Encoder input/decoder output PCM: 16, 24 bits per sample.
- In case of 24-bit PCM, input is MSB aligned in 32-bit register.
- Supported sampling frequencies: 8 kHz, 16 kHz, 24 kHz, 32 kHz, 44.1 kHz, 48 kHz.

- Supports five audio bandwidths:
 - Narrowband(NB): speech or audio sampled at 8 kHz.
 - Wideband(WB): speech or audio sampled at 16 kHz.
 - Semi-Super Wideband (SSWB): speech or audio sampled at 24 kHz.
 - Super Wideband (SWB): speech or audio sampled at 32 kHz.
 - Full-band (FB): speech or audio sampled at 44.1 kHz or 48 kHz.
- Supports bitrates: The relation between bitrate, sampling frequency, and framesize is shown in the following equation: $bitrate = \frac{8000 \times nbytes \times N}{F_{scale} \times Frame_{ms}}$

Here ,

- nbytes is an integer number and ranges over [20, 400].
- $Frame_{ms}$ is framesize in milliseconds.
- The factor $8000/F_{scale}$ is used for frequency scaling for 44.1kHz case and comes out to be 7350. For other sampling frequencies $F_{scale} = 1$

Framesize (ms)	Sampling Frequency (kHz)	Supported bitrate range (kbps)
10	8/16/24/32/48	16 – 320
	44.1	14.7 – 294
7.5	8/16/24/32/48	21.334 - 426.667
	44.1	19.6 – 392

Table 1-1 Relation between Sampling Frequency and Supported Bitrate

- Supports standard packet loss concealment (PLC).
- Encoder supports one or two audio channels.
- For stereo/ two channel cases, encoder expects deinterleaved input and decoder gives output in the same format.
- Frame duration: 10 ms, 7.5ms.

1.4 HiFi LC3 Performance

The HiFi LC3 codec from Cadence was characterized on the HiFi 5-stage DSP. The memory usage and performance figures are provided for design reference.

The HiFi LC3 consists of three separate release packages: lc3_codec, lc3_dec, and lc3_enc. At each communication terminal, the user can pick one of these three packages to suit their needs.

1.4.1 Memory

Library	Text (Kbytes)						Data Kbytes
	Fusion F1	HiFi 1	HiFi 3	HiFi 3z	HiFi 4	HiFi 5	
lc3_code c	84.2	80.1	88.7	88.5	94.8	125.2	41.7
lc3_dec	43.6	39.6	44.7	44.5	48.7	62.2	34.8
lc3_enc	61.7	58.3	65.7	64.7	70.2	92.7	41.2

	Run Time Memory (Kbytes)				
	Persistent	Scratch	Stack	Input	Output
Encoder	6.8	10.8	2.1	3.8	0.9
Decoder	10.1	12.1	2.1	0.9	3.8

Note Memory size is the worst case for all test scenarios.

1.4.2 Timings

Encoder

Rate kHz	nch	Bit Rate kbps	Average CPU Load (MHz)						
			Fusion F1	HiFi 1	HiFi 3	HiFi 3z	HiFi 4	HiFi 5	
48	1	80	11.0	8.6	9.8	8.5	8.2	7.8	Frame=10ms
48	1	320	14.3	11.8	13.7	11.5	10.9	10.5	Frame=10ms
48	1	80	12.1	9.5	11.0	9.4	9.1	8.8	Frame=7.5ms
48	1	320	15.1	12.6	14.6	12.3	11.7	11.4	Frame=7.5ms

Decoder

Rate kHz	nch	Bit Rate kbps	Average CPU Load (MHz)						
			Fusion F1	HiFi 1	HiFi 3	HiFi 3z	HiFi 4	HiFi 5	
48	1	80	5.2	4.1	4.8	4.2	4.1	3.8	Frame=10ms
48	1	320	9.0	7.3	9.2	7.8	7.8	7.5	Frame=10ms
48	1	80	5.7	4.6	5.4	4.6	4.5	4.3	Frame=7.5ms
48	1	320	9.4	7.8	9.7	8.2	8.2	8.0	Frame=7.5ms

Note The above performance numbers are captured with RI.8 tools and XT-CLANG compiler.

Note Performance specification measurements are carried on a cycle-accurate simulator assuming an ideal memory system, *i.e.*, one with zero memory wait states. This is equivalent to running with all code and data in local memories or using an infinite-size, pre-filled cache model. The MCPS numbers for HiFi 3z/HiFi 4/HiFi 5/Fusion F1 are obtained by running the test that is recompiled from the HiFi 3 source code in the HiFi 3z/HiFi 4/HiFi 5/Fusion F1 configuration. No specific optimization is performed for HiFi 3z/HiFi 4/HiFi 5/Fusion F1. Specific optimization is performed for HiFi 1.

Note The input and output buffer sizes above are for 16-bit PCM samples.

2. Generic HiFi Speech Codec API

This section describes the API, which is common to all the HiFi speech codec libraries. The API facilitates any codec that works in the overall method shown in the following diagram.




Figure 1 HiFi Speech Codec Interfaces

Section 2.1 discusses all the types of run time memory required by the codecs. There is no state information held in static memory, therefore a single thread can perform time division processing of multiple codecs. Additionally, multiple threads can perform concurrent codec processing.

2.1 Memory Management

The HiFi speech codec API supports a flexible memory scheme and a simple interface that eases the integration into the final application. The API allows the codecs to request the required memory for their operations during run time.

The run time memory requirement consists primarily of the scratch and persistent memory. The codecs also require an input buffer and output buffer for the passing of data into and out of the codec.

2.1.1 API Handle / Persistent Memory

The codec API stores its data in a structure that is passed via a handle that is a pointer to an opaque object from the application for each API call. All state information and the memory tables that the codec requires are referenced from this structure. This object also forms the static or context memory of the speech codecs. This is the state or history information that is maintained from one codec invocation to the next within the same thread or instance. The codecs expect that the contents of the persistent memory be unchanged by the system apart from the codec library itself for the complete lifetime of the codec operation.

2.1.2 Scratch Memory

This is the temporary buffer used by the codec for processing. The contents of this memory region should not be changed if the actual codec execution process is active, *i.e.*, if the thread running the codec is inside any API call. This region can be used freely by the system between successive calls to the codec.

2.1.3 Input Buffer

This is the buffer used by the algorithm for accepting input data. Before the call to the codec, the input buffer must be completely filled with input data.

2.1.4 Output Buffer

This is the buffer in which the algorithm writes the output. This buffer must be made available for the codec before its execution call. The output buffer pointer can be changed by the application between calls to the codec. This allows the codec to write directly to the required output area.

2.2 C Language API

An overview of the codec flow is shown in Figure 1. The speech codec API consists of query, initialization, and execution functions. In the naming scheme below, `<codec>` is either the codec name (*e.g.*, `LC3`), or the codec name with an `_enc` or `_dec` suffix for encoder- and decoder-specific functions, respectively.

Query Functions: `xa_<codec>_get_<data>`

The query functions are used in the startup and the memory allocation codec stages to obtain information about the version and the memory requirements of the codec library.

Initialization Functions: `xa_<codec>_init`

The initialization functions are used to reset the codec to its initial state. Because the codec library is fully reentrant, a process can initialize the codec library multiple times and multiple processes can initialize the same codec library as appropriate.

Execution Functions: `xa_<codec>`

The execution functions are used to encode and decode speech frames.




Figure 2 Speech Codec Flow Overview

2.3 Generic API Errors

Speech codec API functions return error code of type `XA_ERRORCODE`, which is of type `signed int`. The format of the error codes is defined in the following table.

31	30-15	14 - 11	10 - 6	5 - 0
Fatal	Reserved	Class	Codec	Sub code

The errors that can be returned from the API are subdivided into those that are fatal, which require the restarting of the entire codec, and those that are nonfatal and are provided for information to the application. The class of an error can be either API, Config, or Execution. The API category errors are concerned with the incorrect use of the API. The Config errors are produced when the codec parameters are incorrect or outside the supported usage. The Execution errors are returned after a call to the main encoding or decoding process and indicate situations that have arisen due to the input data.

2.4 Common API Errors

These errors are fatal and should not be encountered during normal application operation. They signal that a serious error has occurred in the application that is calling the codec.

- `XA_API_FATAL_MEM_ALLOC`
At least one of the pointers passed into the API function is NULL
- `XA_API_FATAL_MEM_ALIGN`
At least one of the pointers passed into the API function is not properly aligned

2.5 Files Describing the API

The common include files (`include`)

- `xa_error_standards.h`
The macros and definitions for all the generic errors
- `xa_error_handler.h`
Definitions used by error handling functions
- `xa_type_def.h`
All the types required for the API calls

3. HiFiDSP LC3 Codec API

The HiFi DSP LC3 codec conforms to the generic speech codec API. The supported I/O formats, bit rates as well as the API functions and the files specific to the LC3 codec are described in the following sections.

3.1 Files Specific to the LC3 Codec

The LC3 codec parameter header file (`include/lc3_codec`):

- `xa_lc3_codec_api.h`

The LC3 codec library (`lib`):

- `xa_lc3_codec.a`

3.2 I/O Formats

The input for the Encoder is a block of 16- or 24-bit speech samples representing speech frame data. The Encoder can accept input signals of sampling frequency from 8 kHz, 16 kHz, 24 kHz, 32 kHz, 44.1 kHz, and 48 kHz.

The Decoder processes the encoded bitstream frame by frame. Under normal conditions, one complete packet is required in the input buffer. The Decoder outputs frames composed of 16 or 24-bit PCM samples. The Decoder can generate output signals of sampling frequency from 8 kHz, 16 kHz, 24 kHz, 32 kHz, 44.1 kHz, and 48 kHz. The Encoder generates (or Decoder processes) bitstream in packed format or G192 bitstream format.

3.3 Control Structure for LC3 Codec

Encoder control structure `xa_lc3_enc_init_cfg_t` is used to communicate various parameters listed in Table 3-1 between codec library and the application. Note that all the parameters are **WORD32**.

Table 3-1 Encoder Control Structure `xa_lc3_enc_init_cfg_t` Parameters

Parameter	Input/ Output	Default Value	Description
sampleRate	input	8000	Input signal sampling rate in Hz As described in Section 1.3
nChannels	input	1	Number of channels of input signal; 1 or 2
bitrate	input	32000	Bitrate in bps As described in Section 1.3
bipsIn	input	16	Input data pcm-width; 16 or 24 bits per sample

The decoder control structure `xa_lc3_dec_init_cfg_t` is used to communicate various parameters listed in the following table between the codec library and the application. Note that all the parameters are **WORD32**.

Table 3-2 Decoder Control Structure `xa_lc3_dec_init_cfg_t` Parameters

Parameter	Input/ Output	Default Value	Description
sampleRate	input	8000	Output signal sampling rate in Hz As described in Section 1.3
nChannels	input	1	Number of channels of output signal; 1 or 2
bipsOut	input	16	Output data pcm_width; 16 or 24 bits per sample

3.4 API Functions

The LC3 Codec API functions relevant to each stage in the codec flow are specified in the following sections.

3.4.1 Startup Stage

The API startup functions described in Table 3-3 are used to get the various identification strings from the codec library. They are for information only and their usage is optional. These functions do not take any input arguments and return `const char *`.

Table 3-3 Library Identification Functions

Function	Description
<code>xa_lc3_get_lib_name_string</code>	Get the name of the library.
<code>xa_lc3_get_lib_version_string</code>	Get the version of the library.
<code>xa_lc3_get_lib_api_version_string</code>	Get the version of the API.

Example

```
const char *name = xa_lc3_get_lib_name_string();
const char *ver = xa_lc3_get_lib_version_string();
const char *apiver = xa_lc3_get_lib_api_version_string();
```

Errors

- None

3.4.2 Memory Allocation Stage

During the memory allocation stage, the application must reserve the necessary memory for the LC3 Encoder and Decoder API handles (persistent state) and scratch buffers. The required alignment of the handles and the scratch buffers is 8 bytes. The application can use the functions listed in Table 3-4 to query the codec library for the required size of each buffer. The functions take a pointer of type `xa_lc3_enc_init_cfg_t` for encoder and `xa_lc3_dec_init_cfg_t` for decoder, and return `WORD32`.

While input and output frame buffers are required for the operation of the codec, they need not be reserved at this stage. Pointers to the frame buffers are passed in each invocation of the main codec execution function. The size and alignment requirements of the I/O buffers are specified in section 3.4.4.

Table 3-4 Memory Management Functions

Function	Description
<code>xa_lc3_enc_get_handle_byte_size</code>	Returns the size of the LC3 Encoder API handle (persistent state) in bytes.
<code>xa_lc3_dec_get_handle_byte_size</code>	Returns the size of the LC3 Decoder API handle (persistent state) in bytes.
<code>xa_lc3_enc_get_scratch_byte_size</code>	Returns the size of the LC3 Encoder scratch buffer.
<code>xa_lc3_dec_get_scratch_byte_size</code>	Returns the size of the LC3 Decoder scratch buffer.

Example

```
WORD32 enc_handle_size, dec_handle_size;
WORD32 enc_scratch_size, dec_scratch_size;
xa_lc3_enc_init_cfg_t enc_control;
xa_lc3_dec_init_cfg_t dec_control;

enc_handle_size = xa_lc3_enc_get_handle_byte_size(
```

```

                                &enc_control);
dec_handle_size = xa_lc3_dec_get_handle_byte_size(
                                &dec_control);
enc_scratch_size = xa_lc3_enc_get_scratch_byte_size(
                                &enc_control);
dec_scratch_size = xa_lc3_dec_get_scratch_byte_size(
                                &dec_control);

```

Errors

- **XA_LC3_CONFIG_FATAL_SAMP_FREQ_NOT_SUPPORTED**
Sampling frequency not supported.
- **XA_LC3_CONFIG_FATAL_NUM_CHANNEL_NOT_SUPPORTED**
Number of channel not supported.

3.4.3 Initialization Stage

In the initialization stage, the application points the LC3 codec to its API handle and scratch buffer. The application also specifies various other parameters related to the operation of the codec and places the codec in its initial state. The API functions for LC3 Encoder and Decoder initialization are specified in Table 3-5 and Table 3-6, respectively.

Table 3-5 LC3 Encoder Initialization Function

Function	<code>xa_lc3_enc_init</code>
Syntax	<pre> XA_ERRORCODE xa_lc3_enc_init (xa_codec_handle_t handle, pWORD32 scratch, xa_lc3_enc_init_cfg_t *enc_control); </pre>
Description	Resets the encoder API handle into its initial state. Sets up the encoder to run using the supplied scratch buffer and the specified initial configuration parameters.
Parameters	<p>Input: <code>handle</code> Pointer to the Encoder handle (persistent state) Required size: see <code>xa_lc3_enc_get_handle_byte_size</code> Required alignment: 8 bytes</p> <p>Input: <code>enc_control</code> Pointer to the encoder control structure. Refer to <code>xa_lc3_enc_init_cfg_t</code> described in section 3.3.</p>

Example

```

xa_codec_handle_t handle =
    (xa_codec_handle_t)malloc(handle_size);
pWORD32 scratch = (pWORD32)malloc(scratch_size);
xa_lc3_enc_init_cfg_t enc_control;

error_code = xa_lc3_enc_init (handle,
                             scratch,
                             &enc_control);

```

Errors

- XA_API_FATAL_MEM_ALLOC
- XA_API_FATAL_MEM_ALIGN
- XA_LC3_CONFIG_FATAL_SAMP_FREQ_NOT_SUPPORTED
Sampling frequency not supported.
- XA_LC3_CONFIG_FATAL_NUM_CHANNEL_NOT_SUPPORTED
Number of channel not supported.
- XA_LC3_CONFIG_FATAL_ENC_BITRATE_NOT_SUPPORTED
Bitrate not supported.
- XA_LC3_CONFIG_FATAL_BITDEPTH_NOT_SUPPORTED
Bitdepth not supported.

Table 3-6 LC3 Decoder Initialization Function

Function	xa_lc3_dec_init
Syntax	XA_ERRORCODE xa_lc3_dec_init (xa_codec_handle_t handle, pWORD32 scratch, xa_lc3_dec_init_cfg_t *dec_control)
Description	Resets the decoder API handle into its initial state. Sets up the decoder to run using the supplied scratch buffer and specified initial configuration parameters.
Parameters	Input: handle Pointer to the Decoder handle (persistent state) Required size: see xa_lc3_dec_get_handle_byte_size

	<p>Required alignment: 8 bytes</p> <p>Input: <code>dec_control</code> Pointer to the decoder control structure. Refer to <code>xa_lc3_dec_init_cfg_t</code> described in section 3.3.</p>
--	---

Example

```

xa_codec_handle_t handle =
    (xa_codec_handle_t)malloc(handle_size);
pWORD32 scratch = (pWORD32)malloc(scratch_size);
xa_lc3_dec_init_cfg_t dec_control;
error_code = xa_lc3_dec_init( handle,
                              scratch
                              &dec_control);

```

Errors

- `XA_API_FATAL_MEM_ALLOC`
- `XA_API_FATAL_MEM_ALIGN`
- `XA_LC3_CONFIG_FATAL_SAMP_FREQ_NOT_SUPPORTED`
Not valid setting of sampling frequency.
- `XA_LC3_CONFIG_FATAL_NUM_CHANNEL_NOT_SUPPORTED`
Number of channels not supported.
- `XA_LC3_CONFIG_FATAL_BITDEPTH_NOT_SUPPORTED`
Bit-depth not supported.

3.4.4 Execution Stage

The LC3 codec processes the input stream and generates the output stream frame-by-frame. Each call to a codec execution function requires one complete frame as input and produces one complete packet as output.

The following macros are used in calculation of I/O buffer sizes and configuring of LC3.

Table 3-7 Macros used to calculate I/O buffer size

Defines with Values	Description
<code>XA_LC3_MAX_NUM_CHANNELS</code> 2	Maximum number of channels
<code>XA_LC3_MAX_SAMPLES</code> 480	Maximum number of samples in a frame

Defines with Values	Description
XA_LC3_MAX_BYTES 870	Maximum number of bytes in a frame

The syntax of the LC3 Encoder and Decoder execution functions is specified in Table 3-7 and Table 3-8, respectively.

Table 3-8 LC3 Encoder Execution Function

Function	xa_lc3_enc_process
Syntax	<pre> XA_ERRORCODE xa_lc3_enc_process (xa_codec_handle_t handle, pVOID p_in_data, pVOID p_out_data, pUWORD32 p_in_samples, pUWORD32 p_out_bytes, WORD32 scratch_size); </pre>
Description	Encode one frame of data.
Parameters	<p>Input: handle Pointer to the Encoder handle (persistent state)</p> <p>Input: p_in_data Pointer to the input speech pcm samples. There must be at least one frame of data in the input Required alignment: 8 bytes</p> <p>Output: p_out_data Pointer to the encoded data. Required alignment: 8 bytes</p> <p>Input/Output: p_in_samples Pointer to the number of samples in input buffer.</p> <p>Input/Output: p_out_bytes Pointer to the number of bytes in the output buffer generated by the encoder.</p>
Note	None

Example

```

xa_codec_handle_t handle;
pVOID inp_buf;
pVOID out_buf;
pUWORD32 p_in_samples;

```

```

pUWORD32 p_out_bytes;
WORD32 scratch_size;

error_code = xa_lc3_enc_process(handle,
                                inp_buf,
                                out_buf,
                                p_in_samples,
                                p_out_bytes,
                                scratch_size);

```

Errors

- XA_API_FATAL_MEM_ALLOC
- XA_API_FATAL_MEM_ALIGN
- XA_LC3_EXECUTE_FATAL_NOT_INITIALIZED
LC3 not initialized.

Table 3-9 LC3 Decoder Execution Function

Function	xa_lc3_dec_process
Syntax	XA_ERRORCODE xa_lc3_dec_process (xa_codec_handle_t handle, pVOID p_in_data, pVOID p_out_data, pWORD32 p_in_bytes, pWORD32 p_out_samples, WORD32 scratch_size, WORD32 bfi_ext);
Description	Decode one frame of data
Parameters	Input: handle Pointer to the Decoder handle (persistent state) Input: p_in_data Pointer to the input bytes of bitstream. Required alignment: 8 bytes Output: p_out_data Pointer to the decoded PCM data. Required alignment: 8 bytes Input/Output: p_in_bytes Pointer to the number of bytes in the input buffer

	Input/Output: <code>p_out_samples</code> Pointer to the number of samples in the output buffer.
Note	None

Example

```
xa_codec_handle_t handle;
pVOID inp_buf;
pVOID out_buf;
pUWORD32 p_in_bytes;
pUWORD32 p_out_samples;
WORD32 scratch_size;
WORD32 bfi_ext;

error_code = xa_lc3_dec_process(handle,
                                inp_buf,
                                out_buf,
                                p_in_bytes,
                                p_out_samples,
                                scratch_size,
                                bfi_ext);
```

Errors

- `XA_API_FATAL_MEM_ALLOC`
- `XA_API_FATAL_MEM_ALIGN`
- `XA_LC3_EXECUTE_FATAL_NOT_INITIALIZED`
LC3 not initialized.
- `XA_LC3_EXECUTE_FATAL_DEC_NUMBYTES_ERROR`
Invalid number of bytes.
- `XA_LC3_EXECUTE_NONFATAL_DECODE_ERROR`
Frame failed to decode and was concealed.

Table 3-10 LC3 Encoder Set Parameter Function

Function	<code>xa_lc3_enc_set_param</code>
Syntax	<pre>XA_ERRORCODE xa_lc3_enc_set_param (xa_codec_handle_t handle, xa_lc3_enc_param_id_t param_id, pVOID p_param_value);</pre>
Description	Sets the parameter specified by <code>param_id</code> to the value passed in the buffer pointed to by <code>p_param_value</code>
Parameters	<p>Input: <code>handle</code> Pointer to the Encoder handle (persistent state)</p> <p>Input: <code>param_id</code> Identifies the parameter to be written.</p> <p>Input: <code>p_param_value</code> A pointer to a buffer that contains the parameter value.</p>
Note	None

Example

```
xa_codec_handle_t handle;
xa_lc3_enc_param_id_t param_id;
pVOID p_param_value;

error_code = xa_lc3_enc_set_param (handle,
                                   param_id,
                                   p_param_value);
```

Errors

- `XA_API_FATAL_MEM_ALLOC`
- `XA_API_FATAL_MEM_ALIGN`
- `XA_LC3_CONFIG_FATAL_ENC_BITRATE_NOT_SUPPORTED`
Invalid bitrate.
- `XA_LC3_CONFIG_NONFATAL_INVALID_PARAM`
- `XA_LC3_FRAMEMS_NOT_SUPPORTED`
Parameter identifier (`param_id`) is not valid.

Table 3-11 LC3 Encoder Set Parameter Commands

Command	Description
XA_LC3_ENC_PARAM_BITRATE	Set encoder bitrate
XA_LC3_ENC_PARAM_FRAME_DMS	Set encoder frame size in dms

Table 3-12 LC3 Encoder Get Parameter Function

Function	xa_lc3_enc_get_param
Syntax	<pre>XA_ERRORCODE xa_lc3_enc_get_param (xa_codec_handle_t handle, xa_lc3_enc_param_id_t param_id, pVOID p_param_value);</pre>
Description	Gets the value of the parameter specified by <code>param_id</code> in the buffer pointed to by <code>p_param_value</code>
Parameters	<p>Input: <code>handle</code> Pointer to the Encoder handle (persistent state)</p> <p>Input: <code>param_id</code> Identifies the parameter to be written.</p> <p>Input: <code>p_param_value</code> A pointer to a buffer that contains the parameter value.</p>
Note	None

Example

```
xa_codec_handle_t handle;
xa_lc3_enc_param_id_t param_id;
pVOID p_param_value;

error_code = xa_lc3_enc_get_param (handle,
                                   param_id,
                                   p_param_value);
```

Errors

- XA_API_FATAL_MEM_ALLOC
- XA_API_FATAL_MEM_ALIGN
- XA_LC3_CONFIG_NONFATAL_INVALID_PARAM
Parameter identifier (`param_id`) is not valid.

Table 3-13 Encoder Get Parameter Commands

Command	Description
XA_LC3_ENC_PARAM_FRAME_LENGTH	Get encoder frame length
XA_LC3_ENC_PARAM_REAL_BITRATE	Get encoder real bitrate
XA_LC3_ENC_PARAM_DELAY_COMPENSATION	Get delay compensation in encoder

Table 3-14 LC3 Decoder Get Parameter Function

Function	xa_lc3_dec_get_param
Syntax	<pre>XA_ERRORCODE xa_lc3_dec_get_param (xa_codec_handle_t handle, xa_lc3_dec_param_id_t param_id, pVOID p_param_value);</pre>
Description	Gets the value of the parameter specified by <code>param_id</code> in the buffer pointed to by <code>p_param_value</code>
Parameters	<p>Input: <code>handle</code> Pointer to the Decoder handle (persistent state)</p> <p>Input: <code>param_id</code> Identifies the parameter to be written.</p> <p>Input: <code>p_param_value</code> A pointer to a buffer that contains the parameter value.</p>
Note	None

Example

```
xa_codec_handle_t handle;
xa_lc3_dec_param_id_t param_id;
pVOID p_param_value;

error_code = xa_lc3_dec_get_param (handle,
                                   param_id,
                                   p_param_value);
```

Errors

- XA_API_FATAL_MEM_ALLOC
- XA_API_FATAL_MEM_ALIGN

- XA_LC3_CONFIG_NONFATAL_INVALID_PARAM

Parameter identifier (`param_id`) is not valid.

Table 3-15 LC3 Decoder Get Parameter Commands

Command	Description
XA_LC3_DEC_PARAM_DELAY_COMPENSATION	Get delay compensation in decoder
XA_LC3_DEC_PARAM_FRAME_LENGTH	Get decoder frame length

Table 3-16 LC3 Decoder Set Parameter Function

Function	<code>xa_lc3_dec_set_param</code>
Syntax	<pre>XA_ERRORCODE xa_lc3_dec_set_param (xa_codec_handle_t handle, xa_lc3_dec_param_id_t param_id, pVOID p_param_value);</pre>
Description	Sets the parameter specified by <code>param_id</code> to the value passed in the buffer pointed to by <code>p_param_value</code>
Parameters	<p>Input: <code>handle</code> Pointer to the Decoder handle (persistent state)</p> <p>Input: <code>param_id</code> Identifies the parameter to be written.</p> <p>Input: <code>p_param_value</code> A pointer to a buffer that contains the parameter value.</p>
Note	None

Example

```
xa_codec_handle_t handle;
xa_lc3_dec_param_id_t param_id;
pVOID p_param_value;

error_code = xa_lc3_dec_set_param (handle,
                                   param_id,
                                   p_param_value);
```

Errors

- XA_API_FATAL_MEM_ALLOC
- XA_API_FATAL_MEM_ALIGN

- XA_LC3_CONFIG_NONFATAL_INVALID_PARAM
- XA_LC3_FRAMEMS_NOT_SUPPORTED

Parameter identifier (`param_id`) is not valid.

Table 3-17 LC3 Decoder Set Parameter Commands

Command	Description
XA_LC3_DEC_PARAM_FRAME_DMS	Set decoder frame size in dms

4. Introduction to the Example Test Bench

The LC3 codec library is provided with two sample test bench applications: one for the encoder and one for the decoder. The LC3 codec library is released as a .tgz file for Linux/makefile based usage, and an .xws file for Xtensa Xplorer based usage. The supplied test benches consist of the following files:

- Test bench source files (test/src)
 - xa_lc3_decoder_sample_testbench.c
 - xa_lc3_encoder_sample_testbench.c
 - xa_lc3_codec_error_handler.c
- Makefile to build the executables (test/build)
 - makefile_testbench_sample

4.1 Making the Executable

To build the applications from the codec .tgz based release package, follow these steps:

1. Go to test/build.
2. From the command-line prompt, enter:

```
xt-make -f makefile_testbench_sample clean all
```

This will build the encoder example test bench xa_lc3_enc_test and the decoder example test bench xa_lc3_dec_test.

To build the application from the decoder or encoder only .tgz based release package, follow these steps:

1. Go to test/build.
2. From the command-line prompt, enter:

```
xt-make -f makefile_testbench_sample clean [lc3_dec|lc3_enc]
```

This will build the decoder/encoder example test bench xa_lc3_dec_test/xa_lc3_enc_test.

Note	If you have source code distribution for the codec package, you must build the LC3 codec library before you can build the test bench.
-------------	---

Follow these steps:

1. Go to `build`.
2. At the command prompt, enter: `xt-make -f clean all install` to build the LC3 codec library.

The LC3 library `xa_lc3_codec.a` will be built and copied to the `lib` directory.

Note If you have source code distribution for the decoder or encoder only package, you must build the LC3 decoder or encoder library before you can build the testbench.

Follow these steps:

1. Go to `build`.
2. At the command prompt, enter:
`xt-make -f clean [lc3_dec|lc3_enc] install`
to build the LC3 dec/enc library.

The LC3 library `xa_lc3_dec.a` or `xa_lc3_enc.a` will be built and copied to the `lib` directory respectively.

To build and execute the application from xws based release package, refer to the `readme.html` file available in the imported application project.

4.2 Usage

The sample application executable can be run with direct command-line options or with a parameter file. For executing sample application from Xtensa Xplorer workspace, refer to the `readme.html` file available in the imported project.

Encoder

The sample application encoder executable can be run from the command line as follows:

```
xt-run xa_lc3_enc_test [OPTIONS] <INPUT> <OUTPUT> <BITRATE>
```

Where:

< INPUT >:	Input WAV file (1 or 2 channels, 16 or 24 bit-depth, sample-rate: 8, 16, 24, 32, 44.1 or 48 kHz)
< OUTPUT >:	Output encoded bitstream file
< BITRATE >:	Target bitrate, specified in bits per second (real bitrate would be an approximation of target bitrate as per Table 1-1). Alternatively, a switching file can be provided.
[OPTIONS]:	

```

-frame_ms:      NUM Frame length in ms. NUM must be 10 (default) or 7.5
-formatG192:    Activate G192 bitstream format. A filename.cfg will be used
                to store/load decoder info.
-cfgG192 FILE:  Specify a configuration file for G192 bitstream format.
-epf FILE:      Enable packet loss simulation using error pattern from FILE
-dc NUM: 0:     Do not use delay compensation
                1:   Compensate delay in decoder (default)
                2:   Split delay equally between encoder and decoder
-ept:           Use together with -epf FILE to create bitstream triggering
                PLC via special value of lastnz
-y:            StartFrame: frame number where encoding/decoding shall
                start
-z:            StopFrame: frame number where encoding/decoding shall
                stop

```

Decoder

The sample application decoder executable can be run from the command line as follows:

```
xt-run xa_lc3_dec_test [OPTIONS] <INPUT> <OUTPUT>
```

Where:

```

< INPUT >:      Input encoded bitstream file
< OUTPUT >:     Output decoded WAV file
[OPTIONS]:
  -bps NUM:      Output bits per sample. NUM must be 16 (default) or 24
  -formatG192:   Activate G192 bitstream format. A filename.cfg will be used
                to store/load decoder info.
  -cfgG192 FILE: Specify a configuration file for G192 bitstream format.
  -dc NUM: 0:    Do not use delay compensation
                1:   Compensate delay in decoder (default)
                2:   Split delay equally between encoder and decoder
  -epf FILE:     Enable packet loss simulation using error pattern from FILE
  -edf FILE:     Write error pattern as detected to FILE
  -y:           StartFrame: frame number where encoding/decoding shall
                start
  -z:           StopFrame: frame number where encoding/decoding shall
                stop

```

Note that an invalid input argument (starting with alphabet) to `-dc NUM` results in no delay compensation.

If no command line arguments are given, the Encoder or Decoder application reads the commands from the parameter file `paramfilesimple_encode.txt` or `paramfilesimple_decode.txt`, respectively.

Following is the syntax for writing the `paramfilesimple`:

```
@Start

@Input_path <path to be appended to all input files>

@Output_path <path to be appended to all output files>
<command line 1>
<command line 2>
....
@Stop
```

The LC3 encoder and decoder can be run for multiple test files using the different command lines. The syntax for command lines in the parameter file is the same as the syntax for specifying options on the command line to the test bench program.

Note All the `@<command>s` should be at the first column of a line except the `@New_line` command.

Note All the `@<command>s` are case sensitive. If the command line in the parameter file has to be broken to two parts on two different lines use the `@New_line` command.

E.g.,
`<command line part 1> @ New_line`
`<command line part 1>`

Note Blank lines will be ignored.

Note Individual lines can be commented out using `"/"` at the beginning of the line.

5. Reference

- [1] *LC3 Specification version 1.0:*
<https://www.bluetooth.com/specifications/le-audio/>
- [2] *LC3 Test suite version 1.0:*
<https://www.bluetooth.com/specifications/qualification-test-requirements/>
- [3] *LC3 Reference binary*
https://www.bluetooth.org/DocMan/DocInfo.aspx?doc_id=497700