

Device Name	Type	OS	Did it pair?	Control Play/Pause?	Control Next/Previous?	Control Volume?	Display Track Name?	Display Play/Pause Status?	Connection Consistent?	Note*
Samsung Ativ S	Smartphone	Windows Phone 8.1 (H330 34503.306)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
iPod Touch G6	OMP	iOS 12.5.4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Same as A58F
BlackBerry Z10	Smartphone	BlackBerry 10 (10.3.3.2128)	Yes	Yes	Yes	No	Yes	Yes	Yes	
BlackBerry Classic	Smartphone	BlackBerry 10 (10.3.3.2127)	Yes	Yes	Yes	No	Yes	Yes	Yes	
BlackBerry Bold 9900	Smartphone	BlackBerry 7.1 OS Bundle 2679 (7.1.1.0.5866)	Yes	Yes	Yes	No	Yes	Yes	Yes	36, not 40
Raspberry Pi 4 Model B 800	Single-board Computer (ARM v8 64-bit SOC)	Raspberry Pi OS (Raspbian 9.10)	Yes	Yes	Yes	No	No	Yes	No	Same as A58F
Walkman NW2-F006	OMP	Android 4.0.4	Yes	Yes	Yes	No	No	Yes	Yes	Same as A58F
Samsung S6	Smartphone	Android 7.0.0	Yes	Inconsistently	Yes	No	Inconsistently	No	Yes	Same as A58F
Nokia 5.3	Smartphone	Android 11	Yes	Maybe?	Maybe?	No	Maybe?	Maybe?	Yes	Same as A58F
LG G6	Smartphone	Android 8.0.0	Yes	No	Yes	No	Yes	Yes	Yes	Same as A58F
Schell Classic	Smart Feature Phone	Android 9 Go Edition	Yes	No	No	No	Yes	Yes	Yes	
Nokia 8110-4G	Smart Feature Phone	S405 2.5.3	Yes	No	No	No	Yes	Yes	Yes	
BlackBerry KeyOne	Smartphone	Android 8.1.0	Yes	No	No	No	Yes	Yes	Yes	Same as A58F
Nokia 5.3	Smartphone	Android 10	Yes	No	No	No	Yes	No	Yes	
LG Chocolate Touch	Feature Phone	Proprietary	Yes	No	No	No	No	No	Yes	
GPD Win 1	PC - 64bit (x86 Portable)	Windows 10 Pro (10290, Build 17000.130)	Yes	No	No	No	No	No	Yes	
Lenovo Ideapad Z565	PC - 64bit (x86 Portable)	Windows 8.1 (9601, Build 9600)	Yes	No	No	No	No	No	Yes	
Lenovo UX34	OMP	Proprietary	No	N/A	N/A	N/A	N/A	N/A	N/A	
Nokia Lumia 900	Smartphone	Windows Phone 7.5	No	No	N/A	N/A	N/A	N/A	N/A	Incompatible

Device Name	Note* Details	Tested Apps List
Walkman NW2-F006	While this OMP can control the music, the BT connection breaks when the screen turns off. Best suggested use-case: Useful as an audio system with the screen set to never turn off.	N/A
LG G6	With certain music apps, no controls at all are present, but not obvious as to why on one app.	* Simple Music Player * Spotify
BlackBerry KeyOne	Some apps consistently displayed the current song title and play/pause status while others did not. This is not useful, but it is noteworthy.	* Pulse Music Player * Simple Music Player * Music Player by "Music Player." * Local music player * Music Player - MP3 Player (Music Player) * MP3 player without advertising * Spotify * Play Music- Music Player, MP3 Player, Audio Player * Soundwave Music, Music
iPod Touch G6	Be sure to select "Yes" when a prompt appears and asks if you are pairing to iPhone.	N/A
Samsung S6	When the band is first connected (not just paired, but also reconnected), it gets exactly one consistent chance to control play/pause. After that, it is totally random and unpredictable when you can press and use the button. The name of the track is also inconsistently displayed... it feels random when it decides to update that info.	* Samsung Music * Spotify
Nokia 5.3 (Android 11)	Some apps consistently displayed the current song title while others did not. As well, it seems that sometimes the play/pause button is arbitrarily left to power (play arrow icon), but not function normal after tapping it once or twice. It is still very much usable. However this was upon first trial. After this I could not recreate the results. Further testing is needed.	* Simple Music Player * Spotify
Raspberry Pi 4 Model B 800	The controls work, minus volume.	* VLC Player

How reliable the information provided here is depends on what the last person who used it had permission to use. It is not a guarantee that the data and findings presented are correct.