

	A	B	C	D	E	F	G	H	I	J	K
	Device Name	Type	OS	Did it pair?	Control Play/Pause?	Control Next/Previous?	Control Volume?	Display Track Name?	Display Play/Pause Status?	Connection Consistent?	Notes
	Walkman NWZ-F806	GMP	Android 4.0.4	Yes	Yes	Yes	No	No	Yes	No*	Jump to A206
	Samsung S6	Smartphone	Android 7.0.0	Yes	Inconsistently*	Yes	No	Inconsistently*	No	Yes	Jump to A206
	LG G6	Smartphone	Android 8.0.0	Yes	No	Yes	No	Yes	Yes	Yes	Jump to A206
	Schok Classic	Smart Feature Phone	Android 8.00 Edition	Yes	No	No	No	Yes	Yes	Yes	
	BlackBerry KeyOne	Smartphone	Android 8.1.0	Yes	No	No	No	Yes*	Yes	Yes	Jump to A206
	Nokia 5.3	Smartphone	Android 10	Yes	No	No	No	Yes	No	Yes	
	Nokia 5.3	Smartphone	Android 11	Yes	Yes	Yes	No	Yes*	Yes*	Yes	Jump to A206
	BlackBerry Z10	Smartphone	BlackBerry 10 OS 3.3.4.1226	Yes	Yes	Yes	No	Yes	Yes	Yes	
	BlackBerry Classic	Smartphone	BlackBerry 10 OS 3.3.4.1226	Yes	Yes	Yes	No	Yes	Yes	Yes	
	BlackBerry Bold 9930	Smartphone	BlackBerry 7.1 OS Bundle 2879 (v.7.1.2.1065)	Yes	Yes	Yes	No	Yes	Yes	Yes	3G, not 4G
	iPod Touch G6	GMP	iOS 12.5.4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Jump to A206
	Phone 12	Smartphone	iOS 14.4.2	?	?	?	?	?	?	?	?
	Nokia 8110 4G	Smart Feature Phone	KaiOS 2.5.1	Yes	No	No	No	Yes	Yes	Yes	
	Lenovo LX14	GMP	Proprietary	No	N/A	N/A	N/A	N/A	N/A	N/A	
	LG Chocolate Touch	Feature Phone	Proprietary	Yes	No	No	No	No	No	Yes	
	Raspberry Pi 4 Model B 8GB	Single-Board Computer	Raspberry Pi OS (ARMv8) 5.10 (v2104, Bullseye 2020.12.01)	Yes	Yes	Yes	No	No	Yes	Yes	Jump to A211
	GPD Win 1	PC: 64bit (x86 Portable)	Windows 11 Pro	Yes	No	No	No	No	No	Yes	
	Lenovo Ideapad Z585	PC: 64bit (x86 Portable)	Windows 8.1 (v.8.1, Build 9600)	Yes	No	No	No	No	No	Yes	
	Nokia Lumia 900	Smartphone	Windows Phone 7.5	No	N/A	N/A	N/A	N/A	N/A	N/A	
	Samsung Ativ S	Smartphone	Windows Phone 8.1	Yes	N/A	Yes	Yes	Yes	Yes	Yes	

	Device Name	Note Details	Tested Apps List
	Walkman NWZ-F806	While this GMP can control the music, the BT connection breaks when the screen turns off. Best suggested use-case: Docked at an audio system with the screen set to never turn off.	N/A
	LG G6	With certain music apps, no controls at all are present, but next/previous at least works on one app.	<ul style="list-style-type: none"> Simple Music Player Spotify
	BlackBerry KeyOne	Some apps consistently displayed the current song title and play/pause icons while others did not. This is not useful, but it is noteworthy.	<ul style="list-style-type: none"> Pulsar Music Player Simple Music Player Music Player by "Music Player." Local music player Music Player - MP3 Player (Music Player) MP3 player without advertising Spotify Play Music- Music Player, MP3 Player, Audio Player MusicMaker Music Player
	iPod Touch G6	Be sure to select "Yes" when a prompt appears and asks if you are pairing to iPhone.	N/A
	Samsung S6	When the Band is first connected (not just paired, but also reconnected), it gets exactly one consistent chance to control play/pause. After that, it is totally random and unpredictable when you can press and use the button. The name of the track is also inconsistently displayed... it feels random when it decides to update that info.	<ul style="list-style-type: none"> Samsung Music Spotify
	Nokia 5.3 (Android 11)	Some apps consistently displayed the current song title while others did not. As well, it seems that sometimes the play/pause button is effectively left to pause (play arrow icon), but still function normal after tapping it once or twice. It is still very much usable.	<ul style="list-style-type: none"> Simple Music Player Spotify
	Raspberry Pi 4 Model B 8GB	The controls work, minus volume.	<ul style="list-style-type: none"> VLC Player

* Some GMPs that don't properly control track consistently with the Band. Green means that it performed more consistently with the Band, and yellow means it is inconsistent.