

Andes 乙級證照 108考題練習與解析

Q1

考題類型	<input type="checkbox"/> Non-OS <input type="checkbox"/> Linux
實作平台	<input type="checkbox"/> ADP-XC5FF676 <input type="checkbox"/> ADPAG102-UP <input type="checkbox"/> ADP-WT95F064 <input checked="" type="checkbox"/> VEP (AndeSight™ STD v2.0)
環境設定	1. PC 主機：Host OS - Microsoft Windows XP。 2. Andes/AndeSight V2.0 Toolchains。
實作內容	在 AndeSight™整合開發環境撰寫程式，使用 ESL 環境下的 VEP(Virtual Evaluation Platform)功能，設定屬性 Target Chip 使用 ADP-AG101-4GB-N1033-S; Tool Chain 必須用 nds32le-elf-newlib-v2 (1) 實現五次” My name is James 等字 ” 文字顯示；(2) 產生最小容量的 bin 檔案。
注意事項	1. 請將作答所產生之所有檔案儲存於資料夾 Q1\Ans 內。 2. 可依需要參考或使用 Q1\ 內各子資料夾預存之程式碼或資料。 ↵

C Project

Create C project of selected type

Project name: ACETQ1_20200520

☒ Use default location

Location: C:\Andestech\AndeSight200STD\ide_64\workspace\ACETQ1_20200520

Browse...

Choose file system: default

Connection Type

☒ Simulator ☐ AICE

Target Chip

Name	Chip	CPU	Simulator Config
ADP-AG101P-16MB-N801-S	ADP-AG101P-16MB-N801-S	[N801-S]	ADP-XC5-for-N801-S-16M.vep
ADP-AG101P-4GB-N1033A-S	ADP-AG101P-4GB-N1033A-S	[N1033A-S]	ADP-XC5-for-N1033A-S.vep
ADP-AG101P-4GB-N1068A-S	ADP-AG101P-4GB-N1068A-S	[N1068A-S]	ADP-XC5-for-N1068A-S.vep
ADP-AG101P-4GB-N1233-FPU	ADP-AG101P-4GB-N1233F-S	[N1233-FPU]	ADP-XC5-for-N1233-FPU.vep
ADP-AG101P-4GB-N1337-FPU	ADP-AG101P-4GB-N1337-FPU	[N1337-FPU]	ADP-XC5-for-N1337-FPU.vep
ADP-AG101P-4GB-N903-S-32GPR	ADP-AG101P-4GB-N903-S-32GPR	[N903-S]	ADP-XC5-for-N903A-S.vep

Project type:

Andes Executable

☒ Empty Project

☐ Hello World ANSI C Project

Andes Shared Library

Andes Static Library

Makefile project

Toolchains:

nds32le-elf-mculib-v2

nds32le-elf-mculib-v2j

☒ nds32le-elf-newlib-v2

nds32le-elf-newlib-v2j

nds32le-linux-glibc-v2

☒ Show project types and toolchains only if they are supported on the platform


?

< Back


Next >


Finish


Cancel





```
2 * hello.c
7
8 #include <stdio.h>
9
10 int main()
11 {
12     int cnt=0;
13     for(cnt=0; cnt<5; cnt++){
14         puts("My name is Steven Su");
15     }
16 }
```











type filter text

General
C/C++
Help
Install/Update
License
Remote Systems
Run/Debug
Target Management default settings
TCF Agent Configurations
Team
Terminal
VEP Editor

Target Management default setting

User Settings for Target Management.

All of the settings in this page are global to the entire workspace except for those in Target Chip section.

Target Manager Internal TCP Port Range

Start Port 9900

End Port 49151

- ☐ Enable Simulator Multiple Instances
☒ Enable AICE plug-in
☐ Disable Simulator/AICE consoles

Connection Type

☒ Simulator ☐ AICE

ICEman Misc Arguments

Simulator Misc Arguments

Vep2Conf Misc Arguments

Target Chip

Name	Chip	CPU	Simulator Config
ADP-AG101P-16MB-N801-S	ADP-AG101P-16MB-N801-S	[N801-S]	ADP-XC5-for-N801-S-16M.vep
ADP-AG101P-4GB-N1033A-S	ADP-AG101P-4GB-N1033A-S	[N1033A-S]	ADP-XC5-for-N1033A-S.vep
ADP-AG101P-4GB-N1068A-S	ADP-AG101P-4GB-N1068A-S	[N1068A-S]	ADP-XC5-for-N1068A-S.vep
ADP-AG101P-4GB-N1233-FPU	ADP-AG101P-4GB-N1233F-S	[N1233-FPU]	ADP-XC5-for-N1233-FPU.vep
ADP-AG101P-4GB-N1337-FPU	ADP-AG101P-4GB-N1337-FPU	[N1337-FPU]	ADP-XC5-for-N1337-FPU.vep
ADP-AG101P-4GB-N903-S-32GPR	ADP-AG101P-4GB-N903-S-32GPR	[N903-S]	ADP-XC5-for-N903A-S.vep

Front-end Selection

Setup System Calls

Restore Defaults

Apply



OK

Cancel

type filter text

- Resource
- Builders
- C/C++ Build
 - Build Variables
 - Discovery Options
 - Environment
 - Logging
 - Settings**
 - Target Configuration
 - Tool Chain Editor
- C/C++ General
- Project References
- Run/Debug Settings

Settings

Configuration: Debug [Active]

Manage Configurations...

Tool Settings Build Steps Build Artifact Binary Parsers Error Parsers

nds32le-elf-newlib-v2 Configurations

Andes C Compiler

- Preprocessor
- Symbols
- Directories
- Optimization
- Debugging
- Warnings
- Miscellaneous

Andes C Linker

- General
- Libraries
- Miscellaneous
- Shared Library Settings
- Loaded Address

Andes Assembler

- General

NM (symbol listing)

- General

Readelf (ELF info listing)

- General

Objdump (disassembly)

- General

Objcopy (object content copy)

- General**

Size (section size listing)

- General

☐ Disable. (Do not auto-generate output file.)☒ Remove all symbol and relocation information. (-S)☒ Remove all debugging symbols _sections. (-g)☒ Remove all non-global symbols. (-x)☒ Remove any compiler-generated symbols. (-X)

Other flags: -O binary

顯示.bin檔步驟：

1.打開Properties

2.點選Objcopy/General

3.勾選下面四項

(p.s 第一項為不自動產生bin檔)

Restore Defaults

Apply

OK

Cancel

type filter text

Resource
Builders
C/C++ Build
Build Variables
Discovery Options
Environment
Logging
Settings
Target Configuration
Tool Chain Editor
C/C++ General
Project References
Run/Debug Settings

Settings

Configuration: Debug [Active]

Manage Configurations...

Tool Settings

Build Steps

Build Artifact

Binary Parsers

Error Parsers

nds32le-elf-newlib-v2 Configurations

Andes C Compiler

Preprocessor

Symbols

Directories

Optimization

Debugging

Warnings

Miscellaneous

Andes C Linker

General

Libraries

Miscellaneous

Shared Library Settings

Loaded Address

Andes Assembler

General

NM (symbol listing)

General

Readelf (ELF info listing)

General

Objdump (disassembly)

General

Objcopy (object content copy)

General

Size (section size listing)

General

Optimization Level

Optimize Size most (-Os)

Other optimization flags

☒ Remove unused function sections (-ffunction-sections)☒ Remove unused data sections (-fdata-sections)

顯示.bin檔步驟：

4.點選

Andes C Compiler/Optimization

5.選擇Optimization Size most(-Os)


6.勾選下面兩項

Restore Defaults


Apply

OK

Cancel




.bin由.adx產生



打開檔案總管
查看.bin檔案大小

**若是你的程式碼結果沒有顯示
請到以下畫面設定**



Preferences

type filter text

General
C/C++
Help
Install/Update
License
Remote Systems
Run/Debug
Target Management default setting
TCF Agent Configurations
Team
Terminal
VEP Editor

Target Management default setting

User Settings for Target Management.

All of the settings in this page are global to the entire workspace except for those in Target Chip section.

Target Manager Internal TCP Port Range

Start Port 9900

End Port 49151

☐ Enable Simulator Multiple Instances
☒ Enable AICE plug-in
☐ Disable Simulator/AICE consoles

Connection Type
☒ Simulator ☐ AICE

ICEman Misc Arguments

Simulator Misc Arguments

Vep2Conf Misc Arguments

Target Chip

Name	Chip	CPU	Simulator Config
ADP-AG101P-16MB-N801-S	ADP-AG101P-16MB-N801-S	[N801-S]	ADP-XC5-for-N801-S-16M.vep
ADP-AG101P-4GB-N1033A-S	ADP-AG101P-4GB-N1033A-S	[N1033A-S]	ADP-XC5-for-N1033A-S.vep
ADP-AG101P-4GB-N1068A-S	ADP-AG101P-4GB-N1068A-S	[N1068A-S]	ADP-XC5-for-N1068A-S.vep
ADP-AG101P-4GB-N1233-FPU	ADP-AG101P-4GB-N1233F-S	[N1233-FPU]	ADP-XC5-for-N1233-FPU.vep
ADP-AG101P-4GB-N1337-FPU	ADP-AG101P-4GB-N1337-FPU	[N1337-FPU]	ADP-XC5-for-N1337-FPU.vep
ADP-AG101P-4GB-N903-S-32GPR	ADP-AG101P-4GB-N903-S-32GPR	[N903-S]	ADP-XC5-for-N903A-S.vep
ADP-AG101P-4GB-N968A-S	ADP-AG101P-4GB-N968A-S	[N968A-S]	ADP-XC5-for-N968A-S.vep

Front-end Selection Setup System Calls

Restore Defaults Apply

OK Cancel

Setup System Calls

ADP-AG101P-4GB-N1033A-S

Name	Description	Append CPU Option
<input checked="" type="checkbox"/> VIOS	VIOS Mode	--config-default-exception-support 1 --environment user
<input type="checkbox"/> RAW	RAW Mode	--config-default-exception-support 0 --environment operating

VIOS mode:

Any OS or applications can safely assume the system call services and exception handlers will be handled by the Simulator.

RAW mode:

The Simulator won't handle system call services and exception handlers.
It is OS or applications' responsibility to implement the system call and exception handlers


OK Cancel

點選RAM→無法顯示
點選VIOS→可以顯示

Q2

考題類型	<input type="checkbox"/> Non-OS <input type="checkbox"/> Linux
實作平台	<input type="checkbox"/> ADP-XC5FF676 <input type="checkbox"/> ADPAG102-UP <input type="checkbox"/> ADP-WT95F064 <input checked="" type="checkbox"/> VEP (AndeSight™ STD v2.0)
環境設定	1. PC 主機：Host OS - Microsoft Windows XP 2. Andes/AndeSight V2.0 Toolchains
實作內容	在 AndeSight™整合開發環境撰寫程式，使用 ESL 平台環境下(1) 將程式修改為一系列 LED 間隔之閃爍效果(2)使 LED 同時兩列以上達到跑馬燈閃爍之顯示效果。
注意事項	1. 請將作答所產生之所有檔案儲存於資料夾 Q2\Ans 內。 2. 可依需要參考或使用 Q2\ 內各子資料夾預存之程式碼或資料。


Q2_(1)



Q2_(1) 一列LED相鄰不亮


0xAA → 1010 , 反向 → 0x0101

```
1 #define GPIO_BASE 0x98700000
2 #define GPIO_DATA_OUT (*((unsigned int *)(GPIO_BASE+0x00)))
3
4 #define LED_GREEN 0xAA
5 #define DELAY_TIME 100000
6
7 void toggleLED (unsigned int LEDMask);
8 void delay(unsigned int count);
```



```
10 int main()
11 {
12     GPIO_DATA_OUT=0;
13     while(1)
14     {
15         toggleLED(LED_GREEN);
16         delay(DELAY_TIME);
17     }
18     return 0;
19 }
```


```
1 #define GPIO_BASE 0x98700000
2 #define GPIO_DATA_OUT (*((unsigned int *) (GPIO_BASE+0x00)))
3
4 #define LED_GREEN 0x55555555
5 #define DELAY_TIME 100000
6
7 void toggleLED (unsigned int LEDMask);
8 void delay(unsigned int count);
9
10 int main()
11 {
12     GPIO_DATA_OUT=0;
13     while(1)
14     {
15         toggleLED(LED_GREEN);
16         delay(DELAY_TIME);
17     }
18     return 0;
19 }
20
```



Q2_(2)將亮燈位置儲存在陣列中

```
10 unsigned int data[]={0x0101,0x0202,0x0404,0x0808,  
11                      0x1010,0x2020,0x4040,0x8080,  
12                      0x4040,0x2020,0x1010,0x0808,  
13                      0x0404,0x0202};  
14 int main()  
15 {  
16     GPIO_DATA_OUT=0;    //輸出緩衝器=0，LED滅掉  
17     int cnt;  
18     for(cnt=0; cnt<3; cnt++){  
19         toggleLED(LED_GREEN);    //執行一次LED即滅掉  
20         delay(DELAY_TIME);  
21     }  
22     while(1){  
23         for(cnt=0; cnt<14; cnt++){  
24             GPIO_DATA_OUT = data[cnt];  
25             delay(DELAY_TIME);  
26         }  
27     }  
28     return 0;  
29 }
```

//把跑馬燈順序放入陣列



```
#define GPIO_BASE 0x98700000
#define GPIO_DATA_OUT (*((unsigned int *)(GPIO_BASE+0x00)))
```

```
#define LED_GREEN 0x99669966
#define DELAY_TIME 100000
```

```
void toggleLED (unsigned int LEDMask);
void delay(unsigned int count);
```

```
int main()
{
    GPIO_DATA_OUT=0;
    while(1)
    {
        toggleLED(LED_GREEN);
        delay(DELAY_TIME);
    }
    return 0;
}
```

```
void toggleLED (unsigned int LEDMask)
{
    GPIO_DATA_OUT ^= LEDMask;
}
```

```
void delay(unsigned int count)
{
    for(;count>0;count--);
}
```




```

1 #define GPIO_BASE 0x98700000|
2 #define GPIO_DATA_OUT (*((unsigned int *)(GPIO_BASE+0x00)))
3
4 #define LED_GREEN 0x00FF00FF //1.3列閃
5 #define DELAY_TIME 100000
6
7 void toggleLED (unsigned int LEDMask);
8 void delay(unsigned int count);
9
10 int main()
11 {
12     GPIO_DATA_OUT=0;
13     while(1)
14     {
15         toggleLED(LED_GREEN);
16         delay(DELAY_TIME);
17     }
18     return 0;
19 }
20

```




```
1 #define GPIO_BASE 0x98700000
2 #define GPIO_DATA_OUT (*((unsigned int *) (GPIO_BASE+0x00)))
3
4 #define LED_GREEN 0xAA55AA55
5 #define DELAY_TIME 100000
6
7 void toggleLED (unsigned int LEDMask);
8 void delay(unsigned int count);
9
10 int main()
11 {
12     GPIO_DATA_OUT=0;
13     while(1)
14     {
15         toggleLED(LED_GREEN);
16         delay(DELAY_TIME);
17     }
18     return 0;
19 }
20
```



```
11 unsigned int outdata=0x01;
12 GPIO_DATA_OUT=0;|
13
14 while(1)
15 {
16     while(outdata<0x80){
17         GPIO_DATA_OUT=outdata;
18         outdata = outdata<<1;
19         delay(DELAY_TIME);
20     }
21     GPIO_DATA_OUT=outdata;
22     delay(DELAY_TIME);
23     outdata = outdata>>1;
24
25     while(outdata>0x01){
26         GPIO_DATA_OUT=outdata;
27         outdata = outdata>>1;
28         delay(DELAY_TIME);
29     }
30 }
```

霹靂燈



```

#define GPIO_BASE 0x98700000
#define GPIO_DATA_OUT (*((unsigned int *)(GPIO_BASE+0x00))

#define DELAY_TIME 500000

void toggleLED (unsigned int LEDMask);
void delay(unsigned int count);

int main()
{
    unsigned int outdata=0x01;
    GPIO_DATA_OUT=0;

    while(1)
    {
        while(outdata<0x80){
            GPIO_DATA_OUT=outdata;
            outdata = outdata<<1;
            delay(DELAY_TIME);
        }
        GPIO_DATA_OUT=outdata;
        delay(DELAY_TIME);
        outdata = outdata>>1;

        while(outdata>0x01){
            GPIO_DATA_OUT=outdata;
            outdata = outdata>>1;
            delay(DELAY_TIME);
        }
    }
    return 0;
}

void toggleLED (unsigned int LEDMask)
{
    GPIO_DATA_OUT ^= LEDMask;
}

void delay(unsigned int count)
{
    for(;count>0;count--);
}


```

```

9 int main()
10 {
11     unsigned int outdata=0x01000001;
12     GPIO_DATA_OUT=0;
13
14     while(1)
15     {
16         while(outdata<0x80000080){
17             GPIO_DATA_OUT=outdata;
18             outdata = outdata<<1;
19             delay(DELAY_TIME);
20         }
21         GPIO_DATA_OUT=outdata;
22         delay(DELAY_TIME);
23         outdata = outdata>>1;
24
25         while(outdata>0x01000001){
26             GPIO_DATA_OUT=outdata;
27             outdata = outdata>>1;
28             delay(DELAY_TIME);
29         }
30     }
31     return 0;
32 }

```

1.4 霹靂燈



```

#define GPIO_BASE 0x98700000
#define GPIO_DATA_OUT (*((unsigned int *)(GPIO_BASE+0x00))

#define DELAY_TIME 500000

void toggleLED (unsigned int LEDMask);
void delay(unsigned int count);

int main()
{
    unsigned int outdata=0x01000001;
    GPIO_DATA_OUT=0;

    while(1)
    {
        while(outdata<0x80000080){
            GPIO_DATA_OUT=outdata;
            outdata = outdata<<1;
            delay(DELAY_TIME);
        }
        GPIO_DATA_OUT=outdata;
        delay(DELAY_TIME);
        outdata = outdata>>1;

        while(outdata>0x01000001){
            GPIO_DATA_OUT=outdata;
            outdata = outdata>>1;
            delay(DELAY_TIME);
        }
    }
    return 0;
}

void toggleLED (unsigned int LEDMask)
{
    GPIO_DATA_OUT ^= LEDMask;
}

void delay(unsigned int count)
{
    for(;count>0;count--);
}

```



```
21 while(1)
22 {
23     GPIO_DAT_PE = 0xFFFF;
24     delay1(1000000);
25     int i=0;
26     for(i=0;i<15;i++)
27         GPIO_DAT_PE = Data[i];
28         delay1(1000000);
29 }
30     GPIO_DAT_PE = 0xFFFF;
31     delay1(1000000);
32     int i=0;
33     for(i=0;i<15;i++)
34         GPIO_DAT_PE = Data[i]<<8+0xFF;
35         delay1(1000000);
36 return 0;
37 }
```



Q3


題號: 3

版本:1.0

考題類型	<input type="checkbox"/> Non-OS <input type="checkbox"/> Linux
實作平台	<input type="checkbox"/> ADP-XC5FF676 <input type="checkbox"/> ADPAG102-UP <input type="checkbox"/> ADP-WT95F064 <input checked="" type="checkbox"/> VEP (AndeSight™ STD v2.0)
環境設定	1. PC 主機：Host OS - Microsoft Windows XP。 2. Andes/AndeSight V2.0 Toolchains。
實作內容	在 AndeSight™整合開發環境，使用 VEP(Virtual Evaluation Platform) 功能，(1) 在 UART 傳送文字字串至終端機上顯示。(2)完整的呈現 Interrupt 步驟。 參考設定參數： Memory Map 在 URAT 的 “Base” 欄位輸入 “0x99600000”； “Size” 欄位輸入 “0x00000020”。
注意事項	1. 請將作答所產生之所有檔案儲存於資料夾 Q3\Ans 內。 2. 可依需要參考或使用 Q3\內各子資料夾預存之程式碼或資料。

- SWI_VEP
 - Binaries
 - Includes
 - bin
 - include
 - obj
 - src
 - exampleC.ld
 - Makefile
 - readme
 - script.ld
 - swi.vep
 - swi.vep.bak





Preferences

type filter text

GeneralC/C++HelpInstall/UpdateLicenseRemote SystemsRun/DebugTarget Management default settingServer settingTCF Agent ConfigurationsTeamTerminalVEP Editor

Target Management default setting

User Settings for Target Management.

All of the settings in this page are global to the entire workspace except for those in Target Chip section.

Target Manager Internal TCP Port Range

Start Port9900

End Port49151

☐ Enable Simulator Multiple Instances

☒ Enable AICE plug-in

☐ Disable Simulator/AICE consoles

Connection Type

☒ Simulator☐ AICE

ICEman Misc Arguments

Simulator Misc Arguments

Vep2Conf Misc Arguments

Target Chip

Name	Chip	CPU	Simulator Config
ADP-AG101P-16MB-N801-S	ADP-AG101P-16MB-N801-S	[N801-S]	ADP-XC5-for-N801-S-16M.vep
ADP-AG101P-4GB-N1033A-S	ADP-AG101P-4GB-N1033A-S	[N1033A-S]	ADP-XC5-for-N1033A-S.vep
ADP-AG101P-4GB-N1068A-S	ADP-AG101P-4GB-N1068A-S	[N1068A-S]	ADP-XC5-for-N1068A-S.vep
ADP-AG101P-4GB-N1233-FPU	ADP-AG101P-4GB-N1233F-S	[N1233-FPU]	ADP-XC5-for-N1233-FPU.vep
ADP-AG101P-4GB-N1337-FPU	ADP-AG101P-4GB-N1337-FPU	[N1337-FPU]	ADP-XC5-for-N1337-FPU.vep
ADP-AG101P-4GB-N903-S-32GPR	ADP-AG101P-4GB-N903-S-32GPR	[N903-S]	ADP-XC5-for-N903A-S.vep

Front-end Selection


Setup System Calls

Restore Defaults

Apply

?

OKCancel



C:\C++ - SWI_VEP\bin\swi - AndeSight Standard Version

File Edit Navigate Search Run Project Window Help

Project Explorer

SWI_VEP

Binaries

Includes

bin

swi - [Andes/le]

swi.bin

swi.map

swi.text

include

obj

src

inhandling.c

main.c

start.S

uartio.c

exampleC.ld

Makefile

readme

script.ld

swi.vep

Outline

Target Manag...

Targets

ADP-AG101P-16MB-N801-S

ADP-AG101P-4GB-N1033A-S

ADP-AG101P-4GB-N1068A-S

ADP-AG101P-4GB-N1233-FPU

ADP-AG101P-4GB-N1337-FPU

ADP-AG101P-4GB-N903-S-32GP

ADP-AG101P-4GB-N968A-S

VirtualMCU-N8

VirtualMCU-N9

Generic Targets

Running Target

ADP-AG101P-4GB-N1033A-S Gd

CFC

Uart

Uart2

LCDC

Uart3

GPIO

RTC

SDC

PWM

gloss

Andes Project Creator

main.c

swi

C:\Users\I5302\Desktop\Source code \Q3\SWI\bin\swi: file format elf32-nds32

C:\Users\I5302\Desktop\Source code \Q3\SWI\bin\swi

architecture: nih, flags 0x0000112:

EXEC_P, HAS_SYMS, D_PAGED

start address 0x0050014e

Program Header:

LOAD off 0x00001000 vaddr 0x00500000 paddr 0x00500000 align 2**12

filesz 0x000091dc memsz 0x0000920c flags rwx

private flags = 20006241: n1 instructions

Sections:

Idx	Name	Size	VMA	LMA	File off	Align
0	.text	00008518	00500000	00500000	00001000	2**4
	CONTENTS, ALLOC, LOAD, READONLY, CODE					
1	.rodata	00000390	00508518	00508518	00009518	2**3
	CONTENTS, ALLOC, LOAD, READONLY, DATA					
2	.rodata.str1.4	00000064	005088a8	005088a8	000098a8	2**2
	CONTENTS, ALLOC, LOAD, READONLY, DATA					
3	.data	00000870	00508910	00508910	00009910	2**3
	CONTENTS, ALLOC, LOAD, DATA					
4	.sdata_w	00000028	00509180	00509180	0000a180	2**2
	CONTENTS, ALLOC, LOAD, DATA					
5	.sdata_b	00000003	005091a8	005091a8	0000a1a8	2**0
	CONTENTS, ALLOC, LOAD, DATA					
6	.eh_frame	00000030	005091ac	005091ac	0000a1ac	2**2
	CONTENTS, ALLOC, LOAD, DATA					
7	.sbss_w	00000004	005091dc	005091dc	0000a1dc	2**2
	ALLOC					
8	.bss	0000002c	005091e0	005091e0	0000a1dc	2**2
	ALLOC					
9	.debug_pubnames	000000de	00000000	00000000	0000a1dc	2**0
	CONTENTS, READONLY, DEBUGGING					

Problems

Console

Properties

Uart3

Uart3: (CONNECTED)

Start to test Software interrupt

Generate a Software interrupt


hw-uart-atc010: Uart3

Uart3: (CONNECTED)

Start to test Software interrupt

Generate a Software interrupt

|




Project Explorer

- Chip Profile Editor
- SWI_VEP

swi.vep

cpu

Memory
























Outline Target Mana...


Targets

- Chip Profile Editor
 - ADP-AG101P-4GB-N1033A-S-01
 - ADP-XC5-for-N1033A-S.vep
 - AG101P-4GB.reg
 - AG101P-4GB-memory.mem
 - N1033A-S.crgs
 - TargetChip.atd


複製swi.vep到內建檔案

- ▲  Chip Profile Editor
 - ▲  ADP-AG101P-4GB-N1033A-S-01
 -  ADP-XC5-for-N1033A-S.vep
 -  AG101P-4GB.reg
 -  AG101P-4GB-memory.mem
 -  N1033A-S.crgs
 -  swi.vep
 -  TargetChip.atd
- ▲  SWI_VEP
 - ▷  Binaries
 - ▷  Includes
 - ▷  bin
 - ▷  include
 - ▷  obj
 - ▷  src
 -  exampleC.ld
 -  Makefile
 -  readme
 -  script.ld
 -  swi.vep
 -  swi.vep.bak

新增Uart與排線





Memory Map 在URAT的
"Base"欄位輸入"0x99600000"
"Size"欄位輸入"0x00000020"




Device Name	Base	Size (Byte)	Range
▲ AHB			
Memory	0x00000000	0x10000000	0x00000000 - 0xFFFFFFFF
▲ APB			
Uart	0x99600000	0x00000020	0x99600000 - 0x9960001F

點選TargetChip.atd







將更新後的目標版匯入



新增後即顯示於下



原SWI_VEP需設定新的目標





Setup System Calls



ADP-AG101P-4GB-N1033A-S-01

Name	Description	Append CPU Option
<input type="checkbox"/> VIOS	VIOS Mode	--config-default-exception-support 1 --environment user
<input checked="" type="checkbox"/> RAW	RAW Mode	--config-default-exception-support 0 --environment operating

VIOS mode:

Any OS or applications can safely assume the system call services and exception handlers will be handled by the Simulator.


RAW mode:













The Simulator won't handle system call services and exception handlers.
It is OS or applications' responsibility to implement the system call and exception handlers



OK

Cancel



-  ADP-AG101P-4GB-N1068A-S
-  ADP-AG101P-4GB-N1233-FPU
-  ADP-AG101P-4GB-N1337-FPU
-  ADP-AG101P-4GB-N903-S-32GPR
-  ADP-AG101P-4GB-N968A-S
-  VirtualMCU-N8
-  VirtualMCU-N9
-  WT59F064
- ▲  ADP-AG101P-4GB-N1033A-S-01
 - ▲  ADP-AG101P-4GB-N1033A-S-01 GdbServer:9902
 -  gloss
 -  Uart

```
Properties Console Uart x
Uart: (CONNECTED)

Start to test Software interrupt

Generate a Software interrupt

*****
* Enter software interrupt service routine *
*****

End of software interrupt testing
```


Q4

題號: 4

版本:1.0

考題類型	<input type="checkbox"/> Non-OS <input type="checkbox"/> Linux
實作平台	<input type="checkbox"/> ADP-XC5FF676 <input type="checkbox"/> ADPAG102-UP <input type="checkbox"/> ADP-WT95F064 <input checked="" type="checkbox"/> VEP (<u>AndeSight™</u> STD v2.0)
環境設定	1. PC 主機：Host OS - Microsoft Windows XP。 2. <u>Andes/AndeSight V2.0 Toolchains</u> 。
實作內容	<p>在 <u>AndeSight™</u>整合開發環境，使用 VEP(Virtual Evaluation Platform) 功能，(1) 在 LCD(LCDC)視窗有圖片顯示，設定屬性 Target Chip 使用 ADP-AG101-4GB-N1033-S。(2) 承上題，使用此 VEP 模擬包 AHB 上能有 Memory, CPU 與 LCDC 但不包括其它元件，實現顯示 JPEG 解碼器(decoder)。(3) 將 CPU N1033-S 改成 N1233-S，其 JPEG 結果一樣可以顯示。</p> <p>參考設定 AHB 參數：</p> <p>Memory Map 在 AHB 下 LCD 的 <u>"Base"</u> 欄位輸入 <u>"0x90600000"</u>， <u>"Size(Byte)"</u> 欄位輸入 <u>"0x00001000"</u>。</p>

Q4_(1)



Select archive containing the projects to import

電腦 > 本機磁碟 (C:) > Andestech > AndeSight200STD > demo

搜尋 demo

組合管理 新增資料夾

我的最愛

下載

桌面

最近的位置

媒體櫃

文件

音樂

視訊

圖片

電腦

本機磁碟 (C:)

本機磁碟 (D:)

BROWN BEAR (I

名稱	修改日期	類型	大小
startup	2019/2/25 上午 1...	檔案資料夾	
Dhrystone_XC5.tgz	2012/9/6 下午 06...	TGZ 檔案	18 KB
libgloss.tgz	2012/9/6 下午 06...	TGZ 檔案	5 KB
sharelib_ap.tgz	2012/9/6 下午 05...	TGZ 檔案	5 KB
STD_JPEG.tgz	2012/9/6 下午 06...	TGZ 檔案	706 KB
STD_MP3.tgz	2012/9/6 下午 06...	TGZ 檔案	387 KB

檔案名稱(N): STD_JPEG.tgz

.jar;.zip;*.tar;*.tar.gz;*.tgz

開啟舊檔(O)

取消

Import

Import Projects

Select a directory to search for existing Eclipse projects.

☐ Select root directory:

☒ Select archive file:

Projects:


☒ JPEG (JPEG)

☒ Copy projects into workspace

Working sets

☒ Add project to working sets

Working sets:



type filter text

- Resource
- Builders
- C/C++ Build
 - Build Variables
 - Discovery Options
 - Environment
 - Logging
 - Settings
 - Target Configuration**
 - Tool Chain Editor
- C/C++ General
- Project References
- Run/Debug Settings

Target Configuration

Configuration: Debug [Active]

Manage Configurations...

☒ Replace Project Default Target and Connection Type in project-specific.

Target Chip

ADP-AG101P-4GB-N903-S-32GPR

Browse...

Connection Type

☒ Simulator ☐ AICE

Clean and Rebuild Project

☐ Clean project

☒ Build project

Select Target

Select Target: [Current: ADP-AG101P-4GB-N903-S-32GPR]

Connection: Local

New...

rse://LOCALHOST/~target/ADP-AG101P-4GB-N1033A-S

Targets

- ADP-AG101P-16MB-N801-S
- ADP-AG101P-4GB-N1033A-S**
- ADP-AG101P-4GB-N1068A-S
- ADP-AG101P-4GB-N1233-FPU
- ADP-AG101P-4GB-N1337-FPU
- ADP-AG101P-4GB-N903-S-32GPR
- ADP-AG101P-4GB-N968A-S

Toolchain

☐ Select Toolchain: [Current: nds32le-elf-newlib-v2]

- nds32le-elf-mculib-v2
- nds32le-elf-mculib-v2j
- nds32le-elf-newlib-v2**
- nds32le-elf-newlib-v2i

☒ Change Target and Toolchain setting to all configurations

OK

Cancel

Create, manage, and run configurations



type filter text

- (DSF) C/C++ Applic
- JPEG Debug
- Launch Group



Filter matched 3 of 3 items

Name: JPEG Debug

Main Arguments Debugger Advanced Source Common

C/C++ Application:

Debug\JPEG.adx

Search Project...

Browse...

Project:

JPEG

Browse...
























Apply


Revert




Run

Close

- ▲  Targets
 -  ADP-AG101P-16MB-N801-S
 - ▷  ADP-AG101P-4GB-N1033A-S
 -  ADP-AG101P-4GB-N1068A-S
 -  ADP-AG101P-4GB-N1233-FPU
 -  ADP-AG101P-4GB-N1337-FPU
 -  ADP-AG101P-4GB-N903-S-32GPR
 -  ADP-AG101P-4GB-N968A-S
 -  VirtualMCU-N8
 -  VirtualMCU-N9
- ▷  Generic Targets
- ▲  Running Target
 - ▲  ADP-AG101P-4GB-N1033A-S GdbServer:9900
 -  CFC
 -  Uart
 -  Uart2
 -  LCDC
 -  Uart3
 -  GPIO
 -  RTC
 -  SDC
 -  PWM
 -  gloss



Q4_(2)



type filter text

- Resource
- Builders
- C/C++ Build
 - Build Variables
 - Discovery Options
 - Environment
 - Logging
 - Settings
 - Target Configuration**
 - Tool Chain Editor
- C/C++ General
- Project References
- Run/Debug Settings

Target Configuration

Configuration: Default [Active]

Manage Configurations...

☒ Replace Project Default Target and Connection Type in project-specific.

Target Chip

rse://LOCALHOST/~target/VEP-LCD-N10

Browse...

Cannot find the selected target chip.

Connection Type

☒ Simulator ☐ AICE

Clean and Rebuild Project

☐ Clean project

☒ Build project

Select Target

Select Target:

Connection: Local

New...

rse://LOCALHOST/~target/ADP-AG101P-4GB-N1033A-S

Targets

- ADP-AG101P-16MB-N801-S
- ADP-AG101P-4GB-N1033A-S**
- ADP-AG101P-4GB-N1068A-S
- ADP-AG101P-4GB-N1233-FPU
- ADP-AG101P-4GB-N1337-FPU
- ADP-AG101P-4GB-N903-S-32GPR
- ADP-AG101P-4GB-N968A-S

Toolchain

☒ Select Toolchain: [Current: nds.nds32le-elf-newlib-v2.base]

- nds32le-elf-mculib-v2
- nds32le-elf-mculib-v2j
- nds32le-elf-newlib-v2**
- nds32le-elf-newlib-v2i

☒ Change Target and Toolchain setting to all configurations

Restore Defaults

Apply

OK

Cancel


OK

Cancel

or Preferences

Console Properties

graph Default [(DSF) C/C++ Application] EX_LCD_V.adx



Andes Chip Profile Model

Andes Chip Profile Model

Select a Target Chip Template



Target Chip

Name	Chip	CPU	Simulator Config
ADP-AG101P-16MB-N801-S	ADP-AG101P-16MB-N801-S	[N801-S]	ADP-XC5-for-N801-S-16M.vep
ADP-AG101P-4GB-N1033A-S	ADP-AG101P-4GB-N1033A-S	[N1033A-S]	ADP-XC5-for-N1033A-S.vep
ADP-AG101P-4GB-N1068A-S	ADP-AG101P-4GB-N1068A-S	[N1068A-S]	ADP-XC5-for-N1068A-S.vep
ADP-AG101P-4GB-N1233-FPU	ADP-AG101P-4GB-N1233F-S	[N1233-FPU]	ADP-XC5-for-N1233-FPU.vep
ADP-AG101P-4GB-N1337-FPU	ADP-AG101P-4GB-N1337-FPU	[N1337-FPU]	ADP-XC5-for-N1337-FPU.vep
ADP-AG101P-4GB-N903-S-32GPR	ADP-AG101P-4GB-N903-S-32GPR	[N903-S]	ADP-XC5-for-N903A-S.vep
ADP-AG101P-4GB-N968A-S	ADP-AG101P-4GB-N968A-S	[N968A-S]	ADP-XC5-for-N968A-S.vep
VirtualMCU-N8	ADP-AG101P-16MB-N801-S	[N801-S]	VirtualMCU-N8.vep
VirtualMCU-N9	ADP-AG101P-4GB-N903-S-32GPR	[N903-S]	VirtualMCU-N9.vep



< Back

Next >

Finish

Cancel

Andes Chip Profile Model

Andes Chip Profile Model

Name the folder of the created Andes Chip Profile Model and specify its parent folder



Enter or select the parent folder:

graph



graph



JPEG

Chip Profile Name: ADP-AG101P-4GB-N1033A-S-01




< Back


Next >

Finish

Cancel




原本的



- ADP-AG101P-4GB-N1033A-S-01
 - ADP-XC5-for-N1033A-S.vep
 - AG101P-4GB.reg
 - AG101P-4GB-memory.mem
 - EX_LCD_V.vep
 - N1033A-S.crgs
 - TargetChip.atd

新增LCDC



Memory Map

[illegible]

Problems Memory Map IRQ Map Clock Setting Clock Domain System Call Emulation

Clock Domain	Clock Source	Scale
TARGET	target	1
HOST	host	1

add


Properties

Property


Problems Memory Map IRQ Map Clock Setting Clock Domain X

Clock Domain	Clock Source	Scale	
TARGET	target	1	
LCDC_clk	host	100	
HOST	host	1	


[illegible]



Properties	
Property	Value
Chip ID	ADP-AG101P-4GB-N1033A-S
ICEman Misc Args	
Linker Script File	
Memory Map File	AG101P-4GB-memory.mem
Preferred Toolchain	nds32le-elf-newlib-v2
Simulator Misc Args	
Soc Registers File	AG101P-4GB.reg
Vep File	ADP-XC5-for-N1033A-S.vep
Vep IO Filter	
Vep IO Mode	



Properties	
Property	Value
Chip ID	ADP-AG101P-4GB-N1033A-S
ICEman Misc Args	
Linker Script File	
Memory Map File	AG101P-4GB-memory.mem
Preferred Toolchain	nds32le-elf-newlib-v2
Simulator Misc Args	
Soc Registers File	AG101P-4GB.reg
Vep File	EX_LCD_V.vep
Vep IO Filter	
Vep IO Mode	



Targets

ADP-AG101P-16MB-N801-S

ADP-AG101P-4GB-N1033A-S

ADP-AG101P-4GB-N1068A-S

ADP-AG101P-4GB-N1233-FPU

ADP-AG101P-4GB-N1337-FPU

ADP-AG101P-4GB-N903-S-32GPR

ADP-AG101P-4GB-N968A-S

VirtualMCU-N8

VirtualMCU-N9

ADP-AG101P-4GB-N1033A-S-01

type filter text

- Resource
- Builders
- C/C++ Build
 - Build Variables
 - Discovery Options
 - Environment
 - Logging
 - Settings
 - Target Configuration
 - Tool Chain Editor
- C/C++ General
- Project References
- Run/Debug Settings

Target Configuration

Configuration: Default [Active]

☒ Replace Project Default Target and Connection Type in project-specific.

Target Chip

ADP-AG101P-4GB-N1033A-S

Browse...

Connection Type

☒ Simulator ☐ AICE

Clean and Rebuild Project

☐ Clean project

☒ Build project

剪取工具

在要擷取區域的四周拖曳游標。

Manage Configurations...

Select Target

Select Target: [Current: ADP-AG101P-4GB-N1033A-S]

Connection: Local

New...

rse://LOCALHOST/~target/ADP-AG101P-4GB-N1033A-S-01

- ADP-AG101P-4GB-N1337-FPU
- ADP-AG101P-4GB-N903-S-32GPR
- ADP-AG101P-4GB-N968A-S
- VirtualMCU-N8
- VirtualMCU-N9
- ADP-AG101P-4GB-N1033A-S-01

Generic Targets

Running Target

Toolchain

☒ Select Toolchain: [Current: nds.nds32le-elf-newlib-v2.base]

- nds32le-elf-mculib-v2
- nds32le-elf-mculib-v2j
- nds32le-elf-newlib-v2
- nds32le-elf-newlib-v2i

☒ Change Target and Toolchain setting to all configurations

Restore Defaults

Apply

OK

Cancel



Problems Memory Map IRQ Map Clock Setting

Not Available.

Properties

graph

Target

Resource

Properties

cpu0

mem0

Name

path

SoC n

Conn

OK

Cancel

Create, manage, and run configurations



type filter text

- ▲ (DSF) C/C++ Application
 - graph Default
 - graph Default (1)
 - graph Default (2)
 - graph Default (3)
 - JPEG Debug
- ▶ Launch Group

Filter matched 7 of 7 items

Name: graph Default (3)

Main Arguments Debugger Advanced Source Common

C/C++ Application:

EX_LCD_V.adx

Search Project...

Browse...

Project:

graph

Browse...



Apply

Revert




Run

Close



Q4_(3)_CPUN1233



重新安裝平台

