



# XM112 Module Software

## User Guide



XM112 Module Software

User Guide

Author: Acconeer AB

Version:a111-v2.12.0

Acconeer AB June 20, 2022



## Contents

<b>1</b>	<b>Introduction</b>	<b>4</b>
<b>2</b>	<b>Installing Software Image</b>	<b>5</b>
2.1	Install Tools . . . . .	5
2.2	Upgrade Procedure . . . . .	5
<b>3</b>	<b>Power Save</b>	<b>6</b>
3.1	MODULE_POWER_MODE . . . . .	6
3.2	SENSOR_POWER_MODE . . . . .	6
3.3	UPDATE_RATE . . . . .	6
3.4	REPETITION_MODE . . . . .	6
<b>4</b>	<b>Startup Timing</b>	<b>7</b>
<b>5</b>	<b>Physical Interfaces</b>	<b>8</b>
5.1	UART protocol . . . . .	8
5.1.1	UART settings . . . . .	8
5.1.2	Byte Order . . . . .	8
5.1.3	Payload length . . . . .	8
5.1.4	Register Read Request . . . . .	8
5.1.5	Register Read Response . . . . .	8
5.1.6	Register Write Request . . . . .	9
5.1.7	Register Write Response . . . . .	9
5.1.8	Buffer Read Request . . . . .	9
5.1.9	Buffer Read Response . . . . .	9
5.1.10	Buffer Streaming Payload . . . . .	9
5.1.11	Examples . . . . .	10
5.1.12	Read Status Register . . . . .	10
5.1.13	Write Mode . . . . .	10
5.1.14	Buffer Streaming Payload . . . . .	10
5.2	I <sup>2</sup> C protocol . . . . .	11
5.2.1	I <sup>2</sup> C Register Read Request . . . . .	11
5.2.2	I <sup>2</sup> C Register Write Request . . . . .	11
5.2.3	I <sup>2</sup> C Buffer Read Request . . . . .	11
5.2.4	I <sup>2</sup> C Register Read Request Example . . . . .	12
5.2.5	I <sup>2</sup> C Register Write Request Example . . . . .	12
5.3	SPI protocol . . . . .	13
5.3.1	SPI Register Read Request . . . . .	13
5.3.2	SPI Register Write Request . . . . .	13
5.3.3	Buffer Read Request . . . . .	13
5.3.4	SPI Timing . . . . .	13
<b>6</b>	<b>Register Map</b>	<b>14</b>
6.1	General Registers . . . . .	14
6.2	Power Bin Registers . . . . .	17
6.3	Envelope Registers . . . . .	19
6.4	IQ Registers . . . . .	21
6.5	Sparse Registers . . . . .	23
6.6	Distance Register . . . . .	25
6.7	Obstacle Register . . . . .	27
6.8	Presence Registers . . . . .	29
<b>7</b>	<b>Examples</b>	<b>31</b>
7.1	Python Example . . . . .	31
7.2	Reading Distances . . . . .	31
7.3	Reading Power Bin Data (UART Streaming) . . . . .	32
<b>8</b>	<b>Debug Logging Output</b>	<b>33</b>
<b>9</b>	<b>Minimum needed connections</b>	<b>34</b>



## 10 Disclaimer

35



## 1 Introduction

The module software enable register-based access to radar functionality from external devices connected to a module. The module software is delivered as an image.

Typical usages of the module software are:

- Integration of radar functionality in your product to decrease development cost and time to market.
- Module evaluation and algorithm development in Python together with the “Acconeer Python Exploration Tool” that is available for download on GitHub <https://github.com/acconeer/>.

The module software provides a rich register-based API that can be accessed over UART, SPI and I<sup>2</sup>C depending on module. The module software currently support the following services and detectors:

- Power Bins Service
- Envelope Service
- IQ Service
- Sparse Service
- Distance peak distance with fixed threshold
- Distance detector
- Obstacle detector
- Presence detector

Note that the performance and max range of the different detectors and services depends on the module that is being used as well as the configured settings like update rate and downsampling factor. Depending on use case the performance might not be good enough when using a low power module.

Support for more detectors is planned for future module software releases. A software image comprising the module software is available for download from Acconeer’s website. See “Installing Software Image” at page 5 for instruction on how to install the module software. For an introduction to Acconeer’s technology and product offer refer to “Introduction to Acconeer’s sensor technology”, available at the Acconeer website.



## 2 Installing Software Image

### 2.1 Install Tools

In order to update the software on the XM112 module we recommend using the BOSSA application. The application along with instructions are available at <http://www.shumatech.com/web/products/bossa>. The application is available for Linux, Windows and Apple Mac OS X.

### 2.2 Upgrade Procedure


The SAM E70 CPU have a ROM boot loader that is used during the software update. In order to enter this boot mode the internal flash must be erased with the following sequence:

1. Connect the XB112 together with XM112 to your PC with a micro USB cable to the “USB1/Power/UART0” connector
2. Press and hold the “ERASE” button on the board
3. Press the “NRST” button (still holding the “ERASE” button)
4. Release the “NRST” button
5. Release the “ERASE” button

The internal flash of the SAM E70 is now erased and the ROM boot code is executing.

Start the BOSSA application

1. Select correct port, e.g. “/dev/ttyUSB0” if running on Linux or “COM1” if running on Windows.
2. Press “Browse” and select the new firmware file
3. Make sure that “Erase all” and “Boot to flash” is selected
4. Press “Write”





### 3 Power Save

Related Physical pins:

Pin Name	Functionality	Description
MCU_GPIO, PA30	WAKE_UP	This pin is active high and is used to wake up the module.
MCU_INT, PC2	MCU_INT	This pin is active high. Also see “INTERRUPT_MODE” and “INTERRUPT_MASK” registers.

The power consumption of the module is mainly affected by three registers: `MODULE_POWER_MODE`, `SENSOR_POWER_MODE` and `UPDATE_RATE`.

The registers for `SENSOR_POWER_MODE`, `UPDATE_RATE` and `REPETITION_MODE` mostly corresponds to the configuration for respective service and detector in the software API, see the documents at [developer.acconeer.com](https://developer.acconeer.com).

#### 3.1 MODULE\_POWER\_MODE

This controls the modules power mode. 0x00 (default) means highest performance with lowest latency. This is suitable to use when a high and accurate update frequency is needed.

0x01 Means that the module still is responsive, but there might be some delays and the update rate is not as accurate. Before communicating with the module the `WAKE_UP` pin must be set to high level.

0x02 Means that the module is in low power mode. Any activated mode is kept activated, but the data is only updated when the `WAKE_UP` pin is set to high level. This mode is suitable when running lower frequency update rates where the `REPETITION_MODE` is set to 0x02 (on demand), `SENSOR_POWER_MODE` is set to OFF and `UPDATE_RATE` is set to 0. This enables the host controller to wakeup the module (e.g. once every minute) by raising the `WAKE_UP` pin and then clear the data and wait for the result.

#### 3.2 SENSOR\_POWER\_MODE

The values corresponds towards the different `ACC_POWER_SAVE_MODE` modes in the RSS API: OFF(0), SLEEP(1), READY(2), ACTIVE(3), HIBERNATE(4). See the Service User Guide for respective service for more information.

`ACC_POWER_SAVE_MODE_HIBERNATE` is not supported on xm112.

Not all modes support this register, see the documentation for respective detector or service.

#### 3.3 UPDATE\_RATE

This controls the update rate. A value of 0 together with `REPETITION_MODE` set to 0x02 (on demand) means that the data is served as fast as possible once the data ready bit in the status register have been cleared by writing 0x04 to the `MAIN_CONTROL` register.

Not all modes support this register, see the documentation for respective detector or service.

#### 3.4 REPETITION\_MODE

This controls if the sensor or the module controls the update rate.

Not all modes support this register, see the documentation for respective detector or service.



## 4 Startup Timing

After providing power to the module or after a reset there is a 200 ms delay before the software is ready to be used.

During this period no communication should be performed with the module.





## 5 Physical Interfaces

### 5.1 UART protocol

#### 5.1.1 UART settings

The baud rate can be adjusted by writing to the UART\_BAUDRATE register with the following sequence:

1. Write desired baudrate to the UART\_BAUDRATE register
2. Wait for the "Register Write Response" packet
3. Change to the new baudrate

Default baud rate	115200
Byte size	8-bit
Parity	None
Flow control	None

The maximum supported baud rate is 3 Mbps. This can also be read from the PRODUCT\_MAX\_UART\_BAUDRATE register.

Other baud rates are also supported, the actual used baud rate might differ slightly from the configured. The supported baud rates can be calculated as  $3000000 / N$  where N is an integer.

Example: The default baud rate is 115200. The actual used baud rate will be  $3000000 / 26 = 115385$ .

Common baud rates:

Configured baud rate	Actual baud rate
115200	115385
230400	230769
250000	250000
500000	500000
1000000	1000000
1500000	1500000
3000000	3000000

When using the XM112 together with XB112 the FT230XS is used between the host computer. FT230XS calculates its actual used baud rate as:

$$\text{Baud rate} = 3000000 / (N + x)$$

where 'N' can be any integer between 2 and 16,384 (= 2<sup>14</sup>) and 'x' can be a sub-integer of the value 0, 0.125, 0.25, 0.375, 0.5, 0.625, 0.75, or 0.875. When N = 1, x = 0, i.e. baud rate divisors with values between 1 and 2 are not possible.

#### 5.1.2 Byte Order

Multi byte integers are coded in little endian format.

#### 5.1.3 Payload length

The payload length below is the length of the packet excluding start marker, the payload length itself, packet type and end marker. It can be used to read a packet without knowing anything about the different packet types. Also see 5.1.11 for a couple of example UART packages.

#### 5.1.4 Register Read Request

Start marker	Payload length	Packet Type	Register Address	End Marker
0xCC	2 bytes	0xF8	1 byte	0xCD

#### 5.1.5 Register Read Response

Start marker	Payload length	Packet Type	Register address	Register value	End Marker
0xCC	2 bytes	0xF6	1 byte	4 bytes	0xCD



### 5.1.6 Register Write Request

Start marker	Payload length	Packet Type	Register address	Register value	End Marker
0xCC	2 bytes	0xF9	1 byte	4 bytes	0xCD

### 5.1.7 Register Write Response

Start marker	Payload length	Packet Type	Register address	Register value	End Marker
0xCC	2 bytes	0xF5	1 byte	4 bytes	0xCD

### 5.1.8 Buffer Read Request

Start marker	Payload length	Packet Type	Buffer index	Buffer offset	End Marker
0xCC	2 bytes	0xFA	0xE8	2 bytes	0xCD

### 5.1.9 Buffer Read Response

Start marker	Payload length	Packet Type	Buffer index	Buffer data	End Marker
0xCC	2 bytes	0xF7	0xE8		0xCD

### 5.1.10 Buffer Streaming Payload

The streaming mode is primarily intended for communication with the Acconeer Python exploration package that is available on GitHub. The format of the steaming payload may be updated in a non-backward compatible way in future versions of the module software.

Start marker	Payload length	Packet Type	Streaming payload	End Marker
0xCC	2 bytes	0xFE		0xCD

The streaming payload consists of:

Result info marker	Result info length	Result info	Buffer marker	Buffer length	Buffer
0xFD	2 bytes		0xFE	2 bytes	

The result info and the streaming buffer are the outputs from the Acconeer Service APIs encoded in little endian format.

The result info is a list of register (1 byte) and its value (4 bytes). The number of items in result info depends on the current mode. The list is terminated with 0xFE. More data may be added in future versions of the module software.

The format of the streaming buffer depends on the service.

Note that a streaming packet is sent asynchronous which means that the client must be able to handle that a streaming packet is received when e.g. a “Register Write Request” is sent but the “Register Write Response” has not yet been received.



Service	Streaming buffer format	
Power Bin	Array of 32-bit floats	
Envelope	Array of 16-bit unsigned integers	
IQ	Array of complex int16 (2 x 16bits). Can also be interpreted as an array of int16 where the real and imaginary parts of the complex numbers are interleaved.	
Presence	Offset	Description
	0	0: No presence detected 1: Presence detected
	1..4	Score (float)
	5..8	Distance (float)
Distance	For each detected object:	Offset (N*6)..(N*6+1) (N*6+2)..(N*6+5)
		Description Amplitude (uint16) Distance (float)
Obstacle	For each detected obstacle:	Offset (N*12)..(N*12+3) (N*12+4)..(N*12+7) (N*12+8)..(N*12+11)
		Description Radial velocity (float)
		Distance (float)
		Amplitude (float)

### 5.1.11 Examples

#### 5.1.12 Read Status Register

0xCC	0x01	0x00	0xF8	0x06	0xCD
------	------	------	------	------	------

#### 5.1.13 Write Mode

0xCC	0x05	0x00	0xF9	0x02	0x02	0x00	0x00	0x00	0xCD
------	------	------	------	------	------	------	------	------	------

#### 5.1.14 Buffer Streaming Payload

Index	Data	Description
0	0xCC	Start marker
1...2	0x3E 0x10	Payload length = 0x103E = 4158 bytes
3	0xFE	Packet type (Buffer streaming payload)
4	0xFD	Result info marker
5...6	0x14 0x00	Result info length = 0x0014 = 20 bytes
7	0xA1	Register 0xA1 (MISSED_DATA)
8...11	0x00 0x00 0x00 0x00	MISSED_DATA Value = 0x0000 0000 (No missed data)
12	0xA0	Register 0xA0 (DATA_SATURATED)
13...16	0x00 0x00 0x00 0x00	DATA_SATURATED Value = 0x0000 0000 (Data not saturated)
17	0xA3	Register 0xA3 (DATA_QUALITY_WARNING)
18...21	0x00 0x00 0x00 0x00	DATA_QUALITY_WARNING Value (No data quality warning)
22	0xA4	Register 0xA4 (SENSOR_COMM_ERROR)
23...26	0x00 0x00 0x00 0x00	SENSOR_COMM_ERROR Value (No comm error)
27	0xFE	Buffer marker
28...29	0x24 0x10	Buffer length = 0x1024 = 4132 Bytes
30...31	0xF4 0x00	Envelope data index 0 = 0x00F4
32...33	0xFA 0x00	Envelope data index 1 = 0x00FA
34...35	0x00 0x01	Envelope data index 2 = 0x0100
35...4124	...	Envelope data index 3...2065
4125	0xCD	End marker



## 5.2 I<sup>2</sup>C protocol

The module server supports communicating using I<sup>2</sup>C. Note that it is required that the host supports "clock stretching".

The I<sup>2</sup>C address is 0x52.

### 5.2.1 I<sup>2</sup>C Register Read Request

In order to read a register an I<sup>2</sup>C write transaction should first be performed:

Packet Type	Register Address
0xF8	1 byte

After this the register value can be read with an I<sup>2</sup>C read transaction:

Register Value
4 bytes

### 5.2.2 I<sup>2</sup>C Register Write Request

Register write can be performed in one transaction:

Packet Type	Register Address	Register Value
0xF9	1 byte	4 bytes

### 5.2.3 I<sup>2</sup>C Buffer Read Request

In order to read the buffer content an I<sup>2</sup>C write transaction should first be performed:


Packet Type	Buffer Index	Buffer Offset
0xFA	0xE8	2 bytes

After this the buffer can be read with an I<sup>2</sup>C read transaction:

Buffer Data
-------------


### 5.2.4 I<sup>2</sup>C Register Read Request Example

The following image shows an example when reading register 0x20 (RANGE\_START). The returned register value in this example is 0xC8 (=200) mm.



### 5.2.5 I<sup>2</sup>C Register Write Request Example

The following image shows an example when writing 1000 (0x03E8) to register 0x20 (RANGE\_START).





### 5.3 SPI protocol

#### 5.3.1 SPI Register Read Request

Packet type	Register address	Dummy bytes	Toggle SS, wait 50 $\mu$ s	Register value
MOSI 0xF8	MOSI 1 bytes	2 bytes		MISO 4 bytes

#### 5.3.2 SPI Register Write Request


Packet type	Register address	Dummy bytes	Toggle SS, wait 50 $\mu$ s	Register value
MOSI 0xF9	MOSI 1 bytes	2 bytes		MOSI 4 bytes

#### 5.3.3 Buffer Read Request

Packet type	Register address	Dummy bytes	Toggle SS, wait 50 $\mu$ s	Register value
MOSI 0xF8	MOSI 0xE8	2 bytes		MISO

#### 5.3.4 SPI Timing

A 50  $\mu$ s delay must be inserted between the SPI command and data.





## 6 Register Map

### 6.1 General Registers

Addr	Read/ Write	Register Name	Function
0x02	R/W	MODE_SELECTION	Selects one of the supported sensor or service mode for the module.
			0x01: Power bins service mode.
			0x02: Envelope service mode.
			0x03: IQ service mode.
			0x04: Sparse service mode.
			0x200: Distance detector mode.
			0x300: Obstacle detector mode.
			0x400: Presence detector mode.
0x03	W	MAIN_CONTROL	Main Control Register. This register is used to control the operation of the module.
			0x00: Stop any started service or detector.
			Create the current service or detector.
			0x01: Sets the 'error_creation' status bit in case of error.
			Activate the current service or detector.
			0x02: Sets the 'error_activation' status bit in case of failure.
			Create and activate the current service or detector.
			0x03:
			0x04: Clears any status bits in the status register.
0x05	R/W	STREAMING_CONTROL	Controls the streaming functionality.
			0x00: Disables UART data streaming.
			0x01: Enables UART data streaming.

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0x06	R	STATUS	<p>Module Status Register. This register is a bit mask with current status of the module.</p> <p>0x00000000: No bits set.</p> <p>0x000000FF: Bits that can't be cleared with the clear status command.</p> <p>0xFFFFFFF0: Mask with bits that can be cleared.</p> <p>0xFFFF0000: Mask with error bits.</p> <p>0x00000001: Service or detector is created.</p> <p>0x00000002: Service or detector is activated.</p> <p>0x00000100: Data is ready to be read from the buffer.</p> <p>0x00010000: An error occurred in the module.</p> <p>0x00020000: Invalid command or parameter received.</p> <p>0x00040000: Invalid mode</p> <p>0x00080000: Error creating the requested service or detector.</p> <p>0x00100000: Error activating the requested service or detector.</p> <p>0x00200000: An attempt to write a register or read the buffer when the module is in wrong state.</p>
0x07	R/W	UART_BAUDRATE	<p>Controls the baudrate for the UART interface. Read the product_max_uart_baudrate register to get the maximum supported baudrate.</p> <p>0x1C200: Default baudrate for the module.</p>
0x08	R/W	INTERRUPT_MASK	<p>Mask for interrupts. Interrupt is active when corresponding bit in the status register is set. The interrupt is inactive when the bit is cleared. Also see interrupt_mode register.</p> <p>0x00000000: No interrupts.</p> <p>0x00000001: Interrupt when service or detector is created.</p> <p>0x00000002: Interrupt when service or detector is activated.</p> <p>0x00000100: Interrupt on data ready.</p> <p>0x00010000: Interrupt on error.</p> <p>0x00020000: Interrupt on invalid command.</p> <p>0x00040000: Interrupt on invalid mode.</p> <p>0x00080000: Interrupt on error creating service or detector.</p> <p>0x00100000: Error activating the requested service or detector.</p> <p>0x00200000: An attempt to write a register or read the buffer when the module is in wrong state.</p>

continued ...





...continued

Addr	Read/ Write	Register Name	Function
0x09	R/W	INTERRUPT_MODE	Set mode for interrupt 0x00: Interrupt disabled, MCU_INT pin is always inactive. 0x01: MCU_INT is active when interrupt is active.
0x0A	R/W	MODULE_POWER_MODE	Module power configuration. This register is hardware specific and described in the "Power Save" chapter.
0x10	R	PRODUCT_IDENTIFICATION	Module Identification register. 0xACC0: The module is a XM112. 0xACC1: The module is a XM122. 0xACC2: The module is a XM132. 0xACC3: The module is a XM131. 0xACC5: The module is a XM124. 0xACC6: The module is a XM123.
0x11	R	PRODUCT_VERSION	Software product version register as 0xMMIIPP where MM is major, II is minor and PP is patch version.
0x12	R	PRODUCT_MAX_UART_BAUDRATE	The maximum UART baudrate supported by the module.
0xE9	R	OUTPUT_BUFFER_LENGTH	Length of data in output buffer.



## 6.2 Power Bin Registers

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/ Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x22	R/W	REPETITION_MODE	Repetition mode for the measurement.

0x01: The sensor controls the update rate with high precision according to the value in the update\_rate register.

0x02: The update rate is software limited according to the value in the update\_rate register. A value of 0 means no limit of the update rate.

0x23	R/W	UPDATE_RATE	The measurement update rate in mHz (i.e. step in 1/1000Hz). See the repetition_mode register for more information.
0x24	R/W	GAIN	Receiver gain, 0-1000 where 0 is the lowest gain and 1000 the highest.
0x25	R/W	SENSOR_POWER_MODE	Radar sensor power mode. See the Service User Guide for respective service for more information.

0x00: Sensor off power mode. Whole sensor is shutdown between sweeps, consumes least power, supports lower frequencies.

0x01: Sensor sleep power mode.

0x02: Sensor ready power mode.

0x03: Sensor active power mode. Whole sensor is active. Consumes most power, supports higher frequencies.

0x04: Sensor hibernate power mode. Sensor is still powered but the internal oscillator is turned off and the application needs to clock the sensor by toggling a GPIO a pre-defined number of times to enter and exit this mode. Only supported for the sparse service on XM122, XM123, XM124, XM131 and XM132 currently.

0x26	R/W	TX_DISABLE	Used to measure RX noise floor and to support TX off spectrum regulation measurements.
0x28	R/W	PROFILE_SELECTION	Each profile consists of a number of settings for the sensor that configures the RX and TX paths.

0x01: Profile 1 maximizes on the depth resolution

0x02: Sliding scale between profile 1 and 5.

0x03: Sliding scale between profile 1 and 5.

0x04: Sliding scale between profile 1 and 5.

0x05: Profile 5 maximizes on radar loop gain with a sliding scale in between.

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0x29	R/W	DOWNSAMPLING_FACTOR	Downsampling factor to be used in sensor.
0x30	R/W	HW_ACC_AVERAGE_SAMPLES	The number of hardware accelerated averaged samples for each data point.
0x31	R/W	NOISE_LEVEL_NORMALIZATION	Noise level normalization scale the signal according to the sensor noise level, default enabled.
0x32	R/W	MAXIMIZE_SIGNAL_ATTENUATION	Maximize signal attenuation to avoid saturation in direct leakage.
0x33	R/W	ASYNCHRONOUS_MEASUREMENT	Used to enable/disable asynchronous mode.
0x34	R/W	MUR	The maximum unambiguous range.

0x06: Maximum unambiguous range 11.5 m,  
maximum measurable distance 7.0 m

0x09: Maximum unambiguous range 17.3 m,  
maximum measurable distance 12.7 m

0x40	R/W	REQ_BIN_COUNT	Number of requested power bins
0x81	R	START	Start of the sweep in mm.
0x82	R	LENGTH	Length of the sweep in mm.
0x83	R	BIN_COUNT	Bin count.
0x84	R	STITCH_COUNT	Sweep has got stitch_count number of stitches.
0x85	R	STEP_LENGTH	Distance in um between adjacent data points.
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA1	R	MISSED_DATA	True if data was lost. Try lowering the update_rate or read the data more often.
0xA3	R	DATA_QUALITY_WARNING	True if bad data quality. May be addressed by restarting the current service or detector.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.



### 6.3 Envelope Registers

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x22	R/W	REPETITION_MODE	Repetition mode for the measurement.

0x01: The sensor controls the update rate with high precision according to the value in the update\_rate register.

0x02: The update rate is software limited according to the value in the update\_rate register. A value of 0 means no limit of the update rate.

0x23	R/W	UPDATE_RATE	The measurement update rate in mHz (i.e. step in 1/1000Hz). See the repetition_mode register for more information.
0x24	R/W	GAIN	Receiver gain, 0-1000 where 0 is the lowest gain and 1000 the highest.
0x25	R/W	SENSOR_POWER_MODE	Radar sensor power mode. See the Service User Guide for respective service for more information.

0x00: Sensor off power mode. Whole sensor is shutdown between sweeps, consumes least power, supports lower frequencies.

0x01: Sensor sleep power mode.

0x02: Sensor ready power mode.

0x03: Sensor active power mode. Whole sensor is active. Consumes most power, supports higher frequencies.

0x04: Sensor hibernate power mode. Sensor is still powered but the internal oscillator is turned off and the application needs to clock the sensor by toggling a GPIO a pre-defined number of times to enter and exit this mode. Only supported for the sparse service on XM122, XM123, XM124, XM131 and XM132 currently.

0x26	R/W	TX_DISABLE	Used to measure RX noise floor and to support TX off spectrum regulation measurements.
0x28	R/W	PROFILE_SELECTION	Each profile consists of a number of settings for the sensor that configures the RX and TX paths.

0x01: Profile 1 maximizes on the depth resolution

0x02: Sliding scale between profile 1 and 5.

0x03: Sliding scale between profile 1 and 5.

0x04: Sliding scale between profile 1 and 5.

0x05: Profile 5 maximizes on radar loop gain with a sliding scale in between.

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0x29	R/W	DOWNSAMPLING_FACTOR	Downsampling factor to be used in sensor.
0x30	R/W	HW_ACC_AVERAGE_SAMPLES	The number of hardware accelerated averaged samples for each data point.
0x31	R/W	NOISE_LEVEL_NORMALIZATION	Noise level normalization scale the signal according to the sensor noise level, default enabled.
0x32	R/W	MAXIMIZE_SIGNAL_ATTENUATION	Maximize signal attenuation to avoid saturation in direct leakage.
0x33	R/W	ASYNCHRONOUS_MEASUREMENT	Used to enable/disable asynchronous mode.
0x34	R/W	MUR	The maximum unambiguous range.

0x06: Maximum unambiguous range 11.5 m,  
maximum measurable distance 7.0 m

0x09: Maximum unambiguous range 17.3 m,  
maximum measurable distance 12.7 m

0x40	R/W	RUN_FACTOR	The running average factor is the factor of which the most recent sweep is weighed against previous sweeps. Value between 0 and 1000 where 0 means that no history is weighed in, i.e filtering is effectively disabled.
0x81	R	START	Start of the sweep in mm.
0x82	R	LENGTH	Length of the sweep in mm.
0x83	R	DATA_LENGTH	Length of the envelope data.
0x84	R	STITCH_COUNT	Sweep has got stitch_count number of stitches.
0x85	R	STEP_LENGTH	Distance in um between adjacent data points.
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA1	R	MISSED_DATA	True if data was lost. Try lowering the update_rate or read the data more often.
0xA3	R	DATA_QUALITY_WARNING	True if bad data quality. May be addressed by restarting the current service or detector.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.



## 6.4 IQ Registers

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x22	R/W	REPETITION_MODE	Repetition mode for the measurement.

0x01: The sensor controls the update rate with high precision according to the value in the update\_rate register.

0x02: The update rate is software limited according to the value in the update\_rate register. A value of 0 means no limit of the update rate.

0x23	R/W	UPDATE_RATE	The measurement update rate in mHz (i.e. step in 1/1000Hz). See the repetition_mode register for more information.
0x24	R/W	GAIN	Receiver gain, 0-1000 where 0 is the lowest gain and 1000 the highest.
0x25	R/W	SENSOR_POWER_MODE	Radar sensor power mode. See the Service User Guide for respective service for more information.

0x00: Sensor off power mode. Whole sensor is shutdown between sweeps, consumes least power, supports lower frequencies.

0x01: Sensor sleep power mode.

0x02: Sensor ready power mode.

0x03: Sensor active power mode. Whole sensor is active. Consumes most power, supports higher frequencies.

0x04: Sensor hibernate power mode. Sensor is still powered but the internal oscillator is turned off and the application needs to clock the sensor by toggling a GPIO a pre-defined number of times to enter and exit this mode. Only supported for the sparse service on XM122, XM123, XM124, XM131 and XM132 currently.

0x26	R/W	TX_DISABLE	Used to measure RX noise floor and to support TX off spectrum regulation measurements.
0x28	R/W	PROFILE_SELECTION	Each profile consists of a number of settings for the sensor that configures the RX and TX paths.

0x01: Profile 1 maximizes on the depth resolution

0x02: Sliding scale between profile 1 and 5.

0x03: Sliding scale between profile 1 and 5.

0x04: Sliding scale between profile 1 and 5.

0x05: Profile 5 maximizes on radar loop gain with a sliding scale in between.

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0x29	R/W	DOWNSAMPLING_FACTOR	Downsampling factor to be used in sensor.
0x30	R/W	HW_ACC_AVERAGE_SAMPLES	The number of hardware accelerated averaged samples for each data point.
0x31	R/W	NOISE_LEVEL_NORMALIZATION	Noise level normalization scale the signal according to the sensor noise level, default enabled.
0x32	R/W	MAXIMIZE_SIGNAL_ATTENUATION	Maximize signal attenuation to avoid saturation in direct leakage.
0x33	R/W	ASYNCHRONOUS_MEASUREMENT	Used to enable/disable asynchronous mode.
0x41	R/W	DEPTH_LPF_RATIO_OVERRIDE	If not 0, the depth lowpass cutoff ratio will be overridden with the value set in depth_lpf_ratio_value
0x42	R/W	DEPTH_LPF_RATIO_VALUE	If iq_depth_lpf_ratio_override is not 0, the depth lowpass cutoff ratio will be overridden with this value divided by 1000000
0x43	R/W	PROXIMITY_POWER	True to enable a power bin with information close to the sensor
0x81	R	START	Start of the sweep in mm.
0x82	R	LENGTH	Length of the sweep in mm.
0x83	R	DATA_LENGTH	Length of the IQ data.
0x84	R	STITCH_COUNT	Sweep has got stitch_count number of stitches.
0x85	R	STEP_LENGTH	Distance in um between adjacent data points.
0x86	R	DEPTH_LPF_RATIO_USED	The used depth lowpass cutoff ratio multiplied by 1000000
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA1	R	MISSED_DATA	True if data was lost. Try lowering the update_rate or read the data more often.
0xA2	R	PROXIMITY_POWER	Power bin with information close to the sensor. Require proximity power to be enabled.
0xA3	R	DATA_QUALITY_WARNING	True if bad data quality. May be addressed by restarting the current service or detector.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.



## 6.5 Sparse Registers

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/ Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x22	R/W	REPETITION_MODE	Repetition mode for the measurement.

0x01: The sensor controls the update rate with high precision according to the value in the update\_rate register.

0x02: The update rate is software limited according to the value in the update\_rate register. A value of 0 means no limit of the update rate.

0x23	R/W	UPDATE_RATE	The measurement update rate in mHz (i.e. step in 1/1000Hz). See the repetition_mode register for more information.
0x24	R/W	GAIN	Receiver gain, 0-1000 where 0 is the lowest gain and 1000 the highest.
0x25	R/W	SENSOR_POWER_MODE	Radar sensor power mode. See the Service User Guide for respective service for more information.

0x00: Sensor off power mode. Whole sensor is shutdown between sweeps, consumes least power, supports lower frequencies.

0x01: Sensor sleep power mode.

0x02: Sensor ready power mode.

0x03: Sensor active power mode. Whole sensor is active. Consumes most power, supports higher frequencies.

0x04: Sensor hibernate power mode. Sensor is still powered but the internal oscillator is turned off and the application needs to clock the sensor by toggling a GPIO a pre-defined number of times to enter and exit this mode. Only supported for the sparse service on XM122, XM123, XM124, XM131 and XM132 currently.

0x26	R/W	TX_DISABLE	Used to measure RX noise floor and to support TX off spectrum regulation measurements.
0x28	R/W	PROFILE_SELECTION	Each profile consists of a number of settings for the sensor that configures the RX and TX paths.

0x01: Profile 1 maximizes on the depth resolution

0x02: Sliding scale between profile 1 and 5.

0x03: Sliding scale between profile 1 and 5.

0x04: Sliding scale between profile 1 and 5.

0x05: Profile 5 maximizes on radar loop gain with a sliding scale in between.

continued ...





...continued

Addr	Read/ Write	Register Name	Function
0x29	R/W	DOWNSAMPLING_FACTOR	Downsampling factor to be used in sensor.
0x30	R/W	HW_ACC_AVERAGE_SAMPLES	The number of hardware accelerated averaged samples for each data point.
0x32	R/W	MAXIMIZE_SIGNAL_ATTENUATION	Maximize signal attenuation to avoid saturation in direct leakage.
0x33	R/W	ASYNCHRONOUS_MEASUREMENT	Used to enable/disable asynchronous mode.
0x34	R/W	MUR	The maximum unambiguous range.

0x06:	Maximum unambiguous range 11.5 m, maximum measurable distance 7.0 m
-------	--

0x09:	Maximum unambiguous range 17.3 m, maximum measurable distance 12.7 m
-------	---

0x40	R/W	SPARSE_SWEEPS_PER_FRAME	The number of sweeps per frame.
0x41	R/W	SPARSE_REQ_SWEEP_RATE	The sweep rate in mHz. Set to 0 for maximum possible.
0x42	R/W	SPARSE_SAMPLING_MODE	Sampling mode

0x00:	A
-------	---

0x01:	B
-------	---

0x81	R	START	Start of the sweep in mm.
0x82	R	LENGTH	Length of the sweep in mm.
0x83	R	DATA_LENGTH	Length of the sparse data.
0x84	R	SWEEP_RATE	Sweep rate in mHz.
0x85	R	STEP_LENGTH	Distance in um between adjacent data points.
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA1	R	MISSED_DATA	True if data was lost. Try lowering the update_rate or read the data more often.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.



## 6.6 Distance Register

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/ Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x24	R/W	GAIN	Receiver gain, 0-1000 where 0 is the lowest gain and 1000 the highest.
0x25	R/W	SENSOR_POWER_MODE	Radar sensor power mode. See the Service User Guide for respective service for more information.

0x00: Sensor off power mode. Whole sensor is shutdown between sweeps, consumes least power, supports lower frequencies.

0x01: Sensor sleep power mode.

0x02: Sensor ready power mode.

0x03: Sensor active power mode. Whole sensor is active. Consumes most power, supports higher frequencies.

0x04: Sensor hibernate power mode. Sensor is still powered but the internal oscillator is turned off and the application needs to clock the sensor by toggling a GPIO a pre-defined number of times to enter and exit this mode. Only supported for the sparse service on XM122, XM123, XM124, XM131 and XM132 currently.

0x28	R/W	PROFILE_SELECTION	Each profile consists of a number of settings for the sensor that configures the RX and TX paths.
------	-----	-------------------	---

0x01: Profile 1 maximizes on the depth resolution

0x02: Sliding scale between profile 1 and 5.

0x03: Sliding scale between profile 1 and 5.

0x04: Sliding scale between profile 1 and 5.

0x05: Profile 5 maximizes on radar loop gain with a sliding scale in between.

0x29	R/W	DOWNSAMPLING_FACTOR	Downsampling factor to be used in sensor.
0x30	R/W	HW_ACC_AVERAGE_SAMPLES	The number of hardware accelerated averaged samples for each data point.
0x32	R/W	MAXIMIZE_SIGNAL_ATTENUATION	Maximize signal attenuation to avoid saturation in direct leakage.
0x33	R/W	ASYNCHRONOUS_MEASUREMENT	Used to enable/disable asynchronous mode.
0x34	R/W	MUR	The maximum unambiguous range.

0x06: Maximum unambiguous range 11.5 m, maximum measurable distance 7.0 m

0x09: Maximum unambiguous range 17.3 m, maximum measurable distance 12.7 m

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0x40	R/W	SWEEP_AVG	Number of sweeps to use for sweep averaging, where 1 means no averaging.
0x41	R/W	THRESHOLD	Threshold type used when finding peaks in sensor data. 0x00: Fixed threshold. 0x02: CFAR threshold.

0x42	R/W	FIXED.THRESHOLD	Value of fixed threshold. Only used if fixed threshold type is selected.
0x44	R/W	SENSITIVITY	Set sensitivity of threshold. Value between 0 and 1000. Only used if cfar threshold type is selected.
0x45	R/W	CFAR_GUARD	Range in mm around the distance of interest that is omitted when calculating CFAR threshold. Only used if cfar threshold type is selected.
0x46	R/W	CFAR_WINDOW	Range in mm next to the CFAR guard from which the threshold level will be calculated. Only used if cfar threshold type is selected.
0x47	R/W	ONLY_LOWER	Instead of determining the CFAR threshold from sweep amplitudes from distances both closer and father away, use only closer. Only used if cfar threshold type is selected.
0x48	R/W	PEAK_SORTING	Peak sorting algorithm specifies in what order peaks should be reported back to the application. 0x00: Sort peaks in order closest first. 0x01: Sort peaks in order strongest first. 0x02: Sort peaks in order strongest reflector first. 0x03: Sort peaks in order strongest flat reflector first.

0x81	R	START	Start of the sweep in mm.
0x82	R	LENGTH	Length of the sweep in mm.
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA1	R	MISSED_DATA	True if data was lost. Try lowering the update_rate or read the data more often.
0xA3	R	DATA_QUALITY_WARNING	True if bad data quality. May be addressed by restarting the current service or detector.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.
0xB0	R	COUNT	Number of detected peaks.
0xB1	R	1_DISTANCE	Distance in mm to first peak.
0xB2	R	1_AMPLITUDE	Amplitude of first peak.
0xB3	R	2_DISTANCE	Distance in mm to second peak.
0xB4	R	2_AMPLITUDE	Amplitude of second peak.
0xB5	R	3_DISTANCE	Distance in mm to third peak.
0xB6	R	3_AMPLITUDE	Amplitude of third peak.
0xB7	R	4_DISTANCE	Distance in mm to fourth peak.
0xB8	R	4_AMPLITUDE	Amplitude of fourth peak.



## 6.7 Obstacle Register

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/ Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x40	R/W	MAX_SPEED	Maximum speed in mm/s
0x41	R/W	ALLOW_REVERSE	Enable measurements of angle for objects moving away from sensor.

0x00: No reverse, allows higher speed at lower sweep frequency.

0x01: Enable to measure angle of objects moving away from sensor.

0x42	R/W	SPEED_HIGHPASS_MASK	The mask transition value as radial speed in mm per second.
0x43	R/W	RANGE_END_OVERSCAN	The range end overscan in mm.
0x44	R/W	BACK_EST_ITER	Number of background estimation iterations.
0x45	R/W	SWEEP_DOWNSAMPLE	A high downsample value will result in less memory usage at resolution cost.
0x46	R/W	DISTANCE_OFFSET	This offset in mm is subtracted from the reported distance for every obstacle.
0x47	R/W	EDGE_TO_PEAK_RATIO	edge to peak ratio in 1/1000 units.
0x48	R/W	PROXIMITY_DETECTION	Enable proximity detection
0x4B	R/W	THR_STATIONARY	The amplitude threshold for stationary objects close to the sensor.
0x4C	R/W	THR_MOVING	The amplitude threshold for moving objects and objects far from the sensor.
0x4D	R/W	THR_DIST_LIMIT_FAR	For distances larger than the far limit, use the moving threshold.
0x4E	R/W	THR_CLOSE_ADDITION	The amplitude increase at closest distance, applied for all velocities.
0x4F	R/W	THR_DIST_LIMIT_NEAR	close threshold is applied from first distance in the range and linearly falls off to close limit.
0x81	R	UPDATE_RATE	The calculated update rate in mHz for the obstacle detector.
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA1	R	MISSED_DATA	True if data was lost. Try lowering the update_rate or read the data more often.
0xA2	R	PROXIMITY_DETECTION	True if object is detected close to the sensor. Require proximity detection to be enabled.
0xA3	R	DATA_QUALITY_WARNING	True if bad data quality. May be addressed by restarting the current service or detector.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.
0xB0	R	COUNT	Number of obstacles.
0xB1	R	1_RADIAL_VELOCITY	Radial velocity to first obstacle in mm / s
0xB2	R	1_DISTANCE	Distance in mm to first obstacle
0xB3	R	1_AMPLITUDE	Amplitude of first obstacle
0xB4	R	2_RADIAL_VELOCITY	Radial velocity to second obstacle
0xB5	R	2_DISTANCE	Distance to second obstacle
0xB6	R	2_AMPLITUDE	Amplitude of second obstacle
0xB7	R	3_RADIAL_VELOCITY	Radial velocity to third obstacle

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0xB8	R	3_DISTANCE	Distance to third obstacle
0xB9	R	3_AMPLITUDE	Amplitude of third obstacle



## 6.8 Presence Registers

Registers which are writable can be used to set a configuration. Registers which are read only contain metadata which is updated either after create or when data is produced. It is recommended to read the the service and detector user guides for more information on configuration and metadata.

Addr	Read/Write	Register Name	Function
0x20	R/W	RANGE_START	Start range in mm of the measurement.
0x21	R/W	RANGE_LENGTH	Length of the range in mm.
0x23	R/W	UPDATE_RATE	The measurement update rate in mHz (i.e. step in 1/1000Hz). See the repetition_mode register for more information.
0x24	R/W	GAIN	Receiver gain, 0-1000 where 0 is the lowest gain and 1000 the highest.
0x25	R/W	SENSOR_POWER_MODE	Radar sensor power mode. See the Service User Guide for respective service for more information.
			0x00: Sensor off power mode. Whole sensor is shutdown between sweeps, consumes least power, supports lower frequencies.
			0x01: Sensor sleep power mode.
			0x02: Sensor ready power mode.
			0x03: Sensor active power mode. Whole sensor is active. Consumes most power, supports higher frequencies.
			0x04: Sensor hibernate power mode. Sensor is still powered but the internal oscillator is turned off and the application needs to clock the sensor by toggling a GPIO a pre-defined number of times to enter and exit this mode. Only supported for the sparse service on XM122, XM123, XM124, XM131 and XM132 currently.
0x28	R/W	PROFILE_SELECTION	Each profile consists of a number of settings for the sensor that configures the RX and TX paths.
			0x01: Profile 1 maximizes on the depth resolution
			0x02: Sliding scale between profile 1 and 5.
			0x03: Sliding scale between profile 1 and 5.
			0x04: Sliding scale between profile 1 and 5.
			0x05: Profile 5 maximizes on radar loop gain with a sliding scale in between.
0x29	R/W	DOWNSAMPLING_FACTOR	Downsampling factor to be used in sensor.
0x30	R/W	HW_ACC_AVERAGE_SAMPLES	The number of hardware accelerated averaged samples for each data point.
0x33	R/W	ASYNCHRONOUS_MEASUREMENT	Used to enable/disable asynchronous mode.
0x40	R/W	THRESHOLD	Detection threshold in 1/1000 for presence.
0x41	R/W	SWEEPS_PER_FRAME	Sweeps per frame for the data from the underlying (sparse) service.
0x42	R/W	INTER_FRAME_DEV_TIME_CONST	Time constant in 1/1000 s of the low pass filter for the (inter-frame) deviation between fast and slow.
0x43	R/W	INTER_FRAME_FAST_CUTOFF	Cutoff frequency in mHz of the low pass filter for the fast filtered subsweep mean.

continued ...



...continued

Addr	Read/ Write	Register Name	Function
0x44	R/W	INTER_FRAME_SLOW_CUTOFF	Cutoff frequency in mHz of the low pass filter for the slow filtered subsweep mean.
0x45	R/W	INTRA_FRAME_TIME_CONST	Time constant in 1/1000 s for the intra frame part.
0x46	R/W	INTRA_FRAME_WEIGHT	The weight, 0-1000, of the intra-frame part in the final output. A value of 1000 corresponds to only using the intra-frame part and a value of 0 corresponds to only using the inter-frame part.
0x47	R/W	OUTPUT_TIME_CONST	Time constant in 1/1000 s of the low pass filter for the detector output.
0x48	R/W	NBR_REMOVED_PC	The number of principal components removed in the PCA based noise reduction. Value between 0 and 2 where 0 disables the PCA based noise reduction completely.
0xA0	R	DATA_SATURATED	Indication of sensor data being saturated, can cause result instability.
0xA4	R	SENSOR_COMM_ERROR	True is an indication of a sensor communication error, service or detector probably needs to be restarted.
0xB0	R	DETECTED	Presence detected or not
0xB1	R	SCORE	Score of the detected movement
0xB2	R	DISTANCE	Distance in mm to the detected movement



## 7 Examples


### 7.1 Python Example

There is a simple python example delivered together with the module software binary. This shows how to communicate with the module software over the UART interface.

Example:

```
python3 module_software_example.py --no-rtscs --port /dev/ttyUSB0
```


### 7.2 Reading Distances







### 7.3 Reading Power Bin Data (UART Streaming)





## 8 Debug Logging Output

RSS and module server logs can be retrieved from the UART2 on the XM112 module. UART2 can be easily accessed from the XB112 break out board. Note that UART2 operates at 1.8 V and that a level shifter may be needed if you need to connect to a device that uses a different voltage level.




Figure 1: UART2 on XB112

```
COM4 - PuTTY
00:00:00.001 [541105920] (I) (ms_system_xmllx): Error counter is now 0
-D- atmel_software_package/drivers/spi/spi.c:177 Spi: configuring chip select 0
-D- atmel_software_package/drivers/spi/spi.c:177 Spi: configuring chip select 0
00:00:00.002 [541105920] (I) (ms_system_xmllx): Magic number read: 0x 4030201
00:00:00.002 [541105920] (I) (ms_system_xmllx): Magic number not matched, unknown revision
00:00:00.002 [541105920] (I) (rss): Radar system services activated
00:00:00.002 [541105920] (I) (module_server): Module server starting with RSS version 1.0
00:00:00.002 [541105920] (I) (ms_mop): Mode distance peak
```

Figure 2: Example log output

Baudrate	3000000
Byte size	8
Parity	None
Stop bits	1

Table 9: Debug UART Settings



## 9 Minimum needed connections

These are the connections needed when connecting the XM112 to a custom board

Pin	Comment
UART0_TXRX	Host connects to TX
UART0_RXTX	Host connects to RX
GND	
1.8v	
NRST	Firmware upgrade over UART0
ERASE	Firmware upgrade over UART0
SWDIO	Firmware upgrade over SWD
SWDCLK	Firmware upgrade over SWD
NRST	Firmware upgrade over SWD
UART2_RXTX	Debug from module server



## 10 Disclaimer

The information herein is believed to be correct as of the date issued. Acconeer AB (“Acconeer”) will not be responsible for damages of any nature resulting from the use or reliance upon the information contained herein. Acconeer makes no warranties, expressed or implied, of merchantability or fitness for a particular purpose or course of performance or usage of trade. Therefore, it is the user’s responsibility to thoroughly test the product in their particular application to determine its performance, efficacy and safety. Users should obtain the latest relevant information before placing orders.

Unless Acconeer has explicitly designated an individual Acconeer product as meeting the requirement of a particular industry standard, Acconeer is not responsible for any failure to meet such industry standard requirements.

Unless explicitly stated herein this document Acconeer has not performed any regulatory conformity test. It is the user’s responsibility to assure that necessary regulatory conditions are met and approvals have been obtained when using the product. Regardless of whether the product has passed any conformity test, this document does not constitute any regulatory approval of the user’s product or application using Acconeer’s product.

Nothing contained herein is to be considered as permission or a recommendation to infringe any patent or any other intellectual property right. No license, express or implied, to any intellectual property right is granted by Acconeer herein.

Acconeer reserves the right to at any time correct, change, amend, enhance, modify, and improve this document and/or Acconeer products without notice.

This document supersedes and replaces all information supplied prior to the publication hereof.

