



OPERATING MANUAL
HYDRAULIC / MECHANICAL
DRILLING JARS

Size	Series
4 $\frac{3}{4}$ " X 2"	341
4 $\frac{3}{4}$ " X 2 $\frac{1}{4}$ "	380
6 $\frac{1}{4}$ "	447
6 $\frac{1}{2}$ " X 2 $\frac{3}{4}$ "	474
6 $\frac{3}{4}$ "	340
7"	450
8"	336-20 (336)
9"	354
9 $\frac{1}{2}$ "	381

Reviewed and Approved By:

OPERATING MANUAL

HYDRAULIC / MECHANICAL DRILLING JAR

CONTENTS

Section	Page
CONTENTS	2
1. DESCRIPTION	3
2. OPERATION	4
2.1. GENERAL	4
2.2. PLACEMENT	5
2.3. JARRING	7
2.4. MAXIMUM ROTATING HOURS	10
3. MAINTENANCE AND STORAGE	11
4. ORDERING	12
5. OPERATING CHARTS	13
6. SPECIFICATIONS	20

1. DESCRIPTION

A drilling jar installed in the drilling string is immediately available to apply jarring action and release the stuck portion of the drilling string.

The Griffith Hydraulic/Mechanical Drilling Jar is designed for use during drilling operations to apply an intensified force either up or down against a stuck portion of the drilling string.

The force or overpull required to free a stuck drill string must be applied in addition to the load already supported by the drilling rig and the drill pipe. This combined force often exceeds the safe tensile strength of the drill pipe, and sometimes the hoisting capacity of the drilling rig. This usually results in a costly and time consuming fishing operation.

The Griffith Hydraulic/Mechanical Drilling Jar was developed to incorporate the features of both hydraulic and mechanical drilling jars, without the inherent disadvantages of either type. Its unique design combines both a hydraulic time delay release and a mechanical latch mechanism, in one relatively short, double acting drilling jar. This tool provides several distinct advantages over conventional hydraulic or mechanical drilling jars.

- Hydraulic time delay allows the operator to vary the overpull applied, then apply the draw-works drum brake. The jarring force is therefore easily controlled, preventing damage to the hoisting equipment.
- Mechanical latch mechanism prevents jar movement during normal drilling operations, eliminating unnecessary wear of internal components.
- Location in BHA is less restricted. Jar can be used in tension or compression within the limits of the latch setting.
- No safety collars or special handling procedures are required on the rig floor.
- Will not fire unexpectedly when drilling, or tripping in or out of the hole.
- Latch re-sets automatically, locking jar in neutral position.
- Linear action latch is not affected by torque.
- Double acting, jarring action in both up and down directions.

To jar up, tension is applied to the jar, stretching the drill string. When the jar releases, the energy stored in the stretched drill string accelerates the jar mandrel rapidly to its fully extended position. The sudden stop of the jar mandrel converts the kinetic energy of the moving mass of drill collars into an intense impact or jarring force. This impact force will vary depending on the actual operating conditions, but can reach eight times the initial overpull.

To jar down, weight is slacked off until the force applied to the jar exceeds the mechanical down latch setting. The latch will then release, allowing the drill string to drop free. When the jar reaches its fully closed position, an intense impact force is applied to the stuck portion of the drill string.

2. OPERATION

2.1. GENERAL

The Griffith Hydraulic/Mechanical Drilling Jar must be installed in the drill string with the mandrel end up. Prior to make up, a suitable thread compound meeting A.P.I. Spec. 7, Appendix "G" should be applied to the end connections.

Protect the mandrel sealing surface from possible damage during handling or storage. Never apply tongs, slips, chains or slings to this area.

Rig tongs should be applied immediately adjacent to the top and bottom connections to avoid breaking or torquing the jar body connections. All body connections are torqued to specification at the service center. Avoid breaking these connections at the rig.

The up and down latch release settings are marked on the jar before shipment. These settings should be recorded before the tool is run into the hole.

The Griffith Hydraulic/Mechanical Drilling Jar is operated by simple up and down motion of the drill string. The intensity of the up-jarring force is directly proportional to applied tension. In the up-jarring mode, as the applied tension exceeds the up-latch setting, the mechanical latch releases and the hydraulic delay sequence begins. After a brief time delay, the jar mandrel is suddenly released and accelerates to the fully extended position.

In down-jarring mode, as the compression force applied to the jar exceeds the down-latch setting, the mechanical latch releases immediately allowing the jar mandrel to move freely to the fully closed position.

2.2. PLACEMENT

Determining the ideal jar position in the bottom hole assembly, is a complex problem, where several factors must be considered. Some of these factors are:


- Anticipated type of sticking; differential or mechanical.
- Hole condition, trajectory, and inclination.
- Configuration of bottom hole assembly.
- Pump pressure.
- Buoyancy factor of drilling fluid.
- Planned range of weight on bit.
- Overpull available.
- Safe working strength of the drill pipe.
- Latch setting on the jar.

Although each situation and combination of factors is unique, there are some general guidelines that can be used to select the location of the jar:

- In zones where differential sticking is anticipated, locate the jar relatively high in the BHA, to minimize the chance of becoming stuck above the jar.
- Where mechanical sticking is more common, the jar may be located lower in the BHA, for increased jarring efficiency.
- Axial forces acting on the Griffith Jar while drilling, should not exceed 50% of the latch release settings. This will provide an adequate safety factor for normal load variations. Charts showing the recommended operating range for each size of jar are included in Section 4.
- For maximum jarring efficiency, the jar should be located as close as possible above the anticipated stuck point, but at least two drill collar lengths above the top stabilizer. This usually locates the jar below the neutral point in the bottom hole assembly and therefore places the jar in compression.
- A sufficient number of drill collars and/or heavy weight drill pipes should be run above the jar, to provide the necessary mass to jar down.
- To avoid becoming stuck above the jar, the drill string above must not exceed the jar diameter.
- Avoid locating the jar at a cross over between BHA components of different diameters such as drill collars and heavy weight drill pipe. The jar should be placed a minimum of two joints above or below a crossover.

Although the drilling jar should be placed as close as possible above the anticipated stuck point, the jar should never be placed immediately above the top stabilizer. Whipping of the drill collars could create severe bending stresses on the jar if placed at this location. A minimum of two drill collar lengths should be placed between the jar and top stabilizer to:

- Minimize bending stresses in jar
- Minimize the risk of becoming stuck above the jar in sloughing formations
- Provide a clear target for a string shot if required.



2.3. JARRING

2.3.1. MECHANICAL LATCH SETTINGS

The latch release force is adjusted to suit normal drilling requirements, at the time of assembly. On request, these settings can be changed for special applications. The down release force is approximately 45% of the up release setting, but may be varied from 35% to 75% of the up release setting, if required.

To prevent the jar from releasing accidentally, the total force acting on the jar must be less than the latch settings.

2.3.2. PUMP OPEN FORCE

If circulation is maintained while jarring, the pressure drop across the bit creates a force tending to extend the jar. The pump open force must be considered in the following calculations since it reduces the force required to jar up and increases the force required to jar down. The pump open force is calculated by multiplying the pressure drop across the bit by the pump open area. The pump open areas are listed for each size of jar in Section 5, "Specifications".

EXAMPLE: 6.75" Jar with 1,000 psi Bit Pressure Drop
Pump Open Force = 11 in² x 1,000 psi = 11,000 Pound Force

2.3.3. WALL DRAG

Additional force may be required to compensate for wall drag, especially in deviated holes. The amount of compensation should be determined from the weight indicator readings during tripping before the drill string became stuck.

2.3.4. FREE STRING WEIGHT

The free string weight is the weight of string above the jar. To determine the free string weight, subtract the weight below the jar from the total string weight.

2.3.5. Jarring Up

The force applied to the jar above free string weight, must be greater than the up latch setting, but less than the recommended maximum load during hydraulic delay.

To determine the overpull above the free string weight, subtract the pump open force from the up latch setting

EXAMPLE: 6.75" Jar with 1,000 PSI (6894 kPa) Bit Pressure Drop

	Imperial units	Metric units
Up Latch Setting =	90,000 lb	40 000 daN
Maximum Load During Hydraulic Delay =	190,000 lb	84 500 daN
Pump Open Force =	11,000 lb	4 900 daN
Minimum Overpull Required = =	90,000 - 11,000 79,000 lb	40 000 - 4 900 35 100 daN
Maximum Recommended Overpull = =	190,000 - 11,000 179,000 lb	84 500 - 4 900 79 600 daN

To jar upward, apply the calculated overpull and set the draw-works brake. The mechanical latch will release and the delay sequence will begin. After the time delay of approximately 30 seconds, the jar will fire.

Lower the drill string until the weight indicator reads less than the free string weight, indicating that the latch has re-engaged. The jar is ready for another jarring cycle or to resume normal drilling operations.

2.3.6. Jarring Down

To determine the slack off required from the free string weight, add the pump open force to the down latch setting.

EXAMPLE: 6.75" Jar with 1,000 PSI (6894 kPa) Bit Pressure Drop

	Imperial units	Metric units
Down Latch Setting =	40,000 lb	17 800 daN
Pump Open Force =	11,000 lb	4 900 daN
Slack Off from the Free string Weight =	40,000 + 11,000 51,000 lb	17 800 + 4 900 22 700 daN


To jar downward, lower the drilling string until the calculated weight is slacked off, at which point the mechanical latch will release. To re-latch the jar raise the drilling string until the weight indicator shows an increase above free string weight. This indicates the latch has re-engaged and that the jar is ready for another jarring cycle.

2.3.7. Inspection

On each round trip the jar should be visually inspected for any indication of damage, excessive wear or leakage. When the jar is first removed from the hole a small quantity of drilling fluid may be noticed draining from the balancing ports. This condition is normal and does not indicate a problem.

2.4. MAXIMUM ROTATING HOURS

The chart shown below, indicates the maximum recommended rotating hours between servicing periods. This chart takes into consideration the rotating speed and static bottom hole temperature, assuming that the jar has only been used for short periods of light jarring totaling less than two hours. The jar should be serviced as soon as possible, following any continuous heavy jarring.



Example: 95 R.P.M. at 200°F = 380 HOURS

3. MAINTENANCE AND STORAGE

New tools are shipped painted. The threaded ends are chemplated with iron-phosphate and coated with rust preventative coating. Thread protectors are installed to eliminate mechanical damage. The rust preventative coating must be removed using petroleum base solvent and a stiff bristle brush before the jar is installed into the drill string.

When the jar is to be laid down the following should be done:

1. Flush all drilling fluid from the bore and from the balancing chamber with fresh water
2. Wash external surfaces of the tool
3. Apply thread compound and protectors to the end connections.

Tools stored horizontally should be rotated to a new position occasionally to prevent seals from setting and resultant fluid leakage.

4. ORDERING

When ordering seal kits, avoid overstating the anticipated bottom hole temperature as sealing materials rated for higher temperatures have a reduced service life. Specifying higher than actual bottom hole temperatures results in both reduced time between servicing and higher seal costs.

National Oilwell Varco (NOV) downhole tools are normally supplied with electroplated hard chrome or HOVF carbide sealing surfaces. Since hard chrome is porous by nature, chlorides can attack the underlying base metal and cause the chrome to lift. Please inform NOV of the type of environment the tool will be operated in. Upon request, NOV can supply tools with alternate surface coatings for extreme corrosion environments.

Orders may be placed by telephone, e-mail, fax or by written request. A purchase order number and shipping instructions must be provided at the time the order is placed.

Terms of payment are Net 30 days (OAC) from date of invoice.

All parts will be sold ExWorks our Edmonton plant.

For additional information, please contact:

MAILING ADDRESS: National Oilwell Varco
Downhole Tools
9118 – 34A Avenue
Edmonton, Alberta, Canada
T6E 5P4

TELEPHONE NUMBER: (780) 944 – 3929

FAX NUMBER: (780) 463 – 2348


E-MAIL: DHPSales@natoil.com

5. OPERATING CHARTS

RECOMMENDED OPERATING RANGE

4 3/4" O.D. x 2 1/4" I.D.

GRIFFITH HYDRAULIC / MECHANICAL DRILLING JAR
SERIES 380




-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.

-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

RECOMMENDED OPERATING RANGE
6 1/4" O.D. x 2 1/4" I.D.
GRIFFITH HYDRAULIC / MECHANICAL DRILLING JAR
SERIES 447




-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.

-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA.

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

RECOMMENDED OPERATING RANGE
6 1/2" O.D. x 2 3/4" I.D.
GRIFFITH HYDRAULIC / MECHANICAL DRILLING JAR
SERIES 474




-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.

-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA.

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

**RECOMMENDED OPERATING RANGE
6 3/4" & 7"
GRIFFITH HYDRAULIC / MECHANICAL DRILLING JARS
SERIES 340 & 450**



-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.


-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA.

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

RECOMMENDED OPERATING RANGE

8"

GRIFFITH HYDRAULIC / MECHANICAL DRILLING JAR
SERIES 336-20 & 336



-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.


-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA.

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

RECOMMENDED OPERATING RANGE

9"

GRIFFITH HYDRAULIC / MECHANICAL DRILLING JAR SERIES 354




-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.

-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA.

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

RECOMMENDED OPERATING RANGE
9 1/2"
GRIFFITH HYDRAULIC / MECHANICAL DRILLING JAR
SERIES 381



-IF LATCH FORCES ARE NOT EXCEEDED, JAR WILL REMAIN LATCHED IN THE NEUTRAL POSITION. TO PROVIDE A SAFETY FACTOR DURING NORMAL DRILLING ACTIVITIES, LOAD ON JAR SHOULD NOT EXCEED FIFTY PERCENT OF UP OR DOWN LATCH SETTINGS.

-HORIZONTAL LINE FROM LOAD ON JAR SHOULD INTERSECT VERTICAL LINE FROM PRESSURE DROP AT JAR WITHIN NON-SHADED AREA.

-OBSERVE MAXIMUM OVERPULL DURING HYDRAULIC DELAY

6. SPECIFICATIONS

TOOL OD		inches	4.75	6.25	6.50	6.75	7.00	8.00	9.00	9.50
(+API DRILL COLLAR TOLERANCE)		(mm)	(121)	(159)	(165)	(171)	(178)	(203)	(229)	(241)
SERIES			380	447	474	340	450	336-20 (336)	354	381
MAX. RECOMMENDED HOLE DIA.		inches	7 7/8	9 7/8	12 1/4	12 1/4	12 1/4	17 1/2	26	26
Hole openers not recommended.		(mm)	(200)	(251)	(311)	(311)	(311)	(445)	(660)	(660)
TOOL ID		inches	2.25	2.25	2.75	2.50	2.50	2.81	2.81	2.81
		(mm)	(57)	(57)	(70)	(64)	(64)	(71)	(71)	(71)
LENGTH (LATCHED)		feet	12.7	16.3	18.5	15.0	15.0	15.0	15.0	15.0
		(m)	(3.9)	(5.0)	(5.6)	(4.6)	(4.6)	(4.6)	(4.6)	(4.6)
WEIGHT		lbs	550	1,300	1,500	1,400	1,540	2,100	2,700	3,000
		(kg)	(250)	(590)	(680)	(640)	(700)	(950)	(1,200)	(1,400)
STROKE UP (FREE STROKE)		inches	4.0	4.5	6.0	4.5	4.5	5.0	5.0	5.0
		(mm)	(102)	(114)	(152)	(114)	(114)	(127)	(127)	(127)
STROKE DOWN		inches	4.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
		(mm)	(102)	(152)	(152)	(152)	(152)	(152)	(152)	(152)
PRESET RELEASE UP (DOWN =45% OF UP)	STD:	lbs	40,000	90,000	90,000	90,000	90,000	95,000	100,000	100,000
		(daN)	(18,000)	(40,000)	(40,000)	(40,000)	(40,000)	(42,000)	(44,000)	(44,000)
	MAX:	lbs	55,000	140,000	140,000	140,000	140,000	150,000	155,000	155,000
		(daN)	(24,000)	(62,000)	(62,000)	(62,000)	(62,000)	(67,000)	(69,000)	(69,000)
MAXIMUM LOAD DURING HYDRAULIC DELAY		lbs	75,000	160,000	180,000	190,000	190,000	220,000	250,000	250,000
		(daN)	(33,000)	(71,000)	(80,000)	(85,000)	(85,000)	(98,000)	(111,000)	(111,000)
MAXIMUM TENSILE LOAD AFTER JARRING		lbs	354,000	755,000	865,000	828,000	828,000	965,000	1,225,000	1,225,000
		(daN)	(157,000)	(336,000)	(385,000)	(368,000)	(368,000)	(429,000)	(545,000)	(545,000)
MAXIMUM TORSIONAL LOAD (TO YIELD BODY CONNECTIONS)		lb.ft	16,000	41,000	41,000	40,000	40,000	68,000	110,000	112,000
		(N.m)	(22,000)	(56,000)	(56,000)	(54,000)	(54,000)	(92,000)	(149,000)	(152,000)
PUMP OPEN AREA		sq.in.	6.5	9.6	11.0	11.0	11.0	14.2	15.9	15.9
		(sq.cm)	(42)	(62)	(71)	(71)	(71)	(92)	(103)	(103)

Specifications subject to change without notice.

|