


Instruction Manual



- 1 Unbox the UPS and check the physical damage, if any revert to the courier and inform IT Helpdesk.
- 2 Find respective components with hardware i.e. Power Cords, Batteries etc.



- 3 Verify equipment Serial Number from Email
- 4 Connect all components to PC / LCD, finally Plug PC/LCD power cables with electrical socket and make sure that power switch is off.

In case of any service issue please revert and contact us on following contact details, we will be happy to continue troubleshooting your query.



<https://ithelpdesk.efulife.com>




helpdesk@efulife.com



(021) 38783926 – Ext 926

NSID Document



5 Now switch on the electrical socket and enjoy the facility

6 Make sure that, UPS power should be off when going back to home after office hours.

In case of any service issue please revert and contact us on following contact details, we will be happy to continue troubleshooting your query.



<https://ithelpdesk.efulife.com>



helpdesk@efulife.com



(021) 38783926 – Ext 926

NSID Document