

# PyDAE user guide

## From DAE Tools

### Contents

- 1 Core module
  - 1.1 Models
  - 1.2 Equations
    - 1.2.1 Declaring equations
    - 1.2.2 Defining equations (equation residual expression)
    - 1.2.3 Defining boundary conditions
  - 1.3 Distribution Domains
    - 1.3.1 Declaring a domain
    - 1.3.2 Defining a domain
    - 1.3.3 Non-uniform grids
    - 1.3.4 Using domains
  - 1.4 Parameters
    - 1.4.1 Declaring a parameter
    - 1.4.2 Defining a parameter
    - 1.4.3 Using parameters
  - 1.5 Variable Types
    - 1.5.1 Declaring a variable type
  - 1.6 Variables
    - 1.6.1 Declaring a variable
    - 1.6.2 Assigning a variable value (setting the degrees of freedom of a model)
    - 1.6.3 Re-assigning a variable value
    - 1.6.4 Accessing a variable raw data
    - 1.6.5 Setting an initial guess
    - 1.6.6 Setting an initial condition
    - 1.6.7 Re-setting an initial condition
    - 1.6.8 Setting an absolute tolerance
    - 1.6.9 Getting a variable value
    - 1.6.10 Getting a variable time derivative
    - 1.6.11 Getting a variable partial derivative
  - 1.7 Ports
- 2 Activity module
- 3 DataReporting module
- 4 Solver module

## Core module

### Models

Models have the following properties:

- **Name:** string (read-only)  
Defines a name of an object ("Temperature" for instance)
- **CanonicalName:** string (read-only)  
It is a method use to describe a location of the object ("HeatExchanger.Temperature" for instance means that the object Temperature belongs to the parent object HeatExchanger). Object names are separated by dot symbols (".")
- **Description:** string
- **Domains:** daeDomain list
- **Parameters:** daeParameter list
- **Variables:** daeVariable list
- **Equations:** daeEquation list
- **Ports:** daePort list
- **ChildModels:** daeModel list
- **PortArrays:** daePortArray list
- **ChildModelArrays:** daeModelArray list
- **InitialConditionMode:** daeInitialConditionMode

The most important functions are:

- **ConnectPorts**
- **SetReportingOn**
- **sum, product, integral, average**
- **d, dt**
- **CreateEquation**
- **IF, ELSE\_IF, ELSE, END\_IF**
- **STN, STATE, SWITCH\_TO, END\_STN**

Every user model has to implement two functions: **\_\_init\_\_** and **DeclareEquations**. **\_\_init\_\_** is the constructor and all parameters, distribution domains, variables, ports, and child models must be declared here. **DeclareEquations** function is used to declare equations and state transition networks.

Models in **pyDAE** can be defined by the following statement:

```
class myModel(daeModel):
    def __init__(self, Name, Parent = None):
        daeModel.__init__(self, Name, Parent)
        ... (here go declarations of domains, parameters, variables, ports, etc)
```

```
def DeclareEquations(self):
    ... (here go declarations of equations and state transitions)
```

Details of how to declare and use parameters, distribution domains, variables, ports, equations, state transition networks (STN) and child models are given in the following sections.

## Equations

**DAE Tools** introduce two types of equations: ordinary and distributed. A residual expression of distributed equations is valid on every point in distributed domains that the equations is distributed on. The most important equation properties are:

- **Name:** string (read-only)
- **CanonicalName:** string (read-only)
- **Description:** string
- **Domains:** daeDomain list (read-only)
- **Residual:** adouble

### Declaring equations

The following statement is used in **pyDAE** to declare an ordinary equation:

```
eq = model.CreateEquation("MyEquation")
```

while to declare a distributed equation the next statemets are used:

```
eq = model.CreateEquation("MyEquation")
d = eq.DistributeOnDomain(myDomain, eClosedClosed)
```

Equations can be distributed on a whole domain or on a part of it. Currently there are 7 options:

- Distribute on a closed domain - analogous to:  $x \in [x_0, x_n]$
- Distribute on a left open domain - analogous to:  $x \in (x_0, x_n]$
- Distribute on a right open domain - analogous to:  $x \in [x_0, x_n)$
- Distribute on a domain open on both sides - analogous to:  $x \in (x_0, x_n)$
- Distribute on the lower bound - only one point:  $x \in \{x_0\}$   
This option is useful for declaring boundary conditions.
- Distribute on the upper bound - only one point:  $x \in \{x_n\}$   
This option is useful for declaring boundary conditions.
- Custom array of points within a domain

where LB stands for the LowerBound and UB stands for the UpperBound of the domain. An overview of various bounds is given in **Figures 1a. to 1h.**. Here we have an equation which is distributed on two domains: **x** and **y** and we can see various available options. Green squares represent the intervals included in the distributed equation, while white squares represent excluded intervals.

### Defining equations (equation residual expression)

The following statement can be used in **pyDAE** to create a residual expression of the ordinary equation:

```
# Notation:
# - V1, V3, V14 are ordinary variables
eq.Residual = V14.dt() + V1() / (V14() + 2.5) + sin(3.14 * V3())
```

The above code translates into:

$$\frac{\partial V_{14}}{\partial t} + \frac{V_1}{V_{14} + 2.5} + \sin(3.14 \cdot V_3) = 0$$

To define a residual expression of the distributed equation the next statements can be used:

```
# Notation:
# - V1, V3 and V14 are distributed variables on domains X and Y
eq = model.CreateEquation("MyEquation")
x = eq.DistributeOnDomain(X, eClosedClosed)
y = eq.DistributeOnDomain(Y, eOpenOpen)
eq.Residual = V14.dt(x,y) + V1(x,y) / (V14(x,y) + 2.5) + sin(3.14 * V3(x,y))
```

The above code translates into:

$$\frac{\partial V_{14}(x,y)}{\partial t} + \frac{V_1(x,y)}{V_{14}(x,y) + 2.5} + \sin(3.14 \cdot V_3(x,y)) = 0; \forall x \in [0, x_n], \forall y \in (0, x_y)$$

### Defining boundary conditions

Assume that we have a simple heat conduction through a very thin rectangular plate. At one side ( $Y = 0$ ) we have a constant temperature (500 K) while at the opposite end we have a constant flux ( $1E6 \text{ W/m}^2$ ). The problem can be defined by the following statements:

```
# Notation:
# - T is a variable distributed on domains X and Y
# - ro, k, and cp are parameters
eq = model.CreateEquation("MyEquation")
```




Figure 1a.  
x: eClosedClosed; y:  
eClosedClosed  
 $x \in [x_0, x_n], y \in [y_0, y_n]$




Figure 1b.  
x: eOpenOpen; y:  
eOpenOpen  
 $x \in (x_0, x_n), y \in (y_0, y_n)$

```
x = eq.DistributeOnDomain(X, eClosedClosed)
y = eq.DistributeOnDomain(Y, eOpenOpen)
eq.Residual = ro() * cp() * T.dt(x,y) - k() * ( T.d2(X,x,y) + T.d2(Y,x,y) )
```

We can note that the equation is defined on the domain Y, which is open on both ends. Now we have to specify the boundary conditions (2 additional equations). To do so, the following statements can be used:

```
# "Left" boundary conditions:
lbc = model.CreateEquation("Left_BC")
x = lbc.DistributeOnDomain(X, eClosedClosed)
y = lbc.DistributeOnDomain(Y, eLowerBound)
lbc.Residual = T(x,y) - 500 # Constant temperature (500 K)
# "Right" boundary conditions:
rbc = model.CreateEquation("Right_BC")
x = rbc.DistributeOnDomain(X, eClosedClosed)
y = rbc.DistributeOnDomain(Y, eUpperBound)
rbc.Residual = - k() * T.d(Y,x,y) - 1E6 # Constant flux (1E6 W/m2)
```

The above statements transform into:

$$T(x, y) = 500; \forall x \in [0, x_n], y = 0$$

and:

$$-k \cdot \frac{\partial T(x, y)}{\partial y} = 1E6; \forall x \in [0, x_n], y = y_n$$

## Distribution Domains

A distribution domain is a general term used to define an array of different objects. Two types of domains exist: arrays and distributed domains. Array is a synonym for a simple vector of objects. Distributed domains are most frequently used to model a spatial distribution of parameters, variables and equations, but can be equally used to spatially distribute just any other object (even ports and models). Domains have the following properties:

- **Name:** string (read-only)
- **CanonicalName:** string (read-only)
- **Description:** string
- **Type:** daeeDomainType (read-only; array or distributed)
- **NumberOfIntervals:** unsigned integer (read-only)
- **NumberOfPoints:** unsigned integer (read-only)
- **Points:** list of floats
- **LowerBound:** float (read-only)
- **UpperBound:** float (read-only)

Distributed domains also have:

- **DiscretizationMethod:** daeeDiscretizationMethod (read-only)  
Currently backward finite difference (**BFDM**), forward finite difference (**FFDM**) and center finite difference method (**CFDM**) are implemented.
- **DiscretizationOrder:** unsigned integer (read-only)  
At the moment, only the 2<sup>nd</sup> order is supported.

There is a difference between number of points in domain and number of intervals. Number of intervals is a number of points (if it is array) or a number of finite difference elements (if it is distributed domain). Number of points is actual number of points in the domain. If it is array then they are equal. If it is distributed, and the scheme is one of finite differences for instance, it is equal to number of intervals + 1.

The most important functions are:

- **CreateArray** for creating a simple array
- **CreateDistributed** for creating a distributed array
- **operator []** for getting a value of the point within domain for a given index (used only to construct equation residuals)
- **Overloaded operator ()** for creating **daeIndexRange** object (used only to construct equation residuals: as an argument of functions array, dt\_array, d\_array, d2\_array)
- **GetNumPyArray** for getting the point values as a numpy one-dimensional array

The process of creating domains is two-fold: first you declare a domain in the model and then you define it (by assigning its properties) in the simulation.

### Declaring a domain

The following statement is used to declare a domain:

```
myDomain = daeDomain("myDomain", Parent, "Description")
```

### Defining a domain

The following statement is used to define a distributed domain:

```
# Center finite diff, 2nd order, 10 elements, Bounds: 0.0 to 1.0
myDomain.CreateDistributed(eCFDM, 2, 10, 0.0, 1.0)
```

while to define an array:




Figure 1c.  
x: eClosedClosed; y:  
eOpenOpen  
 $x \in [x_0, x_n], y \in (y_0, y_n)$




Figure 1d.  
x: eClosedClosed; y:  
eOpenClosed  
 $x \in [x_0, x_n], y \in (y_0, y_n]$




Figure 1e.  
x: LB; y: eClosedOpen  
 $x = x_0, y \in [y_0, y_n)$




Figure 1f.  
x: LB; y: eClosedClosed  
 $x = x_0, y \in [y_0, y_n]$




Figure 1g.  
x: UB; y: eClosedClosed  
 $x = x_n, y \in [y_0, y_n]$

```
# Array of 10 elements
myDomain.CreateArray(10)
```




Figure 1h.  
x: LB; y: UB  
 $x = x_0$ ,  $y = y_n$

## Non-uniform grids

In certain situations it is not desired to have a uniform distribution of the points within the given interval (LowerBound, UpperBound). In these cases, a non-uniform grid can be specified by the following statement:

```
# First create a distributed domain
myDomain.CreateDistributed(eCFDM, 2, 10, 0.0, 1.0)
# The original 11 points are: [0.0, 0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9, 1.0]
# If we have a stiff profile at the beginning of the domain,
# then we can place more points there
myDomain.Points = [0.0, 0.05, 0.10, 0.15, 0.20, 0.25, 0.30, 0.35, 0.40, 0.60, 1.00]
```

The comparison of the effects of uniform and non-uniform grids is given in **Figure 2**. (a simple heat conduction problem from the Tutorial3 has been served as a basis for comparison). Here we have the following cases:

- Blue line (normal case, 10 intervals): uniform grid - a very rough prediction
- Red line (10 intervals): more points at the beginning of the domain
- Black line (100 intervals): uniform-grid (closer to the analytical solution)

We can clearly observe that we get much more precise results by using denser grid at the beginning of the domain.

## Using domains

**NOTE:** It is important to understand that all functions in this section are used ONLY to construct equation residuals and NOT to access the real (raw) data.

I) To get a value of the point within the domain at the given index we can use **operator []**. For instance if we want variable **myVar** to be equal to the sixth point (indexing in python and c/c++ starts at 0) in the domain **myDomain**, we can write:

```
# Notation:
# - eq is a daeEquation object
# - myDomain is daeDomain object
# - myVar is an daeVariable object
eq.Residual = myVar() - myDomain[5]
```

The above statement translates into:

```
myVar = myDomain[5]
```

II) **daeDomain operator ()** returns the **daeIndexRange** object which is used as an argument of functions **array**, **dt\_array**, **d\_array** and **d2\_array** in **daeParameter** and **daeVariable** classes to obtain an array of parameter/variable values, or an array of variable time (or partial) derivatives.

More details on parameter/variable arrays will be given in the following sections.

## Parameters

Parameters are time invariant quantities that will not change during simulation. Usually a good choice what should be a parameter is a physical constant, number of discretization points in a domain etc. Parameters have the following properties:

- **Name:** string (read-only)
- **CanonicalName:** string (read-only)
- **Description:** string
- **Type:** **daeParameterType** (read-only; real, integer, boolean)
- **Domains:** **daeDomain** list

The most important functions are:

- Overloaded **operator ()** for getting the parameter value (used only to construct equation residuals)
- Overloaded function **array** for getting an array of values (used only to construct equation residuals as an argument of functions like sum, product etc)
- Overloaded functions **SetValue** and **GetValue** for access to the parameter's raw data
- **GetNumPyArray** for getting the values as a numpy multidimensional array

The process of creating parameters is two-fold: first you declare a parameter in the model and then you define it (by assigning its value) in the simulation.

## Declaring a parameter

Parameters are declared in a model constructor (**\_\_init\_\_** function). An ordinary parameter can be declared by the following statement:

```
myParam = daeParameter("myParam", eReal, Parent, "Description")
```

Parameters can be distributed on domains. A distributed parameter can be declared by the next statement:

```
myParam = daeParameter("myParam", eReal, Parent, "Description")
myParam.DistributeOnDomain(myDomain)
```

Here, argument **Parent** can be either **daeModel** or **daePort**. Currently only **eReal** type is supported (others are ignored and used identically as the **eReal** type).

## Defining a parameter




Figure 2. Comparison of the effects of uniform and non-uniform grids on the numerical solution

Parameters are defined in a simulation class (**SetUpParametersAndDomains** function). To set a value of an ordinary parameter:

```
myParam.SetValue(1.0)
```

To set a value of distributed parameters (one-dimensional for example):

```
for i in range(0, myDomain.NumberOfPoints)
    myParam.SetValue(i, 1.0)
```

## Using parameters

**NOTE:** It is important to understand that all functions in this section are used ONLY to construct equation residuals and NOT to access the real (raw) data.

**I)** To get a value of the ordinary parameter the **operator ()** can be used. For instance, if we want variable *myVar* to be equal to the sum of the value of the parameter *myParam* and 15, we can write the following statement:

```
# Notation:
# - eq is a daeEquation object
# - myParam is an ordinary daeParameter object (not distributed)
# - myVar is an ordinary daeVariable object (not distributed)
eq.Residual = myVar() - myParam() - 15
```

This code translates into:

$$myVar = myParam + 15$$

**II)** To get a value of a distributed parameter we can again use **operator ()**. For instance, if we want distributed variable *myVar* to be equal to the sum of the value of the parameter *myParam* and 15 at each point of the domain *myDomain*, we need an equation for each point in the *myDomain* and we can write:

```
# Notation:
# - myDomain is daeDomain object
# - n is the number of points in the myDomain
# - eq is a daeEquation object distributed on the myDomain
# - d is daeDEDI object (used to iterate through the domain points)
# - myParam is daeParameter object distributed on the myDomain
# - myVar is daeVariable object distributed on the myDomain
d = eq.DistributeOnDomain(myDomain, eClosedClosed)
eq.Residual = myVar(d) - myParam(d) - 15
```

This code translates into *n* equations:

$$myVar(d) = myParam(d) + 15; \forall d \in [0, d_n]$$

which is equivalent to writing (in pseudo-code):

```
for d = 0 to n:
    myVar(d) = myParam(d) + 15
```

which internally transforms into *n* separate equations.

Obviously, a parameter can be distributed on more than one domain. In that case we can use identical functions which accept two arguments:

```
# Notation:
# - myDomain1, myDomain2 are daeDomain objects
# - n is the number of points in the myDomain1
# - m is the number of points in the myDomain2
# - eq is a daeEquation object distributed on the domains myDomain1 and myDomain2
# - d is daeDEDI object (used to iterate through the domain points)
# - myParam is daeParameter object distributed on the myDomain1 and myDomain2
# - myVar is daeVariable object distributed on the myDomain1 and myDomain2
d1 = eq.DistributeOnDomain(myDomain1, eClosedClosed)
d2 = eq.DistributeOnDomain(myDomain2, eClosedClosed)
eq.Residual = myVar(d1,d2) - myParam(d1,d2) - 15
```

The above statement translates into:

$$myVar(d_1, d_2) = myParam(d_1, d_2) + 15; \forall d_1 \in [0, d_{1n}], \forall d_2 \in [0, d_{2n}]$$

**III)** To get an array of parameter values we can use the function **array** which returns the **adouble\_array** object. Arrays of values can only be used in conjunction with mathematical functions that operate on **adouble\_array** objects: **sum**, **product**, **sqrt**, **sin**, **cos**, **min**, **max**, **log**, **log10** etc. For instance, if we want variable *myVar* to be equal to the sum of values of the parameter *myParam* for all points in the domain *myDomain*, we can use the function **sum** (defined in **daeModel** class) which accepts results of the **array** function (defined in **daeParameter** class). Arguments for the array function are **daeIndexRange** objects obtained by the call to **daeDomain's operator ()**. Thus, we can write the following statement:

```
# Notation:
# - myDomain is daeDomain object
# - n is the number of points in the domain myDomain
# - eq is daeEquation object
# - myVar is daeVariable object
# - myParam is daeParameter object distributed on the myDomain
eq.Residual = myVar() - sum( myParam.array( myDomain() ) )
```

This code translates into:

$$myVar = myParam(0) + myParam(1) + \dots + myParam(n)$$

The above example could be also written in the following form:

```
# points_range is daeDomainRange object
points_range = daeDomainRange(myDomain)
# arr is adouble_array object
arr = myVar2.array(points_range)
# Finally:
eq.Residual = myVar() - sum(arr)
```

On the other hand, if we want variable myVar to be equal to the sum of values of the parameter myParam only for certain points in the myDomain, there are two ways to do it:

```
# Notation:
# - myDomain is daeDomain object
# - n is the number of points in the domain myDomain
# - eq is a daeEquation object
# - myVar is an ordinary daeVariable object
# - myParam is a daeParameter object distributed on the myDomain
# 1) For a given array of points; the points must be in the range [0,n-1]
eq.Residual = myVar() - sum( myParam.array( myDomain( [0, 5, 12] ) ) )
# 2) For a given slice of points in the domain;
# slices are defined by 3 arguments: start_index, end_index, step
# in this example: start_index = 1
#                   end_index = 10
#                   step = 2
eq.Residual = myVar() - sum( myParam.array( myDomain(1, 10, 2) ) )
```

The code sample 1) translates into:

$myVar = myParam(0) + myParam(5) + myParam(12)$

The code sample 2) translates into:

$myVar = myParam(1) + myParam(3) + \dots + myParam(9)$

**NOTE:** One may argue that the function **array** calls can be somewhat simpler and directly accept python lists or slices as its arguments. For instance it would be possible to write:

```
eq.Residual = myVar() - sum( myParam.array( [0, 1, 3] ) )
```

or:

```
eq.Residual = myVar() - sum( myParam.array( slice(1,10,2) ) )
```

However, that would be more error prone since it does not check whether a valid domain is used for that index and whether specified indexes lay within the domain bounds (which should be done by the user).

## Variable Types

Variable types are used to describe variables. The most important properties are:

- **Name:** string
- **Units:** string
- **LowerBound:** float
- **UpperBound:** float
- **InitialGuess:** float
- **AbsoluteTolerance:** float

Declaration of variable types is usually done outside of model definitions (as global variables).

### Declaring a variable type

To declare a variable type:

```
# Temperature, units: Kelvin, limits: 100 - 1000K, Def.value: 273K, Abs.Tol: 1E-5
typeTemperature = daeVariableType("Temperature", "K", 100, 1000, 273, 1E-5)
```

## Variables

Variables are time variant quantities (state variables). The most important properties are:

- **Name:** string (read-only)
- **CanonicalName:** string (read-only)
- **Description:** string
- **Type:** daeVariableType object
- **Domains:** daeDomain list
- **ReportingOn:** boolean

The most important functions are:

- Overloaded **operator ()** for getting the variable value/time derivative/partial derivative (used only to construct equation residuals)
- Overloaded functions **array**, **dt\_array**, **d\_array**, and **d2\_array** for getting an array of values/time derivatives/partial derivatives (used only to construct equation residuals as an argument of functions like **sum**, **product** etc)
- Overloaded functions **AssignValue** to fix degrees of freedom of the model
- Overloaded functions **ReAssignValue** to change a value of a fixed variable

- Overloaded functions **SetValue** and **GetValue** for access to the variable's raw data
- Overloaded function **SetInitialGuess** for setting an initial guess of the variable
- Overloaded function **SetInitialCondition** for setting an initial condition of the variable
- Overloaded function **ReSetInitialCondition** for re-setting an initial condition of the variable
- Overloaded function **SetAbsoluteTolerances** for setting an absolute tolerance of the variable
- **GetNumPyArray** for getting the values as a numpy multidimensional array

The process of creating variables is two-fold: first you declare a variable in the model and then you define it (by assigning its value) in the simulation.

## Declaring a variable

Variables are declared in a model constructor (`__init__` function). To declare an ordinary variable:

```
myVar = daeVariable("myVar", variableType, Parent, "Description")
```

Variables can be distributed on domains. To declare a distributed variable:

```
myVar = daeVariable("myVar", variableType, Parent, "Description")
myVar.DistributeOnDomain(myDomain)
```

Here, argument Parent can be either **daeModel** or **daePort**.

## Assigning a variable value (setting the degrees of freedom of a model)

Degrees of freedom can be fixed in a simulation class in **SetUpVariables** function by assigning the value of a variable. Assigning the value of an ordinary variables can be done by the following statement:

```
myVar.AssignValue(1.0)
```

while the assigning the value of a distributed variable (one-dimensional for example) can be done by the next statement:

```
for i in range(myDomain.NumberOfPoints)
    myVar.AssignValue(i, 1.0)
```

## Re-assigning a variable value

Sometime during a simulation it is necessary to re-assign the variable value. This can be done by the following statement:

```
myVar.ReAssignValue(1.0)
... re-assign or re-initialize some other variables too (optional)
simulation.ReInitialize()
```

**NOTE:** After re-assigning or after re-initializing variable(s) the function **ReInitialize** in the simulation object **MUST** be called before continuing with the simulation!

## Accessing a variable raw data

Functions **GetValue/SetValue** access the variable raw data and should be used directly with a great care!!!

**NOTE:** ONLY USE THIS FUNCTION IF YOU EXACTLY KNOW WHAT ARE YOU DOING AND THE POSSIBLE IMPLICATIONS!!

Setting the value of ordinary variables can be done by the following statement::

```
myVar.SetValue(1.0)
```

while setting the value of a distributed variable can be done by:

```
for i in range(myDomain.NumberOfPoints)
    myVar.SetValue(i, 1.0)
```

## Setting an initial guess

Initial guesses can be set in a simulation class in **SetUpVariables** function. An initial guess of an ordinary variable can be set by the following statement:

```
myVar.SetInitialGuess(1.0)
```

while the initial guess of a distributed variable by:

```
for i in range(myDomain.NumberOfPoints)
    myVar.SetInitialGuess(i, 1.0)
```

Setting an initial guess of a distributed variable to a single value for all points in all domains can be done by the following statement:

```
myVar.SetInitialGuesses(1.0)
```

## Setting an initial condition

Initial conditions can be set in a simulation class in **SetUpVariables** function. In **DAE Tools** there are two modes. You can set either set an algebraic value or use the **eSteadyState** flag. This is controlled by the property **InitialConditionMode** in the simulation class (can be **eAlgebraicValuesProvided** or **eSteadyState**). **However, only the algebraic parts can be set at the moment.** An initial condition of an ordinary variable can be set by the following statement:

```
myVar.SetInitialCondition(1.0)
```

while the initial guess of a distributed variable by:

```
for i in range(myDomain.NumberOfPoints)
    myVar.SetInitialCondition(i, 1.0)
```

## Re-setting an initial condition

Sometime during a simulation it is necessary to re-initialize the variable value. This can be done by the following statement:

```
myVar.ReSetInitialCondition(1.0)
... re-assign or re-initialize some other variables too (optional)
simulation.ReInitialize()
```

**NOTE:** After re-assigning or after re-initializing the variable values the function **Reinitialize** in the simulation object **MUST** be called before continuing with the simulation!

## Setting an absolute tolerance

Absolute tolerances can be set in a simulation class in **SetUpVariables** function by the following statement:

```
myVar.SetAbsoluteTolerances(1E-5)
```

## Getting a variable value

**NOTE:** It is important to understand that all functions in this and all following sections are used **ONLY** to construct equation residuals and **NOT** no to access the real (raw) data.

For the examples how to get a variable value see the sub-sections **I - III** in the section Using parameters. **Operator ()** in **daeVariable** class behaves in the same way as the **operator ()** in **daeParameter** class.

## Getting a variable time derivative

**I)** To get a time derivative of the ordinary variable the function **dt** can be used. For example, if we want a time derivative of the variable **myVar** to be equal to some constant, let's say 1.0, we can write:

```
# Notation:
# - eq is a daeEquation object
# - myVar is an ordinary daeVariable (not distributed)
eq.Residual = myVar.dt() - 1
```

The above statement translates into:

$$\frac{\partial myVar}{\partial t} = 1$$

**II)** Getting a time derivative of distributed variables is analogous to getting a parameter value (see the sub-section **II** in the section [\[\[pydae\\_user\\_guide#Using Parameters\]\]](#)). The function **dt** accepts the same arguments and it is called in the same way as the **operator ()** in **daeParameter** class.

**III)** Getting an array of time derivatives of distributed variables is analogous to getting an array of parameter values (see the sub-section **III** in the section [\[\[pydae\\_user\\_guide#Using Parameters\]\]](#)). The function **dt\_array** accepts the same arguments and it is called in the same way as the function **array** in **daeParameter** class.

**Note:** Sometime a derivative of an expression is needed. In that case the function **dt** from the **daeModel** class can be used.

```
# Notation:
# - eq is a daeEquation object
# - myVar1 is an ordinary daeVariable (not distributed)
# - myVar2 is an ordinary daeVariable (not distributed)
eq.Residual = model.dt( myVar1() + myVar2() )
```

## Getting a variable partial derivative

It is possible to get a partial derivative only of the distributed variables and only for a domain which is distributed (not an ordinary array).

**I)** To get a partial derivative of the variable per some domain, we can use functions **d** or **d2** (the function **d** calculates a partial derivative of the first order while the function **d2** calculates a partial derivative of the second order). For instance, if we want a first order partial derivative of the variable **myVar** to be equal to some constant, let's say 1.0, we can write:

```
# Notation:
```



```
# - myDomain is daeDomain object
# - n is the number of points in the myDomain
# - eq is a daeEquation object distributed on the myDomain
# - d is daeDEI object (used to iterate through the domain points)
# - myVar is daeVariable object distributed on the myDomain
d = eq.DistributeOnDomain(myDomain, eOpenOpen)
eq.Residual = myVar.d(myDomain, d) - 1
```

This code translates into:

$$\frac{\partial myVar(d)}{\partial myDomain} = 1; \forall d \in (0, d_n)$$

Please note that the function myEquation is not distributed on the whole myDomain (it does not include the bounds).

In the case we want to get a partial derivative of the second order we can use the function **d2** which is called in the same fashion as the function **d**:

```
d = eq.DistributeOnDomain(myDomain, eOpenOpen)
eq.Residual = myVar.d2(myDomain, d) - 1
```

which translates into:

$$\frac{\partial^2 myVar(d)}{\partial myDomain^2} = 1; \forall d \in (0, d_n)$$

**II)** To get an array of partial derivatives we can use functions **d\_array** and **d2\_array** which return the **adouble\_array** object (the function **d\_array** returns an array of partial derivatives of the first order while the function **d2\_array** returns an array of partial derivatives of the second order). Again these arrays can only be used in conjunction with mathematical functions that operate on **adouble\_array** objects: **sum**, **product**, etc. For instance, if we want variable myVar to be equal to the minimal value in the array of partial derivatives of the variable myVar2 for all points in the domain myDomain, we can use the function **min** (defined in **daeModel** class) which accepts arguments of type **adouble\_array**. Arguments for the **d\_array** function are **daeIndexRange** objects obtained by the call to **daeDomain operator ()**. In this particular example we need a minimum among partial derivatives for the specified points (0, 1, and 3). Thus, we can write:

```
# Notation:
# - myDomain is daeDomain object
# - n is the number of points in the domain myDomain
# - eq is daeEquation object
# - myVar is daeVariable object
# - myVar2 is daeVariable object distributed on myDomain
eq.Residual = myVar() - min( myVar2.d_array(myDomain, myDomain( [0, 1, 3] ) ) )
```

The above code translates into:

$$myVar = \min\left(\frac{\partial myVar(0)}{\partial myDomain}, \frac{\partial myVar(1)}{\partial myDomain}, \frac{\partial myVar(3)}{\partial myDomain}\right)$$

**Note:** Sometime a partial derivative of an expression is needed. In that case the function **d** from the **daeModel** class can be used.

```
# Notation:
# - myDomain is daeDomain object
# - eq is a daeEquation object
# - myVar1 is an ordinary daeVariable (not distributed)
# - myVar2 is an ordinary daeVariable (not distributed)
eq.Residual = model.d( myVar1() + myVar2(), myDomain )
```

## Ports

Ports are used to connect two instances of models. Like models, ports can contain domains, parameters and variables. The most important properties are:

- **Name:** string (read-only)
- **CanonicalName:** string (read-only)
- **Description:** string
- **Type:** daePortType (inlet, outlet, inlet-outlet)
- **Domains:** daeDomain list
- **Parameters:** daeParameter list
- **Variables:** daeVariable list

The most important functions are:

- **SetReportingOn**

## Activity module

## DataReporting module

## Solver module

Retrieved from "[http://daetools.sourceforge.net/w/index.php/PyDAE\\_user\\_guide](http://daetools.sourceforge.net/w/index.php/PyDAE_user_guide)"

- This page was last modified on 5 April 2011, at 07:14.
- This page has been accessed 575 times.
- Content is available under GNU Free Documentation License 1.3.

- Privacy policy
- About DAE Tools
- Disclaimers