

i.MX8 HSM API

Revision_1.6

Generated by Doxygen 1.8.15

1 HSM API	1
2 Revision History	1
3 General concepts related to the API	1
3.1 Session	2
3.2 Service flow	2
3.3 Key store	2
3.3.1 Key management	2
3.3.2 NVM writing	2
4 Module Index	3
4.1 Modules	3
5 Data Structure Index	3
5.1 Data Structures	3
6 Module Documentation	4
6.1 Error codes	4
6.1.1 Detailed Description	5
6.1.2 Enumeration Type Documentation	5
6.2 Session	6
6.2.1 Detailed Description	6
6.2.2 Function Documentation	6
6.3 Key store	8
6.3.1 Detailed Description	8
6.3.2 Function Documentation	8
6.4 Key management	10
6.4.1 Detailed Description	12
6.4.2 Function Documentation	12
6.5 Ciphering	16
6.5.1 Detailed Description	16
6.5.2 Function Documentation	16
6.6 Signature generation	19
6.6.1 Detailed Description	20
6.6.2 Function Documentation	20
6.7 Signature verification	22
6.7.1 Detailed Description	22
6.7.2 Function Documentation	22
6.8 Random number generation	25
6.8.1 Detailed Description	25
6.8.2 Function Documentation	25
6.9 Hashing	27
6.9.1 Detailed Description	27

6.9.2 Function Documentation	27
6.10 Public key reconstruction	29
6.10.1 Detailed Description	29
6.10.2 Function Documentation	29
6.11 Public key decompression	30
6.11.1 Detailed Description	30
6.11.2 Function Documentation	30
6.12 ECIES encryption	31
6.12.1 Detailed Description	31
6.12.2 Function Documentation	31
6.13 Public key recovery	32
6.13.1 Detailed Description	32
6.13.2 Function Documentation	32
6.14 Data storage	33
6.14.1 Detailed Description	33
6.14.2 Function Documentation	33
6.15 Group14	35
6.15.1 Detailed Description	35
6.15.2 Function Documentation	35
7 Data Structure Documentation	36
7.1 hsm_op_ecies_dec_args_t Struct Reference	36
7.2 hsm_op_ecies_enc_args_t Struct Reference	36
7.3 hsm_op_kik_export_args_t Struct Reference	37
7.4 hsm_op_pub_key_dec_args_t Struct Reference	37
7.5 hsm_op_pub_key_rec_args_t Struct Reference	38
7.6 hsm_op_pub_key_recovery_args_t Struct Reference	38
7.7 op_auth_enc_args_t Struct Reference	39
7.8 op_butl_key_exp_args_t Struct Reference	39
7.9 op_cipher_one_go_args_t Struct Reference	40
7.10 op_data_storage_args_t Struct Reference	41
7.11 op_generate_key_args_t Struct Reference	41
7.12 op_generate_sign_args_t Struct Reference	41
7.13 op_get_random_args_t Struct Reference	42
7.14 op_hash_one_go_args_t Struct Reference	42
7.15 op_import_public_key_args_t Struct Reference	42
7.16 op_manage_key_args_t Struct Reference	43
7.17 op_manage_key_group_args_t Struct Reference	43
7.18 op_prepare_sign_args_t Struct Reference	43
7.19 op_verify_sign_args_t Struct Reference	44
7.20 open_session_args_t Struct Reference	44
7.21 open_svc_cipher_args_t Struct Reference	44

7.22 open_svc_data_storage_args_t Struct Reference	44
7.23 open_svc_hash_args_t Struct Reference	45
7.24 open_svc_key_management_args_t Struct Reference	45
7.25 open_svc_key_store_args_t Struct Reference	45
7.26 open_svc_rng_args_t Struct Reference	45
7.27 open_svc_sign_gen_args_t Struct Reference	45
7.28 open_svc_sign_ver_args_t Struct Reference	45

Index

47

1 HSM API

This document is a software reference description of the API provided by the i.MX8 HSM solutions.

2 Revision History

Revision	date	description
0.1 - subject to change	Mar 29 2019	Preliminary draf
0.8 - subject to change	May 24 2019	It adds the following API: -signature generation -signature verification -rng -hash -butterfly key expansion -ECIES enc/dec -public key reconstruction -public key decompression
0.9 - subject to change	May 28 2019	Explicit addresses are replaced by pointers.
1.0 - subject to change	May 29 2019	- bug/typos fix. - Change HSM_SVC_KEY_STORE_FLAGS definition
1.1 - subject to change	July 31 2019	- hsm_butterfly_key_expansion argument definition: dest_key_↔ identifier is now a pointer. - Add error code definition. - improve argument comments clarity
1.5 - subject to change	Sept 13 2019	- manage key argument: fix padding size - butterfly key expansion: change argument definition - introduce public key recovery API
1.6 - subject to change	Oct 14 2019	- add Key store section in chapter 3 - change key_info and flags definition, substitute key_type_ext with group_id - hsm_generate_key, hsm_manage_key, hsm_butterfly_key_↔ expansion: change argument definition - hsm_manage_key: change argument definition - add hsm_manage_key_group API

3 General concepts related to the API

3.1 Session

The API must be initialized by a potential requestor by opening a session.

The session establishes a route (MU, DomainID...) between the requester and the HSM. When a session is opened, the HSM returns a handle identifying the session to the requester.

3.2 Service flow

For a given category of services, the requestor is expected to open a service flow by invoking the appropriate HSM API.

The session handle, as well as the control data needed for the service flow, are provided as parameters of the call. Upon reception of the open request, the HSM allocates a context in which the session handle, as well as the provided control parameters are stored and return a handle identifying the service flow.

The context is preserved until the service flow, or the session, are closed by the user and it is used by the HSM to proceed with the sub-subsequent operations requested by the user on the service flow.

3.3 Key store

A key store can be created by specifying the CREATE flag in the `hsm_open_key_store_service` API. Please note that the created key store will be not stored in the NVM till a key is generated/imported specifying the STRICT OPERATION flag.

Only symmetric and private keys are stored into the key store. Public keys can be exported during the key pair generation operation or recalculated through the `hsm_pub_key_recovery` API.

Secret keys cannot be exported under any circumstances, while they can be imported in encrypted form.

3.3.1 Key management

Keys are divided in groups, keys belonging to the same group are written/read from the NVM as a monolithic block. Up to 3 key groups can be handled in the HSM local memory (those immediately available to perform crypto operation), while up to 1024 key groups can be handled in the external NVM and imported in the local memory as needed. If the local memory is full (3 key groups already reside in the HSM local memory) and a new key group is needed by an incoming user request, the HSM swaps one of the local key group with the one needed by the user request. A control of which key group should be kept in the local memory (cached) is provided through the `manage_key_group` API lock/unlock mechanism.

As general concept, frequently used keys should be kept, when possible, in the same key group and locked in the local memory for performance optimization.

3.3.2 NVM writing

All the APIs modifying the content of the key store (key generation/management) provide a "STRICT OPERATION" flag. If the flag is set, the HSM triggers and export of the encrypted key group into the external NVM and blows one bit of the OTP monotonic counter.

Any update to the key store must be considered as effective only after an operation specifying the flag "STRICT OPERATION" is acknowledged by the HSM. All the operations not specifying the "STRICT OPERATION" flags impact the HSM local memory only and will be lost in case of system reset.

Due to the limited monotonic counter size (QXPB0 up to 1620 update available), the user should, when possible, perform multiple updates before setting the "STRICT OPERATION" flag.

Once the monotonic counter is completely blown a warning is returned on each update operation to inform the user that the new updates are not roll-back protected.

4 Module Index

4.1 Modules

Here is a list of all modules:

Error codes	4
Session	6
Key store	8
Key management	10
Ciphering	16
Signature generation	19
Signature verification	22
Random number generation	25
Hashing	27
Public key reconstruction	29
Public key decompression	30
ECIES encryption	31
Public key recovery	32
Data storage	33
Group14	35

5 Data Structure Index

5.1 Data Structures

Here are the data structures with brief descriptions:

hsm_op_ecies_dec_args_t	36
hsm_op_ecies_enc_args_t	36
hsm_op_kik_export_args_t	37
hsm_op_pub_key_dec_args_t	37
hsm_op_pub_key_rec_args_t	38
hsm_op_pub_key_recovery_args_t	38
op_auth_enc_args_t	39
op_butl_key_exp_args_t	39

op_cipher_one_go_args_t	40
op_data_storage_args_t	41
op_generate_key_args_t	41
op_generate_sign_args_t	41
op_get_random_args_t	42
op_hash_one_go_args_t	42
op_import_public_key_args_t	42
op_manage_key_args_t	43
op_manage_key_group_args_t	43
op_prepare_sign_args_t	43
op_verify_sign_args_t	44
open_session_args_t	44
open_svc_cipher_args_t	44
open_svc_data_storage_args_t	44
open_svc_hash_args_t	45
open_svc_key_management_args_t	45
open_svc_key_store_args_t	45
open_svc_rng_args_t	45
open_svc_sign_gen_args_t	45
open_svc_sign_ver_args_t	45

6 Module Documentation

6.1 Error codes

Enumerations

- enum `hsm_err_t` {
 - `HSM_NO_ERROR` = 0x0,
 - `HSM_INVALID_MESSAGE` = 0x1,
 - `HSM_INVALID_ADDRESS` = 0x2,
 - `HSM_UNKNOWN_ID` = 0x3,
 - `HSM_INVALID_PARAM` = 0x4,
 - `HSM_NVM_ERROR` = 0x5,
 - `HSM_OUT_OF_MEMORY` = 0x6,
 - `HSM_UNKNOWN_HANDLE` = 0x7,
 - `HSM_UNKNOWN_KEY_STORE` = 0x8,
 - `HSM_KEY_STORE_AUTH` = 0x9,
 - `HSM_KEY_STORE_ERROR` = 0xA,

```

HSM_ID_CONFLICT = 0xB,
HSM_RNG_NOT_STARTED = 0xC,
HSM_CMD_NOT_SUPPORTED = 0xD,
HSM_INVALID_LIFECYCLE = 0xE,
HSM_KEY_STORE_CONFLICT = 0xF,
HSM_KEY_STORE_COUNTER = 0x10,
HSM_FEATURE_NOT_SUPPORTED = 0x11,
HSM_GENERAL_ERROR = 0xFF }

```

6.1.1 Detailed Description

6.1.2 Enumeration Type Documentation

6.1.2.1 hsm_err_t

```
enum hsm_err_t
```

Error codes returned by HSM functions.

Enumerator

HSM_NO_ERROR	Success.
HSM_INVALID_MESSAGE	The received message is invalid or unknown.
HSM_INVALID_ADDRESS	The provided address is invalid or doesn't respect the API requirements.
HSM_UNKNOWN_ID	The provided identifier is not known.
HSM_INVALID_PARAM	One of the parameter provided in the command is invalid.
HSM_NVM_ERROR	NVM generic issue.
HSM_OUT_OF_MEMORY	There is not enough memory to handle the requested operation.
HSM_UNKNOWN_HANDLE	Unknown session/service handle.
HSM_UNKNOWN_KEY_STORE	The key store identified by the provided "key store Id" doesn't exist and the "create" flag is not set.
HSM_KEY_STORE_AUTH	Key store authentication fails.
HSM_KEY_STORE_ERROR	An error occurred in the key store internal processing.
HSM_ID_CONFLICT	An element (key store, key. . .) with the provided ID already exists.
HSM_RNG_NOT_STARTED	The internal RNG is not started.
HSM_CMD_NOT_SUPPORTED	The functionality is not supported for the current session/service/key store configuration.
HSM_INVALID_LIFECYCLE	Invalid lifecycle for requested operation.
HSM_KEY_STORE_CONFLICT	A key store with the same attributes already exists.
HSM_KEY_STORE_COUNTER	The current key store reaches the max number of monotonic counter updates, updates are still allowed but monotonic counter will not be blown.
HSM_FEATURE_NOT_SUPPORTED	The requested feature is not supported by the firmware.
HSM_GENERAL_ERROR	Error not covered by other codes occurred.

6.2 Session

Data Structures

- struct [open_session_args_t](#)

Typedefs

- typedef uint32_t **hsm_hdl_t**

Functions

- [hsm_err_t hsm_open_session](#) ([open_session_args_t](#) *args, hsm_hdl_t *session_hdl)
- [hsm_err_t hsm_close_session](#) (hsm_hdl_t session_hdl)

6.2.1 Detailed Description

The API must be initialized by a potential requestor by opening a session. Once a session is closed all the associated service flows are closed by the HSM.

6.2.2 Function Documentation

6.2.2.1 hsm_open_session()

```
hsm_err_t hsm_open_session (
    open_session_args_t * args,
    hsm_hdl_t * session_hdl )
```

Parameters

<i>args</i>	pointer to the structure containing the function arguments.
<i>session_hdl</i>	pointer to where the session handle must be written.

Returns

`error_code` error code.

6.2.2.2 hsm_close_session()

```
hsm_err_t hsm_close_session (
    hsm_hdl_t session_hdl )
```

Terminate a previously opened session. All the services opened under this session are closed as well

Parameters

<code>session_hdl</code>	pointer to the handle identifying the session to be closed.
--------------------------	---

Returns

`error_code` error code.

6.3 Key store

Data Structures

- struct [open_svc_key_store_args_t](#)

Macros

- `#define HSM_SVC_KEY_STORE_FLAGS_CREATE ((hsm_svc_key_store_flags_t)(1 << 0))`
It must be specified to create a new key store. The key store will be stored in the NVM only once a key is generated/imported specifying the STRICT OPERATION flag.
- `#define HSM_SVC_KEY_STORE_FLAGS_UPDATE ((hsm_svc_key_store_flags_t)(1 << 2))`
Not supported - It must be specified in order to open a key management service flow.
- `#define HSM_SVC_KEY_STORE_FLAGS_DELETE ((hsm_svc_key_store_flags_t)(1 << 3))`
Not supported - It must be specified to delete an existing key store.

Typedefs

- `typedef uint8_t hsm_svc_key_store_flags_t`

Functions

- `hsm_err_t hsm_open_key_store_service (hsm_hdl_t session_hdl, open_svc_key_store_args_t *args, hsm_hdl_t *key_store_hdl)`
- `hsm_err_t hsm_close_key_store_service (hsm_hdl_t key_store_hdl)`

6.3.1 Detailed Description

User must open a key store service flow in order to perform the following operations:

- create a new key store
- update an existing key store
- delete an existing key store
- perform operations involving keys stored in the key store (ciphering, signature generation...)

The authentication is based on the user domain ID and messaging unit, additionally an authentication nonce is provided.

6.3.2 Function Documentation

6.3.2.1 hsm_open_key_store_service()

```
hsm_err_t hsm_open_key_store_service (
    hsm_hdl_t session_hdl,
    open_svc_key_store_args_t * args,
    hsm_hdl_t * key_store_hdl )
```

Open a service flow on the specified key store.

Parameters

<i>session_hdl</i>	pointer to the handle indentifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.
<i>key_store_hdl</i>	pointer to where the key store service flow handle must be written.

Returns

error_code error code.

6.3.2.2 hsm_close_key_store_service()

```
hsm_err_t hsm_close_key_store_service (
    hsm_hdl_t key_store_hdl )
```

Close a previously opened key store service flow. The key store is deleted from the HSM local memory, any update not written in the NVM is lost

Parameters

<i>handle</i>	indentifying the key store service flow to be closed.
---------------	---

Returns

error_code error code.

6.4 Key management

Data Structures

- struct `open_svc_key_management_args_t`
- struct `op_generate_key_args_t`
- struct `op_manage_key_args_t`
- struct `op_manage_key_group_args_t`
- struct `op_butl_key_exp_args_t`

Macros

- #define `HSM_KEY_TYPE_ECDSA_NIST_P224` ((hsm_key_type_t)0x01)
not supported
- #define `HSM_KEY_TYPE_ECDSA_NIST_P256` ((hsm_key_type_t)0x02)
- #define `HSM_KEY_TYPE_ECDSA_NIST_P384` ((hsm_key_type_t)0x03)
- #define `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224` ((hsm_key_type_t)0x12)
not supported
- #define `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256` ((hsm_key_type_t)0x13)
- #define `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384` ((hsm_key_type_t)0x15)
- #define `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224` ((hsm_key_type_t)0x22)
not supported
- #define `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256` ((hsm_key_type_t)0x23)
not supported
- #define `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384` ((hsm_key_type_t)0x25)
not supported
- #define `HSM_KEY_TYPE_AES_128` ((hsm_key_type_t)0x30)
- #define `HSM_KEY_TYPE_AES_192` ((hsm_key_type_t)0x31)
- #define `HSM_KEY_TYPE_AES_256` ((hsm_key_type_t)0x32)
- #define `HSM_OP_KEY_GENERATION_FLAGS_UPDATE` ((hsm_op_key_gen_flags_t)(1 << 0))
User can replace an existing key only by generating a key with the same type of the original one.
- #define `HSM_OP_KEY_GENERATION_FLAGS_CREATE` ((hsm_op_key_gen_flags_t)(1 << 1))
Create a new key.
- #define `HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION` ((hsm_op_key_gen_flags_t)(1 << 7))
The request is completed only when the new key has been written in the NVM. This applicable for persistent key only.
- #define `HSM_KEY_INFO_PERMANENT` ((hsm_key_info_t)(1 << 0))
When set, the key is permanent (write locked). Once created, it will not be possible to update or delete the key anymore. Transient keys will be anyway deleted after a PoR or when the corresponding key store service flow is closed. This bit can never be reset.
- #define `HSM_KEY_INFO_TRANSIENT` ((hsm_key_info_t)(1 << 1))
not supported - Transient keys are deleted when the corresponding key store service flow is closed or after a PoR. Transient keys cannot be in the same key group than persistent keys.
- #define `HSM_KEY_INFO_PERSISTENT` ((hsm_key_info_t)(0 << 1))
Persistent keys are stored in the external NVM. The entire key group is written in the NVM at the next STRICT operation.
- #define `HSM_KEY_INFO_MASTER` ((hsm_key_info_t)(1 << 2))
When set, the key is considered as a master key. Only master keys can be used as input of key derivation functions (i.e butterfly key expansion)
- #define `HSM_OP_MANAGE_KEY_FLAGS_IMPORT_UPDATE` ((hsm_op_manage_key_flags_t)(1 << 0))
User can replace an existing key only by importing a key with the same type of the original one.
- #define `HSM_OP_MANAGE_KEY_FLAGS_IMPORT_CREATE` ((hsm_op_manage_key_flags_t)(1 << 1))

- User can create a new key id by importing an encrypted key.*

 - #define **HSM_OP_MANAGE_KEY_FLAGS_DELETE** ((hsm_op_manage_key_flags_t)(1 << 2))

Delete an existing key.
- #define **HSM_OP_MANAGE_KEY_FLAGS_PRE_SHARED_PART_UNIQUE_KEY** ((hsm_op_manage_key_flags_t)(1 << 3))

The key to be imported is encrypted using the pre-shared part-unique kek.
- #define **HSM_OP_MANAGE_KEY_FLAGS_PRE_SHARED_COMMON_KEY** ((hsm_op_manage_key_flags_t)(1 << 4))

The key to be imported is encrypted using the pre-shared common kek.
- #define **HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION** ((hsm_op_manage_key_flags_t)(1 << 7))

The request is completed only when the new key has been written in the NVM. This applicable for persistent key only.
- #define **HSM_OP_MANAGE_KEY_GROUP_FLAGS_CACHE_LOCKDOWN** ((hsm_op_manage_key_group_flags_t)(1 << 0))

The entire key group will be cached in the HSM local memory.
- #define **HSM_OP_MANAGE_KEY_GROUP_FLAGS_CACHE_UNLOCK** ((hsm_op_manage_key_group_flags_t)(1 << 1))

HSM may export the key group in the external NVM to free up the local memory. HSM will copy the key group in the local memory again in case of key group usage/update.
- #define **HSM_OP_MANAGE_KEY_GROUP_FLAGS_DELETE** ((hsm_op_manage_key_group_flags_t)(1 << 2))

not supported - delete an existing key group
- #define **HSM_OP_MANAGE_KEY_GROUP_FLAGS_STRICT_OPERATION** ((hsm_op_manage_key_group_flags_t)(1 << 7))

The request is completed only when the update has been written in the NVM. Not applicable for cache lock-down/unlock.
- #define **HSM_OP_BUTTERFLY_KEY_FLAGS_UPDATE** ((hsm_op_but_key_exp_flags_t)(1 << 0))

User can replace an existing key only by generating a key with the same type of the original one.
- #define **HSM_OP_BUTTERFLY_KEY_FLAGS_CREATE** ((hsm_op_but_key_exp_flags_t)(1 << 1))

Create a new key.
- #define **HSM_OP_BUTTERFLY_KEY_FLAGS_IMPLICIT_CERTIF** ((hsm_op_but_key_exp_flags_t)(0 << 2))

butterfly key expansion using implicit certificate.
- #define **HSM_OP_BUTTERFLY_KEY_FLAGS_EXPLICIT_CERTIF** ((hsm_op_but_key_exp_flags_t)(1 << 2))

butterfly key expansion using explicit certificate.
- #define **HSM_OP_BUTTERFLY_KEY_FLAGS_STRICT_OPERATION** ((hsm_op_but_key_exp_flags_t)(1 << 7))

The request is completed only when the new key has been written in the NVM.

Typedefs

- typedef uint8_t **hsm_svc_key_management_flags_t**
- typedef uint8_t **hsm_op_key_gen_flags_t**
- typedef uint8_t **hsm_key_type_t**
- typedef uint16_t **hsm_key_info_t**
- typedef uint16_t **hsm_key_group_t**
- typedef uint8_t **hsm_op_manage_key_flags_t**
- typedef uint8_t **hsm_op_manage_key_group_flags_t**
- typedef uint8_t **hsm_op_but_key_exp_flags_t**

Functions

- [hsm_err_t hsm_open_key_management_service](#) (hsm_hdl_t key_store_hdl, [open_svc_key_management_args_t](#) *args, hsm_hdl_t *key_management_hdl)
- [hsm_err_t hsm_generate_key](#) (hsm_hdl_t key_management_hdl, [op_generate_key_args_t](#) *args)
- [hsm_err_t hsm_manage_key](#) (hsm_hdl_t key_management_hdl, [op_manage_key_args_t](#) *args)
- [hsm_err_t hsm_manage_key_group](#) (hsm_hdl_t key_management_hdl, [op_manage_key_group_args_t](#) *args)
- [hsm_err_t hsm_butterfly_key_expansion](#) (hsm_hdl_t key_management_hdl, [op_butt_key_exp_args_t](#) *args)
- [hsm_err_t hsm_close_key_management_service](#) (hsm_hdl_t key_management_hdl)

6.4.1 Detailed Description

6.4.2 Function Documentation

6.4.2.1 hsm_open_key_management_service()

```
hsm_err_t hsm_open_key_management_service (
    hsm_hdl_t key_store_hdl,
    open_svc_key_management_args_t * args,
    hsm_hdl_t * key_management_hdl )
```

Open a key management service flow

User must open this service flow in order to perform operation on the key store keys (generate, update, delete)

Parameters

<i>key_store_hdl</i>	handle indentifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>key_management_hdl</i>	pointer to where the key management service flow handle must be written.

Returns

error_code error code.

6.4.2.2 hsm_generate_key()

```
hsm_err_t hsm_generate_key (
    hsm_hdl_t key_management_hdl,
    op_generate_key_args_t * args )
```

Generate a key or a key pair. Only the confidential keys (symmetric and private keys) are stored in the internal key store, while the non-confidential keys (public key) are exported.

The generated key can be stored using a new or existing key identifier with the restriction that an existing key can be replaced only by a key of the same type.

User can call this function only after having opened a key management service flow.

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.4.2.3 hsm_manage_key()

```
hsm_err_t hsm_manage_key (
    hsm_hdl_t key_management_hdl,
    op_manage_key_args_t * args )
```

This command is designed to perform the following operations:

- import a key creating a new key identifier
- import a key using an existing key identifier
- delete an existing key

The key encryption key (KEK) can be previously pre-shared or stored in the key store.

In order to import a key into the key store, the user must encrypt it with KEK. \ The encryption algorithm is AES GCM (AAD = 0, IV = 12 bytes, Tag = 16 bytes).

User can call this function only after having opened a key management service flow

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.4.2.4 hsm_manage_key_group()

```
hsm_err_t hsm_manage_key_group (
    hsm_hdl_t key_management_hdl,
    op_manage_key_group_args_t * args )
```

This command is designed to perform the following operations:

- lock/unlock down a key group in the HSM local memory so that the keys are available to the HSM without additional latency
- un-lock a key group. HSM may export the key group into the external NVM to free up local memory as needed
- delete an existing key group

User can call this function only after having opened a key management service flow

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.4.2.5 hsm_butterfly_key_expansion()

```
hsm_err_t hsm_butterfly_key_expansion (
    hsm_hdl_t key_management_hdl,
    op_butt_key_exp_args_t * args )
```

This command is designed to perform the butterfly key expansion operation on an ECC private key in case of implicit and explicit certificates. Optionally the resulting public key is exported.

The result of the key expansion function f_k is calculated outside the HSM and passed as input. The expansion function is defined as $f_k = f_{k_int} \bmod I$, where I is the order of the group of points on the curve.

User can call this function only after having opened a key management service flow.

Explicit certificates:

- f_k = expansion function value

$out_key = Key + f_k$

Implicit certificates:

- f_k = expansion function value,
- hash = hash value used to in the derivation of the pseudonym ECC key,
- pr_v = private reconstruction value

$out_key = (Key + f_k) * hash + pr_v$

Parameters

<i>key_management_hdl</i>	handle identifying the key store management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.4.2.6 hsm_close_key_management_service()

```
hsm_err_t hsm_close_key_management_service (  
    hsm_hdl_t key_management_hdl )
```

Terminate a previously opened key management service flow

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
---------------------------	---

Returns

error code

6.5 Ciphering

Data Structures

- struct [open_svc_cipher_args_t](#)
- struct [op_cipher_one_go_args_t](#)
- struct [op_auth_enc_args_t](#)
- struct [hsm_op_ecies_dec_args_t](#)

Macros

- #define **HSM_CIPHER_ONE_GO_ALGO_AES_ECB** ((hsm_op_cipher_one_go_algo_t)(0x00))
- #define **HSM_CIPHER_ONE_GO_ALGO_AES_CBC** ((hsm_op_cipher_one_go_algo_t)(0x01))
- #define **HSM_CIPHER_ONE_GO_ALGO_AES_CCM** ((hsm_op_cipher_one_go_algo_t)(0x04))
Perform AES CCM with following constraints: AES CCM where Adata = 0, Tlen = 16 bytes, nonce size = 12 bytes.
- #define **HSM_CIPHER_ONE_GO_FLAGS_DECRYPT** ((hsm_op_cipher_one_go_flags_t)(0 << 0))
- #define **HSM_CIPHER_ONE_GO_FLAGS_ENCRYPT** ((hsm_op_cipher_one_go_flags_t)(1 << 0))
- #define **HSM_AUTH_ENC_ALGO_AES_GCM** ((hsm_op_auth_enc_algo_t)(0x00))
Perform AES GCM with following constraints: AES GCM where AAD supported, Tag len = 16 bytes, IV len = 12 bytes.
- #define **HSM_AUTH_ENC_FLAGS_DECRYPT** ((hsm_op_auth_enc_flags_t)(0 << 0))
- #define **HSM_AUTH_ENC_FLAGS_ENCRYPT** ((hsm_op_auth_enc_flags_t)(1 << 0))

Typedefs

- typedef uint8_t **hsm_svc_cipher_flags_t**
- typedef uint8_t **hsm_op_cipher_one_go_algo_t**
- typedef uint8_t **hsm_op_cipher_one_go_flags_t**
- typedef uint8_t **hsm_op_auth_enc_algo_t**
- typedef uint8_t **hsm_op_auth_enc_flags_t**
- typedef uint8_t **hsm_op_ecies_dec_flags_t**

Functions

- [hsm_err_t hsm_open_cipher_service](#) (hsm_hdl_t key_store_hdl, [open_svc_cipher_args_t](#) *args, hsm_hdl_t *cipher_hdl)
- [hsm_err_t hsm_cipher_one_go](#) (hsm_hdl_t cipher_hdl, [op_cipher_one_go_args_t](#) *args)
- [hsm_err_t hsm_auth_enc](#) (hsm_hdl_t cipher_hdl, [op_auth_enc_args_t](#) *args)
- [hsm_err_t hsm_ecies_decryption](#) (hsm_hdl_t cipher_hdl, [hsm_op_ecies_dec_args_t](#) *args)
- [hsm_err_t hsm_close_cipher_service](#) (hsm_hdl_t cipher_hdl)

6.5.1 Detailed Description

6.5.2 Function Documentation

6.5.2.1 hsm_open_cipher_service()

```
hsm_err_t hsm_open_cipher_service (
    hsm_hdl_t key_store_hdl,
    open_svc_cipher_args_t * args,
    hsm_hdl_t * cipher_hdl )
```

Open a cipher service flow

User can call this function only after having opened a key store service flow.

User must open this service in order to perform cipher operation

Parameters

<i>key_store_hdl</i>	handle indentifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arugments.
<i>cipher_hdl</i>	pointer to where the cipher service flow handle must be written.

Returns

error code

6.5.2.2 hsm_cipher_one_go()

```
hsm_err_t hsm_cipher_one_go (
    hsm_hdl_t cipher_hdl,
    op_cipher_one_go_args_t * args )
```

Perform ciphering operation

User can call this function only after having opened a cipher service flow

Parameters

<i>cipher_hdl</i>	handle identifying the cipher service flow.
<i>args</i>	pointer to the structure containing the function arugments.

Returns

error code

6.5.2.3 hsm_auth_enc()

```
hsm_err_t hsm_auth_enc (
    hsm_hdl_t cipher_hdl,
    op_auth_enc_args_t * args )
```

Perform authenticated encryption and precisely AES GCM

User can call this function only after having opened a cipher service flow

Parameters

<i>cipher_hdl</i>	handle identifying the cipher service flow.
<i>args</i>	pointer to the structure containing the function arugments.

Returns

error code

6.5.2.4 hsm_ecies_decryption()

```
hsm_err_t hsm_ecies_decryption (
    hsm_hdl_t cipher_hdl,
    hsm_op_ecies_dec_args_t * args )
```

Decrypt data usign ECIES

User can call this function only after having opened a cipher store service flow.

ECIES is supported with the constraints specified in 1609.2-2016.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.

Returns

error code

6.5.2.5 hsm_close_cipher_service()

```
hsm_err_t hsm_close_cipher_service (
    hsm_hdl_t cipher_hdl )
```

Terminate a previously opened cipher service flow

Parameters

<i>cipher_hdl</i>	pointer to handle identifying the cipher service flow to be closed.
-------------------	---

Returns

error code

6.6 Signature generation

Data Structures

- struct [open_svc_sign_gen_args_t](#)
- struct [op_generate_sign_args_t](#)
- struct [op_prepare_sign_args_t](#)

Macros

- `#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P224_SHA_256 ((hsm_signature_scheme_id_t)0x01)`
not supported
- `#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P256_SHA_256 ((hsm_signature_scheme_id_t)0x02)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P384_SHA_384 ((hsm_signature_scheme_id_t)0x03)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_224_SHA_256 ((hsm_signature_scheme_id_t)0x12)`
not supported
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_256_SHA_256 ((hsm_signature_scheme_id_t)0x13)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_384_SHA_384 ((hsm_signature_scheme_id_t)0x15)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_224_SHA_256 ((hsm_signature_scheme_id_t)0x22)`
not supported
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_256_SHA_256 ((hsm_signature_scheme_id_t)0x23)`
not supported
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_384_SHA_384 ((hsm_signature_scheme_id_t)0x25)`
not supported
- `#define HSM_OP_GENERATE_SIGN_FLAGS_INPUT_DIGEST ((hsm_op_generate_sign_flags_t)(0 << 0))`
- `#define HSM_OP_GENERATE_SIGN_FLAGS_INPUT_MESSAGE ((hsm_op_generate_sign_flags_t)(1 << 0))`
- `#define HSM_OP_GENERATE_SIGN_FLAGS_COMPRESSED_POINT ((hsm_op_generate_sign_flags_t)(1 << 1))`
- `#define HSM_OP_GENERATE_SIGN_FLAGS_LOW_LATENCY_SIGNATURE ((hsm_op_generate_sign_flags_t)(1 << 2))`
- `#define HSM_OP_PREPARE_SIGN_INPUT_DIGEST ((hsm_op_prepare_signature_flags_t)(0 << 0))`
- `#define HSM_OP_PREPARE_SIGN_INPUT_MESSAGE ((hsm_op_prepare_signature_flags_t)(1 << 0))`
- `#define HSM_OP_PREPARE_SIGN_COMPRESSED_POINT ((hsm_op_prepare_signature_flags_t)(1 << 1))`

Typedefs

- `typedef uint8_t hsm_svc_signature_generation_flags_t`
- `typedef uint8_t hsm_signature_scheme_id_t`
- `typedef uint8_t hsm_op_generate_sign_flags_t`
- `typedef uint8_t hsm_op_prepare_signature_flags_t`

Functions

- [hsm_err_t hsm_open_signature_generation_service](#) (hsm_hdl_t key_store_hdl, [open_svc_sign_gen_args_t](#) *args, hsm_hdl_t *signature_gen_hdl)
- [hsm_err_t hsm_close_signature_generation_service](#) (hsm_hdl_t signature_gen_hdl)
- [hsm_err_t hsm_generate_signature](#) (hsm_hdl_t signature_gen_hdl, [op_generate_sign_args_t](#) *args)
- [hsm_err_t hsm_prepare_signature](#) (hsm_hdl_t signature_gen_hdl, [op_prepare_sign_args_t](#) *args)

6.6.1 Detailed Description

6.6.2 Function Documentation

6.6.2.1 hsm_open_signature_generation_service()

```
hsm_err_t hsm_open_signature_generation_service (
    hsm_hdl_t key_store_hdl,
    open_svc_sign_gen_args_t * args,
    hsm_hdl_t * signature_gen_hdl )
```

Open a signature generation service flow

User can call this function only after having opened a key store service flow.

User must open this service in order to perform signature generation operations.

Parameters

<i>key_store_hdl</i>	handle indentifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arugments.
<i>signature_gen_hdl</i>	pointer to where the signature generation service flow handle must be written.

Returns

error code

6.6.2.2 hsm_close_signature_generation_service()

```
hsm_err_t hsm_close_signature_generation_service (
    hsm_hdl_t signature_gen_hdl )
```

Terminate a previously opened signature generation service flow

Parameters

<i>signature_gen_hdl</i>	handle identifying the signature generation service flow to be closed.
--------------------------	--

Returns

error code

6.6.2.3 hsm_generate_signature()

```
hsm_err_t hsm_generate_signature (
    hsm_hdl_t signature_gen_hdl,
    op_generate_sign_args_t * args )
```

Generate a digital signature according to the signature scheme

User can call this function only after having opened a signature generation service flow

The signature $S=(r,s)$ is stored in the format $r||s||Ry$ where Ry is an additional byte containing the lsb of y . Ry has to be considered valid only if the `HSM_OP_GENERATE_SIGN_FLAGS_COMPRESSED_POINT` is set.

Parameters

<i>signature_gen_hdl</i>	handle identifying the signature generation service flow
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.6.2.4 hsm_prepare_signature()

```
hsm_err_t hsm_prepare_signature (
    hsm_hdl_t signature_gen_hdl,
    op_prepare_sign_args_t * args )
```

Prepare the creation of a signature by pre-calculating the operations having not dependencies on the input message.

The pre-calculated value will be stored internally and used once call `hsm_generate_signature`

User can call this function only after having opened a signature generation service flow

The signature $S=(r,s)$ is stored in the format $r||s||Ry$ where Ry is an additional byte containing the lsb of y . Ry has to be considered valid only if the `HSM_OP_PREPARE_SIGN_FLAGS_COMPRESSED_POINT` is set.

Parameters

<i>signature_gen_hdl</i>	handle identifying the signature generation service flow
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.7 Signature verification

Data Structures

- struct [open_svc_sign_ver_args_t](#)
- struct [op_verify_sign_args_t](#)
- struct [op_import_public_key_args_t](#)

Macros

- `#define HSM_OP_VERIFY_SIGN_FLAGS_INPUT_DIGEST ((hsm_op_verify_sign_flags_t)(0 << 0))`
- `#define HSM_OP_VERIFY_SIGN_FLAGS_INPUT_MESSAGE ((hsm_op_verify_sign_flags_t)(1 << 0))`
- `#define HSM_OP_VERIFY_SIGN_FLAGS_COMPRESSED_POINT ((hsm_op_verify_sign_flags_t)(1 << 1))`
- `#define HSM_OP_VERIFY_SIGN_FLAGS_KEY_INTERNAL ((hsm_op_verify_sign_flags_t)(1 << 2))`
when set the value passed by the key argument is considered as the internal reference of a key imported through the hsm_import_pub_key API.
- `#define HSM_VERIFICATION_STATUS_SUCCESS ((hsm_verification_status_t)(0x5A3CC3A5))`

Typedefs

- `typedef uint8_t hsm_svc_signature_verification_flags_t`
- `typedef uint8_t hsm_op_verify_sign_flags_t`
- `typedef uint32_t hsm_verification_status_t`
- `typedef uint8_t hsm_op_import_public_key_flags_t`

Functions

- `hsm_err_t hsm_open_signature_verification_service (hsm_hdl_t session_hdl, open_svc_sign_ver_args_t *args, hsm_hdl_t *signature_ver_hdl)`
- `hsm_err_t hsm_verify_signature (hsm_hdl_t signature_ver_hdl, op_verify_sign_args_t *args, hsm_hdl_t *signature_ver_hdl, hsm_verification_status_t *status)`
- `hsm_err_t hsm_import_public_key (hsm_hdl_t signature_ver_hdl, op_import_public_key_args_t *args, uint32_t *key_ref)`
- `hsm_err_t hsm_close_signature_verification_service (hsm_hdl_t signature_ver_hdl)`

6.7.1 Detailed Description

6.7.2 Function Documentation

6.7.2.1 hsm_open_signature_verification_service()

```
hsm_err_t hsm_open_signature_verification_service (
    hsm_hdl_t session_hdl,
    open\_svc\_sign\_ver\_args\_t * args,
    hsm_hdl_t * signature_ver_hdl )
```

User must open this service in order to perform signature verification operations.
 User can call this function only after having opened a session.

Parameters

<i>session_hdl</i>	handle indentifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.
<i>signature_ver_hdl</i>	pointer to where the signature verification service flow handle must be written.

Returns

error code

6.7.2.2 hsm_verify_signature()

```
hsm_err_t hsm_verify_signature (
    hsm_hdl_t signature_ver_hdl,
    op_verify_sign_args_t * args,
    hsm_verification_status_t * status )
```

Verify a digital signature according to the signature scheme

User can call this function only after having opened a signature verification service flow

The signature $S=(r,s)$ is expected to be in format $r||s||R_y$ where R_y is an additional byte containing the lsb of y . R_y will be considered as valid only if the `HSM_OP_VERIFY_SIGN_FLAGS_COMPRESSED_POINT` is set.

Only not-compressed keys (x,y) can be used by this command. Compressed keys can be decompressed by using the dedicated API.

Parameters

<i>signature_ver_hdl</i>	handle identifying the signature verification service flow.
<i>args</i>	pointer to the structure containing the function arugments.
<i>status</i>	pointer to where the verification status must be stored if the verification suceed the value <code>HSM_VERIFICATION_STATUS_SUCCESS</code> is returned.

Returns

error code

6.7.2.3 hsm_import_public_key()

```
hsm_err_t hsm_import_public_key (
    hsm_hdl_t signature_ver_hdl,
    op_import_public_key_args_t * args,
    uint32_t * key_ref )
```

Import a public key to be used for several verification operations, a reference to the imported key is returned.

User can use the returned reference in the `hsm_verify_signature` API by setting the `HSM_OP_VERIFY_SIGN_FLAGS_KEY_INTERNAL` flag

Only not-compressed keys (x,y) can be imprted by this command. Compressed keys can be decompressed by using the dedicated API. User can call this function only after having opened a signature verification service flow.

Parameters

<i>signature_ver_hdl</i>	handle identifying the signature verification service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>key_ref</i>	pointer to where the 4 bytes key reference to be used as key in the hsm_verify_signature will be stored

Returns

error code

6.7.2.4 hsm_close_signature_verification_service()

```
hsm_err_t hsm_close_signature_verification_service (  
    hsm_hdl_t signature_ver_hdl )
```

Terminate a previously opened signature verification service flow

Parameters

<i>signature_ver_hdl</i>	handle identifying the signature verification service flow to be closed.
--------------------------	--

Returns

error code

6.8 Random number generation

Data Structures

- struct [open_svc_rng_args_t](#)
- struct [op_get_random_args_t](#)

Typedefs

- typedef uint8_t **hsm_svc_rng_flags_t**

Functions

- [hsm_err_t hsm_open_rng_service](#) (hsm_hdl_t session_hdl, [open_svc_rng_args_t](#) *args, hsm_hdl_t *rng_hdl)
- [hsm_err_t hsm_close_rng_service](#) (hsm_hdl_t rng_hdl)
- [hsm_err_t hsm_get_random](#) (hsm_hdl_t rng_hdl, [op_get_random_args_t](#) *args)

6.8.1 Detailed Description

6.8.2 Function Documentation

6.8.2.1 hsm_open_rng_service()

```
hsm_err_t hsm_open_rng_service (
    hsm_hdl_t session_hdl,
    open_svc_rng_args_t * args,
    hsm_hdl_t * rng_hdl )
```

Open a random number generation service flow

User can call this function only after having opened a session.

User must open this service in order to perform rng operations.

Parameters

<i>session_hdl</i>	handle indentifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.
<i>rng_hdl</i>	pointer to where the rng service flow handle must be written.

Returns

error code

6.8.2.2 hsm_close_rng_service()

```
hsm_err_t hsm_close_rng_service (
    hsm_hdl_t rng_hdl )
```

Terminate a previously opened rng service flow

Parameters

<i>rng_hdl</i>	handle identifying the rng service flow to be closed.
----------------	---

Returns

error code

6.8.2.3 hsm_get_random()

```
hsm_err_t hsm_get_random (
    hsm_hdl_t rng_hdl,
    op_get_random_args_t * args )
```

Get a freshly generated random number

User can call this function only after having opened a rng service flow

Parameters

<i>rng_hdl</i>	handle identifying the rng service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.9 Hashing

Data Structures

- struct [open_svc_hash_args_t](#)
- struct [op_hash_one_go_args_t](#)

Macros

- #define **HSM_HASH_ALGO_SHA_224** ((hsm_hash_algo_t)(0x0))
- #define **HSM_HASH_ALGO_SHA_256** ((hsm_hash_algo_t)(0x1))
- #define **HSM_HASH_ALGO_SHA_384** ((hsm_hash_algo_t)(0x2))
- #define **HSM_HASH_ALGO_SHA_512** ((hsm_hash_algo_t)(0x3))

Typedefs

- typedef uint8_t **hsm_svc_hash_flags_t**
- typedef uint8_t **hsm_hash_algo_t**
- typedef uint8_t **hsm_op_hash_one_go_flags_t**

Functions

- [hsm_err_t hsm_open_hash_service](#) (hsm_hdl_t session_hdl, [open_svc_hash_args_t](#) *args, hsm_hdl_t *hash_hdl)
- [hsm_err_t hsm_close_hash_service](#) (hsm_hdl_t hash_hdl)
- [hsm_err_t hsm_hash_one_go](#) (hsm_hdl_t hash_hdl, [op_hash_one_go_args_t](#) *args)

6.9.1 Detailed Description

6.9.2 Function Documentation

6.9.2.1 hsm_open_hash_service()

```
hsm_err_t hsm_open_hash_service (
    hsm_hdl_t session_hdl,
    open_svc_hash_args_t * args,
    hsm_hdl_t * hash_hdl )
```

Open an hash service flow

User can call this function only after having opened a session.

User must open this service in order to perform an hash operations.

Parameters

<i>session_hdl</i>	handle indentifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.
<i>hash_hdl</i>	pointer to where the hash service flow handle must be written.

Returns

error code

6.9.2.2 hsm_close_hash_service()

```
hsm_err_t hsm_close_hash_service (
    hsm_hdl_t hash_hdl )
```

Terminate a previously opened hash service flow

Parameters

<i>hash_hdl</i>	handle identifying the hash service flow to be closed.
-----------------	--

Returns

error code

6.9.2.3 hsm_hash_one_go()

```
hsm_err_t hsm_hash_one_go (
    hsm_hdl_t hash_hdl,
    op_hash_one_go_args_t * args )
```

Perform the hash operation on a given input

User can call this function only after having opened a hash service flow

Parameters

<i>hash_hdl</i>	handle identifying the hash service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.10 Public key reconstruction

Data Structures

- struct [hsm_op_pub_key_rec_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_pub_key_rec_flags_t](#)

Functions

- [hsm_err_t hsm_pub_key_reconstruction](#) ([hsm_hdl_t session_hdl](#), [hsm_op_pub_key_rec_args_t](#) *args)

6.10.1 Detailed Description

6.10.2 Function Documentation

6.10.2.1 hsm_pub_key_reconstruction()

```
hsm_err_t hsm_pub_key_reconstruction (
    hsm_hdl_t session_hdl,
    hsm_op_pub_key_rec_args_t * args )
```

Reconstruct an ECC public key provided by an implicit certificate

User can call this function only after having opened a session

This API implements the followign formula:

$out_key = (pub_rec * hash) + ca_key$

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.

Returns

error code

6.11 Public key decompression

Data Structures

- struct [hsm_op_pub_key_dec_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_pub_key_dec_flags_t](#)

Functions

- [hsm_err_t hsm_pub_key_decompression](#) (hsm_hdl_t session_hdl, [hsm_op_pub_key_dec_args_t](#) *args)

6.11.1 Detailed Description

6.11.2 Function Documentation

6.11.2.1 hsm_pub_key_decompression()

```
hsm\_err\_t hsm_pub_key_decompression (
    hsm_hdl_t session_hdl,
    hsm\_op\_pub\_key\_dec\_args\_t * args )
```

Decompress an ECC public key

The expected key format is x||lsb_y where lsb_y is 1 byte having value 1 if the least-significant bit of the original (uncompressed) y coordinate is set, and 0 otherwise.

User can call this function only after having opened a session

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.12 ECIES encryption

Data Structures

- struct [hsm_op_ecies_enc_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_ecies_enc_flags_t](#)

Functions

- [hsm_err_t hsm_ecies_encryption](#) (hsm_hdl_t session_hdl, [hsm_op_ecies_enc_args_t](#) *args)

6.12.1 Detailed Description

6.12.2 Function Documentation

6.12.2.1 hsm_ecies_encryption()

```
hsm_err_t hsm_ecies_encryption (
    hsm_hdl_t session_hdl,
    hsm_op_ecies_enc_args_t * args )
```

Encrypt data usign ECIES

User can call this function only after having opened a session.

ECIES is supported with the constraints specified in 1609.2-2016.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arugments.

Returns

error code

6.13 Public key recovery

Data Structures

- struct [hsm_op_pub_key_recovery_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_pub_key_recovery_flags_t](#)

Functions

- [hsm_err_t hsm_pub_key_recovery](#) (hsm_hdl_t key_store_hdl, [hsm_op_pub_key_recovery_args_t](#) *args)

6.13.1 Detailed Description

6.13.2 Function Documentation

6.13.2.1 hsm_pub_key_recovery()

```
hsm\_err\_t hsm_pub_key_recovery (
    hsm_hdl_t key_store_hdl,
    hsm\_op\_pub\_key\_recovery\_args\_t * args )
```

Recover Public key from private key present in key store
User can call this function only after having opened a key store.

Parameters

<i>key_store_hdl</i>	handle identifying the current key store.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.14 Data storage

Data Structures

- struct [open_svc_data_storage_args_t](#)
- struct [op_data_storage_args_t](#)

Macros

- #define [HSM_OP_DATA_STORAGE_FLAGS_STORE](#) ((hsm_op_data_storage_flags_t)(1 << 0))
Store data.
- #define [HSM_OP_DATA_STORAGE_FLAGS_RETRIEVE](#) ((hsm_op_data_storage_flags_t)(0 << 0))
Retrieve data.

Typedefs

- typedef uint8_t [hsm_svc_data_storage_flags_t](#)
- typedef uint8_t [hsm_op_data_storage_flags_t](#)

Functions

- [hsm_err_t hsm_open_data_storage_service](#) (hsm_hdl_t key_store_hdl, [open_svc_data_storage_args_t](#) *args, hsm_hdl_t *data_storage_hdl)
- [hsm_err_t hsm_data_storage](#) (hsm_hdl_t data_storage_hdl, [op_data_storage_args_t](#) *args)
- [hsm_err_t hsm_close_data_storage_service](#) (hsm_hdl_t data_storage_hdl)

6.14.1 Detailed Description

6.14.2 Function Documentation

6.14.2.1 hsm_open_data_storage_service()

```
hsm_err_t hsm_open_data_storage_service (
    hsm_hdl_t key_store_hdl,
    open_svc_data_storage_args_t * args,
    hsm_hdl_t * data_storage_hdl )
```

Open a data storage service flow

User must open this service flow in order to store retrieve generic data in the HSM.

Parameters

<i>key_store_hdl</i>	handle indentifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arugments.
<i>data_storage_hdl</i>	pointer to where the data storage service flow handle must be written.

Returns

error_code error code.

6.14.2.2 hsm_data_storage()

```
hsm_err_t hsm_data_storage (
    hsm_hdl_t data_storage_hdl,
    op_data_storage_args_t * args )
```

Store or Retrieve generic data defined by a data_id.

Parameters

<i>data_storage_hdl</i>	handle identifying the data storage service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.14.2.3 hsm_close_data_storage_service()

```
hsm_err_t hsm_close_data_storage_service (
    hsm_hdl_t data_storage_hdl )
```

Terminate a previously opened data storage service flow

Parameters

<i>data_storage_hdl</i>	handle identifying the data storage service flow.
-------------------------	---

Returns

error code

6.15 Group14

Data Structures

- struct [hsm_op_kik_export_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_kik_export_flags_t](#)

Functions

- [hsm_err_t hsm_kik_export](#) (hsm_hdl_t session_hdl, [hsm_op_kik_export_args_t](#) *args)

6.15.1 Detailed Description

6.15.2 Function Documentation

6.15.2.1 hsm_kik_export()

```
hsm\_err\_t hsm_kik_export (
    hsm_hdl_t session_hdl,
    hsm\_op\_kik\_export\_args\_t * args )
```

Export the derived key import key.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

7 Data Structure Documentation

7.1 hsm_op_ecies_dec_args_t Struct Reference

Data Fields

- `uint32_t key_identifier`
identifier of the private key to be used for the operation
- `uint8_t * input`
pointer to the VCT input
- `uint8_t * p1`
pointer to the KDF P1 input parameter
- `uint8_t * p2`
pointer to the MAC P2 input parameter should be NULL
- `uint8_t * output`
pointer to the output area where the plaintext must be written
- `uint32_t input_size`
length in bytes of the input VCT should be equal to 96 bytes
- `uint32_t output_size`
length in bytes of the output plaintext should be equal to 16 bytes
- `uint16_t p1_size`
length in bytes of the KDF P1 parameter should be equal to 32 bytes
- `uint16_t p2_size`
length in bytes of the MAC P2 parameter should be zero reserved for generic use cases
- `uint16_t mac_size`
length in bytes of the requested message authentication code should be equal to 16 bytes
- `hsm_key_type_t key_type`
indicates the type of the used key (only NIST P256 and Br256r1 are supported)
- `hsm_op_ecies_dec_flags_t flags`
bitmap specifying the operation attributes.

7.2 hsm_op_ecies_enc_args_t Struct Reference

Data Fields

- `uint8_t * input`
pointer to the input plaintext
- `uint8_t * pub_key`
pointer to the input recipient public key
- `uint8_t * p1`
pointer to the KDF P1 input parameter
- `uint8_t * p2`
pointer to the MAC P2 input parameter should be NULL
- `uint8_t * output`
pointer to the output area where the VCT must be written
- `uint32_t input_size`
length in bytes of the input plaintext should be equal to 16 bytes
- `uint16_t p1_size`
length in bytes of the KDF P1 parameter should be equal to 32 bytes

- uint16_t [p2_size](#)
length in bytes of the MAC P2 parameter should be zero reserved for generic use cases
- uint16_t [pub_key_size](#)
length in bytes of the recipient public key should be equal to 64 bytes
- uint16_t [mac_size](#)
length in bytes of the requested message authentication code should be equal to 16 bytes
- uint32_t [out_size](#)
length in bytes of the output VCT should be equal to 96 bytes
- hsm_key_type_t [key_type](#)
indicates the type of the recipient public key (only NIST P256 and Br256r1 are supported)
- hsm_op_ecies_enc_flags_t [flags](#)
bitmap specifying the operation attributes.
- uint16_t **reserved**

7.3 hsm_op_kik_export_args_t Struct Reference

Data Fields

- uint8_t * [signed_message](#)
pointer to signed_message authorizing the operation
- uint8_t * [out_kik](#)
pointer to the kik address where the derived kik (key import key) must be written
- uint16_t [signed_msg_size](#)
size of the signed_message authorizing the operation
- uint16_t [kik_size](#)
length in bytes of the kik. Must be 32 bytes.
- hsm_op_kik_export_flags_t [flags](#)
flags bitmap specifying the operation attributes.
- uint8_t **reserved** [3]

7.4 hsm_op_pub_key_dec_args_t Struct Reference

Data Fields

- uint8_t * [key](#)
pointer to the compressed ECC public key. The expected key format is x||lsb_y where lsb_y is 1 byte having value 1 if the least-significant bit of the original (uncompressed) y coordinate is set, and 0 otherwise.
- uint8_t * [out_key](#)
pointer to the output area where the decompressed public key must be written.
- uint16_t [key_size](#)
length in bytes of the input compressed public key
- uint16_t [out_key_size](#)
length in bytes of the resulting public key
- hsm_key_type_t [key_type](#)
indicates the type of the managed keys.
- hsm_op_pub_key_dec_flags_t [flags](#)
bitmap specifying the operation attributes.
- uint16_t **reserved**

7.5 hsm_op_pub_key_rec_args_t Struct Reference

Data Fields

- uint8_t * [pub_rec](#)
pointer to the public reconstruction value extracted from the implicit certificate.
- uint8_t * [hash](#)
pointer to the input hash value. In the butterfly scheme it corresponds to the hash value calculated over PCA certificate and, concatenated, the implicit certificat.
- uint8_t * [ca_key](#)
pointer to the CA public key
- uint8_t * [out_key](#)
pointer to the output area where the reconstructed public key must be written.
- uint16_t [pub_rec_size](#)
length in bytes of the public reconstruction value
- uint16_t [hash_size](#)
length in bytes of the input hash
- uint16_t [ca_key_size](#)
length in bytes of the input CA public key
- uint16_t [out_key_size](#)
length in bytes of the output key
- hsm_key_type_t [key_type](#)
indicates the type of the manged keys.
- hsm_op_pub_key_rec_flags_t [flags](#)
flags bitmap specifying the operation attributes.
- uint16_t **reserved**

7.6 hsm_op_pub_key_recovery_args_t Struct Reference

Data Fields

- uint32_t [key_identifier](#)
pointer to the identifier of the key to be used for the operation
- uint8_t * [out_key](#)
pointer to the output area where the generated public key must be written
- uint16_t [out_key_size](#)
length in bytes of the output key
- hsm_key_type_t [key_type](#)
indicates the type of the key to be recovered
- hsm_op_pub_key_recovery_flags_t [flags](#)
bitmap specifying the operation attributes.

7.7 op_auth_enc_args_t Struct Reference

Data Fields

- uint32_t [key_identifier](#)
identifier of the key to be used for the operation
- uint8_t * [iv](#)
pointer to the initialization vector or nonce
- uint16_t [iv_size](#)
*length in bytes of the initialization vector
It must be 12.*
- uint8_t * [aad](#)
pointer to the additional authentication data
- uint16_t [aad_size](#)
length in bytes of the additional authentication data
- hsm_op_auth_enc_algo_t [ae_algo](#)
algorithm to be used for the operation
- hsm_op_auth_enc_flags_t [flags](#)
bitmap specifying the operation attributes
- uint8_t * [input](#)
*pointer to the input area
plaintext for encryption
(ciphertext + tag) for decryption*
- uint8_t * [output](#)
*pointer to the output area
(ciphertext + tag) for encryption
plaintext for decryption if the tag is verified*
- uint32_t [input_size](#)
length in bytes of the input
- uint32_t [output_size](#)
length in bytes of the output

7.8 op_but_key_exp_args_t Struct Reference

Data Fields

- uint32_t [key_identifier](#)
identifier of the key to be expanded
- uint8_t * [expansion_function_value](#)
pointer to the expansion function value input
- uint8_t * [hash_value](#)
*pointer to the hash value input.
In case of explicit certificate, the hash value address must be set to 0.*
- uint8_t * [pr_reconstruction_value](#)
*pointer to the private reconstruction value input.
In case of explicit certificate, the pr_reconstruction_value address must be set to 0.*
- uint8_t [expansion_function_value_size](#)
length in bytes of the expansion function input
- uint8_t [hash_value_size](#)
*length in bytes of the hash value input.
In case of explicit certificate, the hash_value_size parameter must be set to 0.*

- `uint8_t pr_reconstruction_value_size`
length in bytes of the private reconstruction value input.
In case of explicit certificate, the `pr_reconstruction_value_size` parameter must be set to 0.
- `hsm_op_but_key_exp_flags_t flags`
bitmap specifying the operation properties
- `uint32_t * dest_key_identifier`
pointer to identifier of the derived key to be used for the operation.
In case of create operation the new destination key identifier will be stored in this location.
- `uint8_t * output`
pointer to the output area where the public key must be written.
- `uint16_t output_size`
length in bytes of the generated key, if the size is 0, no key is copied in the output.
- `hsm_key_type_t key_type`
indicates the type of the key to be derived.
- `uint8_t reserved`
- `hsm_key_group_t key_group`
it must be a value in the range 0-1023. Keys belonging to the same group can be cached in the HSM local memory through the `ham_manage_key_group` API
- `hsm_key_info_t key_info`
bitmap specifying the properties of the derived key.

7.9 op_cipher_one_go_args_t Struct Reference

Data Fields

- `uint32_t key_identifier`
identifier of the key to be used for the operation
- `uint8_t * iv`
pointer to the initialization vector (nonce in case of AES CCM)
- `uint16_t iv_size`
length in bytes of the initialization vector
it must be 0 for algorithms not using the initialization vector.
It must be 12 for AES in CCM mode
- `hsm_op_cipher_one_go_algo_t cipher_algo`
algorithm to be used for the operation
- `hsm_op_cipher_one_go_flags_t flags`
bitmap specifying the operation attributes
- `uint8_t * input`
pointer to the input area
plaintext for encryption
ciphertext for decryption (in case of CCM is the purported ciphertext)
- `uint8_t * output`
pointer to the output area
ciphertext for encryption (in case of CCM is the output of the generation-encryption process)
plaintext for decryption
- `uint32_t input_size`
length in bytes of the input
- `uint32_t output_size`
length in bytes of the output

7.10 op_data_storage_args_t Struct Reference

Data Fields

- uint8_t * [data](#)
pointer to the data. In case of store request, it will be the input data to store. In case of retrieve, it will be the the pointer where to load data.
- uint32_t [data_size](#)
length in bytes of the data
- uint16_t [data_id](#)
id of the data
- hsm_op_data_storage_flags_t [flags](#)
flags bitmap specifying the operation attributes.
- uint8_t **reserved**

7.11 op_generate_key_args_t Struct Reference

Data Fields

- uint32_t * [key_identifier](#)
*pointer to the identifier of the key to be used for the operation.
In case of create operation the new key identifier will be stored in this location.*
- uint16_t [out_size](#)
length in bytes of the generated key. It must be 0 in case of symmetric keys.
- hsm_op_key_gen_flags_t [flags](#)
bitmap specifying the operation properties.
- hsm_key_type_t [key_type](#)
indicates which type of key must be generated.
- hsm_key_group_t [key_group](#)
*Key group of the generated key, relevant only in case of create operation. it must be a value in the range 0-1023.
Keys belonging to the same group can be cached in the HSM local memory through the ham_manage_key_group API.*
- hsm_key_info_t [key_info](#)
bitmap specifying the properties of the key.
- uint8_t * [out_key](#)
pointer to the output area where the generated public key must be written

7.12 op_generate_sign_args_t Struct Reference

Data Fields

- uint32_t [key_identifier](#)
identifier of the key to be used for the operation
- uint8_t * [message](#)
pointer to the input (message or message digest) to be signed
- uint8_t * [signature](#)
pointer to the output area where the signature must be stored. The signature $S=(r,s)$ is stored in format $r||s||R_y$ where R_y is an additional byte containing the lsb of y . R_y has to be considered valid only if the `HSM_OP_GENERATE_SIGN_FLAGS_COMPRESSED_POINT` is set.
- uint32_t [message_size](#)
length in bytes of the input
- uint16_t [signature_size](#)
length in bytes of the output
- hsm_signature_scheme_id_t [scheme_id](#)
identifier of the digital signature scheme to be used for the operation
- hsm_op_generate_sign_flags_t [flags](#)
bitmap specifying the operation attributes

7.13 op_get_random_args_t Struct Reference

Data Fields

- uint8_t * [output](#)
pointer to the output area where the random number must be written
- uint32_t [random_size](#)
length in bytes of the random number to be provided.

7.14 op_hash_one_go_args_t Struct Reference

Data Fields

- uint8_t * [input](#)
pointer to the input data to be hashed
- uint8_t * [output](#)
pointer to the output area where the resulting digest must be written
- uint32_t [input_size](#)
length in bytes of the input
- uint32_t [output_size](#)
length in bytes of the output
- hsm_hash_algo_t [algo](#)
hash algorithm to be used for the operation
- hsm_op_hash_one_go_flags_t [flags](#)
flags bitmap specifying the operation attributes.
- uint16_t **reserved**

7.15 op_import_public_key_args_t Struct Reference

Data Fields

- uint8_t * [key](#)
pointer to the public key to be imported
- uint16_t [key_size](#)
length in bytes of the input key
- hsm_key_type_t [key_type](#)
indicates the type of the key to be imported.
- hsm_op_import_public_key_flags_t [flags](#)
bitmap specifying the operation attributes

7.16 op_manage_key_args_t Struct Reference

Data Fields

- uint32_t * [key_identifier](#)
*pointer to the identifier of the key to be used for the operation.
In case of create operation the new key identifier will be stored in this location.*
- uint32_t [kek_identifier](#)
identifier of the key to be used to decrypt the imported key (key encryption key), only AES-256 key can be uses as KEK. It must be 0 if the HSM_OP_MANAGE_KEY_FLAGS_PRE_SHARED_PART_UNIQUE_KEY or HSM_OP_MANAGE_KEY_FLAGS_PRE_SHARED_COMMON_KEY flags are set.
- uint16_t [input_size](#)
*length in bytes of the input key area. It must be eqaul to the length of the IV (12 bytes) + ciphertext + Tag (16 bytes).
It must be 0 in case of delete operation.*
- hsm_op_manage_key_flags_t [flags](#)
bitmap specifying the operation properties.
- hsm_key_type_t [key_type](#)
indicates the type of the key to be managed.
- hsm_key_group_t [key_group](#)
key group of the imported key, only relevant in case of create operation (it must be 0 otherwise). It must be a value in the range 0-1023. Keys belonging to the same group can be cached in the HSM local memory throug the ham_manage_key_group API
- hsm_key_info_t [key_info](#)
bitmap specifying the properties of the key, in case of update operation it will replace the existing value. It must be 0 in case of delete operation.
- uint8_t * [input_data](#)
pointer to the input buffer to decrypted in order to get tkey to be imported. The input buffer is the concatenation of the IV, the ciphertext and the Tag. It must be 0 in case of delete operation.

7.17 op_manage_key_group_args_t Struct Reference

Data Fields

- hsm_key_group_t [key_group](#)
it must be a value in the range 0-1023. Keys belonging to the same group can be cached in the HSM local memory throug the ham_manage_key_group API
- hsm_op_manage_key_group_flags_t [flags](#)
bitmap specifying the operation properties.
- uint8_t **reserved**

7.18 op_prepare_sign_args_t Struct Reference

Data Fields

- hsm_signature_scheme_id_t [scheme_id](#)
identifier of the digital signature scheme to be used for the operation
- hsm_op_prepare_signature_flags_t [flags](#)
bitmap specifying the operation attributes
- uint16_t **reserved**

7.19 op_verify_sign_args_t Struct Reference

Data Fields

- uint8_t * [key](#)
pointer to the public key to be used for the verification. If the HSM_OP_VERIFY_SIGN_FLAGS_KEY_INTERNAL is set, it must point to the key reference returned by the hsm_import_public_key API.
- uint8_t * [message](#)
pointer to the input (message or message digest)
- uint8_t * [signature](#)
pointer to the input signature. The signature $S=(r,s)$ is expected to be in the format $r||s||R_y$ where R_y is an additional byte containing the lsb of y . R_y will be considered as valid only if the HSM_OP_VERIFY_SIGN_FLAGS_COMPRESSED_POINT is set.
- uint16_t [key_size](#)
length in bytes of the input key
- uint16_t [signature_size](#)
length in bytes of the output - it must contains one additional byte where to store the R_y .
- uint32_t [message_size](#)
length in bytes of the input message
- hsm_signature_scheme_id_t [scheme_id](#)
identifier of the digital signature scheme to be used for the operation
- hsm_op_verify_sign_flags_t [flags](#)
bitmap specifying the operation attributes
- uint16_t **reserved**

7.20 open_session_args_t Struct Reference

Data Fields

- uint8_t [session_priority](#)
*not supported in current release, any value accepted. */*
- uint8_t [operating_mode](#)
*not supported in current release, any value accepted. */*
- uint16_t **reserved**

7.21 open_svc_cipher_args_t Struct Reference

Data Fields

- hsm_svc_cipher_flags_t [flags](#)
bitmap specifying the services properties.
- uint8_t **reserved** [3]

7.22 open_svc_data_storage_args_t Struct Reference

Data Fields

- hsm_svc_data_storage_flags_t [flags](#)
bitmap specifying the services properties.
- uint8_t **reserved** [3]

7.23 open_svc_hash_args_t Struct Reference

Data Fields

- hsm_svc_hash_flags_t [flags](#)
bitmap indicating the service flow properties
- uint8_t **reserved** [3]

7.24 open_svc_key_management_args_t Struct Reference

Data Fields

- hsm_svc_key_management_flags_t [flags](#)
bitmap specifying the services properties.
- uint8_t **reserved** [3]

7.25 open_svc_key_store_args_t Struct Reference

Data Fields

- uint32_t [key_store_identifier](#)
user defined id identifying the key store./*
- uint32_t [authentication_nonce](#)
*user defined nonce used as authentication proof for accesing the key store. */*
- uint16_t [max_updates_number](#)
*maximum number of updates authorized for the key store. Valid only for create operation. */*
- hsm_svc_key_store_flags_t [flags](#)
*bitmap specifying the services properties. */*
- uint8_t **reserved**

7.26 open_svc_rng_args_t Struct Reference

Data Fields

- hsm_svc_rng_flags_t [flags](#)
bitmap indicating the service flow properties
- uint8_t **reserved** [3]

7.27 open_svc_sign_gen_args_t Struct Reference

Data Fields

- hsm_svc_signature_generation_flags_t [flags](#)
bitmap specifying the services properties.
- uint8_t **reserved** [3]

7.28 open_svc_sign_ver_args_t Struct Reference

Data Fields

- hsm_svc_signature_verification_flags_t [flags](#)
bitmap indicating the service flow properties
- uint8_t **reserved** [3]

Index

Ciphering, [16](#)

- hsm_auth_enc, [17](#)
- hsm_cipher_one_go, [17](#)
- hsm_close_cipher_service, [18](#)
- hsm_ecies_decryption, [17](#)
- hsm_open_cipher_service, [16](#)

Data storage, [33](#)

- hsm_close_data_storage_service, [34](#)
- hsm_data_storage, [34](#)
- hsm_open_data_storage_service, [33](#)

ECIES encryption, [31](#)

- hsm_ecies_encryption, [31](#)

Error codes, [4](#)

- HSM_CMD_NOT_SUPPORTED, [5](#)
- hsm_err_t, [5](#)
- HSM_FEATURE_NOT_SUPPORTED, [5](#)
- HSM_GENERAL_ERROR, [5](#)
- HSM_ID_CONFLICT, [5](#)
- HSM_INVALID_ADDRESS, [5](#)
- HSM_INVALID_LIFECYCLE, [5](#)
- HSM_INVALID_MESSAGE, [5](#)
- HSM_INVALID_PARAM, [5](#)
- HSM_KEY_STORE_AUTH, [5](#)
- HSM_KEY_STORE_CONFLICT, [5](#)
- HSM_KEY_STORE_COUNTER, [5](#)
- HSM_KEY_STORE_ERROR, [5](#)
- HSM_NO_ERROR, [5](#)
- HSM_NVM_ERROR, [5](#)
- HSM_OUT_OF_MEMORY, [5](#)
- HSM_RNG_NOT_STARTED, [5](#)
- HSM_UNKNOWN_HANDLE, [5](#)
- HSM_UNKNOWN_ID, [5](#)
- HSM_UNKNOWN_KEY_STORE, [5](#)

Group14, [35](#)

- hsm_kik_export, [35](#)

Hashing, [27](#)

- hsm_close_hash_service, [28](#)
- hsm_hash_one_go, [28](#)
- hsm_open_hash_service, [27](#)

hsm_auth_enc

- Ciphering, [17](#)

hsm_butterfly_key_expansion

- Key management, [14](#)

hsm_cipher_one_go

- Ciphering, [17](#)

hsm_close_cipher_service

- Ciphering, [18](#)

hsm_close_data_storage_service

- Data storage, [34](#)

hsm_close_hash_service

- Hashing, [28](#)

hsm_close_key_management_service

Key management, [15](#)

hsm_close_key_store_service

- Key store, [9](#)

hsm_close_rng_service

- Random number generation, [25](#)

hsm_close_session

- Session, [6](#)

hsm_close_signature_generation_service

- Signature generation, [20](#)

hsm_close_signature_verification_service

- Signature verification, [24](#)

HSM_CMD_NOT_SUPPORTED

- Error codes, [5](#)

hsm_data_storage

- Data storage, [34](#)

hsm_ecies_decryption

- Ciphering, [17](#)

hsm_ecies_encryption

- ECIES encryption, [31](#)

hsm_err_t

- Error codes, [5](#)

HSM_FEATURE_NOT_SUPPORTED

- Error codes, [5](#)

HSM_GENERAL_ERROR

- Error codes, [5](#)

hsm_generate_key

- Key management, [12](#)

hsm_generate_signature

- Signature generation, [21](#)

hsm_get_random

- Random number generation, [26](#)

hsm_hash_one_go

- Hashing, [28](#)

HSM_ID_CONFLICT

- Error codes, [5](#)

hsm_import_public_key

- Signature verification, [23](#)

HSM_INVALID_ADDRESS

- Error codes, [5](#)

HSM_INVALID_LIFECYCLE

- Error codes, [5](#)

HSM_INVALID_MESSAGE

- Error codes, [5](#)

HSM_INVALID_PARAM

- Error codes, [5](#)

HSM_KEY_STORE_AUTH

- Error codes, [5](#)

HSM_KEY_STORE_CONFLICT

- Error codes, [5](#)

HSM_KEY_STORE_COUNTER

- Error codes, [5](#)

HSM_KEY_STORE_ERROR

- Error codes, [5](#)

hsm_kik_export

- Group14, [35](#)

- hsm_manage_key
 - Key management, 13
- hsm_manage_key_group
 - Key management, 13
- HSM_NO_ERROR
 - Error codes, 5
- HSM_NVM_ERROR
 - Error codes, 5
- hsm_op_ecies_dec_args_t, 36
- hsm_op_ecies_enc_args_t, 36
- hsm_op_kik_export_args_t, 37
- hsm_op_pub_key_dec_args_t, 37
- hsm_op_pub_key_rec_args_t, 38
- hsm_op_pub_key_recovery_args_t, 38
- hsm_open_cipher_service
 - Ciphering, 16
- hsm_open_data_storage_service
 - Data storage, 33
- hsm_open_hash_service
 - Hashing, 27
- hsm_open_key_management_service
 - Key management, 12
- hsm_open_key_store_service
 - Key store, 8
- hsm_open_rng_service
 - Random number generation, 25
- hsm_open_session
 - Session, 6
- hsm_open_signature_generation_service
 - Signature generation, 20
- hsm_open_signature_verification_service
 - Signature verification, 22
- HSM_OUT_OF_MEMORY
 - Error codes, 5
- hsm_prepare_signature
 - Signature generation, 21
- hsm_pub_key_decompression
 - Public key decompression, 30
- hsm_pub_key_reconstruction
 - Public key reconstruction, 29
- hsm_pub_key_recovery
 - Public key recovery, 32
- HSM_RNG_NOT_STARTED
 - Error codes, 5
- HSM_UNKNOWN_HANDLE
 - Error codes, 5
- HSM_UNKNOWN_ID
 - Error codes, 5
- HSM_UNKNOWN_KEY_STORE
 - Error codes, 5
- hsm_verify_signature
 - Signature verification, 23
- Key management, 10
 - hsm_butterfly_key_expansion, 14
 - hsm_close_key_management_service, 15
 - hsm_generate_key, 12
 - hsm_manage_key, 13
 - hsm_manage_key_group, 13
 - hsm_open_key_management_service, 12
- Key store, 8
 - hsm_close_key_store_service, 9
 - hsm_open_key_store_service, 8
- op_auth_enc_args_t, 39
- op_but_key_exp_args_t, 39
- op_cipher_one_go_args_t, 40
- op_data_storage_args_t, 41
- op_generate_key_args_t, 41
- op_generate_sign_args_t, 41
- op_get_random_args_t, 42
- op_hash_one_go_args_t, 42
- op_import_public_key_args_t, 42
- op_manage_key_args_t, 43
- op_manage_key_group_args_t, 43
- op_prepare_sign_args_t, 43
- op_verify_sign_args_t, 44
- open_session_args_t, 44
- open_svc_cipher_args_t, 44
- open_svc_data_storage_args_t, 44
- open_svc_hash_args_t, 45
- open_svc_key_management_args_t, 45
- open_svc_key_store_args_t, 45
- open_svc_rng_args_t, 45
- open_svc_sign_gen_args_t, 45
- open_svc_sign_ver_args_t, 45
- Public key decompression, 30
 - hsm_pub_key_decompression, 30
- Public key reconstruction, 29
 - hsm_pub_key_reconstruction, 29
- Public key recovery, 32
 - hsm_pub_key_recovery, 32
- Random number generation, 25
 - hsm_close_rng_service, 25
 - hsm_get_random, 26
 - hsm_open_rng_service, 25
- Session, 6
 - hsm_close_session, 6
 - hsm_open_session, 6
- Signature generation, 19
 - hsm_close_signature_generation_service, 20
 - hsm_generate_signature, 21
 - hsm_open_signature_generation_service, 20
 - hsm_prepare_signature, 21
- Signature verification, 22
 - hsm_close_signature_verification_service, 24
 - hsm_import_public_key, 23
 - hsm_open_signature_verification_service, 22
 - hsm_verify_signature, 23