

# NetX Duo™

## Simple Mail Transfer Protocol for Clients (NetX Duo SMTP Client)

User Guide

Renesas Synergy™ Platform

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.  
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

# Renesas Synergy Specific Information

If you are using NetX Duo SMTP Client for the Renesas Synergy platform, please use the following information.

## Installation

**Page 8:** If you are using Renesas Synergy SSP and the e2 studio ISDE, SMTP Client will already be installed. You can ignore the Installation and Use of NetX Duo SMTP Client section.

## Product Distribution

**Page 8:** The distribution of SMTP Client included with the Renesas Synergy SSP installation does not include the file **demo\_netxdue\_smtp\_client.c**. Please ignore references to this file.

## Multiple Network Interface

Multiple network interface has not been tested for SSP v1.5.0.



**NetX Duo Simple Mail Transfer Protocol  
for Clients  
(NetX Duo SMTP Client)**

**User Guide**

Express Logic, Inc.  
858.613.6640  
Toll Free 888.THREADX  
FAX 858.521.4259  
[www.expresslogic.com](http://www.expresslogic.com)



**©2002-2018 by Express Logic, Inc.**

All rights reserved. This document and the associated NetX software are the sole property of Express Logic, Inc. Each contains proprietary information of Express Logic, Inc. Reproduction or duplication by any means of any portion of this document without the prior written consent of Express Logic, Inc. is expressly forbidden. Express Logic, Inc. reserves the right to make changes to the specifications described herein at any time and without notice in order to improve design or reliability of NetX. The information in this document has been carefully checked for accuracy; however, Express Logic, Inc. makes no warranty pertaining to the correctness of this document.

**Trademarks**

NetX, NetX Duo, Piconet, and UDP Fast Path are trademarks of Express Logic, Inc. ThreadX is a registered trademark of Express Logic, Inc.

All other product and company names are trademarks or registered trademarks of their respective holders.

**Warranty Limitations**

Express Logic, Inc. makes no warranty of any kind that the NetX products will meet the USER's requirements, or will operate in the manner specified by the USER, or that the operation of the NetX products will operate uninterrupted or error free, or that any defects that may exist in the NetX products will be corrected after the warranty period. Express Logic, Inc. makes no warranties of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, with respect to the NetX products. No oral or written information or advice given by Express Logic, Inc., its dealers, distributors, agents, or employees shall create any other warranty or in any way increase the scope of this warranty, and licensee may not rely on any such information or advice.

Part Number: 000-1054

Revision 5.11

# Contents

---

Chapter 1 .....	3
Introduction to NetX Duo SMTP Client.....	3
NetX Duo SMTP Client Requirements.....	3
NetX Duo SMTP Client Constraints .....	3
Commands Supported by NetX Duo SMTP Client .....	4
Getting Started .....	4
NetX Duo SMTP Authentication.....	6
RFCs Supported by NetX Duo SMTP Client .....	7
Chapter 2 Installation and Use of NetX Duo SMTP Client.....	8
NetX Duo SMTP Client Installation.....	8
Using NetX Duo SMTP Client .....	8
Small Example System .....	9
Client Configuration Options.....	13
Chapter 3 Client Description of SMTP Client Services .....	16
nxd_smtp_client_create .....	17
nx_smtp_client_delete .....	19
nx_smtp_mail_send .....	20

# Chapter 1

## Introduction to NetX Duo SMTP Client

The Simple Mail Transfer Protocol (SMTP) is a protocol for transferring mail across networks and the Internet. It utilizes the reliable Transmission Control Protocol (TCP) services to perform its content transfer function.

## NetX Duo SMTP Client Requirements

The NetX Duo SMTP Client requires creation of a NetX Duo IP instance and NetX Duo packet pool. The SMTP Client uses a TCP socket to connect to an SMTP Server on the well-known port 25. Therefore, TCP must first be enabled by calling the `nx_tcp_enable` service on a previously created IP instance.

The SMTP Client create call (`nxd_smtp_client_create`) requires a previously created packet pool for transmitting SMTP commands to the Server as well as for sending the actual mail message. Packet payload depends on the anticipated size of the mail contents and must allow for TCP, IP header, and MAC header. (Note that the IPv6 header is 40 bytes while the IPv4 header is 20 bytes.)

If the entire mail message cannot fit in one packet, the SMTP Client allocates additional packets to contain the rest of the message.

## NetX Duo SMTP Client Constraints

While the NetX Duo SMTP protocol implements the RFC 2821 and 2554 standards, there are some constraints:

1. The NetX Duo SMTP Client supports only LOGIN and PLAIN authentication, but not CRAM-MD5 digest authentication.
2. The NetX Duo SMTP Client messages are limited to one recipient per mail item, and only one mail message per TCP connection with the SMTP server.



3. VRFY, SEND, SOML, EXPN, SAML, ETRN, TURN and SIZE SMTP options are not supported.
4. The SMTP Client is not mail browser (“mail user agent”) which is typically used for creating the mail message. It is a “mail transfer agent” only. It will provide the necessary processing of the mail message body for SMTP transport as specified in RFC 2821. It does not check the contents for correct syntax e.g. the recipient and reverse pathway. There is no restriction what is in the mail buffer e.g. MIME data or clear text messages. Mail message format, specified in RFC 2822 for including headers and message body is beyond the scope of the SMTP Client API.

## Commands Supported by NetX Duo SMTP Client

The NetX Duo SMTP Client uses the following commands during a mail session with an SMTP Server.

<u>Command</u>	<u>Meaning</u>
EHLO	The Client would like to initiate a session that includes some or all extension protocol SMTP services available from the SMTP Server. This is the default.
HELO	The Client would like to initiate a session limited to basic SMTP services.
MAIL	The Client would like the Server to receive Client mail.
AUTH	The Client would like to initiate authentication by the Server.
RCPT	The Client would like to submit a mailbox of another host it would like the mail to be delivered to.
DATA	The Client would like to initiate sending mail message data to the Server.
QUIT	The Client would like to terminate the session.

## Getting Started

The SMTP Client application creates an IP instance and enables TCP on that IP instance. It then creates the SMTP Client using the following service:

```
UINT  nxd_smtp_client_create(NX_SMTP_CLIENT *client_ptr,
                             NX_IP *ip_ptr, NX_PACKET_POOL
                             *client_packet_pool_ptr,
                             CHAR *username, CHAR *password,
                             CHAR *from_address,
                             CHAR *client_domain,
                             UINT authentication_type,
                             NXD_ADDRESS *server_address, UINT port)
```

The *client\_packet\_pool\_ptr* is a pointer to a previously created packet pool the SMTP Client will use to send messages to the SMTP Server.

Note that an application must provide a *from\_address* for the local device and a server IP address. All addresses must be fully qualified domain names. A fully qualified domain name contains a local-part and a domain name, separated by an '@' character. Note that the SMTP Client does not check the syntax of the *from\_address* or the *recipient\_address* in the *nx\_smtp\_mail\_send* service below.

After the SMTP Client is created, the SMTP Client application creates a mail item with a properly formatted SMTP mail message, and makes the mail item send request to the SMTP Client using the following API:

```
UINT  nx_smtp_mail_send(NX_SMTP_CLIENT *client_ptr,
                        CHAR *recipient_address, UINT priority,
                        CHAR *subject, CHAR *mail_body,
                        UINT mail_body_length)
```

There is essentially no difference in running SMTP Client over IPv4 or IPv6 from user perspective. Differences between the two IP protocols are handled in the underlying NetX Duo layer.

Note that an application wishing to send mail must provide a recipient address in the *nx\_smtp\_client\_mail* call.

For authentication, usernames can either be fully qualified domain names, or display user names. This depends on how the Server performs authentication.

The demo in the Small Example section later in this User Guide shows how the message should be formatted. The status if the mail item was successfully sent will be *NX\_SUCCESS*. If an error occurs, whether it is an internal error, a broken TCP connection or receiving a Server reply error code, *nx\_smtp\_mail\_send* will return a non-zero error status.

When sending a mail item, NetX Duo SMTP Client creates a new TCP connection with the SMTP server and begins an SMTP session. In this session, the Client sends a series of commands to the SMTP Server as part of the SMTP protocol, culminating in sending out the actual mail message. The TCP connection is then terminated, regardless of the outcome of the SMTP session.

After mail transmission, regardless of success or failure, the SMTP Client is returned to the 'initial' state, and can be used for another mail transfer session.

## **NetX Duo SMTP Authentication**

Authentication is a way for SMTP Clients to prove their identity to the SMTP Server and have their mail delivered as trusted users. Most commercial SMTP Servers require that Clients be authenticated.

Typically, authentication data consists of the sender's username and password. During an authentication challenge, the Server prompts for this information and the Client responds by sending the requested data in encoded format. The Server decodes the data and attempts to find a match in its user database. If found, the Server indicates the authentication is successful. SMTP authentication is defined in RFC 2554.

There are two flavors of authentication, namely basic and digest. Digest is not supported in the current NetX Duo SMTP Client, and will not be discussed here. Basic authentication is equivalent to the name and password authentication described above. In SMTP basic authentication, the name and passwords are base64 encoded. The advantage of basic authentication is its ease of implementation and widespread use. The main disadvantage of basic authentication is name and password data is transmitted openly in the request.

### **Plain Authentication**

The NetX Duo SMTP Client sends an AUTH command with the PLAIN parameter. If the NetX Duo SMTP Server supports this type of authentication, it will reply with a 334 reply code. The Client replies with a single base64 encoded username and password message to the Server. If the Server determines the Client authentication is successful, it responds with the 235 success code.

## **Login Authentication**

The NetX Duo SMTP Client sends an AUTH command with the LOGIN parameter. If the NetX Duo SMTP Server supports this type of authentication, it will reply with a 334 reply code as the start of the authentication 'challenge'. It sends a base64 encoded prompt back to the Client which is typically "Username". The Client decodes the prompt, and replies with a base64 encoded username. If the Server accepts the Client username, it sends out a base64 encoded prompt for the Client password. The Client responds with a base64 encoded password. If the Server determines the Client authentication is successful, it responds with the 235 success code.

## **No Authentication**

Some SMTP Servers are configured without authentication. If so, their 250 response to the Client EHLO message will not list any authentication types. However, no authentication types listed does not necessarily mean the Server does not require or support authentication. If the Client is configured for PLAIN or LOGIN authentication in this situation, the NetX Duo Client thread task will default to PLAIN. If the Client is configured for NONE, the authentication step is skipped and the SMTP state advances to the MAIL state.

Note that if the Client is configured for no authentication and the SMTP Server does support authentication, the Client authentication type is switched to PLAIN.

## **RFCs Supported by NetX Duo SMTP Client**

NetX Duo SMTP Client API is compliant with RFC2821 "Simple Mail Transfer Protocol" and RFC 2554 "SMTP Service Extension for Authentication. "

## Chapter 2 Installation and Use of NetX Duo SMTP Client

This chapter contains a description of various issues related to installation, setup, and usage of the NetX Duo SMTP Client component.

### NetX Duo SMTP Client Installation

The NetX Duo SMTP Client is shipped on a single CD-ROM compatible disk. The package includes the following files:

nxd\_smtp\_client.c C Source file for NetX Duo SMTP Client API  
nxd\_smtp\_client.h C Header file for NetX Duo SMTP Client API  
demo\_netxdue\_smtp\_client.c Demo for NetX Duo SMTP Client  
nxd\_smtp\_client.pdf User Guide for NetX Duo SMTP Client API

To use the NetX Duo SMTP Client API, the entire distribution mentioned previously may be copied to the same directory where NetX Duo is installed. For example, if NetX Duo is installed in the directory "c:\myproject" then the nxd\_smtp\_client.h, and nxd\_smtp\_client.c files should be copied into this directory.

### Using NetX Duo SMTP Client

To create the NetX Duo SMTP Client application, it must first build the ThreadX and NetX Duo libraries and include them in the build project. The application must then include tx\_api.h and nx\_api.h in its application source code. This will enable ThreadX and NetX Duo services. It must also include nxd\_smtp\_client.c and nxd\_smtp\_client.h after tx\_api.h and nx\_api.h to use SMTP Client services.

These files must be compiled in the same manner as other application files and the object code must be linked along with the files of the application. This is all that is required to create a NetX Duo SMTP Client application.

## Small Example System

An example of using the NetX Duo SMTP Client is described in Figure 1 that appears below. The packet pool for the IP instance is created using the `nx_packet_pool_create` service, on line 68 and has a very small packet payload. This is because the IP instance only sends control packets which don't require much payload. The SMTP Client packet pool created on line 84 and is used for transmitting SMTP Client messages to the server and message data. Its packet payload is much larger. The IP instance is created in line 118 using the same packet pool. TCP, required for the SMTP protocol, is enabled on the IP instance in line 130.

In the application thread, the SMTP Client is created using the `nxd_smtp_client_create` service, in line 170. The `nxd_smtp_client_create` service supports both IPv4 and IPv6 SMTP server connections although this example is limited to IPv4. Then the mail message is submitted to the SMTP Client for transmission on line 184 using the `nx_smtp_mail_send` service. Note that the subject line with the mail content header is created separately from the message body. Also note that the send mail request accepts only one recipient mail address which is assumed to be syntactically correct.

Then the application terminates the SMTP Client on line 200. The `nx_smtp_client_delete` service checks that the socket connection is closed and the port is unbound. Note that it is up to the SMTP Client application to delete the packet pool if it no longer has use for it.

```
1  /*
2      demo_netxd duo_smtp_client.c
3
4      This is a small demo of the NetX Duo SMTP Client on the high-performance NetX
5      Duo TCP/IP stack. This demo relies on Thread, NetX Duo and SMTP Client API to
6      perform simple SMTP mail transfers in an SMTP client application to an SMTP mail
7      server.  */
8
9  #include "nx_api.h"
10 #include "nx_ip.h"
11 #include "nxd_smtp_client.h"
12
13
14 /* Define the host user name and mail box parameters */
15 #define USERNAME          "myusername"
16 #define PASSWORD          "mypassword"
17 #define FROM_ADDRESS      "my@mycompany.com"
18 #define RECIPIENT_ADDRESS "your@yourcompany.com"
19 #define LOCAL_DOMAIN      "mycompany.com"
20
21 #define SUBJECT_LINE      "NetX Duo SMTP Client Demo"
22 #define MAIL_BODY          "NetX Duo SMTP client is an SMTP client \r\n" \
23                             "implementation for embedded devices to send \r\n" \
24                             "email to SMTP servers. This feature is \r\n" \
```

```

24                                     "intended to allow a device to send simple \r\n " \
25                                     "status reports using the most universal \r\n " \
26                                     "Internet application, email.\r\n"
27
28 /* See the NetX Duo SMTP Client User Guide for how to set the authentication type.
29    The most common authentication type is PLAIN. */
30 #define CLIENT_AUTHENTICATION_TYPE 3
31
32
33 #define CLIENT_IP_ADDRESS IP_ADDRESS(1,2,3,5)
34 #define SERVER_IP_ADDRESS IP_ADDRESS(1,2,3,4)
35 #define SERVER_PORT      25
36
37
38 /* Define the NetX Duo and ThreadX structures for the SMTP client application. */
39 NX_PACKET_POOL ip_packet_pool;
40 NX_PACKET_POOL client_packet_pool;
41 NX_IP client_ip;
42 TX_THREAD demo_client_thread;
43 static NX_SMTP_CLIENT demo_client;
44
45
46 void _nx_ram_network_driver(struct NX_IP_DRIVER_STRUCT *driver_req);
47 void demo_client_thread_entry(ULONG info);
48
49 /* Define main entry point. */
50 int main()
51 {
52     /* Enter the ThreadX kernel. */
53     tx_kernel_enter();
54 }
55
56 /* Define what the initial system looks like. */
57 void tx_application_define(void *first_unused_memory)
58 {
59
60     UINT status;
61     CHAR *free_memory_pointer;
62
63
64     /* Setup the pointer to unallocated memory. */
65     free_memory_pointer = (CHAR *) first_unused_memory;
66
67     /* Create IP default packet pool. */
68     status = nx_packet_pool_create(&ip_packet_pool, "Default IP Packet Pool",
69                                   128, free_memory_pointer, 2048);
70
71     /* Update pointer to unallocated (free) memory. */
72     free_memory_pointer = free_memory_pointer + 2048;
73
74     /* Create SMTP Client packet pool. This is only for transmitting packets to the
75        server. It need not be a separate packet pool than the IP default packet pool
76        but for more efficient resource use, we use two different packet pools
77        because the Client SMTP messages generally require more payload than IP
78        control packets.
79
80        Packet payload depends on the SMTP Client application requirements. Size of
81        packet payload must include IP and TCP headers. For IPv6 connections, IP and
82        TCP header data is 60 bytes. For IPv4 IP and TCP header data is 40 bytes (not
83        including TCP options). */
84     status |= nx_packet_pool_create(&client_packet_pool, "SMTP Client Packet Pool",
85                                   800, free_memory_pointer, (10*800));
86
87     if (status != NX_SUCCESS)
88     {
89         return;
90     }
91
92     /* Update pointer to unallocated (free) memory. */
93     free_memory_pointer = free_memory_pointer + (10*800);
94

```

```

95     /* Initialize the NetX system. */
96     nx_system_initialize();
97
98     /* Create the client thread */
99     status = tx_thread_create(&demo_client_thread, "client_thread",
100                             demo_client_thread_entry, 0, free_memory_pointer,
101                             2048, 16, 16,
102                             TX_NO_TIME_SLICE, TX_DONT_START);
103
104     if (status != NX_SUCCESS)
105     {
106
107         printf("Error creating Client thread. Status 0x%x\r\n", status);
108         return;
109     }
110
111     /* Update pointer to unallocated (free) memory. */
112     free_memory_pointer = free_memory_pointer + 4096;
113
114
115     /* Create Client IP instance. Remember to replace the generic driver
116        with a real ethernet driver to actually run this demo! */
117
118     status = nx_ip_create(&client_ip, "SMTP Client IP Instance", CLIENT_IP_ADDRESS,
119                          0xFFFFFFFFUL, &ip_packet_pool, _nx_ram_network_driver,
120                          free_memory_pointer, 2048, 1);
121
122     free_memory_pointer = free_memory_pointer + 2048;
123
124     /* Enable ARP and supply ARP cache memory. */
125     status = nx_arp_enable(&client_ip, (void **) free_memory_pointer, 1040);
126
127     /* Update pointer to unallocated (free) memory. */
128     free_memory_pointer = free_memory_pointer + 1040;
129
130     /* Enable TCP for client. */
131     status = nx_tcp_enable(&client_ip);
132
133     if (status != NX_SUCCESS)
134     {
135         return;
136     }
137
138     /* Enable ICMP for client. */
139     status = nx_icmp_enable(&client_ip);
140
141     if (status != NX_SUCCESS)
142     {
143         return;
144     }
145
146     /* Start the client thread. */
147     tx_thread_resume(&demo_client_thread);
148
149     return;
150 }
151
152 /* Define the smtp application thread task. */
153 void demo_client_thread_entry(ULONG info)
154 {
155
156     UINT          status;
157     UINT          error_counter = 0;
158     NXD_ADDRESS server_ip_address;
159
160
161     tx_thread_sleep(100);
162
163     /* Set up the server IP address. */

```



```

164     server_ip_address.nxd_ip_version = NX_IP_VERSION_V4;
165     server_ip_address.nxd_ip_address.v4 = SERVER_IP_ADDRESS;
166
167     /* The demo client username and password is the authentication
168        data used when the server attempts to authentication the client. */
169
170     status = nxd_smtp_client_create(&demo_client, &client_ip, &client_packet_pool,
171                                   USERNAME,
172                                   PASSWORD,
173                                   FROM_ADDRESS,
174                                   LOCAL_DOMAIN, CLIENT_AUTHENTICATION_TYPE,
175                                   &server_ip_address, SERVER_PORT);
176
177     if (status != NX_SUCCESS)
178     {
179         printf("Error creating the client. Status: 0x%x.\n\r", status);
180         return;
181     }
182
183     /* Create a mail instance with the above text message and recipient info. */
184     status = nx_smtp_mail_send(&demo_client, RECIPIENT_ADDRESS,
185                               NX_SMTP_MAIL_PRIORITY_NORMAL,
186                               SUBJECT_LINE, MAIL_BODY, strlen(MAIL_BODY));
187
188     /* Check for errors. */
189     if (status != NX_SUCCESS)
190     {
191         /* Mail item was not sent. Note that we need not delete the client. The
192            error status may be a failed authentication check or a broken connection.
193            We can simply call nx_smtp_mail_send again. */
194         error_counter++;
195     }
196
197     /* Release resources used by client. Note that the transmit packet
198        pool must be deleted by the application if it no longer has use for it.*/
199     status = nx_smtp_client_delete(&demo_client);
200
201     /* Check for errors. */
202     if (status != NX_SUCCESS)
203     {
204         error_counter++;
205     }
206
207     return;
208 }
209
210

```

Figure 1. Example of SMTP Client use with NetX Duo

# Client Configuration Options

There are several configuration options with the NetX Duo SMTP Client API. Following is a list of all options described in detail:

Define

Meaning

`NX_SMTP_CLIENT_TCP_WINDOW_SIZE`

This option sets the size of the Client TCP receive window. This should be set to below the MTU size of the underlying Ethernet hardware and allow room for IP and TCP headers. The default NetX Duo SMTP Client TCP window size is 1460.

.

`NX_SMTP_CLIENT_PACKET_TIMEOUT`

This option sets the timeout on NetX packet allocation. The default NetX Duo SMTP Client packet timeout is 2 seconds.

`NX_SMTP_CLIENT_CONNECTION_TIMEOUT`

This option sets the Client TCP socket connect timeout. The default NetX Duo SMTP Client connect timeout is 10 seconds.

`NX_SMTP_CLIENT_DISCONNECT_TIMEOUT`

This option sets the Client TCP socket disconnect timeout. The default NetX Duo SMTP Client disconnect timeout is 5 seconds. Note that if the SMTP Client encounters an internal error such as a broken connection it may terminate the connection with a zero wait timeout.

**NX\_SMTP\_GREETING\_TIMEOUT**

This option sets the timeout for the Client to receive the Server reply to its greeting. The default NetX Duo SMTP Client value is 10 seconds.

**NX\_SMTP\_ENVELOPE\_TIMEOUT**

This option sets the timeout for the Client to receive the Server reply to a Client command. The default NetX Duo SMTP Client value is 10 seconds.

**NX\_SMTP\_MESSAGE\_TIMEOUT**

This option sets the timeout for the Client to receive the Server reply to receiving the mail message data. The default NetX Duo SMTP Client value is 30 seconds.

**NX\_SMTP\_CLIENT\_SEND\_TIMEOUT**

This option defines the wait option of the buffer to store the user password during SMTP authentication with the Server. The default value is 20 bytes.

**NX\_SMTP\_SERVER\_CHALLENGE\_MAX\_STRING**

This option defines the size of the buffer for extracting the Server challenge during SMTP authentication. The default value is 200 bytes. For LOGIN and PLAIN authentication, the SMTP Client can probably use a smaller buffer.

**NX\_SMTP\_CLIENT\_MAX\_PASSWORD**

This option defines the size of the buffer to store the user password during SMTP authentication with the Server. The default value is 20 bytes.

**NX\_SMTP\_CLIENT\_MAX\_USERNAME**

This option defines the size of the buffer to store the host username during SMTP authentication with the Server. The default value is 40 bytes.

## Chapter 3 Client Description of SMTP Client Services

This chapter contains a description of all NetX Duo SMTP Client services (listed below) in order of usage in a typical SMTP Client application.

In the “Return Values” section in the following API descriptions, values in **BOLD** are not affected by the *NX\_DISABLE\_ERROR\_CHECKING* define that is used to disable API error checking, while non-bold values are completely disabled.

### Services for Client Session and Mail Setup

`nxd_smtp_client_create`  
Create an SMTP Client Instance

`nx_smtp_client_delete`  
Delete an SMTP Client instance

`nx_smtp_mail_send`  
Create and send an SMTP Mail item

# nxd\_smtp\_client\_create

Create an SMTP Client Instance

## Prototype

```
UINT nxd_smtp_client_create(NX_SMTP_CLIENT *client_ptr,
                           NX_IP *ip_ptr, NX_PACKET_POOL
                           *client_packet_pool_ptr,
                           CHAR *username, CHAR *password,
                           CHAR *from_address,
                           CHAR *client_domain,
                           UINT authentication_type,
                           NXD_ADDRESS *server_address,
                           UINT port)
```

## Description

This service creates an SMTP Client instance on the specified IP instance.

## Input Parameters

client_ptr	Pointer to SMTP Client control block;
ip_ptr	Pointer to IP instance;
packet_pool_ptr	Pointer to Client packet pool;
username	NULL-terminated Username for uthentication;
password	NULL-terminated password for authentication;
from_address	NULL-terminated sender's address;
client_domain	NULL-terminated domain name;
authentication_type	Client authentication type Supported types are: NX_SMTP_CLIENT_AUTH_LOGIN NX_SMTP_CLIENT_AUTH_PLAIN NX_SMTP_CLIENT_AUTH_NONE
server_address	Pointer to SMTP Server IP address
server_port	SMTP Server TCP port

## Return Values

NX_SUCCESS	(0x00)	SMTP Client successfully created TCP socket creation status
NX_SMTP_INVALID_PARAM	(0xA5)	Invalid non pointer input
NX_IP_ADDRES_ERROR	(0x21)	Invalid IP address type
NX_PTR_ERROR	(0x07)	Invalid input pointer parameter

## Allowed From

### Application Code

#### Example

```

/* Create the SMTP Client instance. */
NX_PACKET_POOL      client_packet_pool;
NX_IP                client_ip;
NX_SMTP_CLIENT       demo_client;

#define USERNAME      "myusername"
#define PASSWORD      "mypassword"
#define FROM_ADDRESS  "myname@mycompany.com"
#define LOCAL_DOMAIN  "mycompany.com"

#define SERVER_PORT   25

/* Define client authentication type as LOGIN. If not specified or
   unknown the SMTP Client will set it to PLAIN. */

#define CLIENT_AUTHENTICATION_TYPE NX_SMTP_CLIENT_AUTH_LOGIN

NXD_ADDRESS server_ip_address;

#ifdef USE_IPV6
    /* Set up the Server IPv6 address. */
    server_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
    server_ip_address.nxd_ip_address.v6[0] = 0x20010db8;
    server_ip_address.nxd_ip_address.v6[1] = 0xf101;
    server_ip_address.nxd_ip_address.v6[2] = 0;
    server_ip_address.nxd_ip_address.v6[3] = 0x106;
#else
    server_ip_address.nxd_ip_version = NX_IP_VERSION_V4;
    server_ip_address.nxd_ip_address.v4 = SERVER_IP_ADDRESS;
#endif

status = nxd_smtp_client_create(&demo_client, &client_ip,
                                &client_packet_pool,
                                USERNAME,
                                PASSWORD,
                                FROM_ADDRESS,
                                LOCAL_DOMAIN,
                                CLIENT_AUTHENTICATION_TYPE,
                                &server_ip_address, SERVER_PORT);

/* If an SMTP Client instance was successfully created, status =
   NX_SUCCESS. */

```

## nx\_smtp\_client\_delete

---

Delete an SMTP Client Instance

### Prototype

```
UINT nx_smtp_client_delete(NX_SMTP_CLIENT *client_ptr)
```

### Description

This service deletes a previously created SMTP Client instance.

### Input Parameters

client_ptr	Pointer to SMTP Client instance.
------------	----------------------------------

### Return Values

NX_SUCCESS	(0x00)	Client successfully deleted
NX_PTR_ERROR	(0x07)	Invalid input pointer parameter

### Allowed From

Threads

### Example

```
/* Delete the SMTP Client instance "my_client." */
NX_SMTP_CLIENT demo_client;

status = nx_smtp_client_delete(&demo_client);

/* If an SMTP Client instance was successfully
   deleted, status = NX_SUCCESS. */
```



## nx\_smtp\_mail\_send

---

Create and send an SMTP mail item

### Prototype

```
UINT    nx_smtp_mail_send(NX_SMTP_CLIENT *client_ptr,
                          CHAR *recipient_address,
                          UINT priority, CHAR *subject,
                          CHAR *mail_body,
                          UINT mail_body_length)
```

### Description

This service creates and sends an SMTP mail item. The SMTP Client establishes a TCP connection with the SMTP Server and sends a series of SMTP commands. If no errors are encountered, it will transmit the mail message to the Server. Regardless if the mail is sent successfully it will terminate the TCP connection and return a status indicating outcome of the mail transmission. The application may call this service for as many mail messages as it needs to send without limit.

### Input Parameters

client_ptr	Pointer to SMTP Client
recipient_address	NULL-terminated recipient address.
subject	NULL-terminated subject line text;.
priority	Priority level at which mail is delivered
mail_body	Pointer to mail message
mail_body_length	Size of mail message

### Return Values

NX_SUCCESS	(0x00)	Mail successfully sent
NX_SMTP_CLIENT_NOT_INITIALIZED	(0xB2)	SMTP Client instance not initialized for SMTP session
status		Outcome of SMTP session
NX_PTR_ERROR	(0x07)	Invalid pointer parameter
NX_SMTP_INVALID_PARAM	(0xA5)	Invalid non pointer input
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

## Allowed From

### Threads

## Example

```

/* Create and send a Client mail item. */

#define RECIPIENT_ADDRESS "your@yourcompany.com"
#define SUBJECT          "NetX Duo SMTP Client Demo"
#define MAIL_BODY        "NetX Duo SMTP client is an SMTP client " \
                          "implementation for embedded devices \r\n" \
                          "to send email to SMTP servers.\r\n"

status = nx_smtp_mail_send(&demo_client, RECIPIENT_ADDRESS,
                          NX_SMTP_MAIL_PRIORITY_NORMAL,
                          SUBJECT_LINE, MAIL_BODY,
                          strlen(MAIL_BODY));

/* Return status being NX_SUCCESS indicates the mail has been
   successfully sent. */

```

---

NetX Duo Simple Mail Transfer Protocol for  
Clients (NetX Duo SMTP Client) User Guide

Publication Date: Rev.5.11 Nov 8, 2018

Published by: Renesas Electronics Corporation

---



## SALES OFFICES

## Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

### **Renesas Electronics Corporation**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

### **Renesas Electronics America Inc.**

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.

Tel: +1-408-432-8888, Fax: +1-408-434-5351

### **Renesas Electronics Canada Limited**

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3

Tel: +1-905-237-2004

### **Renesas Electronics Europe Limited**

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

Tel: +44-1628-651-700

### **Renesas Electronics Europe GmbH**

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-6503-0, Fax: +49-211-6503-1327

### **Renesas Electronics (China) Co., Ltd.**

Room 1709 Quantum Plaza, No.27 ZhichunLu, Haidian District, Beijing, 100191 P. R. China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

### **Renesas Electronics (Shanghai) Co., Ltd.**

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, 200333 P. R. China

Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

### **Renesas Electronics Hong Kong Limited**

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2265-6688, Fax: +852 2886-9022

### **Renesas Electronics Taiwan Co., Ltd.**

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

### **Renesas Electronics Singapore Pte. Ltd.**

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949

Tel: +65-6213-0200, Fax: +65-6213-0300

### **Renesas Electronics Malaysia Sdn.Bhd.**

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia

Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

### **Renesas Electronics India Pvt. Ltd.**

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India

Tel: +91-80-67208700, Fax: +91-80-67208777

### **Renesas Electronics Korea Co., Ltd.**

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5338

# NetX Duo Simple Mail Transfer Protocol for Clients (NetX Duo SMTP Client) User Guide



Renesas Electronics Corporation

R11UM0037EU0511