

STANDARD DEPARTURE CHART - INSTRUMENT

RJFO / OITA

RNAV TRANSITION

DONAR TRANSITION / DOUGO TRANSITION / FIATO TRANSITION SALTY TRANSITION / SPIDE TRANSITION / ASHIZURI TRANSITION		RNAV1
Note 1) DME/DME/IRU or GNSS required. 2) RADAR service required.	Critical DME	SALTY TRANSITION SUC : 8.3NM to SALTY – 4.3NM to SALTY FIATO TRANSITION SUC : 8.3NM to SALTY – 4.3NM to SALTY SWE : SALTY – FIATO
	DME GAP	—
	Inappropriate Nav aids	See AD1.1.6.10.3. Inappropriate NAV AIDs for RNAV1
<div>VAR 7°W (2017)</div>		
<u>DONAR TRANSITION</u> From FUSHA, to DONAR at or above FL160.		
<u>DOUGO TRANSITION</u> From FUSHA, to DONAR at or above FL160, to MYE.		
<u>FIATO TRANSITION</u> From FUSHA, to DONAR at or above FL160, to SALTY, to FIATO.		
<u>SALTY TRANSITION</u> From FUSHA, to DONAR at or above FL160, to SALTY.		
<u>SPIDE TRANSITION</u> From FUSHA, to DONAR at or above FL160, to SPIDE.		
<u>ASHIZURI TRANSITION</u> From FUSHA, to SUC.		

STANDARD DEPARTURE CHART - INSTRUMENT

RJFO / OITA

RNAV TRANSITION

DONAR TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	FUSHA	—	—	-7.4	—	—	—	—	—	RNAV1
002	TF	DONAR	—	086 (078.7)	-7.4	17.8	—	+FL160	—	—	RNAV1

DOUGO TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	FUSHA	—	—	-7.4	—	—	—	—	—	RNAV1
002	TF	DONAR	—	086 (078.7)	-7.4	17.8	—	+FL160	—	—	RNAV1
003	TF	MYE	—	027 (019.8)	-7.4	30.6	—	—	—	—	RNAV1

FIATO TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	FUSHA	—	—	-7.4	—	—	—	—	—	RNAV1
002	TF	DONAR	—	086 (078.7)	-7.4	17.8	—	+FL160	—	—	RNAV1
003	TF	SALTY	—	043 (036.1)	-7.4	37.3	—	—	—	—	RNAV1
004	TF	FIATO	—	044 (036.3)	-7.4	11.8	—	—	—	—	RNAV1

SALTY TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	FUSHA	—	—	-7.4	—	—	—	—	—	RNAV1
002	TF	DONAR	—	086 (078.7)	-7.4	17.8	—	+FL160	—	—	RNAV1
003	TF	SALTY	—	043 (036.1)	-7.4	37.3	—	—	—	—	RNAV1

STANDARD DEPARTURE CHART - INSTRUMENT

RJFO / OITA

RNAV TRANSITION

SPIDE TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	FUSHA	—	—	-7.4	—	—	—	—	—	RNAV1
002	TF	DONAR	—	086 (078.7)	-7.4	17.8	—	+FL160	—	—	RNAV1
003	TF	SPIDE	—	061 (054.1)	-7.4	30.1	—	—	—	—	RNAV1

ASHIZURI TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	FUSHA	—	—	-7.4	—	—	—	—	—	RNAV1
002	TF	SUC	—	134 (126.5)	-7.4	54.0	—	—	—	—	RNAV1